Computer Architecture: Assignment 02 23k-2001

Answer#01:

Data Registers: They are general purpose registers mainly used to store temporary data during execution. In x86 architectures, the registers are as follows:

AX: Accumulator register -> used for arithmetic operations.

BX: Base register -> used for indexed addressing

CX: Counter register -> used in loops/shift operations.

DX: Data register -> used in input/output operations & * or /.

Pointer Registers: They are used to store memory addresses and control memory access. The registers are as follows:

SP: Stack Pointer -> points to the top of the stack.

BP: Base Pointer -> used to access function parameters & local Variables in stack frames.

ST: Source Index -> used in string & memory operations.

DI: Destination Index -> used in string & memory operations along SI.

IP: Instruction Pointer -> stores offset of next instruction to be executed.

extended (32-bit) 16-bit 8-bit

AX AH, AL.

EAX	AX	AH,AL
EBX	BX	BHSBL
ECX	CX	CH, CL
EDX	DX	DH, DL
ESP	SP	_
EBP	ВР	-1.75%
EST	ST	
EDT	DI	-
TP	TP	-

Purpose of Segment Registers

Code Segment Register: stores starting address of code segment & tells CPU where current program instructions are stored.

Data Segment Register: stores starting address of data segment is used to access global and static variables.

Extra Segment Register: additional data segment register, used for string operations.

Stack Segment Register: stores starting address of the stack, used in managing function calls, returns and local variables.

Memory Management Unit:

The MMU is a core hardware component in a computer architecture, used by the computer programs. The function of MMU are as follows:

- -> Translates virtual addresses into physical addresses.
- -> Controls memory protection and access rights.
- -> Helps isolate processes in multitasking environments.
- -> Enables virtual memory implementation such as paging /segmentation.
- -> Boosts security and stability by preventing unauthorized access.

Answer#02:

Key Characteristics of RISC Architecture:

i. Simple Instructions: RISC uses fewer and simpler instructions that execute in one cycle.

ii. load/Store Architecture: Memory access is limited to specific load and store instructions.

in. large number of registers: Allows storage of more variables in · registers, reducing memory access.

iv. Fixed-length Instructions: Simplifies instruction decoding and pipeline design.

v. Efficient Pipelining: Due to uniform instruction size & execution time.

vi. Simple Addressing: Most of the instructions use simple register addressing.

(b) Performance benefits of RTSC Architecture:

i. Faster execution: simpler instructions reduce execution time, allowing to be executed in a single clock cycle.

ii. Efficient pipeling: fixed instruction size and uniform instruction format allows efficient pipelining, processing multiple instructions

simultaneously.

iii. Simpler hardware design: small instruction set in RISC simplifies the combrol logic, reducing the complexity and cost of hordware implementation.

iv. Higher instruction throughput: RISC systems can execute more instructions per second due to consistent and rapid execution.

v. Compiler optimization: regular instruction format makes it easier for compilers to generate efficient machine code.

vi. low power consumption: simpler instructions and streamlined hardware contribute to reduced power usage.

Answer#03:

Data Transfer Operations: used in moving or copying of data. The data is not altered i.e no arithmetic or logical operations are performed. The data is moved between registers, memory and I/O ports. Examples: MOV, PUSH, POP, LOAD, STORE.

logical Operations: used to perform bitwise logic operations on binary data. The data bits are manipulated to perform comparisons, masking, conditional operations and setting/toggling. Examples: AND, OR, XOR, NOT

Answer#04:

Data Types of x86 Architecture:

- Byte (8 bit): smallest data unit, used for char
- Word (16-bit): two bytes, the default size for many 8086 instructions.
- Double word (32-bit): 4 bytes, used in modern x86 processors.
- Quadword (64-bit): 8 bytes, used in 64 bit systems for high-precision calculations.
- BCD & Floating Point: Binary coded decimal and floating point, used to represent real numbers with single-precision (32 bit) and double precision (64-bit).

Processor Actions on various operations:

- Data transfer: move data between registers, memory or I/O.
- Arithmetic operation: perform add, subtract, multiply or divide.
- logical operation: perform bituise operations such as AND, OR, XOR, NOT.
- I/O operations: perform read/write to I/O ports.
- Control operations; after the flow of execution (eg: jump, calls).
- Shift Rotate Operations: shift or rotate bits within a register.

Answer#05:


(a)

RISC processor

- · Simple and few instructions.
- · One clock cycle to exewte instructions.
- · Memory access is limited to load/store instructions,
- · Pipelining is easier to implement.
- · Fixed length instructions.
- · Hardware required is simpler and easy to implement.
- · eg: ARM,

CISC processor

- · Complex instructions.
- · Varying number of clock cycles.
- Multiple memory access per instruction.
- · Pipelining is difficult to implement.
- · Variable length instructions.
- · Hardwore required is complex and larger.
- · eg: x86



- 0000	Marigs.	t
RAW	WAR	WAW
· Read After Write.	· Write After Read	· Write After Write
· known as true dependency. · instruction depends on the result of previous instruction. eg:	· instructions writes to register before the	· known as output dependency. · two instructions write to the same register.
ADD R1, R2, R3 SUB R4, R1, R5 RAW hazard	eg: SUB RY, R1, R5 ADD R1, R2, R3 WAR hazard	eg: MOV R1, R2 ADD R1, R3, R4 WAW hazard

23K-2001