Arithmetic/Logic instructions

"easy": two operands or one operand and a constant (immediate)

like sll, add, xor, slt, etc.

because immediate are limited in terms of space, we can use a register with lui (12 bits), then addiu (add unsigned) and xor to copy

Assembler directives

Like .text, .data, .asciiz..


Functions

jal x1, sqrt \rightarrow leaves PC+4 into the x1 register so the funtion can callback x1 with a simple jr x1 when finishing.

With RISCV we can simply use jal offset and ret instead of specifying the register x1.

Stack Pointer

Dynamically Allocating More Space



Stack Pointer

• This is so important that we are going to devote a register to this purpose and **everybody** will comply with our **conventions**

Register	ABI Name	Description	Preserved across call?
x2	sp	Stack pointer	Yes

 Other architectures have special instructions to place stuff on the stack (push) and to retrieve it (pop)

PUSH AX



add sp, sp, -4 sw x5, 0(sp)

4

Passing Arguments

Passing Arguments: The RISC-V Way

- A bit of both
 - Some registers reserved for the arguments and return value(s)

Register	ABI Name	Description	Preserved across call?
x10-11	a0-1	Function arguments/return values	No
x12-17	a2-7	Function arguments	No

Rest goes on the stack

.