
## CS-200 Computer Architecture


Part 2b. Processor, I/Os, and Exceptions Inputs and Outputs

Paolo lenne <paolo.ienne@epfl.ch>


## The Five Classic Components of a Computer




#### The CPU




## **Physical Memory Map**



## **Connecting CPU and Memory**



## The Five Classic Components of a Computer




## Input/Output Devices (I/Os)


Туре	Peripheral	Data Rate	
Human Interaction	Keyboard	~kbps	
<b>Human Interaction</b>	Mouse	~kbps	
Generic	Serial Port (RS-232)	115.2 kbps (max)	
Generic	Parallel Port (LPT)	150 kbps	
Generic	USB 4.0	20-40 Gbps	
Generic	Bluetooth 5.0	2 Mbps	
Generic	PCIe 4.0	16 Gbps per lane	
Storage	SATA III (HDD/SSD)	6.0 Gbps	
Storage	NVMe (PCIe 4.0)	64 Gbps (4-lane)	
Networking	Ethernet (10BASE-T)	10 Mbps	
Networking	10 Gigabit Ethernet (10GBASE-T)	10 Gbps	
Networking	Wi-Fi 6 (802.11ax)	Up to 9.6 Gbps	
Displays	VGA (analog video)	0.6-1.5 Gbps (approx.)	
Displays	HDMI 2.1	48 Gbps	
Optical Discs	CD-ROM	150 KB/s (1x) - 7.68 MB/s (52x)	
Optical Discs	DVD-ROM	1.32 MB/s (1x) - 21.1 MB/s (16x)	
Optical Discs	Blu-ray	4.5 MB/s (1x) - 54 MB/s (12x)	

## Accessing I/Os: Port Mapped I/O (PMIO)

Create a new interface similar to the memory one



## Accessing I/Os: Memory Mapped I/O (MMIO)




No special hardware needed in the CPU

**No special instructions** needed:


```
lui t0, 0x10000 # pointer to I/Os
sw t1, 0(t0) # write LEDs
lw t2, 0x30(t0) # read buttons
```

## Accessing I/Os: Memory Mapped I/O (MMIO)



# Example: A/D Converter

- Signals:
  - Start (START): input; when active begins a new conversion
  - Data Valid (/DV): output; when active, D7—D0 are valid
  - Data (D7—D0): output; last conversion result




# **Example:** Simple Bus Interface

- Suppose that a 8-bit processor has the following signals:
  - Address (A23—A0): output; address bus
  - Data (D7—D0): input/output; data bus
  - Address Strobe (/AS): output; signals the presence of a valid address on the Address bus during a memory access cycle
  - Read/Write (R//W): output; signal the direction of the data flow
  - Data Acknowledge (/DTACK): input; must be activated at the end of a memory access, when the written data have been latched or the read data are ready
- Similar but not identical to the MC68000
- Just an example but already more complex than busses described so far (/DTACK)

# **Example: Memory-Mapped Interface**

- Connect the A/D converter described in the previous slide so that:
  - Any access (R or W) to address 0xFFFFF0 starts a new conversion
  - The Data Valid signal can be read by the processor at address 0xFFFFF4 (bit 0)
  - The result of the conversion can be read by the processor at address 0xFFFFF8


## **A/D Converter: Circuit**




### A/D Converter: Software

#### What Do These Tristate Buffers Do?

What is their logic function?




## **Your System in Lab B**



# Source: Heuring & Jordan, © Addison Wesley 1997

## **Programmed I/Os**

Many peripherals are more developed programmable systems and have a set of registers which the processor reads and writes (a) to send and receive data and (b) to issue commands and read the status



#### **A Classic UART**


- UART = Universal Asynchronous Receiver-Transmitter
- One of the simplest and most common communication peripherals, typically used today to connect terminals to embedded devices
- Our UART has a simple programmed I/O interface with four registers:
  - A control register for the processor to configure the UART
    - Bit 7 must be set to 1 for the UART to be enabled
    - Bits 2..0 configure the communication speed (e.g., 0b001 for 9600 baud)
  - A status register for the processor to check the status of the UART
    - Bit 1 is 1 if there are data available
    - Bit 0 is 1 if the UART is ready to send data
  - A data input register where the received data are available to the processor
  - A data output register where the processor places data to send

#### **A Classic UART**

```
= 0x10000000 # UART status register address
                                                  UART CTRL ADDR
                                                  UART ENABLE BIT
                                                                     = 0x80
                                                                                   # Enable bit (bit 7)
                                                  UART SPEED_9600
                                                                     = 0x01
                                                                                   # Speed setting for 9600 baud (4 bits, [3:0])
                                                  UART STATUS ADDR
                                                                     = 0x10000004 # UART status register address
                                                                                   # Transmitter ready bit (bit 0)
                                                  TX READY BIT
                                                                     = 0 \times 01
                                                                     = 0x10000008 # UART data input (receive) register address
                                                  UART DATAIN ADDR
                                                  UART_DATAOUT_ADDR = 0x1000000C # UART data output (send) register address
                                                  send string:
   Configure and enable the UART
                                                           t0, UART_CTRL_ADDR
                                                                                   # Get UART control address
                                                           t1, UART STATUS ADDR
                                                                                   # Get UART status address
                                                           t2, UART DATAOUT ADDR
                                                                                   # Get UART data address
                                                           t3, UART ENABLE BIT
                                                                                   # Get enable bit (0x80)
                                                           t4, UART SPEED 9600
                                                                                   # Get speed setting (0x01)
                                                                                   # Combine enable and speed bits
                                                           t4, t3, t4
                                                                                   # Configure using the UART control register
                                                           t4, 0(t0)
Wait until we can send
                                                  next char:
   a new character...
                                                      1b t5, 0(a0)
                                                                                   # Load first byte of the string
                                                                                   # If byte is zero (null terminator), finish
                                                      begz t5, finish
                                                  check tx ready:
                                                                                   # Load UART status register
                                                          t6, 0(t1)
    ...and send it
                                                      andi t6, t6, TX READY BIT
                                                                                   # Check if TX READY BIT is set
                                                      begz t6, check tx ready
                                                                                   # If not ready, loop back and check again
                                                           t5, 4(t2)
                                                                                   # Store the character in UART data register
                                                                                   # Increment string pointer (move to next char)
                                                      addi a0, a0, 1
                                                           next char
                                                                                   # Jump back to send the next character
                                                  finish:
                                                                                   # Return when the string is done
                                                      ret
```

## I/O Polling

How do we know if a peripheral has data for us (key pressed, packet arrived, etc.)?



 Very expensive: if the device is fast and requires immediate action, the processor must spend too much time to check frequently