

# **Semiconductor (Ionization) Detectors**



### Bandgap & Ionization Energy

	Mean Ioniz. En. W [eV]	Density [g/cm³]	Fano Factor
Gases	30	7 – 50x10 <sup>-4</sup>	0.1-0.2 (ionization vs. excitation)
Si	3.62	2.33	~0.10 (ionization vs. phonons)
Ge	2.96	5.32	~0.10 (ionization vs. phonons)







Example: Ge bandgap ~ 0.7 eV; Ge mean ionization energy = 2.96 eV  $\rightarrow$  ~ 4x phonon production per e/h pair.

## **Electron/Hole Pairs: Information Carriers**



- Low mean ionization energy → More information carriers / interaction






electron

# Measuring e<sup>-</sup>/h Pairs



- Challenge: Measure ionization with high precision (better than 0.1%) in large detector volumes (>~cm³)
  - E.g. 300 keV energy deposition in Ge  $\rightarrow$  ~10<sup>5</sup> e/h pairs: .1% ~ 100 e/h pairs



#### Requirements

- Establish E-field to accelerate charge collection (with low leakage current)
- Excellent carrier transport
  - High carrier mobility  $(\mu)$  and lifetime  $(\tau)$

# **Establishing E-Fields with Low Leakage**



- Requires material with high resistivity depends on dopant concentration and carrier mobility  $\rho = (eN_D \mu_{mai})^{-1}$ 
  - Dopant dictates majority carrier (p-type = holes, n-type = e<sup>-</sup>)
  - Dopant concentration → total number of available charge carriers
  - Challenge of crystal growth: defects affect carrier mobility
- Truly "pure" material not achievable in practice
  - Properties of Si/Ge determined by minute imbalances of dopant concentrations
  - Compensated material: donor and acceptor impurity concentration equal
    - E.g. Lithium-drifting: Si(Li) & Ge(Li) detectors
- High resistivity can be achieved in some compound semiconductors as well

## Implementation: Reverse-Biased Diodes



Near-intrinsic bulk  $(N_{D} \sim 10^{10} \text{cm}^{-3})$ 

Heavily doped thin contacts


$$N_A \sim 10^{18} \text{cm}^{-3}$$


$$N_{\rm D} \sim 10^{18} {\rm cm}^{-3}$$

B  $\sim$  3 mm Li  $\sim$  0.5 mm



- Attract minority carriers across junction = very low current
- Generate high electric field





# Depletion, Electric Fields, Capacitance




#### Example: Planar detector


Electric field: 
$$-\mathscr{E}(x) = \frac{V}{d} + \frac{\rho}{\varepsilon} \left( \frac{d}{2} - x \right)$$

Depletion voltage: 
$$V_d = \frac{\rho d^2}{2 \varepsilon}$$
  $\rho = \text{charge}$  dens. =  $(eN)$ 

Capacitance per unit area: 
$$C = \sqrt{\frac{\varepsilon \rho}{2 V}}$$

= constant = 
$$\sqrt{\frac{\varepsilon \rho}{2 V_d}}$$
 for  $V > V_d$ 





# Signal Formation - Shockley-Ramo



- Measure current signal induced at electrode due to carrier motion
- Weighting field & potential: convenient constructs for computing induced charge & current

$$i_{ind}(t) = \frac{\mathrm{d}Q_{ind}}{\mathrm{d}t} = -q \frac{\mathrm{d}V_w(P)}{\mathrm{d}t} = -q \frac{\mathrm{d}V_w(P)}{\mathrm{d}\vec{l}} \bullet \frac{\mathrm{d}\vec{l}}{\mathrm{d}t} \qquad \vec{v} = \frac{\mathrm{d}\vec{l}}{\mathrm{d}t}$$

$$i_{ind}(t) = q \vec{E}_w(P) \bullet \vec{v}(P(t))$$


**N.B.** e<sup>-</sup> & holes drift in opposite direction: induce signals of same sign!

$$Q_{ind}(t) = \int idt = q \int \vec{E}_w \bullet d\vec{l} = q(V_w(P_0) - V_w(P_t))$$


$$\vec{v} = \mu(E)\vec{E}$$
 Carrier velocity determined by **electric field**  $\rightarrow$  compute via **Poisson** equation (with space charge) in the detector

 $\vec{V}_w(P)$  Coupling determined by weighting potential  $\rightarrow$  compute via Laplace equation (ignore space charge) according to S/R





































# **High-Purity Germanium (HPGe) Detectors**



- Ge vs. Si detectors:
  - Smaller band gap than Si (0.7 vs 1.1 eV)
  - Higher density (5.32 vs. 2.33 g/cm³) and higher Z (32 vs. 14)
  - Lower impurity (10<sup>9</sup> vs 10<sup>12</sup> cm<sup>-3</sup>) allows much larger volumes to be depleted
- 1962: Pell (LBL) produces first compensated
  Ge(Li) detector
  - Drawbacks: limited volume, must always be kept at LN<sub>2</sub> temperatures
- 1970's: HPGe replaces Ge(Li)
  - Improved purity (zone refining), improved crystal growth methods (Czochralski process)
- 1990's: Large-volume HPGe
  - o >800 cm<sup>3</sup>
  - o Impurity conc O(10<sup>9</sup> cm<sup>-3</sup>) = purest commercially available material on earth!

13		14	15	
	5	6	7	
	B	C	N	
ļ	10.811	12.011	14.007	
	13	14	15	
	Al	Si	P	
	26.982	26.088	30.974	
31		32	33	
Ga		Ge	As	
69.72		72.59	74.922	
	49	50	51	
	In	Sn	Sb	
	114.82	116.69	121.75	
	81 82 Tl Pb 204.37 207.19		83 Bi 208.98	




## **General Remarks**



 HPGe and Si detectors are the "gold-standard" in many applications such as electron spectroscopy (Si) and gamma-ray spectroscopy (HPGe)

- Excellent energy resolution
  - Statistics of charge-carrier production
- High density (solid state)
- Excellent charge carrier collection properties
  - High mobility and lifetimes for both electrons and holes
- Very good timing characteristics
  - Design dependent, but influenced by high carrier mobility




Ag-108m & Ag-110m. Knoll 12.4

# **HPGe Detector Configurations**




- Planar configuration
  - Limited volume




- Bulk material can be n-type or p-type
- Traditional contacts
  - o  $n^+$  by Li diffusion ( $\sim$ O(100 $\mu$ m) thick)
  - o p<sup>+</sup> by boron implantation (<1 $\mu$ m thick)
- Modern contacts: amorphous semiconductor (e.g. α-Ge)
  - Blocking contact for both carrier types

#### Coaxial detectors

Large volume



represents electrical contact surface




## **Signal Shapes in HPGe Detectors**




 Signal induction process → Signal shape depends on interaction position!

#### **Coaxial Geometry**




#### **Planar Geometry**




## Gamma-Ray Energy Spectrum in HPGe



- Features based on various gamma-ray interaction mechanisms (coupled to detector geometry)
  - Full energy peak
    - Last interaction must be PE abs.
  - Features due to Compton scattering
    - Compton continuum, Compton Edge, Compton "valley"
    - Backscatter peak
  - Features from pair production
    - Escape peaks (single, double)
- "Good" coaxial detector
  - Ener. Res. < 0.2% @ > 1 MeV






# **HPGe Detector Efficiency**




- Absolute full-energy (peak) efficiency = (Counts in photopeak) / (number of emitted gamma rays)
- Intrinsic full-energy (peak) efficiency = (Counts in photopeak) / (number of emitted gamma rays incident on the detector)
- Relative full-energy (peak) efficiency = efficiency at 1332 keV (<sup>60</sup>Co source) relative to 3"x3" cylindrical NaI(TI) crystal at 25 cm distance.



# **Historical Note about HPGe Efficiency**



Detector efficiency is often quoted in percent of that for a 3"x3" NaI(Tl) detector (for historical reasons) and generally for the 1332.5 keV line from 60Co.



$$\begin{split} \varepsilon_{geo} &= \frac{1}{2} \Biggl( 1 - \frac{d}{\sqrt{d^2 + a^2}} \Biggr) \qquad d = 25cm, \, a = 1.5 \text{''} \\ \varepsilon_{geo} &= 5.707 \, x 10^{-3} \end{split}$$

$$\varepsilon_{total}(NaI) = 1.2x10^{-3} \rightarrow \varepsilon_{intrinsic}(NaI) = 0.210$$