

Name:	CM:	Start Date: Saturday, August 14, 2021

Due Date: Monday, August 16, 2021

Software and Hardware Co-Design with Zybo, Summer 2021 HUST Lab #4 Add custom IP and write basic software

This is an individual lab. Each student must perform it and demonstrate parts 2 of this lab to obtain credit for it. Late lab submission will be accepted with a grade reduction of 10% for each day that it is late.

You will need to download the first five labs are under "Embedded System Design Flow on Zynq using Vivado" from the Xilinx University Program (XUP) Website. Go to www.xilinx.com. Choose Support/University Program and then Resource/Workshops. See the appendix of this lab for more details.

1. Objectives

- Follow the second two labs from Xilinx University Program on Advanced Embedded System Design on Zynq using Vivado.
 - a. Lab #4 Part 1: ZYNQ Lab 3 Use Vivado to Build Embedded Systems, pages ZYNQ3-1 to ZYNO3-16.
 - b. Lab #4 Part 2: ZYNQ Lab 4 Adding IP Cores in PL, pages ZYNQ2-1 to ZYNQ2-16. Demonstrate this part to get credit for this lab.

2. Deliverables

2.1 Demonstrate Lab #4 Part 2 to get credit for this lab.


Demonstrate your Lab #4 Part 2 to get credit for this lab. Show your SDK terminal display of push button and slide switches. Demonstrate the states of LEDs as you press corresponding push buttons.

```
13
        xil_printf("-- Start of the Program --\r\n");
 14
        XGpio_Initialize(&dip, XPAR_BUTTONS_DEVICE ID); // Modify this
 15
 16
17
18
19
20
21
22
23
24
25
26
27
        XGpio_SetDataDirection(&dip, 1, 0xffffffff);
        XGpio_Initialize(&push, XPAR_SWITCHES_DEVICE_ID); // Modify this
        XGpio_SetDataDirection(&push, 1, 0xffffffff);
        while (1)
           psb_check = XGpio_DiscreteRead(&push, 1);
           xil_printf("Push Buttons Status %x\r\n", psb_check);
           dip_check = XGpio_DiscreteRead(&dip, 1);
           xil_printf("DIP Switch Status %x\r\n", dip_check);
 28
🛚 Problems 🔊 Tasks 🖳 Console 🔲 Properties 🧬 Terminal 1 🛭
                                                          N N □ 🛅 🚮 🔊 🕶 🕶
Serial: (COM4, 115200, 8, 1, None, None - CONNECTED) - Encoding: (ISO-8859-1)
Push Buttons Status A
DIP Switch Status 0
Push Buttons Status A
DTP Switch Status 0
Push Buttons Status A
DIP Switch Status 0
Push Buttons Status A
DIP Switch Status 0
Push Buttons Status A
```




3. Lab #4 Part 1 Create a Custom IP, Part Number xc7z010iclg400-1L


Follow Lab Workbook on Adding Custom IP to the System, pages ZYNQ3-1 to ZYNQ3-16 to create a new IP and add it to your block design. The new IP directory is C:/xup/embedded/led_ip . or any location you want to store it. Click "Finish".




If you do not see LED_WIDTH parameter, right click on the Customization Parameters menu, choose "Import Parameters". Choose led_ip_v1_0 so that LED_WIDTH would show.








If you don't see LED port under Ports and Interfaces menu, right click on the ports window, choose "Import IP Ports".








4. Lab #4 Part 2

Save lab4part1SoC project as lab4part2SoC project. Follow XUP Lab #4 pages ZYNQ 4-1 to ZYNQ 4-11 to complete this part of Lab #4.

You do not need to do any hardware design. Just generate the bit stream file, open implemented design and export hardware.

And then start SDK.

5. Demonstrate your Lab #4 Part 2



Demonstrate your Lab #4 Part 2 circuit on your Zybo board to obtain credit for both Part 1 and Part 2 of Lab #4.



5.1 Lab #4 Part 1 circuit with 4-bit LED IP.

Generate bit stream file for this block design. Make sure lab3 zybo.xdc file is attached to this design.

