# 計算機組織與結構

#### 114-1課程資訊

- 上課時間:週二01:10-04:00PM

■上課地點: 教108

授課教師: 陳麒元 教授

·辦公室: 教穡**417** 

■電子信箱: chency@niu.edu.tw

■個人網站:http://sites.google.com/site/chiyuanchen/

■課程助教:劉育瑋 ryan891118@gmail.com

實驗室:教穡419網路安全實驗室





# 計算機組織與結構

#### 114-1課程資訊

#### -指定教材:


- David A. Patterson & John L. Hennessy, Computer Organization and Design 6/e (MIPS Asia Edition), Elsevier B.V., 2021, ISBN: 9780128201091
- 鍾崇斌, 楊惠親(譯),計算機組織與設計: 硬體/軟體的介面 6/e Patterson,東華書局, 2023, ISBN: 9786267130681


#### 成績計算方式:

平時成績與作業: 40%;(含至少1-2次作業)

■ 期中考: 30%;

■ 期末考: 30%







# 計算機組織與結構

#### 114-1課程資訊

- ■1 計算機抽象化與科技 I
- ■2 計算機抽象化與科技 ||
- -3 指今:計算機的語言 I
- -4 指令:計算機的語言Ⅱ
- ■5 指令:計算機的語言 |||
- -6 計算機的算術 I
- ■7 計算機的算術 ||
- -8 計算機的算術 Ⅲ
- ■9 期中考
- ■10 處理器 I
- ■11 處理器 ||
- ■12 處理器 III
- ■13 利用記憶體階層 I
- ■14 利用記憶體階層Ⅱ
- ■15 利用記憶體階層 III
- ■16 從客戶端到雲端的平行處理器 I
- ■17 從客戶端到雲端的平行處理器 ||
- ■18 期末考

#### 成績計算方式:

- 平時成績與作業: 40%;
  - (含至少1-2次作業)
- 期中考: 30%;
- 期末考: 30%





#### COMPUTER ORGANIZATION AND D

The Hardware/Software Interface



### **Table of Contents**

- 1. Computer Abstractions and Technology
- 2. Instructions: Language of the Computer
- 3. Arithmetic for Computers
- 4. The Processor
- 5. Large and Fast: Exploiting Memory Hierarchy
- 6. Parallel Processors from Client to Cloud



#### COMPUTER ORGANIZATION AND DE

The Hardware/Software Interface



# **Chapter 1**

# Computer Abstractions and Technology

### **The Computer Revolution**

- Progress in computer technology
  - Underpinned by domain-specific accelerators
- Makes novel applications feasible
  - Computers in automobiles
  - Cell phones
  - Human genome project
  - World Wide Web
  - Search Engines
- Computers are pervasive




### **Classes of Computers**

- Personal computers(個人電腦)
  - General purpose, variety of software
  - Subject to cost/performance tradeoff
- Server computers(伺服器電腦)
  - Network based
  - High capacity, performance, reliability
  - Range from small servers to building sized

### **Classes of Computers**

- Supercomputers(超級電腦)
  - Type of server
  - High-end scientific and engineering calculations
  - Highest capability but represent a small fraction of the overall computer market
- Embedded computers(嵌入式電腦)
  - Hidden as components of systems
  - Stringent power/performance/cost constraints

### The PostPC Era



### The PostPC Era

- Personal Mobile Device (PMD,個人行動裝置)
  - Battery operated
  - Connects to the Internet
  - Hundreds of dollars
  - Smart phones, tablets, electronic glasses
- Cloud computing (雲端運算)
  - Warehouse Scale Computers (WSC,倉儲規模電腦)
  - Software as a Service (SaaS,軟體即服務)
  - Portion of software run on a PMD and a portion run in the Cloud
  - Amazon and Google



### What You Will Learn

- How programs are translated into the machine language
  - And how the hardware executes them
- The hardware/software interface
- What determines program performance
  - And how it can be improved
- How hardware designers improve performance
- What is parallel processing



# **Understanding Performance**

Hardware or software component	How this component affects performance	Where is this topic covered?
Algorithm	Determines both the number of source-level statements and the number of I/O operations executed	Other books!
Programming language, compiler, and architecture	Determines the number of computer instructions for each source-level statement	Chapters 2 and 3
Processor and memorysystem	Determines how fast instructions can be executed	Chapters 4, 5, and 6
I/O system (hardware and operating system)	Determines how fast I/O operations may be executed	Chapters 4, 5, and 6



### **Seven Great Ideas**

Use abstraction (抽象化) to simplify design



Make the common case (常見情形) fast



Performance via parallelism (平行性)
























### **Below Your Program**



- Application software
  - Written in high-level language
- System software
  - Compiler: translates HLL code to machine code
  - Operating System: service code
    - Handling input/output
    - Managing memory and storage
    - Scheduling tasks & sharing resources
- Hardware
  - Processor, memory, I/O controllers




# **Levels of Program Code**

- High-level language (高階 語言)
  - Level of abstraction closer to problem domain
  - Provides for productivity and portability
- Assembly language (組合 語言)
  - Textual representation of instructions
- Hardware representation
  - Binary digits (bits)
  - **Encoded instructions and**

High-level language program (in C)

Assembly language program (for MIPS)



Binary machine language program (for MIPS)


000000010100001000000000011000 0000000000110000001100000100001 100011000110001000000000000000000 000110001000000000000000100 

### Components of a Computer

#### **The BIG Picture**







- Same components for all kinds of computer
  - Desktop, server, embedded
- Input/output includes
  - User-interface devices
    - Display, keyboard, mouse
  - Storage devices
    - Hard disk, CD/DVD, flash
  - Network adapters
    - For communicating with other computers




### **Touchscreen**


- PostPC device
- Supersedes keyboard and mouse
- Resistive and Capacitive types
  - Most tablets, smart phones use capacitive
  - Capacitive allows multiple touches simultaneously




# Through the Looking Glass

- LCD screen: picture elements (pixels)
  - Mirrors content of frame buffer memory





# **Opening the Box**




# Inside the Processor (CPU)

- Datapath(資料路徑): performs operations on data
- Control Unit(控制單元): sequences datapath, memory, ...
- Cache memory(快取記憶體)
  - Small fast SRAM memory for immediate access to data

### Inside the Processor

A12 processor



### **Abstractions**

#### **The BIG Picture**

- Abstraction helps us deal with complexity
  - Hide lower-level detail
- Instruction set architecture (ISA)
  - The hardware/software interface
- Application binary interface
  - The ISA plus system software interface
- Implementation
  - The details underlying and interface



### A Safe Place for Data

- Volatile main memory
  - Loses instructions and data when power off
- Non-volatile secondary memory
  - Magnetic disk
  - Flash memory
  - Optical disk (CDROM, DVD)









### **Networks**


- Communication, resource sharing, nonlocal access
- Local area network (LAN): Ethernet
- Wide area network (WAN): the Internet
- Wireless network: WiFi, Bluetooth





# **Technology Trends**

- Electronics technology continues to evolve
  - Increased capacity and performance
  - Reduced cost



DRAM capacity

Year	Technology	Relative performance/cost
1951	Vacuum tube	1
1965	Transistor	35
1975	Integrated circuit (IC)	900
1995	Very large scale IC (VLSI)	2,400,000
2020	Ultra large scale IC	500,000,000,000




### Semiconductor Technology

- Silicon: semiconductor
- Add materials to transform properties:
  - Conductors
  - Insulators
  - Switch




### **Manufacturing ICs**



- Yield(良率): proportion of working dies per wafer(晶圓)
- https://www.youtube.com/watch?v=ife-z2T9QLM
- https://www.youtube.com/watch?v=AHe\_yVZW6no



### Intel® Core 10th Gen



- 300mm wafer, 506 chips, 10nm technology
- Each chip is 11.4 x 10.7 mm



### **Integrated Circuit Cost**

Cost per die = 
$$\frac{\text{Cost per wafer}}{\text{Dies per wafer} \times \text{Yield}}$$

Dies per wafer  $\approx \text{Wafer area/Die area}$ 


Yield =  $\frac{1}{(1+(\text{Defects per area} \times \text{Die area/2}))^2}$ 

- Nonlinear relation to area and defect rate
  - Wafer cost and area are fixed
  - Defect rate determined by manufacturing process
  - Die area determined by architecture and circuit design




# **Defining Performance**

#### Which airplane has the best performance?









### Response Time and Throughput

- Response time(反應時間)
  - How long it takes to do a task
- Throughput(處理量)
  - Total work done per unit time
    - e.g., tasks/transactions/... per hour
- How are response time and throughput affected by
  - Replacing the processor with a faster version?
  - Adding more processors?
- We'll focus on response time for now...

### **Relative Performance**

- Define Performance = 1/Execution Time
- "X is n time faster than Y"

Performance<sub>x</sub>/Performance<sub>y</sub>

- = Execution time  $_{Y}$  /Execution time  $_{X} = n$
- Example: time taken to run a program
  - 10s on A, 15s on B
  - Execution Time<sub>B</sub> / Execution Time<sub>A</sub>= 15s / 10s = 1.5
  - So A is 1.5 times faster than B




### **Measuring Execution Time**

- Elapsed time(經過時間)
  - Total response time, including all aspects
    - Processing, I/O, OS overhead, idle time
  - Determines system performance
- CPU time(執行時間)
  - Time spent processing a given job
    - Discounts I/O time, other jobs' shares
  - Comprises user CPU time and system CPU time
  - Different programs are affected differently by CPU and system performance



# **CPU Clocking**

 Operation of digital hardware governed by a constant-rate clock



- Clock period: duration of a clock cycle
  - e.g.,  $250ps = 0.25ns = 250 \times 10^{-12}s$
- Clock frequency (rate): cycles per second
  - $\bullet$  e.g., 4.0GHz = 4000MHz = 4.0×10<sup>9</sup>Hz

#### **CPU Time**

CPU Time = CPU Clock Cycles × Clock Cycle Time

= CPU Clock Cycles

Clock Rate

- Performance improved by
  - Reducing number of clock cycles
  - Increasing clock rate
  - Hardware designer must often trade off clock rate against cycle count

### **CPU Time Example**

- Computer A: 2GHz clock, 10s CPU time
- Designing Computer B
  - Aim for 6s CPU time
  - Can do faster clock, but causes 1.2 × clock cycles
- How fast must Computer B clock be?

$$Clock Rate_{B} = \frac{Clock Cycles_{B}}{CPU Time_{B}} = \frac{1.2 \times Clock Cycles_{A}}{6s}$$

$$Clock\ Cycles_A = CPU\ Time_A \times Clock\ Rate_A$$

$$= 10s \times 2GHz = 20 \times 10^9$$

Clock Rate<sub>B</sub> = 
$$\frac{1.2 \times 20 \times 10^9}{6s} = \frac{24 \times 10^9}{6s} = 4$$
GHz



#### Instruction Count and CPI

Clock Cycles = Instructio n Count  $\times$  Cycles per Instructio n

CPU Time = Instructio n Count  $\times$  CPI $\times$  Clock Cycle Time  $= \frac{\text{Instructio n Count} \times \text{CPI}}{\text{Clock Rate}}$ 

- Instruction Count for a program
  - Determined by program, ISA and compiler
- Average cycles per instruction
  - Determined by CPU hardware
  - If different instructions have different CPI
    - Average CPI affected by instruction mix



### **CPI Example**

- Computer A: Cycle Time = 250ps, CPI = 2.0
- Computer B: Cycle Time = 500ps, CPI = 1.2
- Same ISA
- Which is faster, and by how much?

$$\begin{aligned} \text{CPU Time}_{A} &= \text{Instructio n Count} \times \text{CPI}_{A} \times \text{Cycle Time}_{A} \\ &= I \times 2.0 \times 250 \text{ps} = I \times 500 \text{ps} & \quad \text{A is faster...} \end{aligned}$$
 
$$\begin{aligned} \text{CPU Time}_{B} &= \text{Instructio n Count} \times \text{CPI}_{B} \times \text{Cycle Time}_{B} \\ &= I \times 1.2 \times 500 \text{ps} = I \times 600 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 1.2 \times 500 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 
$$\begin{aligned} &= I \times 600 \text{ps} \\ &= I \times 500 \text{ps} \end{aligned}$$
 ...by this much

#### **CPI in More Detail**

 If different instruction classes take different numbers of cycles

Clock Cycles = 
$$\sum_{i=1}^{n} (CPI_i \times Instructio n Count_i)$$

Weighted average CPI

$$CPI = \frac{Clock \ Cycles}{Instructio \ n \ Count} = \sum_{i=1}^{n} \left( CPI_i \times \frac{Instructio \ n \ Count}{Instructio \ n \ Count} \right)$$

Relative frequency

### **CPI Example**

 Alternative compiled code sequences using instructions in classes A, B, C

Class	А	В	С
CPI for class	1	2	3
IC in sequence 1	2	1	2
IC in sequence 2	4	1	1

- Sequence 1: IC = 5
  - Clock Cycles= 2×1 + 1×2 + 2×3= 10
  - Avg. CPI = 10/5 = 2.0

- Sequence 2: IC = 6
  - Clock Cycles= 4×1 + 1×2 + 1×3= 9
  - Avg. CPI = 9/6 = 1.5

### **Performance Summary**


#### **The BIG Picture**

$$CPU \ Time = \frac{Instructio \ ns}{Program} \times \frac{Clock \ cycles}{Instructio \ n} \times \frac{Seconds}{Clock \ cycle}$$

- Performance depends on
  - Algorithm: affects IC, possibly CPI
  - Programming language: affects IC, CPI
  - Compiler: affects IC, CPI
  - Instruction set architecture: affects IC, CPI, T<sub>c</sub>



#### **Power Trends**



In CMOS IC technology

Power = Capacitive load × Voltage <sup>2</sup> × Frequency

×30

×1000



# Reducing Power


- Suppose a new CPU has
  - 85% of capacitive load of old CPU
  - 15% voltage and 15% frequency reduction

$$\frac{P_{\text{new}}}{P_{\text{old}}} = \frac{C_{\text{old}} \times 0.85 \times (V_{\text{old}} \times 0.85)^2 \times F_{\text{old}} \times 0.85}{C_{\text{old}} \times V_{\text{old}}^2 \times F_{\text{old}}} = 0.85^4 = 0.52$$

- The power wall
  - We can't reduce voltage further
  - We can't remove more heat
- How else can we improve performance?



#### **Uniprocessor Performance**






### Multiprocessors

- Multicore microprocessors
  - More than one processor per chip
- Requires explicitly parallel programming
  - Compare with instruction level parallelism
    - Hardware executes multiple instructions at once
    - Hidden from the programmer
  - Hard to do
    - Programming for performance
    - Load balancing
    - Optimizing communication and synchronization



#### **SPEC CPU Benchmark**

- Programs used to measure performance
  - Supposedly typical of actual workload
- Standard Performance Evaluation Corp (SPEC)
  - Develops benchmarks for CPU, I/O, Web, ...
- SPEC CPU2006
  - Elapsed time to execute a selection of programs
    - Negligible I/O, so focuses on CPU performance
  - Normalize relative to reference machine
  - Summarize as geometric mean of performance ratios
    - CINT2006 (integer) and CFP2006 (floating-point)



# SPECspeed 2017 Integer benchmarks on a 1.8 GHz Intel Xeon E5-2650L

Description	Name	Instruction Count x 10^9	СРІ	Clock cycle time (seconds x 10^-9)	Execution Time	Reference Time (seconds)	SPECratio
Description				,	(seconds)	, ,	
Perl interpreter	perlbench	2684	0.42	0.556	627	1774	2.83
GNU C compiler	gcc	2322	0.67	0.556	863	3976	4.61
Route planning	mcf	1786	1.22	0.556	1215	4721	3.89
Discrete Event simulation - computer network	omnetpp	1107	0.82	0.556	507	1630	3.21
XML to HTML conversion via XSLT	xalancbmk	1314	0.75	0.556	549	1417	2.58
Video compression	x264	4488	0.32	0.556	813	1763	2.17
Artificial Intelligence: alpha-beta tree search (Chess)	deepsjeng	2216	0.57	0.556	698	1432	2.05
Artificial Intelligence: Monte Carlo tree search (Go)	leela	2236	0.79	0.556	987	1703	1.73
Artificial Intelligence: recursive solution generator (Sudoku)	exchange2	6683	0.46	0.556	1718	2939	1.71
General data compression	xz	8533	1.32	0.556	6290	6182	0.98
Geometric mean							2.36

#### **SPEC Power Benchmark**

- Power consumption of server at different workload levels
  - Performance: ssj\_ops/sec
  - Power: Watts (Joules/sec)

Overall ssj\_ops per Watt = 
$$\left(\sum_{i=0}^{10} ssj_ops_i\right) / \left(\sum_{i=0}^{10} power_i\right)$$

#### SPECpower\_ssj2008 for Xeon E5-2650L

Target Load %	Performance (ssj_ops)	Average Power (watts)
100%	4,864,136	347
90%	4,389,196	312
80%	3,905,724	278
70%	3,418,737	241
60%	2,925,811	212
50%	2,439,017	183
40%	1,951,394	160
30%	1,461,411	141
20%	974,045	128
10%	485,973	115
0%	0	48
Overall Sum	26,815,444	2,165
∑ssj_ops / ∑pov	12,385	

#### Pitfall: Amdahl's Law

 Improving an aspect of a computer and expecting a proportional improvement in overall performance

$$T_{\text{improved}} = \frac{T_{\text{affected}}}{\text{improvemen t factor}} + T_{\text{unaffected}}$$

- Example: multiply accounts for 80s/100s
  - How much improvement in multiply performance to get 5× overall?

$$20 = \frac{80}{n} + 20$$
 • Can't be done!

Corollary: make the common case fast



### Fallacy: Low Power at Idle

- Look back at i7 power benchmark
  - At 100% load: 258W
  - At 50% load: 170W (66%)
  - At 10% load: 121W (47%)
- Google data center
  - Mostly operates at 10% 50% load
  - At 100% load less than 1% of the time
- Consider designing processors to make power proportional to load

#### Pitfall: MIPS as a Performance Metric

- MIPS: Millions of Instructions Per Second
  - Doesn't account for
    - Differences in ISAs between computers
    - Differences in complexity between instructions

$$\begin{split} \text{MIPS} &= \frac{\text{Instructio n count}}{\text{Execution time} \times 10^6} \\ &= \frac{\text{Instructio n count}}{\frac{\text{Instructio n count} \times \text{CPI}}{\text{Clock rate}}} = \frac{\text{Clock rate}}{\text{CPI} \times 10^6} \end{split}$$

CPI varies between programs on a given CPU

## **Concluding Remarks**

- Cost/performance is improving
  - Due to underlying technology development
- Hierarchical layers of abstraction
  - In both hardware and software
- Instruction set architecture
  - The hardware/software interface
- Execution time: the best performance measure
- Power is a limiting factor
  - Use parallelism to improve performance

