NSLS-II SRX Beamline Docs Documentation

Release 0.1

Brookhaven Science Associates, Brookhaven National Lab

CONTENTS

| 1 | 1 SRX (5-ID-1) Beamline Documentation | | |
|---|---------------------------------------|---|--|
| | 1.1 Contents | 3 | |
| 2 | Downloads | 7 | |

These pages are the documentation of the SRX beamline (5-ID-1) at the NSLS-II.

CONTENTS 1

2 CONTENTS

SRX (5-ID-1) BEAMLINE DOCUMENTATION

1.1 Contents

1.1.1 Optics

Placeholder for optics documentation.

1.1.2 Endstation

SRX KB mirrors

Introduction

There are two sets of KB mirrors in the SRX endstation, one high-flux pair and one high-resolution pair.

High-flux

Mir:2 - High-flux VFM

Mechanics

- · Weak link flexures for all translations
- Vertical translation system has four stepper motors, so is overconstrained. Extra axis is twist, and needs to be maintained at zero.
- Horizontal translation for stripe selection done by two SmarAct actuators. These actuators have limited ability to yaw, and as a result can get stuck.
- Longitudinal translation by single SmarAct actuator.

Motion control

- Delta Tau coordinate system implemented for Mir:2 vertical movements: vertical translation, pitch, roll, twist.
- Twist should be maintained at zero.
- A PLC monitors the twist and deactivates the vertical motors if the calculated twist exceeds a specified value.

Mir:3 - High-flux HFM

Mechanics

- Weak-link flexure for all stages.
- No overconstrained systems.

Motion control

Motion axes

| Mirror system | Axis | Motor type | Controller | Notes |
|-------------------------------------|------|-------------|------------|----------------------------|
| Mir:2 (high-flux vertical focusing) | X | SmarAct | SmarAct | Limited yaw capability |
| | | (2) | MCS | |
| | Y | Stepper (4) | Delta Tau | Overconstrained mechanical |
| | | | | system |
| | Z | SmarAct | SmarAct | |
| | | (1) | MCS | |
| Mir:3 (high-flux horizontal | X | SmarAct | SmarAct | Limited yaw capability |
| focusing) | | (2) | MCS | |
| | Y | Stepper (1) | Delta Tau | |

High-resolution

Mir:4 - High-resolution VFM

Mechanics

- Weak link flexures for all translations
- Vertical translation system has two stepper motors, so is not overconstrained.

Motion control

Mir:5 - High-resolution HFM

Mechanics

- Weak link flexures for all translations
- Downstream X translation motor is in line with mirror center, so this motor does not move to implement pitch movement.

Motion control

• Roll motor has approximately +/- 5 degrees of movement.

| Motion | aves |
|--------|------|

| Mirror system | Axis | Motor type | Controller | Notes |
|-----------------------------------|------|-------------|-------------|-------------|
| Mir:4 (high-resolution vertical | X | SmarAct (2) | SmarAct MCS | Limited yaw |
| focusing) | | | | capability |
| | Y | Stepper (2) | Delta Tau | |
| | Z | SmarAct (1) | SmarAct MCS | |
| Mir:5 (high-resolution horizontal | X | SmarAct (2) | SmarAct MCS | Limited yaw |
| focusing) | | | | capability |
| | Y | Stepper (1) | Delta Tau | |
| | Roll | Attocube | Attocube | |
| | | ECGt5050 | ECC100 | |

Instructions

SmarAct motor closed-loop operation

- To activate closed-loop operation, set the 'Closed Loop' button on the desired axis to Enable.
- Moving the axis will reset this to 'Disable' but the axis will remain in closed-loop.
- The motor should show 'Holding' after the move has complete. 'Stopped' indicates open-loop operation.
- To deactivate closed-loop operation, set the 'Closed Loop' button on the desired axis to Disable. Even if it is already showing Disable, this will move the motor into open-loop operation.
- Pressing 'Stop' will stop movement and put the motor into open-loop.

Mir:5 roll referencing

- Turn on both auto-reference and auto-reset in Advanced display.
- Move axis over full range until 'Referenced' light turns green.
- Turn off both auto-reference and auto-reset.

1.1.3 Controls

IOC documentation

A hutch

Servers

| Host name | Function |
|--------------|------------|
| xf05ida-ioc1 | IOC server |

1.1. Contents 5

| IOC ID | Host | Function | Path (if not standard) |
|--------|--------------|-------------------------------|------------------------|
| bpm01 | xf05ida-ioc1 | BPM:01 (AH501D) | |
| bpm02 | xf05ida-ioc1 | BPM:02 (AH501D) | |
| bpm03 | xf05ida-ioc1 | BPM:03 (TetrAMM) | |
| bpm04 | xf05ida-ioc1 | BPM:04 (TetrAMM) | |
| bpm05 | xf05ida-ioc1 | BPM:05 (AH501D) | |
| cam01 | xf05ida-ioc1 | HFM | |
| cam02 | xf05ida-ioc1 | FS:1 | |
| cam03 | xf05ida-ioc1 | DCM Cam:1 | |
| cam04 | xf05ida-ioc1 | DCM Cam:2 | |
| cam05 | xf05ida-ioc1 | BPM:1 (A Hutch) | |
| cam06 | xf05ida-ioc1 | BPM:2 (B Hutch) | |
| cryo1 | xf05ida-ioc1 | DCM cryocooler | |
| mc01 | xf05ida-ioc1 | Slits | |
| mc02 | xf05ida-ioc1 | HFM | |
| mc03 | xf05ida-ioc1 | DCM | |
| mc04 | xf05ida-ioc1 | Mirror fine pitch | |
| mc05 | xf05ida-ioc1 | DCM first crystal fine roll | |
| mc06 | xf05ida-ioc1 | DCM second crystal fine pitch | |
| mc07 | xf05ida-ioc1 | SmarAct - SSA, BPMs | |
| plc1 | xf05ida-ioc1 | EPS PLC | |
| rg-tc1 | xf05ida-ioc1 | Rack temperature controllers | |
| ups1 | xf05ida-ioc1 | UPS | |
| va01 | xf05ida-ioc1 | Vacuum | |

D hutch

IOCs

Servers

| Host name | Function |
|-------------------|------------|
| xf05idd-ioc1 | IOC server |
| xf05idd-ioc-det1 | Xspress3 |
| xf05idd-ioc-det02 | Saturn |
| xf05idd-ioc-det03 | Pixirad |

IOCs

1.1.4 Software

Placeholder for software documentation

| СНАРТ | ER |
|-------|------------|
| TW | / 0 |

DOWNLOADS

Download the SRX Documentation as a PDF