i.MX8 HSM API

Revision_0.1

Generated by Doxygen 1.8.15

1 Main Page

This document is a software referece description of the API provided by the i.MX8 HSM solutions.

2 Revision History

Revision 0.1: 29/03/2019 Savari preliminary draft - subject to change Revision 0.8: 20/05/2019 Adding butterfly key expansion operation; adding signature, rng, hash services.

3 General concepts related to the API

3.1 Session

The API must be initialized by a potential requestor by opening a session.
The session establishes a route (MU, DomainID...) between the requester and the HSM, and grants the usage of a specified key store through a password authentication.
When a session is opened, the HSM returns a handle identifying the session to the requester.

3.2 Service flow

For a given category of services, the requestor is expected to open a service flow by invoking the appropriate HSM API. The session handle, as well as the control data needed for the service flow are provided as parameters of the call. Upon reception of the open request, the HSM allocates a context in which the session handle, as well as the provided control parameters are stored. The context is preserved until the service flow is closed by the user and it is used by the HSM to proceed with the sub-sequent operations requested by the user on the service flow.

4 Module Index

4.1 Modules

Here is a list of all modules:

5 Class Index

5.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

6 Module Documentation

6.1 Hsm_api

i.MX8 HSM API header file

Classes

- struct open_session_args_t
- struct open_svc_key_store_args_t
- struct open_svc_key_management_args_t
- struct op_generate_key_args_t
- struct op_manage_key_args_t
- struct op_butt_key_exp_args_t
- struct open_svc_cipher_args_t
- struct op_cipher_one_go_args_t
- struct open_svc_sign_gen_args_t
- struct op_generate_sign_args_t
- struct op_prepare_sign_args_t
- struct op_finalize_sign_args_t
- struct open_svc_sign_ver_args_t
- struct op_verify_sign_args_t
- struct op_import_public_key_args_t
- struct open_svc_rng_args_t
- struct op_get_random_args_t
- struct open_svc_hash_args_t
- struct op_hash_one_go_args_t
- struct hsm_op_pub_key_rec_args_t
- struct hsm_op_pub_key_dec_args_t
- struct hsm_op_ecies_enc_args_t
- struct hsm_op_ecies_dec_args_t

Macros

- #define HSM_SVC_KEY_STORE_FLAGS_CREATE ((hsm_svc_key_store_flags_t)(1 << 0))
- #define HSM_SVC_KEY_STORE_FLAGS_UPDATE ((hsm_svc_key_store_flags_t)(1 << 1))
- #define HSM_SVC_KEY_STORE_FLAGS_DELETE ((hsm_svc_key_store_flags_t)(1 << 3))
- #define HSM_KEY_TYPE_ECDSA_NIST_P224 ((hsm_key_type_t)0x01)
- #define HSM_KEY_TYPE_ECDSA_NIST_P256 ((hsm_key_type_t)0x02)
- #define HSM_KEY_TYPE_ECDSA_NIST_P384 ((hsm_key_type_t)0x03)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224 ((hsm_key_type_t)0x12)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256 ((hsm_key_type_t)0x13)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384 ((hsm_key_type_t)0x15)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224 ((hsm_key_type_t)0x22)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256 ((hsm_key_type_t)0x23)
- #define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384 ((hsm_key_type_t)0x25)
- #define HSM_KEY_TYPE_AES_128 ((hsm_key_type_t)0x30)
- #define HSM_KEY_TYPE_AES_192 ((hsm_key_type_t)0x31)
- #define HSM_KEY_TYPE_AES_256 ((hsm_key_type_t)0x32)
- #define HSM_KEY_INFO_PERMANENT ((hsm_key_info_t)(1 << 0))
- #define HSM_OP_KEY_GENERATION_FLAGS_UPDATE ((hsm_op_key_gen_flags_t)(1 << 0))
- #define HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT ((hsm_op_key_gen_flags_t)(1 << 1))
- #define HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT ((hsm_op_key_gen_flags_t)(1 << 2))
- #define HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION ((hsm_op_key_gen_flags_t)(1 << 7))
- #define HSM_OP_MANAGE_KEY_FLAGS_UPDATE ((hsm_op_manage_key_flags_t)(1 << 0))
- #define HSM_OP_MANAGE_KEY_FLAGS_CREATE_PERSISTENT ((hsm_op_manage_key_flags_t)(1 << 1))
- #define HSM_OP_MANAGE_KEY_FLAGS_CREATE_TRANSIENT ((hsm_op_manage_key_flags_t)(1 << 2))
- #define HSM_OP_MANAGE_KEY_FLAGS_DELETE ((hsm_op_manage_key_flags_t)(1 << 3))
- #define HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION ((hsm_op_manage_key_flags_t)(1 << 7))
- #define HSM_CIPHER_ONE_GO_ALGO_AES_ECB ((hsm_op_cipher_one_go_algo_t)(0x00))
- #define HSM_CIPHER_ONE_GO_ALGO_AES_CBC ((hsm_op_cipher_one_go_algo_t)(0x01))
- #define HSM_CIPHER_ONE_GO_ALGO_AES_CCM ((hsm_op_cipher_one_go_algo_t)(0x04))

  AES CCM where Adata = 0, Tlen = 16 bytes.
- #define HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT ((hsm_op_cipher_one_go_flags_t)(1 << 0))
- #define HSM_CIPHER_ONE_GO_FLAGS_DECRYPT ((hsm_op_cipher_one_go_flags_t)(1 << 1))
- #define HSM_OP_GENERATE_SIGN_INPUT_DIGEST ((hsm_op_generate_sign_flags_t)(1 << 0))
- #define HSM_OP_GENERATE_SIGN_INPUT_MESSAGE ((hsm_op_generate_sign_flags_t)(1 << 1))
- #define HSM_OP_GENERATE_SIGN_COMPRESSED_POINT ((hsm_op_generate_sign_flags_t)(1 << 2))
- #define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P224_SHA_256 ((hsm_signature_scheme_id_t)0x01)
- #define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_SHA_256 ((hsm_signature_scheme_id_t)0x02)
- #define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_SHA_384 ((hsm_signature_scheme_id_t)0x03)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_224_SHA_256 ((hsm_signature_scheme_id_t)0x12)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_256_SHA_256 ((hsm_signature_scheme_id_t)0x13)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_384_SHA_384 ((hsm_signature_scheme_id_t)0x15)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_224_SHA_256 ((hsm_signature_scheme_id_t)0x22)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_256_SHA_256 ((hsm_signature_scheme_id_t)0x23)
- #define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_384_SHA_384 ((hsm_signature_scheme_id_t)0x25)
- #define HSM_OP_FINALIZE_SIGN_INPUT_DIGEST ((hsm_op_finalize_sign_flags_t)(1 << 0))
- #define HSM_OP_FINALIZE_SIGN_INPUT_MESSAGE ((hsm_op_finalize_sign_flags_t)(1 << 1))
- #define HSM_OP_FINALIZE_SIGN_COMPRESSED_POINT ((hsm_op_finalize_sign_flags_t)(1 << 2))
- #define HSM_OP_VERIFY_SIGN_INPUT_DIGEST ((hsm_op_verify_sign_flags_t)(1 << 0))

- #define HSM_OP_VERIFY_SIGN_INPUT_MESSAGE ((hsm_op_verify_sign_flags_t)(1 << 1))
- #define HSM_OP_VERIFY_SIGN_COMPRESSED_POINT ((hsm_op_verify_sign_flags_t)(1 << 2))
- #define HSM_OP_VERIFY_SIGN_KEY_INTERNAL ((hsm_op_verify_sign_flags_t)(1 << 4))
- #define HSM_VERIFICATION_STATUS_SUCCESS ((hsm_verification_status_t)(0x5A3CC3A5))
- #define HSM_HASH_ALGO_SHA_224 ((hsm_hash_algo_t)(0x0))
- #define HSM_HASH_ALGO_SHA_256 ((hsm_hash_algo_t)(0x1))
- #define HSM_HASH_ALGO_SHA_384 ((hsm_hash_algo_t)(0x2))

Typedefs

- typedef uint32_t hsm_hdl_t
- typedef uint8_t hsm_svc_key_store_flags_t
- typedef uint8_t hsm_svc_key_management_flags_t
- typedef uint8_t hsm_svc_cipher_flags_t
- typedef uint8_t hsm_svc_signature_generation_flags_t
- typedef uint8_t hsm_svc_signature_verification_flags_t
- typedef uint8_t hsm_svc_fast_signature_verification_flags_t
- typedef uint8_t hsm_svc_rng_flags_t
- typedef uint8_t hsm_svc_hash_flags_t
- typedef uint8_t hsm_op_key_gen_flags_t
- typedef uint8_t hsm_op_manage_key_flags_t
- typedef uint8_t hsm_op_but_key_exp_flags_t
- typedef uint8_t hsm_op_cipher_one_go_algo_t
- typedef uint8_t hsm_op_cipher_one_go_flags_t
- typedef uint8_t hsm_op_generate_sign_flags_t
- typedef uint8_t hsm_op_prepare_signature_flags_t
- typedef uint8_t hsm_op_finalize_sign_flags_t
- typedef uint8_t hsm_op_verify_sign_flags_t
- typedef uint8_t hsm_op_fast_signature_gen_flags_t
- typedef uint8_t hsm_op_fast_signature_ver_flags_t
- typedef uint8_t hsm_op_hash_one_go_flags_t
- typedef uint8_t hsm_op_pub_key_rec_flags_t
- typedef uint8_t hsm_op_pub_key_dec_flags_t
- typedef uint8_t hsm_op_ecies_enc_flags_t
- typedef uint8_t hsm_op_ecies_dec_flags_t
- typedef uint8_t hsm_signature_scheme_id_t
- typedef uint8_t hsm_hash_algo_t
- typedef uint8_t hsm_key_type_t
- typedef uint8_t hsm_key_type_ext_t
- typedef uint16_t hsm_key_info_t
- typedef uint32_t hsm_addr_msb_t
- typedef uint32_t hsm_addr_lsb_t
- typedef uint32_t hsm_verification_status_t

Enumerations

- enum hsm_err_t {
  HSM_NO_ERROR = 0x0,
  HSM_INVALID_MESSAGE = 0x1,
  HSM_INVALID_ADDRESS = 0x2,
  HSM_UNKNOWN_ID = 0x3,
  HSM_INVALID_PARAM = 0x4,
  HSM_NVM_ERROR = 0x5,
  HSM_OUT_OF_MEMORY = 0x6,
  HSM_UNKNOWN_HANDLE = 0x7,
  HSM_UNKNOWN_KEY_STORE = 0x8,
  HSM_KEY_STORE_AUTH = 0x9,
  HSM_KEY_STORAGE_ERROR = 0xA,
  HSM_ID_CONFLICT = 0xB,
  HSM_RNG_NOT_STARTED = 0xC,
  HSM_CMD_NOT_SUPPORTED = 0xD,
  HSM_INVALID_LIFECYCLE = 0xE,
  HSM_KEY_STORE_CONFLICT = 0xF,
  HSM_GENERAL_ERROR = 0xFF }

  Error codes returned by HSM functions.

Functions

- hsm_err_t hsm_open_session (open_session_args_t ∗args, hsm_hdl_t ∗session_hdl)
- hsm_err_t hsm_close_session (hsm_hdl_t session_hdl)
- hsm_err_t hsm_open_key_store_service (hsm_hdl_t session_hdl, open_svc_key_store_args_t ∗args, hsm_hdl_t ∗key_store_hdl)
- hsm_err_t hsm_close_key_store_service (hsm_hdl_t key_store_hdl)
- hsm_err_t hsm_open_key_management_service (hsm_hdl_t key_store_hdl, open_svc_key_management_args_t ∗args, hsm_hdl_t ∗key_management_hdl)
- hsm_err_t hsm_generate_key (hsm_hdl_t key_management_hdl, op_generate_key_args_t args)
- hsm_err_t hsm_manage_key (hsm_hdl_t key_management_hdl, op_manage_key_args_t ∗args)
- hsm_err_t hsm_butterfly_key_expansion (hsm_hdl_t key_management_hdl, op_butt_key_exp_args_t ∗args)
- hsm_err_t hsm_close_key_management_service (hsm_hdl_t key_management_hdl)
- hsm_err_t hsm_open_cipher_service (hsm_hdl_t key_store_hdl, open_svc_cipher_args_t ∗args, hsm_hdl_t ∗chiper_hdl)
- hsm_err_t hsm_cipher_one_go (hsm_hdl_t chiper_hdl, op_cipher_one_go_args_t ∗args)
- hsm_err_t hsm_close_cipher_service (hsm_hdl_t chiper_hdl)
- hsm_err_t hsm_open_signature_generation_service (hsm_hdl_t key_store_hdl, open_svc_sign_gen_args_t ∗args, hsm_hdl_t ∗signature_gen_hdl)
- hsm_err_t hsm_close_signature_generation_service (hsm_hdl_t signature_gen_hdl)
- hsm_err_t hsm_generate_signature (hsm_hdl_t signature_gen_hdl, op_generate_sign_args_t ∗args)
- hsm_err_t hsm_prepare_signature (hsm_hdl_t signature_gen_hdl, op_prepare_sign_args_t ∗args)
- hsm_err_t hsm_finalize_signature (hsm_hdl_t signature_gen_hdl, op_finalize_sign_args_t ∗args)
- hsm_err_t hsm_open_signature_verification_service (hsm_hdl_t session_hdl, open_svc_sign_ver_args_t ∗args, hsm_hdl_t ∗signature_ver_hdl)
- hsm_err_t hsm_verify_signature (hsm_hdl_t signature_ver_hdl, op_verify_sign_args_t ∗args, hsm_verification_status_t ∗status)
- hsm_err_t hsm_import_public_key (hsm_hdl_t signature_ver_hdl, op_import_public_key_args_t ∗args, hsm_addr_lsb_t ∗int_key)
- hsm_err_t hsm_close_signature_verification_service (hsm_hdl_t signature_ver_hdl)
- hsm_err_t hsm_open_rng_service (hsm_hdl_t session_hdl, open_svc_rng_args_t ∗args, hsm_hdl_t ∗rng_hdl)
- hsm_err_t hsm_close_rng_service (hsm_hdl_t rng_hdl)

- hsm_err_t hsm_get_random (hsm_hdl_t rng_hdl, op_get_random_args_t ∗args)
- hsm_err_t hsm_open_hash_service (hsm_hdl_t session_hdl, open_svc_hash_args_t ∗args, hsm_hdl_t ∗hash_hdl)
- hsm_err_t hsm_close_hash_service (hsm_hdl_t hash_hdl)
- hsm_err_t hsm_hash_one_go (hsm_hdl_t hash_hdl, op_hash_one_go_args_t ∗args)
- hsm_err_t hsm_pub_key_reconstruction (hsm_hdl_t session_hdl, hsm_op_pub_key_rec_args_t ∗args)
- hsm_err_t hsm_pub_key_decompression (hsm_hdl_t session_hdl, hsm_op_pub_key_dec_args_t ∗args)
- hsm_err_t hsm_ecies_encryption (hsm_hdl_t session_hdl, hsm_op_ecies_enc_args_t ∗args)
- hsm_err_t hsm_ecies_decryption (hsm_hdl_t key_store_hdl, hsm_op_ecies_dec_args_t ∗args)

6.1.1 Detailed Description

i.MX8 HSM API header file

6.1.2 Macro Definition Documentation

6.1.2.1 HSM_SVC_KEY_STORE_FLAGS_CREATE

```
#define HSM_SVC_KEY_STORE_FLAGS_CREATE ((hsm_svc_key_store_flags_t)(1 << 0))
```

It must be specified to create a new key storage

6.1.2.2 HSM_SVC_KEY_STORE_FLAGS_UPDATE

```
#define HSM_SVC_KEY_STORE_FLAGS_UPDATE ((hsm_svc_key_store_flags_t)(1 << 1))
```

6.1.2.3 HSM_SVC_KEY_STORE_FLAGS_DELETE

```
#define HSM_SVC_KEY_STORE_FLAGS_DELETE ((hsm_svc_key_store_flags_t)(1 << 3))
```

6.1.2.4 HSM_KEY_TYPE_ECDSA_NIST_P224

```
#define HSM_KEY_TYPE_ECDSA_NIST_P224 ((hsm_key_type_t)0x01)
```

6.1.2.5 HSM_KEY_TYPE_ECDSA_NIST_P256

```
#define HSM_KEY_TYPE_ECDSA_NIST_P256 ((hsm_key_type_t)0x02)
```

6.1.2.6 HSM_KEY_TYPE_ECDSA_NIST_P384

```
#define HSM_KEY_TYPE_ECDSA_NIST_P384 ((hsm_key_type_t)0x03)
```

6.1.2.7 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224 ((hsm_key_type_t)0x12)
```

6.1.2.8 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256 ((hsm_key_type_t)0x13)
```

6.1.2.9 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384 ((hsm_key_type_t)0x15)
```

6.1.2.10 HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224 ((hsm_key_type_t)0x22)
```

6.1.2.11 HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256 ((hsm_key_type_t)0x23)
```

6.1.2.12 HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384 ((hsm_key_type_t)0x25)
```

6.1.2.13 HSM_KEY_TYPE_AES_128

```
#define HSM_KEY_TYPE_AES_128 ((hsm_key_type_t)0x30)
```

6.1.2.14 HSM_KEY_TYPE_AES_192

```
#define HSM_KEY_TYPE_AES_192 ((hsm_key_type_t)0x31)
```

6.1.2.15 HSM_KEY_TYPE_AES_256

```
#define HSM_KEY_TYPE_AES_256 ((hsm_key_type_t)0x32)
```

6.1.2.16 HSM_KEY_INFO_PERMANENT

```
#define HSM_KEY_INFO_PERMANENT ((hsm_key_info_t)(1 << 0))
```

When set, the key is permanent. Once created, it will not be possible to update or delete the key anymore. This bit can never be reset.

6.1.2.17 HSM_OP_KEY_GENERATION_FLAGS_UPDATE

```
#define HSM_OP_KEY_GENERATION_FLAGS_UPDATE ((hsm_op_key_gen_flags_t)(1 << 0))
```

User can replace an existing key only by generating a key with the same type of the original one.

6.1.2.18 HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT

```
#define HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT ((hsm_op_key_gen_flags_t)(1 << 1))
```

Persistent keys are saved in the non volatile memory.

6.1.2.19 HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT

```
#define HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT ((hsm_op_key_gen_flags_t)(1 << 2))
```

Transient keys are deleted when the corresponding key store service flow is closed.

6.1.2.20 HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION

```
#define HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION ((hsm_op_key_gen_flags_t)(1 << 7))
```

The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.

6.1.2.21 HSM_OP_MANAGE_KEY_FLAGS_UPDATE

```
#define HSM_OP_MANAGE_KEY_FLAGS_UPDATE ((hsm_op_manage_key_flags_t)(1 << 0))
```

User can replace an existing key only by importing a key with the same type of the original one.

6.1.2.22 HSM_OP_MANAGE_KEY_FLAGS_CREATE_PERSISTENT

```
#define HSM_OP_MANAGE_KEY_FLAGS_CREATE_PERSISTENT ((hsm_op_manage_key_flags_t)(1 << 1))
```

Persistent keys are saved in the non volatile memory.

6.1.2.23 HSM_OP_MANAGE_KEY_FLAGS_CREATE_TRANSIENT

```
#define HSM_OP_MANAGE_KEY_FLAGS_CREATE_TRANSIENT ((hsm_op_manage_key_flags_t)(1 << 2))
```

Transient keys are deleted when the corresponding key store service flow is closed.

6.1.2.24 HSM_OP_MANAGE_KEY_FLAGS_DELETE

```
#define HSM_OP_MANAGE_KEY_FLAGS_DELETE ((hsm_op_manage_key_flags_t)(1 << 3))
```

delete an existing key

6.1.2.25 HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION

```
#define HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION ((hsm_op_manage_key_flags_t)(1 << 7))
```

The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.

6.1.2.26 HSM_CIPHER_ONE_GO_ALGO_AES_ECB

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_ECB ((hsm_op_cipher_one_go_algo_t)(0x00))
```

6.1.2.27 HSM_CIPHER_ONE_GO_ALGO_AES_CBC

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_CBC ((hsm_op_cipher_one_go_algo_t)(0x01))
```

6.1.2.28 HSM_CIPHER_ONE_GO_ALGO_AES_CCM

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_CCM ((hsm_op_cipher_one_go_algo_t)(0x04))
```

AES CCM where Adata = 0, Tlen = 16 bytes.

Perform AES CCM with following constraints:

- Adata = 0 - There is no associated data
- Tlen = 16 bytes

6.1.2.29 HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT

```
#define HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT ((hsm_op_cipher_one_go_flags_t)(1 << 0))
```

6.1.2.30 HSM_CIPHER_ONE_GO_FLAGS_DECRYPT

```
#define HSM_CIPHER_ONE_GO_FLAGS_DECRYPT ((hsm_op_cipher_one_go_flags_t)(1 << 1))
```

6.1.2.31 HSM_OP_GENERATE_SIGN_INPUT_DIGEST

```
#define HSM_OP_GENERATE_SIGN_INPUT_DIGEST ((hsm_op_generate_sign_flags_t)(1 << 0))
```

6.1.2.32 HSM_OP_GENERATE_SIGN_INPUT_MESSAGE

```
#define HSM_OP_GENERATE_SIGN_INPUT_MESSAGE ((hsm_op_generate_sign_flags_t)(1 << 1))
```

6.1.2.33 HSM_OP_GENERATE_SIGN_COMPRESSED_POINT

```
#define HSM_OP_GENERATE_SIGN_COMPRESSED_POINT ((hsm_op_generate_sign_flags_t)(1 << 2))
```

6.1.2.34 HSM_SIGNATURE_SCHEME_ECDSA_NIST_P224_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P224_SHA_256 ((hsm_signature_scheme_id_t)0x01)
```

6.1.2.35 HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_SHA_256 ((hsm_signature_scheme_id_t)0x02)
```

6.1.2.36 HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_SHA_384

```
#define HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_SHA_384 ((hsm_signature_scheme_id_t)0x03)
```

6.1.2.37 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_224_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_224_SHA_256 ((hsm_signature_scheme_id_t)0x12)
```

6.1.2.38 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_256_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_256_SHA_256 ((hsm_signature_scheme_id_t)0x13)
```

6.1.2.39 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_384_SHA_384

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_R1_384_SHA_384 ((hsm_signature_scheme_id_t)0x15)
```

6.1.2.40 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_224_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_224_SHA_256 ((hsm_signature_scheme_id_t)0x22)
```

6.1.2.41 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_256_SHA_256

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_256_SHA_256 ((hsm_signature_scheme_id_t)0x23)
```

6.1.2.42 HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_384_SHA_384

```
#define HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL_T1_384_SHA_384 ((hsm_signature_scheme_id_t)0x25)
```

6.1.2.43 HSM_OP_FINALIZE_SIGN_INPUT_DIGEST

```
#define HSM_OP_FINALIZE_SIGN_INPUT_DIGEST ((hsm_op_finalize_sign_flags_t)(1 << 0))
```

6.1.2.44 HSM_OP_FINALIZE_SIGN_INPUT_MESSAGE

```
#define HSM_OP_FINALIZE_SIGN_INPUT_MESSAGE ((hsm_op_finalize_sign_flags_t)(1 << 1))
```

6.1.2.45 HSM_OP_FINALIZE_SIGN_COMPRESSED_POINT

```
#define HSM_OP_FINALIZE_SIGN_COMPRESSED_POINT ((hsm_op_finalize_sign_flags_t)(1 << 2))
```

6.1.2.46 HSM_OP_VERIFY_SIGN_INPUT_DIGEST

```
#define HSM_OP_VERIFY_SIGN_INPUT_DIGEST ((hsm_op_verify_sign_flags_t)(1 << 0))
```

6.1.2.47 HSM_OP_VERIFY_SIGN_INPUT_MESSAGE

```
#define HSM_OP_VERIFY_SIGN_INPUT_MESSAGE ((hsm_op_verify_sign_flags_t)(1 << 1))
```

6.1.2.48 HSM_OP_VERIFY_SIGN_COMPRESSED_POINT

```
#define HSM_OP_VERIFY_SIGN_COMPRESSED_POINT ((hsm_op_verify_sign_flags_t)(1 << 2))
```

6.1.2.49 HSM_OP_VERIFY_SIGN_KEY_INTERNAL

```
#define HSM_OP_VERIFY_SIGN_KEY_INTERNAL ((hsm_op_verify_sign_flags_t)(1 << 4))
```

when set the value passed by the key argument is considered as the internal reference of a key imported throught the hsm__import_pub_key API.

6.1.2.50 HSM_VERIFICATION_STATUS_SUCCESS

```
#define HSM_VERIFICATION_STATUS_SUCCESS ((hsm_verification_status_t)(0x5A3CC3A5))
```

6.1.2.51 HSM_HASH_ALGO_SHA_224

```
#define HSM_HASH_ALGO_SHA_224 ((hsm_hash_algo_t)(0x0))
```

6.1.2.52 HSM_HASH_ALGO_SHA_256

```
#define HSM_HASH_ALGO_SHA_256 ((hsm_hash_algo_t)(0x1))
```

6.1.2.53 HSM_HASH_ALGO_SHA_384

```
#define HSM_HASH_ALGO_SHA_384 ((hsm_hash_algo_t)(0x2))
```

6.1.3 Typedef Documentation

6.1.3.1 hsm_hdl_t

```
typedef uint32_t hsm_hdl_t
```

6.1.3.2 hsm_svc_key_store_flags_t

```
typedef uint8_t hsm_svc_key_store_flags_t
```

6.1.3.3 hsm_svc_key_management_flags_t

```
typedef uint8_t hsm_svc_key_management_flags_t
```

6.1.3.4 hsm_svc_cipher_flags_t

```
typedef uint8_t hsm_svc_cipher_flags_t
```

6.1.3.5 hsm_svc_signature_generation_flags_t

```
typedef uint8_t hsm_svc_signature_generation_flags_t
```

6.1.3.6 hsm_svc_signature_verification_flags_t

```
typedef uint8_t hsm_svc_signature_verification_flags_t
```

6.1.3.7 hsm_svc_fast_signature_verification_flags_t

```
typedef uint8_t hsm_svc_fast_signature_verification_flags_t
```

6.1.3.8 hsm_svc_rng_flags_t

```
typedef uint8_t hsm_svc_rng_flags_t
```

6.1.3.9 hsm_svc_hash_flags_t

```
typedef uint8_t hsm_svc_hash_flags_t
```

6.1.3.10 hsm_op_key_gen_flags_t

```
typedef uint8_t hsm_op_key_gen_flags_t
```

6.1.3.11 hsm_op_manage_key_flags_t

```
typedef uint8_t hsm_op_manage_key_flags_t
```

6.1.3.12 hsm_op_but_key_exp_flags_t

```
typedef uint8_t hsm_op_but_key_exp_flags_t
```

6.1.3.13 hsm_op_cipher_one_go_algo_t

```
typedef uint8_t hsm_op_cipher_one_go_algo_t
```

6.1.3.14 hsm_op_cipher_one_go_flags_t

```
typedef uint8_t hsm_op_cipher_one_go_flags_t
```

6.1.3.15 hsm_op_generate_sign_flags_t

```
typedef uint8_t hsm_op_generate_sign_flags_t
```

6.1.3.16 hsm_op_prepare_signature_flags_t

```
typedef uint8_t hsm_op_prepare_signature_flags_t
```

6.1.3.17 hsm_op_finalize_sign_flags_t

```
typedef uint8_t hsm_op_finalize_sign_flags_t
```

6.1.3.18 hsm_op_verify_sign_flags_t

```
typedef uint8_t hsm_op_verify_sign_flags_t
```

6.1.3.19 hsm_op_fast_signature_gen_flags_t

```
typedef uint8_t hsm_op_fast_signature_gen_flags_t
```

6.1.3.20 hsm_op_fast_signature_ver_flags_t

```
typedef uint8_t hsm_op_fast_signature_ver_flags_t
```

6.1.3.21 hsm_op_hash_one_go_flags_t

```
typedef uint8_t hsm_op_hash_one_go_flags_t
```

6.1.3.22 hsm_op_pub_key_rec_flags_t

```
typedef uint8_t hsm_op_pub_key_rec_flags_t
```

6.1.3.23 hsm_op_pub_key_dec_flags_t

```
typedef uint8_t hsm_op_pub_key_dec_flags_t
```

6.1.3.24 hsm_op_ecies_enc_flags_t

```
typedef uint8_t hsm_op_ecies_enc_flags_t
```

6.1.3.25 hsm_op_ecies_dec_flags_t

```
typedef uint8_t hsm_op_ecies_dec_flags_t
```

6.1.3.26 hsm_signature_scheme_id_t

```
typedef uint8_t hsm_signature_scheme_id_t
```

6.1.3.27 hsm_hash_algo_t

```
typedef uint8_t hsm_hash_algo_t
```

6.1.3.28 hsm_key_type_t

```
typedef uint8_t hsm_key_type_t
```

6.1.3.29 hsm_key_type_ext_t

```
typedef uint8_t hsm_key_type_ext_t
```

6.1.3.30 hsm_key_info_t

```
typedef uint16_t hsm_key_info_t
```

6.1.3.31 hsm_addr_msb_t

```
typedef uint32_t hsm_addr_msb_t
```

6.1.3.32 hsm_addr_lsb_t

```
typedef uint32_t hsm_addr_lsb_t
```

6.1.3.33 hsm_verification_status_t

```
typedef uint32_t hsm_verification_status_t
```

6.1.4 Enumeration Type Documentation

6.1.4.1 hsm_err_t

```
enum hsm_err_t
```

Error codes returned by HSM functions.

Enumerator

HSM_NO_ERROR	Success.
HSM_INVALID_MESSAGE	The received message is invalid or unknown.
HSM_INVALID_ADDRESS	The provided address is invalid or doesn't respect the API requirements.
HSM_UNKNOWN_ID	The provided identifier is not known.
HSM_INVALID_PARAM	One of the parameter provided in the command is invalid.
HSM_NVM_ERROR	NVM generic issue.
HSM_OUT_OF_MEMORY	There is not enough memory to handle the requested operation.
HSM_UNKNOWN_HANDLE	Unknown session/service handle.
HSM_UNKNOWN_KEY_STORE	The key store identified by the provided “key store Id” doesn't exist and the “create” flag is not set.
HSM_KEY_STORE_AUTH	Key storage authentication fails.
HSM_KEY_STORAGE_ERROR	An error occurred in the key storage internal processing.
HSM_ID_CONFLICT	An element (key storage, key. . .) with the provided ID already exists.
HSM_RNG_NOT_STARTED	The internal RNG is not started.
HSM_CMD_NOT_SUPPORTED	The functionality is not supported for the current session/service/key store configuration.
HSM_INVALID_LIFECYCLE	Invalid lifecycle for requested operation.
HSM_KEY_STORE_CONFLICT	A key store with the same attributes already exists.
HSM_GENERAL_ERROR	Error not covered by other codes occured.

6.1.5 Function Documentation

6.1.5.1 hsm_open_session()

```
hsm_err_t hsm_open_session (
            open_session_args_t * args,
            hsm_hdl_t * session_hdl )
```

Initiate a HSM session.

Parameters

args	pointer to the structure containing the function arugments.
session_hdl	pointer to where the session handle must be written.

Returns

error_code error code.

6.1.5.2 hsm_close_session()

```
hsm_err_t hsm_close_session (
            hsm_hdl_t session_hdl )
```

Terminate a previously opened HSM session

Parameters

session_hdl	pointer to the handle identifying the session to be closed.

Returns

error_code error code.

6.1.5.3 hsm_open_key_store_service()

```
hsm_err_t hsm_open_key_store_service (
            hsm_hdl_t session_hdl,
            open_svc_key_store_args_t * args,
            hsm_hdl_t * key_store_hdl )
```

Open a service flow on the specified key store.

Parameters

session_hdl	pointer to the handle indentifing the current session.
args	pointer to the structure containing the function arugments.
key_store_hdl	pointer to where the key store service flow handle must be written.

Returns

error_code error code.

6.1.5.4 hsm_close_key_store_service()

```
hsm_err_t hsm_close_key_store_service (
             hsm_hdl_t key_store_hdl )
```

Close a previously opened key store service flow.

Parameters

handle	indentifing the key store service flow to be closed.

Returns

error_code error code.

6.1.5.5 hsm_open_key_management_service()

```
hsm_err_t hsm_open_key_management_service (
             hsm_hdl_t key_store_hdl,
             open_svc_key_management_args_t * args,
             hsm_hdl_t * key_management_hdl )
```

Open a key management service flow
User must open this service in order to perform operation on the key store content: key generate, delete, update

Parameters

key_store_hdl	handle indentifing the key store service flow.
args	pointer to the structure containing the function arugments.
key_management_hdl	pointer to where the key management service flow handle must be written.

Returns

error_code error code.

6.1.5.6 hsm_generate_key()

```
hsm_err_t hsm_generate_key (
            hsm_hdl_t key_management_hdl,
            op_generate_key_args_t args )
```

Generate a key or a key pair in the key store. In case of asymetic keys, the public key can optionally be exported. The generated key can be stored in a new or in an existing key slot with the restriction that an existing key can be replaced only by a key of the same type.
User can call this function only after having opened a key management service flow

Parameters

key_management_hdl	handle identifying the key management service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.7 hsm_manage_key()

```
hsm_err_t hsm_manage_key (
            hsm_hdl_t key_management_hdl,
            op_manage_key_args_t * args )
```

This command is designed to perform operation on an existing key.
User can call this function only after having opened a key management service flow

Parameters

key_management_hdl	handle identifying the key management service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.8 hsm_butterfly_key_expansion()

```
hsm_err_t hsm_butterfly_key_expansion (
            hsm_hdl_t key_management_hdl,
            op_butt_key_exp_args_t * args )
```

This command is designed to perform the butterfly key expansion operation on an ECC private key in case of implicit certificate. Optionally the resulting public key is exported.
The result of the key expansion function is calculated outside the HSM and passed as input.

User can call this function only after having opened a key management service flow.

The following operation is performed:
out_key = (Key + add_data_1) ∗ multiply_data + add_data_2 (mod n)

Explicit certificates: add_data_1 = 0, add_data_2 = f1/f2(k, i, j), multiply_data = 1
out_key = Key + f1/f2(k, i, j) (mod n)

Implicit certificates: add_data_1 = f1(k, i, j), add_data_2 = private reconstruction value pij, multiply_data = hash value used to in the derivation of the pseudonym ECC key
out_key = (Key + f1(k, i, j))∗Hash + pij

Parameters

key_management_hdl	handle identifying the key store management service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.9 hsm_close_key_management_service()

```
hsm_err_t hsm_close_key_management_service (
             hsm_hdl_t key_management_hdl )
```

Terminate a previously opened key management service flow

Parameters

key_management_hdl	handle identifying the key management service flow.

Returns

error code

6.1.5.10 hsm_open_cipher_service()

```
hsm_err_t hsm_open_cipher_service (
             hsm_hdl_t key_store_hdl,
             open_svc_cipher_args_t * args,
             hsm_hdl_t * chiper_hdl )
```

Open a cipher service flow
User can call this function only after having opened a key store service flow. User must open this service in order to perform cipher operations.

Parameters

key_store_hdl	handle indentifing the key store service flow.
args	pointer to the structure containing the function arugments.
chiper_hdl	pointer to where the cipher service flow handle must be written.

Returns

error code

6.1.5.11 hsm_cipher_one_go()

```
hsm_err_t hsm_cipher_one_go (
            hsm_hdl_t chiper_hdl,
            op_cipher_one_go_args_t * args )
```

Perform ciphering operation
User can call this function only after having opened a cipher service flow

Parameters

chiper_hdl	handle identifying the cipher service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.12 hsm_close_cipher_service()

```
hsm_err_t hsm_close_cipher_service (
            hsm_hdl_t chiper_hdl )
```

Terminate a previously opened cipher service flow

Parameters

chiper_hdl	pointer to handle identifying the cipher service flow to be closed.

Returns

error code

6.1.5.13 hsm_open_signature_generation_service()

```
hsm_err_t hsm_open_signature_generation_service (
            hsm_hdl_t key_store_hdl,
            open_svc_sign_gen_args_t * args,
            hsm_hdl_t * signature_gen_hdl )
```

Open a signature generation service flow
User can call this function only after having opened a key store service flow. User must open this service in order to perform signature generation operations.

Parameters

key_store_hdl	handle indentifing the key store service flow.
args	pointer to the structure containing the function arugments.
signature_gen_hdl	pointer to where the signature generation service flow handle must be written.

Returns

error code

6.1.5.14 hsm_close_signature_generation_service()

```
hsm_err_t hsm_close_signature_generation_service (
            hsm_hdl_t signature_gen_hdl )
```

Terminate a previously opened signature generation service flow

Parameters

signature_gen_hdl	handle identifying the signature generation service flow to be closed.

Returns

error code

6.1.5.15 hsm_generate_signature()

```
hsm_err_t hsm_generate_signature (
            hsm_hdl_t signature_gen_hdl,
            op_generate_sign_args_t * args )
```

Generate a digital signature according to the signature scheme
User can call this function only after having opened a signature generation service flow The signature S=(r,s) is always stored in format r||s||Ry where Ry is an additional byte containing the lsb of y. The Ry validity is based on the “compressed point” flag.

Parameters

signature_gen_hdl	handle identifying the signature generation service flow
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.16 hsm_prepare_signature()

```
hsm_err_t hsm_prepare_signature (
            hsm_hdl_t signature_gen_hdl,
            op_prepare_sign_args_t * args )
```

Prepare the creation of a signature by pre-calculating the operations having not dependencies on the input message. The pre-calculated value will be stored internally and used to the next call of hsm_generate_signature_finalize
User can call this function only after having opened a signature generation service flow The signature S=(r,s) is stored in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameter is based on the “compressed point” flag.

Parameters

signature_gen_hdl	handle identifying the signature generation service flow
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.17 hsm_finalize_signature()

```
hsm_err_t hsm_finalize_signature (
            hsm_hdl_t signature_gen_hdl,
            op_finalize_sign_args_t * args )
```

Finalize the computation of a digital signature
User can call this function only after having called the hsm_prepare_signature API.

Parameters

signature_gen_hdl	handle identifying the signature generation service flow
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.18 hsm_open_signature_verification_service()

```
hsm_err_t hsm_open_signature_verification_service (
            hsm_hdl_t session_hdl,
            open_svc_sign_ver_args_t * args,
            hsm_hdl_t * signature_ver_hdl )
```

User must open this service in order to perform signature verification operations.
User can call this function only after having opened a session.

Parameters

session_hdl	handle indentifing the current session.
args	pointer to the structure containing the function arugments.
signature_ver_hdl	pointer to where the signature verification service flow handle must be written.

Returns

error code

6.1.5.19 hsm_verify_signature()

```
hsm_err_t hsm_verify_signature (
            hsm_hdl_t signature_ver_hdl,
            op_verify_sign_args_t * args,
            hsm_verification_status_t * status )
```

Verify a digital signature according to the signature scheme
User can call this function only after having opened a signature verification service flow The signature S=(r,s) is expected to be in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameters is based on the “compressed point” flag. Only not-compressed keys (x,y) can be used by this command. Compressed keys can be decompressed by using the dedicated API.

Parameters

signature_ver_hdl	handle identifying the signature verification service flow.
args	pointer to the structure containing the function arugments.
status	pointer to where the verification status must be stored if the verification suceed the value HSM_VERIFICATION_STATUS_SUCCESS is returned.

Returns

error code

6.1.5.20 hsm_import_public_key()

```
hsm_err_t hsm_import_public_key (
            hsm_hdl_t signature_ver_hdl,
            op_import_public_key_args_t * args,
            hsm_addr_lsb_t * int_key )
```

Import a public key to be used for several verification operations
User can call this function only after having opened a signature verification service flow. Only not-compressed keys (x,y) can be imprted by this command. Compressed keys can be decompressed by using the dedicated API.

Parameters

signature_ver_hdl	handle identifying the signature verification service flow.
args	pointer to the structure containing the function arugments.
int_key	pointer to where the key reference to be used as key in the hsm_verify_signature will be stored

Returns

error code

6.1.5.21 hsm_close_signature_verification_service()

```
hsm_err_t hsm_close_signature_verification_service (
            hsm_hdl_t signature_ver_hdl )
```

Terminate a previously opened signature verification service flow

Parameters

signature_ver_hdl	handle identifying the signature verification service flow to be closed.

Returns

error code

6.1.5.22 hsm_open_rng_service()

```
hsm_err_t hsm_open_rng_service (
            hsm_hdl_t session_hdl,
            open_svc_rng_args_t * args,
            hsm_hdl_t * rng_hdl )
```

Open a random number generation service flow
User can call this function only after having opened a session. User must open this service in order to perform rng operations.

Parameters

session_hdl	handle indentifing the current session.
args	pointer to the structure containing the function arugments.
rng_hdl	pointer to where the rng service flow handle must be written.

Returns

error code

6.1.5.23 hsm_close_rng_service()

```
hsm_err_t hsm_close_rng_service (
            hsm_hdl_t rng_hdl )
```

Terminate a previously opened rng service flow

Parameters

rng_hdl	handle identifying the rng service flow to be closed.

Returns

error code

6.1.5.24 hsm_get_random()

```
hsm_err_t hsm_get_random (
            hsm_hdl_t rng_hdl,
            op_get_random_args_t * args )
```

Get a freshly generated random number
User can call this function only after having opened a rng service flow

Parameters

rng_hdl	handle identifying the rng service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.25 hsm_open_hash_service()

```
hsm_err_t hsm_open_hash_service (
             hsm_hdl_t session_hdl,
             open_svc_hash_args_t * args,
             hsm_hdl_t * hash_hdl )
```

Open an hash service flow
User can call this function only after having opened a session. User must open this service in order to perform an hash operations.

Parameters

session_hdl	handle indentifing the current session.
args	pointer to the structure containing the function arugments.
hash_hdl	pointer to where the hash service flow handle must be written.

Returns

error code

6.1.5.26 hsm_close_hash_service()

```
hsm_err_t hsm_close_hash_service (
             hsm_hdl_t hash_hdl )
```

Terminate a previously opened hash service flow

Parameters

hash_hdl	handle identifying the hash service flow to be closed.

Returns

error code

6.1.5.27 hsm_hash_one_go()

```
hsm_err_t hsm_hash_one_go (
             hsm_hdl_t hash_hdl,
             op_hash_one_go_args_t * args )
```

Perform the hash operation on a given input
User can call this function only after having opened a hash service flow

Parameters

hash_hdl	handle identifying the hash service flow.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.28 hsm_pub_key_reconstruction()

```
hsm_err_t hsm_pub_key_reconstruction (
            hsm_hdl_t session_hdl,
            hsm_op_pub_key_rec_args_t * args )
```

Reconstruct an ECC public key provided by an implicit certificate
User can call this function only after having opened a session
This API implements the followign formula: out_key = (pub_rec ∗ hash) + ca_key

Parameters

session_hdl	handle identifying the current session.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.29 hsm_pub_key_decompression()

```
hsm_err_t hsm_pub_key_decompression (
            hsm_hdl_t session_hdl,
            hsm_op_pub_key_dec_args_t * args )
```

6.1.5.30 hsm_ecies_encryption()

```
hsm_err_t hsm_ecies_encryption (
            hsm_hdl_t session_hdl,
            hsm_op_ecies_enc_args_t * args )
```

Encrypt data usign ECIES
User can call this function only after having opened a session

Parameters

session_hdl	handle identifying the current session.
args	pointer to the structure containing the function arugments.

Returns

error code

6.1.5.31 hsm_ecies_decryption()

```
hsm_err_t hsm_ecies_decryption (
            hsm_hdl_t key_store_hdl,
            hsm_op_ecies_dec_args_t * args )
```

Decrypt data usign ECIES
User can call this function only after having opened a key store service flow

Parameters

session_hdl	handle identifying the current session.
args	pointer to the structure containing the function arugments.

Returns

error code

7 Class Documentation

7.1 hsm_op_ecies_dec_args_t Struct Reference

Public Attributes

- uint32_t key_identifier

  identifier of the private key to be used for the operation
- hsm_addr_msb_t input_ext

  MSB of the address in the requester space where the input VCT can be found.
- hsm_addr_lsb_t input

  LSB of the address in the requester space where the input VCT can be found.
- hsm_addr_msb_t p1_ext

  MSB of the address in the requester space where the KDF P1 parameter can be found.
- hsm_addr_lsb_t p1

  LSB of the address in the requester space where the KDF P1 parameter can be found.
- hsm_addr_msb_t p2_ext

  MSB of the address in the requester space where the MAC P2 parameter can be found.
- hsm_addr_lsb_t p2

  LSB of the address in the requester space where the MAC P2 parameter can be found.
- uint16_t p1_size

  length in bytes of the KDF P1 parameter
- uint16_t p2_size

  length in bytes of the MAC P2 parameter
- uint32_t input_size

length in bytes of the input VCT

- hsm_addr_msb_t output_ext

  MSB of the address in the requester space where the output plaintext must be written.
- hsm_addr_lsb_t output

  LSB of the address in the requester space where the output plaintext must be written.
- uint32_t out_size

  length in bytes of the ouptu plaintext
- uint16_t mac_size

  length in bytes of the requested message authentication code
- hsm_key_type_t key_type

  indicates the type of the used key
- hsm_op_ecies_dec_flags_t flags

  bitmap specifying the operation attributes.

7.1.1 Member Data Documentation

7.1.1.1 key_identifier

```
uint32_t hsm_op_ecies_dec_args_t::key_identifier
```

identifier of the private key to be used for the operation

7.1.1.2 input_ext

```
hsm_addr_msb_t hsm_op_ecies_dec_args_t::input_ext
```

MSB of the address in the requester space where the input VCT can be found.

7.1.1.3 input

```
hsm_addr_lsb_t hsm_op_ecies_dec_args_t::input
```

LSB of the address in the requester space where the input VCT can be found.

7.1.1.4 p1_ext

```
hsm_addr_msb_t hsm_op_ecies_dec_args_t::p1_ext
```

MSB of the address in the requester space where the KDF P1 parameter can be found.

7.1.1.5 p1

```
hsm_addr_lsb_t hsm_op_ecies_dec_args_t::p1
```

LSB of the address in the requester space where the KDF P1 parameter can be found.

7.1.1.6 p2_ext

```
hsm_addr_msb_t hsm_op_ecies_dec_args_t::p2_ext
```

MSB of the address in the requester space where the MAC P2 parameter can be found.

7.1.1.7 p2

```
hsm_addr_lsb_t hsm_op_ecies_dec_args_t::p2
```

LSB of the address in the requester space where the MAC P2 parameter can be found.

7.1.1.8 p1_size

```
uint16_t hsm_op_ecies_dec_args_t::p1_size
```

length in bytes of the KDF P1 parameter

7.1.1.9 p2_size

```
uint16_t hsm_op_ecies_dec_args_t::p2_size
```

length in bytes of the MAC P2 parameter

7.1.1.10 input_size

```
uint32_t hsm_op_ecies_dec_args_t::input_size
```

length in bytes of the input VCT

7.1.1.11 output_ext

```
hsm_addr_msb_t hsm_op_ecies_dec_args_t::output_ext
```

MSB of the address in the requester space where the output plaintext must be written.

7.1.1.12 output

```
hsm_addr_lsb_t hsm_op_ecies_dec_args_t::output
```

LSB of the address in the requester space where the output plaintext must be written.

7.1.1.13 out_size

```
uint32_t hsm_op_ecies_dec_args_t::out_size
```

length in bytes of the ouptu plaintext

7.1.1.14 mac_size

```
uint16_t hsm_op_ecies_dec_args_t::mac_size
```

length in bytes of the requested message authentication code

7.1.1.15 key_type

```
hsm_key_type_t hsm_op_ecies_dec_args_t::key_type
```

indicates the type of the used key

7.1.1.16 flags

```
hsm_op_ecies_dec_flags_t hsm_op_ecies_dec_args_t::flags
```

bitmap specifying the operation attributes.

7.2 hsm_op_ecies_enc_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t pub_key_ext

  MSB of the address in the requester space where the recipient public key can be found.
- hsm_addr_lsb_t pub_key

  LSB of the address in the requester space where the recipient public key can be found.
- hsm_addr_msb_t input_ext

  MSB of the address in the requester space where the plaintext can be found.
- hsm_addr_lsb_t input

  LSB of the address in the requester space where the plaintext can be found.
- hsm_addr_msb_t p1_ext

  MSB of the address in the requester space where the KDF P1 parameter can be found.
- hsm_addr_lsb_t p1

  LSB of the address in the requester space where the KDF P1 parameter can be found.
- hsm_addr_msb_t p2_ext

  MSB of the address in the requester space where the MAC P2 parameter can be found.
- hsm_addr_lsb_t p2

  LSB of the address in the requester space where the MAC P2 parameter can be found.
- uint16_t p1_size

  length in bytes of the KDF P1 parameter
- uint16_t p2_size

  length in bytes of the MAC P2 parameter
- uint16_t pub_key_size

  length in bytes of the recipient public key
- uint16_t mac_size

  length in bytes of the requested message authentication code
- uint32_t input_size

  length in bytes of the input plaintext
- hsm_addr_msb_t output_ext

  MSB of the address in the requester space where the output VCT must be written.
- hsm_addr_lsb_t output

  LSB of the address in the requester space where the output VCT must be written.
- uint32_t out_size

  length in bytes of the output VCT
- hsm_key_type_t key_type

  indicates the type of the recipient public key
- hsm_op_ecies_enc_flags_t flags

  bitmap specifying the operation attributes.
- uint16_t rsv

7.2.1 Member Data Documentation

7.2.1.1 pub_key_ext

```
hsm_addr_msb_t hsm_op_ecies_enc_args_t::pub_key_ext
```

MSB of the address in the requester space where the recipient public key can be found.

7.2.1.2 pub_key

```
hsm_addr_lsb_t hsm_op_ecies_enc_args_t::pub_key
```

LSB of the address in the requester space where the recipient public key can be found.

7.2.1.3 input_ext

```
hsm_addr_msb_t hsm_op_ecies_enc_args_t::input_ext
```

MSB of the address in the requester space where the plaintext can be found.

7.2.1.4 input

```
hsm_addr_lsb_t hsm_op_ecies_enc_args_t::input
```

LSB of the address in the requester space where the plaintext can be found.

7.2.1.5 p1_ext

```
hsm_addr_msb_t hsm_op_ecies_enc_args_t::p1_ext
```

MSB of the address in the requester space where the KDF P1 parameter can be found.

7.2.1.6 p1

```
hsm_addr_lsb_t hsm_op_ecies_enc_args_t::p1
```

LSB of the address in the requester space where the KDF P1 parameter can be found.

7.2.1.7 p2_ext

```
hsm_addr_msb_t hsm_op_ecies_enc_args_t::p2_ext
```

MSB of the address in the requester space where the MAC P2 parameter can be found.

7.2.1.8 p2

```
hsm_addr_lsb_t hsm_op_ecies_enc_args_t::p2
```

LSB of the address in the requester space where the MAC P2 parameter can be found.

7.2.1.9 p1_size

```
uint16_t hsm_op_ecies_enc_args_t::p1_size
```

length in bytes of the KDF P1 parameter

7.2.1.10 p2_size

```
uint16_t hsm_op_ecies_enc_args_t::p2_size
```

length in bytes of the MAC P2 parameter

7.2.1.11 pub_key_size

```
uint16_t hsm_op_ecies_enc_args_t::pub_key_size
```

length in bytes of the recipient public key

7.2.1.12 mac_size

```
uint16_t hsm_op_ecies_enc_args_t::mac_size
```

length in bytes of the requested message authentication code

7.2.1.13 input_size

```
uint32_t hsm_op_ecies_enc_args_t::input_size
```

length in bytes of the input plaintext

7.2.1.14 output_ext

```
hsm_addr_msb_t hsm_op_ecies_enc_args_t::output_ext
```

MSB of the address in the requester space where the output VCT must be written.

7.2.1.15 output

```
hsm_addr_lsb_t hsm_op_ecies_enc_args_t::output
```

LSB of the address in the requester space where the output VCT must be written.

7.2.1.16 out_size

```
uint32_t hsm_op_ecies_enc_args_t::out_size
```

length in bytes of the output VCT

7.2.1.17 key_type

```
hsm_key_type_t hsm_op_ecies_enc_args_t::key_type
```

indicates the type of the recipient public key

7.2.1.18 flags

```
hsm_op_ecies_enc_flags_t hsm_op_ecies_enc_args_t::flags
```

bitmap specifying the operation attributes.

7.2.1.19 rsv

```
uint16_t hsm_op_ecies_enc_args_t::rsv
```

7.3 hsm_op_pub_key_dec_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t pub_key_ext

  MSB of the address in the requester space where the compressed ECC public key can be found. The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.
- hsm_addr_lsb_t pub_key

  MSB of the address in the requester space where the compressed ECC public key can be found. The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.
- hsm_addr_msb_t out_key_ext

  MSB of the address in the requester space where the output resulting key must be written.
- hsm_addr_lsb_t out_key

  LSB of the address in the requester space where the output resulting key must be written.
- hsm_key_type_t key_type

  indicates the type of the manged keys.
- hsm_op_pub_key_dec_flags_t flags

  bitmap specifying the operation attributes.
- uint16_t rsv

7.3.1 Detailed Description

Decompress an ECC public key
User can call this function only after having opened a session

Parameters

session_hdl	handle identifying the current session.
args	pointer to the structure containing the function arugments.

Returns

error code

7.3.2 Member Data Documentation

7.3.2.1 pub_key_ext

```
hsm_addr_msb_t hsm_op_pub_key_dec_args_t::pub_key_ext
```

MSB of the address in the requester space where the compressed ECC public key can be found. The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.

7.3.2.2 pub_key

```
hsm_addr_lsb_t hsm_op_pub_key_dec_args_t::pub_key
```

MSB of the address in the requester space where the compressed ECC public key can be found. The expected key format is x||lsb_y where lsb_y is 1 byte having value 1 if the least-significant bit of the original (uncompressed) y coordinate is set, and 0 otherwise.

7.3.2.3 out_key_ext

```
hsm_addr_msb_t hsm_op_pub_key_dec_args_t::out_key_ext
```

MSB of the address in the requester space where the output resulting key must be written.

7.3.2.4 out_key

```
hsm_addr_lsb_t hsm_op_pub_key_dec_args_t::out_key
```

LSB of the address in the requester space where the output resulting key must be written.

7.3.2.5 key_type

```
hsm_key_type_t hsm_op_pub_key_dec_args_t::key_type
```

indicates the type of the manged keys.

7.3.2.6 flags

```
hsm_op_pub_key_dec_flags_t hsm_op_pub_key_dec_args_t::flags
```

bitmap specifying the operation attributes.

7.3.2.7 rsv

```
uint16_t hsm_op_pub_key_dec_args_t::rsv
```

7.4 hsm_op_pub_key_rec_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t pub_rec_ext

  MSB of the address in the requester space where the public reconstruction value extracted from the implicit certificate can be found.
- hsm_addr_msb_t pub_rec

  LSB of the address in the requester space where the public reconstruction value extracted from the implicit certificate can be found.
- hsm_addr_msb_t hash_ext

  MSB of the address in the requester space where the hash value can be found. In the butterfly scheme it corresponds to the hash value calculated over PCA certificate and, concatenated, the implicit certificat.
- hsm_addr_lsb_t hash

  LSB of the address in the requester space where the hash value can be found. In the butterfly scheme it corresponds to the hash value calculated over PCA certificate and, concatenated, the implicit certificat.
- hsm_addr_msb_t ca_key_ext

  MSB of the address in the requester space where the CA public key can be found.
- hsm_addr_lsb_t ca_key

  LSB of the address in the requester space where the CA public key can be found.
- hsm_addr_msb_t out_key_ext

  MSB of the address in the requester space where the output resulting key must be written.
- hsm_addr_lsb_t out_key

  LSB of the address in the requester space where the output resulting key must be written.
- uint16_t pub_rec_size

  length in bytes of the public reconstruction value
- uint16_t hash_size

  length in bytes of the input hash
- uint16_t ca_key_size

  length in bytes of the input CA public key
- uint16_t out_key_size

  length in bytes of the output key
- hsm_key_type_t key_type

  indicates the type of the manged keys.
- hsm_op_pub_key_rec_flags_t flags

  flags bitmap specifying the operation attributes.
- uint16_t rsv

7.4.1 Member Data Documentation

7.4.1.1 pub_rec_ext

```
hsm_addr_msb_t hsm_op_pub_key_rec_args_t::pub_rec_ext
```

MSB of the address in the requester space where the public reconstruction value extracted from the implicit certificate can be found.

7.4.1.2 pub_rec

```
hsm_addr_msb_t hsm_op_pub_key_rec_args_t::pub_rec
```

LSB of the address in the requester space where the public reconstruction value extracted from the implicit certificate can be found.

7.4.1.3 hash_ext

```
hsm_addr_msb_t hsm_op_pub_key_rec_args_t::hash_ext
```

MSB of the address in the requester space where the hash value can be found. In the butterfly scheme it corresponds to the hash value calculated over PCA certificate and, concatenated, the implicit certificat.

7.4.1.4 hash

```
hsm_addr_lsb_t hsm_op_pub_key_rec_args_t::hash
```

LSB of the address in the requester space where the hash value can be found. In the butterfly scheme it corresponds to the hash value calculated over PCA certificate and, concatenated, the implicit certificat.

7.4.1.5 ca_key_ext

```
hsm_addr_msb_t hsm_op_pub_key_rec_args_t::ca_key_ext
```

MSB of the address in the requester space where the CA public key can be found.

7.4.1.6 ca_key

```
hsm_addr_lsb_t hsm_op_pub_key_rec_args_t::ca_key
```

LSB of the address in the requester space where the CA public key can be found.

7.4.1.7 out_key_ext

```
hsm_addr_msb_t hsm_op_pub_key_rec_args_t::out_key_ext
```

MSB of the address in the requester space where the output resulting key must be written.

7.4.1.8 out_key

```
hsm_addr_lsb_t hsm_op_pub_key_rec_args_t::out_key
```

LSB of the address in the requester space where the output resulting key must be written.

7.4.1.9 pub_rec_size

```
uint16_t hsm_op_pub_key_rec_args_t::pub_rec_size
```

length in bytes of the public reconstruction value

7.4.1.10 hash_size

```
uint16_t hsm_op_pub_key_rec_args_t::hash_size
```

length in bytes of the input hash

7.4.1.11 ca_key_size

```
uint16_t hsm_op_pub_key_rec_args_t::ca_key_size
```

length in bytes of the input CA public key

7.4.1.12 out_key_size

```
uint16_t hsm_op_pub_key_rec_args_t::out_key_size
```

length in bytes of the output key

7.4.1.13 key_type

```
hsm_key_type_t hsm_op_pub_key_rec_args_t::key_type
```

indicates the type of the manged keys.

7.4.1.14 flags

```
hsm_op_pub_key_rec_flags_t hsm_op_pub_key_rec_args_t::flags
```

flags bitmap specifying the operation attributes.

7.4.1.15 rsv

```
uint16_t hsm_op_pub_key_rec_args_t::rsv
```

7.5 op_butt_key_exp_args_t Struct Reference

Public Attributes

- uint32_t key_identifier

  identifier of the key to be expanded
- hsm_addr_lsb_t add_data_1

  LSB of the address in the requester space where the add_data_1 input can be found.
- hsm_addr_lsb_t add_data_2

  LSB of the address in the requester space where the add_data_2 input can be found.
- hsm_addr_lsb_t multiply_data

  LSB of the address in the requester space where the multiply_data input can be found.
- uint8_t data_1_size

  length in bytes of the add_data_1 input
- uint8_t data_2_size

  length in bytes of the add_data_2 input
- uint8_t multiply_data_size

  length in bytes of the multiply_data input
- hsm_op_but_key_exp_flags_t flags

  bitmap specifying the operation properties
- uint32_t dest_key_identifier

  identifier of the derived key
- hsm_addr_lsb_t out_key

  LSB of the address in the requester space where the public key must be written.
- uint16_t out_size

  length in bytes of the output area, if the size is 0, no key is copied in the output.
- hsm_key_type_t key_type

  indicates the type of the key to be managed.
- uint8_t rsv

7.5.1 Member Data Documentation

7.5.1.1 key_identifier

```
uint32_t op_butt_key_exp_args_t::key_identifier
```

identifier of the key to be expanded

7.5.1.2 add_data_1

```
hsm_addr_lsb_t op_butt_key_exp_args_t::add_data_1
```

LSB of the address in the requester space where the add_data_1 input can be found.

7.5.1.3 add_data_2

```
hsm_addr_lsb_t op_butt_key_exp_args_t::add_data_2
```

LSB of the address in the requester space where the add_data_2 input can be found.

7.5.1.4 multiply_data

```
hsm_addr_lsb_t op_butt_key_exp_args_t::multiply_data
```

LSB of the address in the requester space where the multiply_data input can be found.

7.5.1.5 data_1_size

```
uint8_t op_butt_key_exp_args_t::data_1_size
```

length in bytes of the add_data_1 input

7.5.1.6 data_2_size

```
uint8_t op_butt_key_exp_args_t::data_2_size
```

length in bytes of the add_data_2 input

7.5.1.7 multiply_data_size

```
uint8_t op_butt_key_exp_args_t::multiply_data_size
```

length in bytes of the multiply_data input

7.5.1.8 flags

```
hsm_op_but_key_exp_flags_t op_butt_key_exp_args_t::flags
```

bitmap specifying the operation properties

7.5.1.9 dest_key_identifier

```
uint32_t op_butt_key_exp_args_t::dest_key_identifier
```

identifier of the derived key

7.5.1.10 out_key

```
hsm_addr_lsb_t op_butt_key_exp_args_t::out_key
```

LSB of the address in the requester space where the public key must be written.

7.5.1.11 out_size

```
uint16_t op_butt_key_exp_args_t::out_size
```

length in bytes of the output area, if the size is 0, no key is copied in the output.

7.5.1.12 key_type

```
hsm_key_type_t op_butt_key_exp_args_t::key_type
```

indicates the type of the key to be managed.

7.5.1.13 rsv

```
uint8_t op_butt_key_exp_args_t::rsv
```

7.6 op_cipher_one_go_args_t Struct Reference

Public Attributes

- uint32_t key_identifier

  identifier of the key to be used for the operation
- hsm_addr_lsb_t iv

  LSB of the address in the requester space where the initialization vector can be found.
- uint16_t iv_size

  length in bytes of the initialization vector
  it must be 0 for algorithms not using the initialization vector.
  It must be 12 for AES in CCM mode
- hsm_op_cipher_one_go_algo_t cipher_algo

  algorithm to be used for the operation
- hsm_op_cipher_one_go_flags_t flags

  bitmap specifying the operation attributes
- hsm_addr_lsb_t input

  LSB of the address in the requester space where the input to be processed can be found
  plaintext for encryption
  ciphertext for decryption (tag is concatenated for CCM)
- hsm_addr_lsb_t output

  LSB of the address in the requester space where the output must be stored
  ciphertext for encryption (tag is concatenated for CCM)
  plaintext for decryption.
- uint32_t input_size

  length in bytes of the input
- uint32_t output_size

  length in bytes of the output

7.6.1 Member Data Documentation

7.6.1.1 key_identifier

```
uint32_t op_cipher_one_go_args_t::key_identifier
```

identifier of the key to be used for the operation

7.6.1.2 iv

```
hsm_addr_lsb_t op_cipher_one_go_args_t::iv
```

LSB of the address in the requester space where the initialization vector can be found.

7.6.1.3 iv_size

```
uint16_t op_cipher_one_go_args_t::iv_size
```

length in bytes of the initialization vector
it must be 0 for algorithms not using the initialization vector.
It must be 12 for AES in CCM mode

7.6.1.4 cipher_algo

```
hsm_op_cipher_one_go_algo_t op_cipher_one_go_args_t::cipher_algo
```

algorithm to be used for the operation

7.6.1.5 flags

```
hsm_op_cipher_one_go_flags_t op_cipher_one_go_args_t::flags
```

bitmap specifying the operation attributes

7.6.1.6 input

```
hsm_addr_lsb_t op_cipher_one_go_args_t::input
```

LSB of the address in the requester space where the input to be processed can be found
plaintext for encryption
ciphertext for decryption (tag is concatenated for CCM)

7.6.1.7 output

```
hsm_addr_lsb_t op_cipher_one_go_args_t::output
```

LSB of the address in the requester space where the output must be stored
ciphertext for encryption (tag is concatenated for CCM)
plaintext for decryption.

7.6.1.8 input_size

```
uint32_t op_cipher_one_go_args_t::input_size
```

length in bytes of the input

7.6.1.9 output_size

```
uint32_t op_cipher_one_go_args_t::output_size
```

length in bytes of the output

7.7 op_finalize_sign_args_t Struct Reference

Public Attributes

- uint32_t key_identifier

  identifier of the key to be used for the operation
- hsm_addr_lsb_t message

  LSB of the address in the requester space where the input (message or message digest) to be processed can be found.
- hsm_addr_lsb_t signature

  LSB of the address in the requester space where the signature must be stored. The signature S=(r,s) is stored in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameter is based on the "compressed point" flag.
- uint32_t message_size

  length in bytes of the input
- uint16_t signature_size

  length in bytes of the output
- hsm_op_finalize_sign_flags_t flags

  bitmap specifying the operation attributes
- uint8_t rsv

7.7.1 Member Data Documentation

7.7.1.1 key_identifier

```
uint32_t op_finalize_sign_args_t::key_identifier
```

identifier of the key to be used for the operation

7.7.1.2 message

```
hsm_addr_lsb_t op_finalize_sign_args_t::message
```

LSB of the address in the requester space where the input (message or message digest) to be processed can be found.

7.7.1.3 signature

`hsm_addr_lsb_t op_finalize_sign_args_t::signature`

LSB of the address in the requester space where the signature must be stored. The signature S=(r,s) is stored in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameter is based on the “compressed point” flag.

7.7.1.4 message_size

`uint32_t op_finalize_sign_args_t::message_size`

length in bytes of the input

7.7.1.5 signature_size

`uint16_t op_finalize_sign_args_t::signature_size`

length in bytes of the output

7.7.1.6 flags

`hsm_op_finalize_sign_flags_t op_finalize_sign_args_t::flags`

bitmap specifying the operation attributes

7.7.1.7 rsv

`uint8_t op_finalize_sign_args_t::rsv`

7.8 op_generate_key_args_t Struct Reference

Public Attributes

- uint32_t ∗ key_identifier

  pointer to the identifier of the key to be used for the operation.
  In case of create operation the new key identifier will be stored in this location.
- uint16_t out_size

  length in bytes of the output area, if the size is 0, no key is copied in the output.
- hsm_op_key_gen_flags_t flags

  bitmap specifying the operation properties.
- uint8_t rsv
- hsm_key_type_t key_type

  indicates which type of key must be generated.
- hsm_key_type_ext_t key_type_ext
- hsm_key_info_t key_info

  bitmap specifying the properties of the key.
- hsm_addr_lsb_t out_key

  LSB of the address in the requester space where to store the public key.

7.8.1 Member Data Documentation

7.8.1.1 key_identifier

```
uint32_t* op_generate_key_args_t::key_identifier
```

pointer to the identifier of the key to be used for the operation.
In case of create operation the new key identifier will be stored in this location.

7.8.1.2 out_size

```
uint16_t op_generate_key_args_t::out_size
```

length in bytes of the output area, if the size is 0, no key is copied in the output.

7.8.1.3 flags

```
hsm_op_key_gen_flags_t op_generate_key_args_t::flags
```

bitmap specifying the operation properties.

7.8.1.4 rsv

```
uint8_t op_generate_key_args_t::rsv
```

7.8.1.5 key_type

```
hsm_key_type_t op_generate_key_args_t::key_type
```

indicates which type of key must be generated.

7.8.1.6 key_type_ext

```
hsm_key_type_ext_t op_generate_key_args_t::key_type_ext
```

7.8.1.7 key_info

```
hsm_key_info_t op_generate_key_args_t::key_info
```

bitmap specifying the properties of the key.

7.8.1.8 out_key

```
hsm_addr_lsb_t op_generate_key_args_t::out_key
```

LSB of the address in the requester space where to store the public key.

7.9 op_generate_sign_args_t Struct Reference

Public Attributes

- uint32_t key_identifier

  identifier of the key to be used for the operation
- hsm_addr_lsb_t message

  LSB of the address in the requester space where the input (message or message digest) to be processed can be found.
- hsm_addr_lsb_t signature

  LSB of the address in the requester space where the signature must be stored. The signature S=(r,s) is always stored in format r||s||Ry where Ry is an additional byte containing the lsb of y. The Ry validity is based on the "compressed point" flag.
- uint32_t message_size

  length in bytes of the input
- uint16_t signature_size

  length in bytes of the output
- hsm_signature_scheme_id_t scheme_id

  identifier of the digital signature scheme to be used for the operation
- hsm_op_generate_sign_flags_t flags

  bitmap specifying the operation attributes

7.9.1 Member Data Documentation

7.9.1.1 key_identifier

```
uint32_t op_generate_sign_args_t::key_identifier
```

identifier of the key to be used for the operation

7.9.1.2 message

`hsm_addr_lsb_t op_generate_sign_args_t::message`

LSB of the address in the requester space where the input (message or message digest) to be processed can be found.

7.9.1.3 signature

`hsm_addr_lsb_t op_generate_sign_args_t::signature`

LSB of the address in the requester space where the signature must be stored. The signature S=(r,s) is always stored in format r||s||Ry where Ry is an additional byte containing the lsb of y. The Ry validity is based on the “compressed point” flag.

7.9.1.4 message_size

`uint32_t op_generate_sign_args_t::message_size`

length in bytes of the input

7.9.1.5 signature_size

`uint16_t op_generate_sign_args_t::signature_size`

length in bytes of the output

7.9.1.6 scheme_id

`hsm_signature_scheme_id_t op_generate_sign_args_t::scheme_id`

identifier of the digital signature scheme to be used for the operation

7.9.1.7 flags

`hsm_op_generate_sign_flags_t op_generate_sign_args_t::flags`

bitmap specifying the operation attributes

7.10 op_get_random_args_t Struct Reference

Public Attributes

- hsm_addr_lsb_t output

  LSB of the address in the requester space where the out random number must be written.
- uint32_t random_size

  length in bytes of the random number to be provided.

7.10.1 Member Data Documentation

7.10.1.1 output

```
hsm_addr_lsb_t op_get_random_args_t::output
```

LSB of the address in the requester space where the out random number must be written.

7.10.1.2 random_size

```
uint32_t op_get_random_args_t::random_size
```

length in bytes of the random number to be provided.

7.11 op_hash_one_go_args_t Struct Reference

Public Attributes

- hsm_addr_lsb_t input

  LSB of the address in the requester space where the input payload can be found.
- hsm_addr_lsb_t output

  LSB of the address in the requester space where the output digest must be written.
- uint32_t input_size

  length in bytes of the input
- uint32_t output_size

  length in bytes of the output
- hsm_hash_algo_t algo

  hash algorithm to be used for the operation
- hsm_op_hash_one_go_flags_t flags

  flags bitmap specifying the operation attributes.
- uint16_t rsv

7.11.1 Member Data Documentation

7.11.1.1 input

```
hsm_addr_lsb_t op_hash_one_go_args_t::input
```

LSB of the address in the requester space where the input payload can be found.

7.11.1.2 output

```
hsm_addr_lsb_t op_hash_one_go_args_t::output
```

LSB of the address in the requester space where the output digest must be written.

7.11.1.3 input_size

```
uint32_t op_hash_one_go_args_t::input_size
```

length in bytes of the input

7.11.1.4 output_size

```
uint32_t op_hash_one_go_args_t::output_size
```

length in bytes of the output

7.11.1.5 algo

```
hsm_hash_algo_t op_hash_one_go_args_t::algo
```

hash algorithm to be used for the operation

7.11.1.6 flags

```
hsm_op_hash_one_go_flags_t op_hash_one_go_args_t::flags
```

flags bitmap specifying the operation attributes.

7.11.1.7 rsv

```
uint16_t op_hash_one_go_args_t::rsv
```

7.12 op_import_public_key_args_t Struct Reference

Public Attributes

- hsm_addr_lsb_t key

  LSB of the address in the requester space where the public key to be imported can be found.
- uint16_t key_size

  length in bytes of the input key
- hsm_key_type_t key_type

  indicates the type of the key to be imported.
- hsm_op_verify_sign_flags_t flags

  bitmap specifying the operation attributes

7.12.1 Member Data Documentation

7.12.1.1 key

```
hsm_addr_lsb_t op_import_public_key_args_t::key
```

LSB of the address in the requester space where the public key to be imported can be found.

7.12.1.2 key_size

```
uint16_t op_import_public_key_args_t::key_size
```

length in bytes of the input key

7.12.1.3 key_type

```
hsm_key_type_t op_import_public_key_args_t::key_type
```

indicates the type of the key to be imported.

7.12.1.4 flags

```
hsm_op_verify_sign_flags_t op_import_public_key_args_t::flags
```

bitmap specifying the operation attributes

7.13 op_manage_key_args_t Struct Reference

Public Attributes

- uint32_t ∗ key_identifier

  pointer to the identifier of the key to be used for the operation.
  In case of create operation the new key identifier will be stored in this location.
- uint16_t input_size

  length in bytes of the input key area. Not checked in case of delete operation.
- hsm_op_manage_key_flags_t flags

  bitmap specifying the operation properties.
- uint16_t rsv
- hsm_key_type_t key_type

  indicates the type of the key to be managed.
- hsm_key_type_ext_t key_type_ext
- hsm_key_info_t key_info

  bitmap specifying the properties of the key, it will replace the existing value. Not checked in case of delete operation.
- hsm_addr_lsb_t input_key

  LSB of the address in the requester space where the new key value can be found. Not checked in case of delete operation.

7.13.1 Member Data Documentation

7.13.1.1 key_identifier

```
uint32_t* op_manage_key_args_t::key_identifier
```

pointer to the identifier of the key to be used for the operation.
In case of create operation the new key identifier will be stored in this location.

7.13.1.2 input_size

```
uint16_t op_manage_key_args_t::input_size
```

length in bytes of the input key area. Not checked in case of delete operation.

7.13.1.3 flags

```
hsm_op_manage_key_flags_t op_manage_key_args_t::flags
```

bitmap specifying the operation properties.

7.13.1.4 rsv

```
uint16_t op_manage_key_args_t::rsv
```

7.13.1.5 key_type

```
hsm_key_type_t op_manage_key_args_t::key_type
```

indicates the type of the key to be managed.

7.13.1.6 key_type_ext

```
hsm_key_type_ext_t op_manage_key_args_t::key_type_ext
```

7.13.1.7 key_info

```
hsm_key_info_t op_manage_key_args_t::key_info
```

bitmap specifying the properties of the key, it will replace the existing value. Not checked in case of delete operation.

7.13.1.8 input_key

```
hsm_addr_lsb_t op_manage_key_args_t::input_key
```

LSB of the address in the requester space where the new key value can be found. Not checked in case of delete operation.

7.14 op_prepare_sign_args_t Struct Reference

Public Attributes

- hsm_signature_scheme_id_t scheme_id

  identifier of the digital signature scheme to be used for the operation
- hsm_op_prepare_signature_flags_t flags

  bitmap specifying the operation attributes
- uint16_t rsv

7.14.1 Member Data Documentation

7.14.1.1 scheme_id

```
hsm_signature_scheme_id_t op_prepare_sign_args_t::scheme_id
```

identifier of the digital signature scheme to be used for the operation

7.14.1.2 flags

```
hsm_op_prepare_signature_flags_t op_prepare_sign_args_t::flags
```

bitmap specifying the operation attributes

7.14.1.3 rsv

```
uint16_t op_prepare_sign_args_t::rsv
```

7.15 op_verify_sign_args_t Struct Reference

Public Attributes

- hsm_addr_lsb_t key

  LSB of the address in the requester space where the public key to be used for the verification can be found.
- hsm_addr_lsb_t message

  LSB of the address in the requester space where the input (message or message digest) to be processed can be found.
- hsm_addr_lsb_t signature

  LSB of the address in the requester space where the signature can be found. The signature S=(r,s) is expected to be in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameter is based on the "compressed point" flag.
- uint16_t key_size

  length in bytes of the input key
- uint16_t signature_size

  length in bytes of the output - it must contains one additional byte where to store the Ry.
- uint32_t message_size

  length in bytes of the input message
- hsm_signature_scheme_id_t scheme_id

  identifier of the digital signature scheme to be used for the operation
- hsm_op_verify_sign_flags_t flags

  bitmap specifying the operation attributes
- uint16_t rsv

7.15.1 Member Data Documentation

7.15.1.1 key

```
hsm_addr_lsb_t op_verify_sign_args_t::key
```

LSB of the address in the requester space where the public key to be used for the verification can be found.

7.15.1.2 message

```
hsm_addr_lsb_t op_verify_sign_args_t::message
```

LSB of the address in the requester space where the input (message or message digest) to be processed can be found.

7.15.1.3 signature

```
hsm_addr_lsb_t op_verify_sign_args_t::signature
```

LSB of the address in the requester space where the signature can be found. The signature S=(r,s) is expected to be in format r||s||Ry where Ry is an additional byte containing the lsb of y, the validity of the Ry parameter is based on the “compressed point” flag.

7.15.1.4 key_size

```
uint16_t op_verify_sign_args_t::key_size
```

length in bytes of the input key

7.15.1.5 signature_size

```
uint16_t op_verify_sign_args_t::signature_size
```

length in bytes of the output - it must contains one additional byte where to store the Ry.

7.15.1.6 message_size

```
uint32_t op_verify_sign_args_t::message_size
```

length in bytes of the input message

7.15.1.7 scheme_id

```
hsm_signature_scheme_id_t op_verify_sign_args_t::scheme_id
```

identifier of the digital signature scheme to be used for the operation

7.15.1.8 flags

```
hsm_op_verify_sign_flags_t op_verify_sign_args_t::flags
```

bitmap specifying the operation attributes

7.15.1.9 rsv

```
uint16_t op_verify_sign_args_t::rsv
```

7.16 open_session_args_t Struct Reference

Public Attributes

- uint8_t session_priority

  not supported in current release, any value accepted. ∗/
- uint8_t operating_mode

  not supported in current release, any value accepted. ∗/
- uint16_t rsv

7.16.1 Member Data Documentation

7.16.1.1 session_priority

```
uint8_t open_session_args_t::session_priority
```

not supported in current release, any value accepted. ∗/

7.16.1.2 operating_mode

```
uint8_t open_session_args_t::operating_mode
```

not supported in current release, any value accepted. ∗/

7.16.1.3 rsv

```
uint16_t open_session_args_t::rsv
```

7.17 open_svc_cipher_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_cipher_flags_t flags

  bitmap specifying the services properties.
- uint8_t rsv [3]

7.17.1 Member Data Documentation

7.17.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_cipher_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.17.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_cipher_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.17.1.3 flags

```
hsm_svc_cipher_flags_t open_svc_cipher_args_t::flags
```

bitmap specifying the services properties.

7.17.1.4 rsv

```
uint8_t open_svc_cipher_args_t::rsv[3]
```

7.18 open_svc_hash_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_rng_flags_t flags

  bitmap indicating the service flow properties
- uint8_t rsv [3]

7.18.1 Member Data Documentation

7.18.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_hash_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.18.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_hash_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.18.1.3 flags

```
hsm_svc_rng_flags_t open_svc_hash_args_t::flags
```

bitmap indicating the service flow properties

7.18.1.4 rsv

```
uint8_t open_svc_hash_args_t::rsv[3]
```

7.19 open_svc_key_management_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_key_management_flags_t flags

  bitmap specifying the services properties.
- uint8_t rsv [3]

7.19.1 Member Data Documentation

7.19.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_key_management_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.19.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_key_management_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.19.1.3 flags

```
hsm_svc_key_management_flags_t open_svc_key_management_args_t::flags
```

bitmap specifying the services properties.

7.19.1.4 rsv

```
uint8_t open_svc_key_management_args_t::rsv[3]
```

7.20 open_svc_key_store_args_t Struct Reference

Public Attributes

- uint32_t key_store_identifier

  user defined id identifying the key store.∗/
- uint32_t authentication_nonce

  user defined nonce used as authentication proof for accesing the key storage. ∗/
- uint16_t max_updates_number

  maximum number of updates authorized for the storage. Valid only for create operation. ∗/
- hsm_svc_key_store_flags_t flags

  bitmap specifying the services properties. ∗/
- uint8_t rsv

7.20.1 Member Data Documentation

7.20.1.1 key_store_identifier

```
uint32_t open_svc_key_store_args_t::key_store_identifier
```

user defined id identifying the key store.∗/

7.20.1.2 authentication_nonce

```
uint32_t open_svc_key_store_args_t::authentication_nonce
```

user defined nonce used as authentication proof for accesing the key storage. ∗/

7.20.1.3 max_updates_number

```
uint16_t open_svc_key_store_args_t::max_updates_number
```

maximum number of updates authorized for the storage. Valid only for create operation. ∗/

7.20.1.4 flags

```
hsm_svc_key_store_flags_t open_svc_key_store_args_t::flags
```

bitmap specifying the services properties. ∗/

7.20.1.5 rsv

```
uint8_t open_svc_key_store_args_t::rsv
```

7.21 open_svc_rng_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_rng_flags_t flags

  bitmap indicating the service flow properties
- uint8_t rsv [3]

7.21.1 Member Data Documentation

7.21.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_rng_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.21.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_rng_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.21.1.3 flags

```
hsm_svc_rng_flags_t open_svc_rng_args_t::flags
```

bitmap indicating the service flow properties

7.21.1.4 rsv

```
uint8_t open_svc_rng_args_t::rsv[3]
```

7.22 open_svc_sign_gen_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_signature_generation_flags_t flags

  bitmap specifying the services properties.
- uint8_t rsv [3]

7.22.1 Member Data Documentation

7.22.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_sign_gen_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.22.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_sign_gen_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.22.1.3 flags

```
hsm_svc_signature_generation_flags_t open_svc_sign_gen_args_t::flags
```

bitmap specifying the services properties.

7.22.1.4 rsv

```
uint8_t open_svc_sign_gen_args_t::rsv[3]
```

7.23 open_svc_sign_ver_args_t Struct Reference

Public Attributes

- hsm_addr_msb_t input_address_ext

  most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.
- hsm_addr_msb_t output_address_ext

  most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.
- hsm_svc_signature_verification_flags_t flags

  bitmap indicating the service flow properties
- uint8_t rsv [3]

7.23.1 Member Data Documentation

7.23.1.1 input_address_ext

```
hsm_addr_msb_t open_svc_sign_ver_args_t::input_address_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

7.23.1.2 output_address_ext

```
hsm_addr_msb_t open_svc_sign_ver_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

7.23.1.3 flags

```
hsm_svc_signature_verification_flags_t open_svc_sign_ver_args_t::flags
```

bitmap indicating the service flow properties

7.23.1.4 rsv

```
uint8_t open_svc_sign_ver_args_t::rsv[3]
```

Index