# i.MX8 HSM API

Revision\_0.1

Generated by Doxygen 1.8.15

1 Main Page

1 Main Page	1
2 Revision History	1
3 General concepts related to the API	2
3.1 Session	2
3.2 Service flow	2
4 Module Index	2
4.1 Modules	2
5 Class Index	2
5.1 Class List	2
6 Module Documentation	2
6.1 Hsm_api	2
6.1.1 Detailed Description	6
6.1.2 Macro Definition Documentation	6
6.1.3 Typedef Documentation	13
6.1.4 Enumeration Type Documentation	15
6.1.5 Function Documentation	16
7 Class Documentation	32
7.1 op_generate_key_args_t Struct Reference	32
7.1.1 Member Data Documentation	33
7.2 open_session_args_t Struct Reference	33
7.2.1 Member Data Documentation	34
7.3 open_svc_key_management_args_t Struct Reference	34
7.3.1 Member Data Documentation	34
7.4 open_svc_key_store_args_t Struct Reference	35
7.4.1 Member Data Documentation	35
Index	37

# 1 Main Page

This document is a software referece description of the API provided by the i.MX8 HSM solutions.

# 2 Revision History

Revision 0.1: 29/03/2019 Savari preliminary draft - subject to change Revision 0.8: 20/05/2019 Adding butterfly key expansion operation; adding signature, rng, hash services.

# 3 General concepts related to the API

#### 3.1 Session

The API must be initialized by a potential requestor by opening a session.

The session establishes a route (MU, DomainID...) between the requester and the HSM, and grants the usage of a specified key store through a password authentication.

When a session is opened, the HSM returns a handle identifying the session to the requester.

# 3.2 Service flow

For a given category of services, the requestor is expected to open a service flow by invoking the appropriate HSM API. The session handle, as well as the control data needed for the service flow are provided as parameters of the call. Upon reception of the open request, the HSM allocates a context in which the session handle, as well as the provided control parameters are stored. The context is preserved until the service flow is closed by the user and it is used by the HSM to proceed with the sub-sequent operations requested by the user on the service flow.

# 4 Module Index

#### 4.1 Modules

Here is a list of all modules:

Hsm\_api 2

# 5 Class Index

#### 5.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

```
op_generate_key_args_t32open_session_args_t33open_svc_key_management_args_t34open_svc_key_store_args_t35
```

# 6 Module Documentation

# 6.1 Hsm\_api

i.MX8 HSM API header file

#### Classes

- · struct open\_session\_args\_t
- · struct open\_svc\_key\_store\_args\_t
- struct open\_svc\_key\_management\_args\_t
- struct op\_generate\_key\_args\_t

#### **Macros**

- #define HSM\_SVC\_KEY\_STORE\_FLAGS\_CREATE ((hsm\_svc\_key\_store\_flags\_t)(1 << 0))</li>
- #define HSM SVC KEY STORE FLAGS UPDATE ((hsm svc key store flags t)(1 << 1))</li>
- #define HSM\_SVC\_KEY\_STORE\_FLAGS\_DELETE ((hsm\_svc\_key\_store\_flags\_t)(1 << 3))</li>
- #define HSM\_KEY\_TYPE\_ECDSA\_NIST\_P224 ((hsm\_key\_type\_t)0x01)
- #define HSM\_KEY\_TYPE\_ECDSA\_NIST\_P256 ((hsm\_key\_type\_t)0x02)
- #define HSM\_KEY\_TYPE\_ECDSA\_NIST\_P384 ((hsm\_key\_type\_t)0x03)
- #define HSM KEY TYPE ECDSA BRAINPOOL R1 224 ((hsm key type t)0x12)
- #define HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_256 ((hsm\_key\_type\_t)0x13)
- #define HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_R1\_384 ((hsm\_key\_type\_t)0x15)
- #define HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_T1\_224 ((hsm\_key\_type\_t)0x22)
- #define HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_T1\_256 ((hsm\_key\_type\_t)0x23)
- #define HSM KEY TYPE ECDSA BRAINPOOL T1 384 ((hsm key type t)0x25)
- #define HSM KEY TYPE AES 128 ((hsm key type t)0x30)
- #define HSM\_KEY\_TYPE\_AES\_192 ((hsm\_key\_type\_t)0x31)
- #define HSM\_KEY\_TYPE\_AES\_256 ((hsm\_key\_type\_t)0x32)
- #define HSM KEY INFO PERMANENT ((hsm key info t)(1 << 0))</li>
- #define HSM\_OP\_KEY\_GENERATION\_FLAGS\_UPDATE ((hsm\_op\_key\_gen\_flags\_t)(1 << 0))
- #define HSM\_OP\_KEY\_GENERATION\_FLAGS\_CREATE\_PERSISTENT ((hsm\_op\_key\_gen\_flags\_t)(1 << 1))</li>
- #define HSM\_OP\_KEY\_GENERATION\_FLAGS\_CREATE\_TRANSIENT ((hsm\_op\_key\_gen\_flags\_t)(1 << 2))</li>
- #define HSM\_OP\_KEY\_GENERATION\_FLAGS\_STRICT\_OPERATION ((hsm\_op\_key\_gen\_flags\_t)(1 << 7))</li>
- #define HSM OP MANAGE KEY FLAGS UPDATE ((hsm op manage key flags t)(1 << 0))
- #define HSM OP MANAGE KEY FLAGS DELETE ((hsm op manage key flags t)(1 << 1))</li>
- #define HSM\_OP\_MANAGE\_KEY\_FLAGS\_STRICT\_OPERATION ((hsm\_op\_manage\_key\_flags\_t)(1 << 7))</li>
- #define HSM\_CIPHER\_ONE\_GO\_ALGO\_AES\_ECB ((hsm\_op\_cipher\_one\_go\_algo\_t)(0x00))
- #define HSM CIPHER ONE GO ALGO AES CBC ((hsm op cipher one go algo t)(0x01))
- #define HSM CIPHER ONE GO ALGO AES CCM ((hsm op cipher one go algo t)(0x02))
- #define HSM\_CIPHER\_ONE\_GO\_FLAGS\_ENCRYPT ((hsm\_op\_cipher\_one\_go\_flags\_t)(1 << 0))
- #define HSM\_CIPHER\_ONE\_GO\_FLAGS\_DECRYPT ((hsm\_op\_cipher\_one\_go\_flags\_t)(1 << 1))
- #define HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_DIGEST ((hsm\_op\_signature\_gen\_flags\_t)(0 <<<0))</li>
- #define HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE ((hsm\_op\_signature\_gen\_flags\_t)(1 << 1))</li>
- #define HSM\_OP\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT ((hsm\_op\_signature\_gen\_flags\_t)(2
   << 1))</li>
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P224\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x01)
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x02)
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P384\_SHA\_384 ((hsm\_signature\_scheme\_id\_t)0x03)
- #define HSM SIGNATURE SCHEME ECDSA BRAINPOOL R1 224 SHA 256 ((hsm signature scheme id t)0x12)
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x13)
- #define HSM SIGNATURE SCHEME ECDSA BRAINPOOL R1 384 SHA 384 ((hsm signature scheme id t)0x15)
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_224\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x22)

- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x23)
- #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_384\_SHA\_384 ((hsm\_signature\_scheme\_id\_t)0x25)
- #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_DIGEST ((hsm\_op\_fast\_signature\_gen\_flags\_t)(0 << 0))</li>
- #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE ((hsm\_op\_fast\_signature\_gen\_flags\_t)(1 << 1))
- #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT ((hsm\_op\_fast\_signature\_gen\_flags\_t)(2 << 1))
- #define HSM\_OP\_SIGNATURE\_VERIFICATION\_INPUT\_DIGEST ((hsm\_op\_signature\_ver\_flags\_t)(0 <<<0))</li>
- #define HSM\_OP\_SIGNATURE\_VERIFICATION\_INPUT\_MESSAGE ((hsm\_op\_signature\_ver\_flags\_t)(1 << 1))
- #define HSM VERIFICATION STATUS SUCCESS ((hsm verification status t)(0x5A3CC3A5))
- #define HSM\_VERIFICATION\_STATUS\_FAILURE ((hsm\_verification\_status\_t)(0xA5C33C5A))
- #define HSM\_OP\_FAST\_SIGNATURE\_VERIFICATION\_INPUT\_DIGEST ((hsm\_op\_fast\_signature\_ver\_flags\_t)(0 << 0))</li>
- #define HSM\_OP\_FAST\_SIGNATURE\_VERIFICATION\_INPUT\_MESSAGE ((hsm\_op\_fast\_signature\_ver\_flags\_t)(1 << 1))</li>
- #define HSM\_HASH\_ALGO\_SHA2\_224 ((hsm\_hash\_algo\_t)(0x0))
- #define HSM\_HASH\_ALGO\_SHA2\_256 ((hsm\_hash\_algo\_t)(0x1))
- #define HSM HASH ALGO SHA2 384 ((hsm hash algo t)(0x2))

#### **Typedefs**

- typedef uint32 t hsm hdl t
- typedef uint8\_t hsm\_svc\_key\_store\_flags\_t
- typedef uint8\_t hsm\_svc\_key\_management\_flags\_t
- typedef uint8 t hsm svc cipher flags t
- typedef uint8\_t hsm\_svc\_signature\_flags\_t
- typedef uint8\_t hsm\_svc\_fast\_signature\_verification\_flags\_t
- typedef uint8 t hsm svc fast signature generation flags t
- typedef uint8\_t hsm\_svc\_rng\_flags\_t
- typedef uint8\_t hsm\_svc\_hash\_flags\_t
- typedef uint8\_t hsm\_op\_key\_gen\_flags\_t
- typedef uint8\_t hsm\_op\_manage\_key\_flags\_t
- typedef uint8\_t hsm\_op\_but\_key\_exp\_flags\_t
- typedef uint8\_t hsm\_op\_cipher\_one\_go\_algo\_t
- typedef uint8\_t hsm\_op\_cipher\_one\_go\_flags\_t
- typedef uint8 t hsm op signature gen flags t
- typedef uint8 t hsm op signature ver flags t
- typedef uint8\_t hsm\_op\_fast\_signature\_gen\_flags\_t
- typedef uint8\_t hsm\_op\_fast\_signature\_ver\_flags\_t
- typedef uint16\_t hsm\_key\_type\_t
- typedef uint16 t hsm key info t
- typedef uint8\_t hsm\_signature\_scheme\_id\_t
- typedef uint8\_t hsm\_hash\_algo\_t
- typedef uint32\_t hsm\_verification\_status\_t
- typedef uint32 t hsm addr msb t
- typedef uint32\_t hsm\_addr\_lsb\_t

6.1 Hsm\_api 5

#### **Enumerations**

```
• enum hsm err t {
 HSM NO ERROR = 0x0,
 HSM INVALID MESSAGE = 0x1,
 HSM INVALID ADDRESS = 0x2,
 HSM UNKNOWN ID = 0x3,
 HSM INVALID PARAM = 0x4,
 HSM_NVM_ERROR = 0x5,
 HSM_OUT_OF_MEMORY = 0x6,
 HSM UNKNOWN HANDLE = 0x7,
 HSM_UNKNOWN_KEY_STORE = 0x8,
 HSM_KEY_STORE_AUTH = 0x9,
 HSM_KEY_STORAGE_ERROR = 0xA,
 HSM ID CONFLICT = 0xB,
 HSM RNG NOT STARTED = 0xC,
 HSM CMD NOT SUPPORTED = 0xD,
 HSM INVALID LIFECYCLE = 0xE,
 HSM KEY STORE CONFLICT = 0xF.
 HSM_GENERAL_ERROR = 0xFF }
```

Error codes returned by HSM functions.

#### **Functions**

- hsm err t hsm open session (open session args t \*args, hsm hdl t \*session hdl)
- hsm err t hsm close session (hsm hdl t session hdl)
- hsm\_err\_t hsm\_open\_key\_store\_service (hsm\_hdl\_t session\_hdl, open\_svc\_key\_store\_args\_t \*args, hsm\_hdl\_t \*key\_store\_hdl)
- hsm\_err\_t hsm\_close\_key\_store\_service (hsm\_hdl\_t key\_store\_hdl)
- hsm\_err\_t hsm\_open\_key\_management\_service (hsm\_hdl\_t key\_store\_hdl, open\_svc\_key\_management\_args\_t \*args, hsm\_hdl\_t \*key\_management\_hdl)
- hsm err t hsm generate key (hsm hdl t key management hdl, op generate key args t args)
- hsm\_err\_t hsm\_manage\_key (hsm\_hdl\_t key\_management\_hdl, uint32\_t key\_identifier, hsm\_addr\_lsb\_t key, uint16\_t key\_size, hsm\_key\_type\_t key\_type, hsm\_key\_info\_t key\_info, hsm\_op\_manage\_key\_flags\_t flags)
- hsm\_err\_t hsm\_butterfly\_key\_expansion (hsm\_hdl\_t key\_management\_hdl, uint32\_t key\_identifier, hsm\_addr\_lsb\_t add\_data\_1, hsm\_addr\_lsb\_t add\_data\_2, hsm\_addr\_lsb\_t multiply\_data, uint16\_t data \_1\_size, uint16\_t data\_2\_size, uint16\_t multiply\_data\_size, uint32\_t dest\_key\_identifier, hsm\_addr\_lsb\_t output, uint32\_t output\_size, hsm\_op\_but\_key\_exp\_flags\_t flags)
- hsm\_err\_t hsm\_close\_key\_management\_service (hsm\_hdl\_t key\_management\_hdl)
- hsm\_err\_t hsm\_open\_cipher\_service (hsm\_hdl\_t key\_store\_hdl, hsm\_addr\_msb\_t input\_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, hsm\_svc\_cipher\_flags\_t flags, hsm\_hdl\_t \*chiper\_hdl)
- hsm\_err\_t hsm\_cipher\_one\_go (hsm\_hdl\_t chiper\_hdl, uint32\_t key\_identifier, hsm\_addr\_lsb\_t input, hsm\_addr\_lsb\_t output, hsm\_addr\_lsb\_t iv, uint32\_t input\_size, uint32\_t output\_size, uint32\_t iv\_size, hsm\_op\_cipher\_one\_go\_algo\_t cipher\_algo, hsm\_op\_cipher\_one\_go\_flags\_t flags)
- hsm\_err\_t hsm\_close\_cipher\_service (hsm\_hdl\_t chiper\_hdl)
- hsm\_err\_t hsm\_open\_signature\_generation\_service (hsm\_hdl\_t key\_store\_hdl, hsm\_addr\_msb\_t input
   \_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, hsm\_svc\_signature\_flags\_t flags, hsm\_hdl\_t
   \*signature\_gen\_hdl)
- hsm\_err\_t hsm\_signature\_generation (hsm\_hdl\_t signature\_gen\_hdl, uint32\_t key\_identifier, hsm\_signature\_scheme\_id\_t scheme\_id, hsm\_addr\_lsb\_t message, hsm\_addr\_lsb\_t signature, uint32\_t message\_size, uint32\_← t signature size, hsm op signature gen flags t flags)
- hsm\_err\_t hsm\_close\_signature\_generation\_service (hsm\_hdl\_t signature\_gen\_hdl)
- hsm\_err\_t hsm\_open\_fast\_signature\_generation\_service (hsm\_hdl\_t key\_store\_hdl, hsm\_addr\_msb\_t input\_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, uint32\_t key\_identifier, hsm\_signature\_scheme\_id\_t scheme\_id, hsm\_svc\_fast\_signature\_generation\_flags\_t flags, hsm\_hdl\_t \*fast\_signature\_gen\_hdl)

- hsm\_err\_t hsm\_fast\_signature\_generation (hsm\_hdl\_t fast\_signature\_gen\_hdl, hsm\_addr\_lsb\_t message, hsm\_addr\_lsb\_t signature, uint32\_t message\_size, uint32\_t signature\_size, hsm\_op\_fast\_signature\_gen\_flags\_t flags)
- hsm\_err\_t hsm\_close\_fast\_signature\_generation\_service (hsm\_hdl\_t fast\_signature\_gen\_hdl)
- hsm\_err\_t hsm\_open\_signature\_verification\_service (hsm\_hdl\_t session\_hdl, hsm\_addr\_msb\_t input
   \_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, hsm\_svc\_signature\_flags\_t flags, hsm\_hdl\_t
   \*signature ver hdl)
- hsm\_err\_t hsm\_signature\_verification (hsm\_hdl\_t signature\_ver\_hdl, hsm\_addr\_lsb\_t key\_address, hsm\_signature\_scheme\_id\_t scheme\_id, hsm\_addr\_lsb\_t message, hsm\_addr\_lsb\_t signature, uint32\_t message\_size, uint32\_t signature\_size, hsm\_verification\_status\_t \*status, hsm\_op\_signature\_ver\_flags\_t flags)
- hsm\_err\_t hsm\_close\_signature\_verification\_service (hsm\_hdl\_t signature\_ver\_hdl)
- hsm\_err\_t hsm\_open\_fast\_signature\_verification\_service (hsm\_hdl\_t session\_hdl, hsm\_addr\_msb\_t input
   \_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, hsm\_addr\_msb\_t key\_address\_ext, hsm\_addr\_lsb\_t
   key\_address, hsm\_svc\_fast\_signature\_verification\_flags\_t flags, hsm\_signature\_scheme\_id\_t scheme\_id,
   hsm\_hdl\_t \*fast\_signature\_ver\_hdl)
- hsm\_err\_t hsm\_fast\_signature\_verification (hsm\_hdl\_t fast\_signature\_ver\_hdl, hsm\_addr\_lsb\_t message, hsm\_addr\_lsb\_t signature, uint32\_t message\_size, uint32\_t signature\_size, hsm\_verification\_status\_t \*status, hsm\_op\_fast\_signature\_ver\_flags\_t flags)
- hsm\_err\_t hsm\_close\_fast\_signature\_verification\_service (hsm\_hdl\_t fast\_signature\_ver\_hdl)
- hsm\_err\_t hsm\_open\_rng\_service (hsm\_hdl\_t session\_hdl, hsm\_addr\_msb\_t input\_address\_ext, hsm\_addr\_msb\_t output\_address\_ext, hsm\_svc\_rng\_flags\_t flags, hsm\_hdl\_t \*rng\_hdl)
- hsm\_err\_t hsm\_rng\_get\_random (hsm\_hdl\_t rng\_hdl, hsm\_addr\_lsb\_t output, uint32\_t output\_size)
- hsm err t hsm close rng service (hsm hdl t rng hdl)
- hsm\_err\_t hsm\_open\_hash\_service (hsm\_hdl\_t session\_hdl, hsm\_addr\_msb\_t input\_address\_ext, hsm addr msb t output address ext, hsm svc hash flags t flags, hsm hdl t \*hash hdl)
- hsm\_err\_t hsm\_hash\_one\_go (hsm\_hdl\_t hash\_hdl, hsm\_addr\_lsb\_t input, hsm\_addr\_lsb\_t output, uint32
   — t input\_size, uint32\_t output\_size, hsm\_hash\_algo\_t algo)
- hsm err t hsm close hash service (hsm hdl t hash hdl)

# 6.1.1 Detailed Description

i.MX8 HSM API header file

#### 6.1.2 Macro Definition Documentation

#### 6.1.2.1 HSM\_SVC\_KEY\_STORE\_FLAGS\_CREATE

```
#define HSM_SVC_KEY_STORE_FLAGS_CREATE ((hsm_svc_key_store_flags_t)(1 << 0))</pre>
```

It must be specified to create a new key storage

# 6.1.2.2 HSM\_SVC\_KEY\_STORE\_FLAGS\_UPDATE

```
6.1.2.3 HSM_SVC_KEY_STORE_FLAGS_DELETE
#define HSM_SVC_KEY_STORE_FLAGS_DELETE ((hsm_svc_key_store_flags_t)(1 << 3))</pre>
6.1.2.4 HSM_KEY_TYPE_ECDSA_NIST_P224
#define HSM_KEY_TYPE_ECDSA_NIST_P224 ((hsm_key_type_t)0x01)
6.1.2.5 HSM_KEY_TYPE_ECDSA_NIST_P256
#define HSM_KEY_TYPE_ECDSA_NIST_P256 ((hsm_key_type_t)0x02)
6.1.2.6 HSM_KEY_TYPE_ECDSA_NIST_P384
#define HSM_KEY_TYPE_ECDSA_NIST_P384 ((hsm_key_type_t)0x03)
6.1.2.7 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224 ((hsm_key_type_t)0x12)
6.1.2.8 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256 ((hsm_key_type_t)0x13)
6.1.2.9 HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384 ((hsm_key_type_t)0x15)
6.1.2.10 HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224 ((hsm_key_type_t)0x22)
6.1.2.11 HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256 ((hsm_key_type_t)0x23)
```

## 6.1.2.12 HSM\_KEY\_TYPE\_ECDSA\_BRAINPOOL\_T1\_384

```
#define HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384 ((hsm_key_type_t)0x25)
```

#### 6.1.2.13 HSM\_KEY\_TYPE\_AES\_128

```
#define HSM_KEY_TYPE_AES_128 ((hsm_key_type_t)0x30)
```

#### 6.1.2.14 HSM\_KEY\_TYPE\_AES\_192

```
#define HSM_KEY_TYPE_AES_192 ((hsm_key_type_t)0x31)
```

# 6.1.2.15 HSM\_KEY\_TYPE\_AES\_256

```
#define HSM_KEY_TYPE_AES_256 ((hsm_key_type_t)0x32)
```

# 6.1.2.16 HSM\_KEY\_INFO\_PERMANENT

```
#define HSM_KEY_INFO_PERMANENT ((hsm_key_info_t)(1 << 0))</pre>
```

When set, the key is permanent. Once created, it will not be possible to update or delete the key anymore. This bit can never be reset.

## 6.1.2.17 HSM\_OP\_KEY\_GENERATION\_FLAGS\_UPDATE

User can replace an existing key only by generating a key with the same type of the original one.

#### 6.1.2.18 HSM\_OP\_KEY\_GENERATION\_FLAGS\_CREATE\_PERSISTENT

```
#define HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT ((hsm_op_key_gen_flags_t)(1 << 1))
```

Persistent keys are saved in the non volatile memory.

## 6.1.2.19 HSM\_OP\_KEY\_GENERATION\_FLAGS\_CREATE\_TRANSIENT

```
#define HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT ((hsm_op_key_gen_flags_t)(1 << 2))
```

Transient keys are deleted when the corresponding key store service flow is closed.

#### 6.1.2.20 HSM\_OP\_KEY\_GENERATION\_FLAGS\_STRICT\_OPERATION

```
#define HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION ((hsm_op_key_gen_flags_t)(1 << 7))</pre>
```

The request is completed only when the new key has been written in the NVM. This applicable for persistent key only.

## 6.1.2.21 HSM\_OP\_MANAGE\_KEY\_FLAGS\_UPDATE

```
#define HSM_OP_MANAGE_KEY_FLAGS_UPDATE ((hsm_op_manage_key_flags_t)(1 << 0))</pre>
```

#### 6.1.2.22 HSM\_OP\_MANAGE\_KEY\_FLAGS\_DELETE

```
#define HSM_OP_MANAGE_KEY_FLAGS_DELETE ((hsm_op_manage_key_flags_t)(1 << 1))</pre>
```

# 6.1.2.23 HSM\_OP\_MANAGE\_KEY\_FLAGS\_STRICT\_OPERATION

```
#define HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION ((hsm_op_manage_key_flags_t)(1 << 7))
```

The request is completed only when the modification has been written in the NVM. This applicable for persistent key only.

## 6.1.2.24 HSM\_CIPHER\_ONE\_GO\_ALGO\_AES\_ECB

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_ECB ((hsm_op_cipher_one_go_algo_t)(0x00))
```

#### 6.1.2.25 HSM CIPHER ONE GO ALGO AES CBC

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_CBC ((hsm_op_cipher_one_go_algo_t)(0x01))
```

#### 6.1.2.26 HSM\_CIPHER\_ONE\_GO\_ALGO\_AES\_CCM

```
#define HSM_CIPHER_ONE_GO_ALGO_AES_CCM ((hsm_op_cipher_one_go_algo_t)(0x02))
```

Perform AES CCM with following prerequisites:

- Adata = 0 There is no associated data
- Tlen = 16 bytes

# 6.1.2.27 HSM\_CIPHER\_ONE\_GO\_FLAGS\_ENCRYPT #define HSM\_CIPHER\_ONE\_GO\_FLAGS\_ENCRYPT ((hsm\_op\_cipher\_one\_go\_flags\_t)(1 << 0)) 6.1.2.28 HSM\_CIPHER\_ONE\_GO\_FLAGS\_DECRYPT #define HSM\_CIPHER\_ONE\_GO\_FLAGS\_DECRYPT ((hsm\_op\_cipher\_one\_go\_flags\_t)(1 << 1))</pre> 6.1.2.29 HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_DIGEST #define HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_DIGEST ((hsm\_op\_signature\_gen\_flags\_t)(0 << 0)) 6.1.2.30 HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE #define HSM\_OP\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE ((hsm\_op\_signature\_gen\_flags\_t)(1 << 1)) 6.1.2.31 HSM\_OP\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT #define HSM\_OP\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT ((hsm\_op\_signature\_gen\_flags\_t)(2 << 1)) 6.1.2.32 HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P224\_SHA\_256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P224\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x01) 6.1.2.33 HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P256\_SHA\_256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x02) 6.1.2.34 HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P384\_SHA\_384 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_NIST\_P384\_SHA\_384 ((hsm\_signature\_scheme\_id\_t)0x03) 6.1.2.35 HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_224\_SHA\_256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINFOOL\_R1\_224\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x12)

6.1 Hsm\_api 11

# 6.1.2.36 HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_256\_SHA\_256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x13) 6.1.2.37 HSM SIGNATURE SCHEME ECDSA BRAINPOOL R1 384 SHA 384 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_R1\_384\_SHA\_384 ((hsm\_signature\_scheme\_id\_t)0x15) 6.1.2.38 HSM SIGNATURE SCHEME ECDSA BRAINPOOL T1 224 SHA 256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_224\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x22) 6.1.2.39 HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_256\_SHA\_256 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_256\_SHA\_256 ((hsm\_signature\_scheme\_id\_t)0x23) 6.1.2.40 HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_384\_SHA\_384 #define HSM\_SIGNATURE\_SCHEME\_ECDSA\_BRAINPOOL\_T1\_384\_SHA\_384 ((hsm\_signature\_scheme\_id\_t)0x25) 6.1.2.41 HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_DIGEST #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_DIGEST ((hsm\_op\_fast\_signature\_gen\_flags\_t)(0 << 0)) 6.1.2.42 HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_INPUT\_MESSAGE ((hsm\_op\_fast\_signature\_gen\_flags\_t)(1 << 1)) 6.1.2.43 HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT #define HSM\_OP\_FAST\_SIGNATURE\_GENERATION\_COMPRESSED\_POINT ((hsm\_op\_fast\_signature\_gen\_flags\_t)(2 << 1))

```
6.1.2.44 HSM_OP_SIGNATURE_VERIFICATION_INPUT_DIGEST
#define HSM_OP_SIGNATURE_VERIFICATION_INPUT_DIGEST ((hsm_op_signature_ver_flags_t)(0 << 0))</pre>
6.1.2.45 HSM_OP_SIGNATURE_VERIFICATION_INPUT_MESSAGE
#define HSM_OP_SIGNATURE_VERIFICATION_INPUT_MESSAGE ((hsm_op_signature_ver_flags_t)(1 << 1))
6.1.2.46 HSM_VERIFICATION_STATUS_SUCCESS
#define HSM_VERIFICATION_STATUS_SUCCESS ((hsm_verification_status_t)(0x5A3CC3A5))
6.1.2.47 HSM_VERIFICATION_STATUS_FAILURE
#define HSM_VERIFICATION_STATUS_FAILURE ((hsm_verification_status_t)(0xA5C33C5A))
6.1.2.48 HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_DIGEST
#define HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_DIGEST ((hsm_op_fast_signature_ver_flags_t)(0
<< 0))
6.1.2.49 HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_MESSAGE
#define HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_MESSAGE ((hsm_op_fast_signature_ver_flags_t)(1
<< 1))
6.1.2.50 HSM_HASH_ALGO_SHA2_224
#define HSM_HASH_ALGO_SHA2_224 ((hsm_hash_algo_t)(0x0))
6.1.2.51 HSM_HASH_ALGO_SHA2_256
#define HSM_HASH_ALGO_SHA2_256 ((hsm_hash_algo_t)(0x1))
6.1.2.52 HSM_HASH_ALGO_SHA2_384
#define HSM_HASH_ALGO_SHA2_384 ((hsm_hash_algo_t)(0x2))
```

## 6.1.3 Typedef Documentation

```
6.1.3.1 hsm hdl t
typedef uint32_t hsm_hdl_t
6.1.3.2 hsm_svc_key_store_flags_t
typedef uint8_t hsm_svc_key_store_flags_t
6.1.3.3 hsm_svc_key_management_flags_t
typedef uint8_t hsm_svc_key_management_flags_t
6.1.3.4 hsm_svc_cipher_flags_t
typedef uint8_t hsm_svc_cipher_flags_t
6.1.3.5 hsm_svc_signature_flags_t
typedef uint8_t hsm_svc_signature_flags_t
6.1.3.6 hsm_svc_fast_signature_verification_flags_t
typedef uint8_t hsm_svc_fast_signature_verification_flags_t
6.1.3.7 hsm_svc_fast_signature_generation_flags_t
typedef uint8_t hsm_svc_fast_signature_generation_flags_t
6.1.3.8 hsm_svc_rng_flags_t
typedef uint8_t hsm_svc_rng_flags_t
```

```
6.1.3.9 hsm_svc_hash_flags_t
typedef uint8_t hsm_svc_hash_flags_t
6.1.3.10 hsm_op_key_gen_flags_t
typedef uint8_t hsm_op_key_gen_flags_t
6.1.3.11 hsm_op_manage_key_flags_t
typedef uint8_t hsm_op_manage_key_flags_t
6.1.3.12 hsm_op_but_key_exp_flags_t
typedef uint8_t hsm_op_but_key_exp_flags_t
6.1.3.13 hsm_op_cipher_one_go_algo_t
typedef uint8_t hsm_op_cipher_one_go_algo_t
6.1.3.14 hsm_op_cipher_one_go_flags_t
typedef uint8_t hsm_op_cipher_one_go_flags_t
6.1.3.15 hsm_op_signature_gen_flags_t
typedef uint8_t hsm_op_signature_gen_flags_t
6.1.3.16 hsm_op_signature_ver_flags_t
typedef uint8_t hsm_op_signature_ver_flags_t
6.1.3.17 hsm_op_fast_signature_gen_flags_t
{\tt typedef\ uint8\_t\ hsm\_op\_fast\_signature\_gen\_flags\_t}
```

```
6.1.3.18 hsm_op_fast_signature_ver_flags_t
typedef uint8_t hsm_op_fast_signature_ver_flags_t
6.1.3.19 hsm_key_type_t
typedef uint16_t hsm_key_type_t
6.1.3.20 hsm_key_info_t
typedef uint16_t hsm_key_info_t
6.1.3.21 hsm_signature_scheme_id_t
typedef uint8_t hsm_signature_scheme_id_t
6.1.3.22 hsm_hash_algo_t
typedef uint8_t hsm_hash_algo_t
6.1.3.23 hsm_verification_status_t
typedef uint32_t hsm_verification_status_t
6.1.3.24 hsm_addr_msb_t
typedef uint32_t hsm_addr_msb_t
6.1.3.25 hsm_addr_lsb_t
typedef uint32_t hsm_addr_lsb_t
6.1.4 Enumeration Type Documentation
6.1.4.1 hsm_err_t
enum hsm_err_t
Error codes returned by HSM functions.
```

# Enumerator

HSM_NO_ERROR	Success.
HSM_INVALID_MESSAGE	The received message is invalid or unknown.
HSM_INVALID_ADDRESS	The provided address is invalid or doesn't respect the API requirements.
HSM_UNKNOWN_ID	The provided identifier is not known.
HSM_INVALID_PARAM	One of the parameter provided in the command is invalid.
HSM_NVM_ERROR	NVM generic issue.
HSM_OUT_OF_MEMORY	There is not enough memory to handle the requested operation.
HSM_UNKNOWN_HANDLE	Unknown session/service handle.
HSM_UNKNOWN_KEY_STORE	The key store identified by the provided "key store Id" doesn't exist and the
	"create" flag is not set.
HSM_KEY_STORE_AUTH	Key storage authentication fails.
HSM_KEY_STORAGE_ERROR	An error occurred in the key storage internal processing.
HSM_ID_CONFLICT	An element (key storage, key) with the provided ID already exists.
HSM_RNG_NOT_STARTED	The internal RNG is not started.
HSM_CMD_NOT_SUPPORTED	The functionality is not supported for the current session/service/key store
	configuration.
HSM_INVALID_LIFECYCLE	Invalid lifecycle for requested operation.
HSM_KEY_STORE_CONFLICT	A key store with the same attributes already exists.
HSM_GENERAL_ERROR	Error not covered by other codes occured.

# 6.1.5 Function Documentation

# 6.1.5.1 hsm\_open\_session()

Initiate a HSM session.

# **Parameters**

args	pointer to the structure containing the specific function arugments.
session_hdl	pointer to where the session handle must be written.

# Returns

error\_code error code.

# 6.1.5.2 hsm\_close\_session()

17 6.1 Hsm\_api Terminate a previously opened HSM session

# **Parameters**

session hdl	pointer to the handle identifying the session to be closed.

# Returns

error\_code error code.

# 6.1.5.3 hsm\_open\_key\_store\_service()

Open a service flow on the specified key store.

#### **Parameters**

session_hdl	pointer to the handle indentifing the current session.
args	pointer to the structure containing the specific function arugments.
key_store_hdl	pointer to where the key store service flow handle must be written.

# Returns

error\_code error code.

# 6.1.5.4 hsm\_close\_key\_store\_service()

Close a previously opened key store service flow.

# **Parameters**

J.
J.

# Returns

error\_code error code.

#### 6.1.5.5 hsm\_open\_key\_management\_service()

Open a key management service flow

User must open this service in order to perform operation on the key store content: key generate, delete, update

#### **Parameters**

key_store_hdl	handle indentifing the key store service flow.
args	pointer to the structure containing the specific function arugments.
key_management_hdl	pointer to where the key management service flow handle must be written.

#### Returns

error\_code error code.

# 6.1.5.6 hsm\_generate\_key()

Generate a key or a key pair in the key store. In case of asymetic keys, the public key can optionally be exported. The generated key can be stored in a new or in an existing key slot with the restriction that an existing key can be replaced only by a key of the same type.

User can call this function only after having opened a key management service flow

## **Parameters**

key_management_hdl	handle identifying the key management service flow.
args	pointer to the structure containing the specific function arugments.

#### Returns

error code

#### 6.1.5.7 hsm\_manage\_key()

```
hsm_key_type_t key_type,
hsm_key_info_t key_info,
hsm_op_manage_key_flags_t flags )
```

This command is designed to perform operation on an existing key.

User can call this function only after having opened a key management service flow

#### **Parameters**

key_management_hdl	handle identifying the key management service flow.
key_identifier	identifier of the key to be used for the operation.
key_address	LSB of the address in the requester space where the new key value can be found. Not checked in case of delete operation.
key_size	lenght in bytes of the input key area. Not checked in case of delete operation.
key_type	indicates the type of the key to be managed.
key_info	bitmap specifying the properties of the key, it will replace the existing value. Not checked in case of delete operation
flags	bitmap specifying the operation properties

#### Returns

error code

# 6.1.5.8 hsm\_butterfly\_key\_expansion()

```
hsm_err_t hsm_butterfly_key_expansion (
    hsm_hdl_t key_management_hdl,
    uint32_t key_identifier,
    hsm_addr_lsb_t add_data_1,
    hsm_addr_lsb_t add_data_2,
    hsm_addr_lsb_t multiply_data,
    uint16_t data_1_size,
    uint16_t data_2_size,
    uint16_t multiply_data_size,
    uint32_t dest_key_identifier,
    hsm_addr_lsb_t output,
    uint32_t output_size,
    hsm_op_but_key_exp_flags_t flags )
```

This command is designed to perform the butterfly key expansion operation on an ECC private key in case of implicit certificate. Optionally the resulting public key is exported.

User can call this function only after having opened a key management service flow

The following operation is performed: ButKey = (Key + AddData1) \* MultiplyData + AddData2 (mod n)

key_management_hdl	handle identifying the key store management service flow.
key_identifier	identifier of the key to be used for the operation.
add_data_1	LSB of the address in the requester space where the add_data_1 input can be found value 0 in case of explicit certificate expansion function f1(k, i, j) result value in case of implicit certificate.

#### **Parameters**

add_data_2	LSB of the address in the requester space where the add_data_2 input can be found expansion function f1/f2(k, i, j) result value in case of explicit certificate the private reconstruction value used in the derivation of the pseudonym ECC key in case of implicit certificate
multiply_data	LSB of the address in the requester space where the multiply_data input can be found value 1 in case of explicit certificate the hash value used to in the derivation of the pseudonym ECC key
data_1_size	lenght in bytes of the add_data_1 input
data_2_size	lenght in bytes of the add_data_2 input
multiply_date_size	lenght in bytes of the multiply_data input
output	LSB of the address in the requester space where the public key must be written.
output_size	lenght in bytes of the output area, if the size is 0, no key is copied in the output.
flags	bitmap specifying the operation properties

# Returns

error code

## 6.1.5.9 hsm\_close\_key\_management\_service()

Terminate a previously opened key management service flow

# **Parameters**

key_management_hdl	handle identifying the key management service flow.
--------------------	---

## Returns

error code

# 6.1.5.10 hsm\_open\_cipher\_service()

# Open a cipher service flow

User can call this function only after having opened a key store service flow. User must open this service in order to perform cipher operations.

# **Parameters**

key_store_hdl	handle indentifing the key store service flow.
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.
flags	bitmap indicating the service flow properties - not supported in current release, any value accepted.
error_code	pointer to where the error code should be written.
chiper_hdl	pointer to where the cipher service flow handle must be written.

# Returns

error code

# 6.1.5.11 hsm\_cipher\_one\_go()

```
hsm_err_t hsm_cipher_one_go (
    hsm_hdl_t chiper_hdl,
    uint32_t key_identifier,
    hsm_addr_lsb_t input,
    hsm_addr_lsb_t output,
    hsm_addr_lsb_t iv,
    uint32_t input_size,
    uint32_t output_size,
    uint32_t iv_size,
    hsm_op_cipher_one_go_algo_t cipher_algo,
    hsm_op_cipher_one_go_flags_t flags )
```

# Perform ciphering operation

User can call this function only after having opened a cipher service flow

chiper_hdl	handle identifying the cipher service flow.
key_identifier	identifier of the key to be used for the operation
input	LSB of the address in the requester space where the input to be processed can be found plaintext for encryption
	ciphertext for decryption (tag is concatenated for CCM)
output	LSB of the address in the requester space where the output must be stored ciphertext for encryption (tag is concatenated for CCM) plaintext for decryption
iv	LSB of the address in the requester space where the initialization vector can be found
input_size	lenght in bytes of the input
iv_size	lenght in bytes of the initialization vector
	it must be 0 for algorithms not using the initialization vector.
	It must be 12 for AES in CCM mode
cipher_algo	algorithm to be used for the operation
flags	bitmap specifying the operation attributes

#### Returns

error code

#### 6.1.5.12 hsm\_close\_cipher\_service()

Terminate a previously opened cipher service flow

# **Parameters**

chiper hdl	pointer to handle identifying the cipher service flow to be closed.

#### Returns

error code

# 6.1.5.13 hsm\_open\_signature\_generation\_service()

# Open a signature generation service flow

User can call this function only after having opened a key store service flow. User must open this service in order to perform signature generation operations.

# **Parameters**

key_store_hdl	handle indentifing the key store service flow.
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.
flags	bitmap indicating the service flow properties - not supported in current release, any value accepted.
error_code	pointer to where the error code should be written.
signature_gen_hdl	pointer to where the signature generation service flow handle must be written.

# Returns

error code

# 6.1.5.14 hsm\_signature\_generation()

Generate a digital signature according to the signature scheme User can call this function only after having opened a signature generation service flow

#### **Parameters**

signature_gen_hdl	handle identifying the signature generation service flow
key_identifier	identifier of the key to be used for the operation
scheme_id	identifier of the digital signature scheme to be used for the operation
message	LSB of the address in the requester space where the input (message or message digest) to be processed can be found
signature	LSB of the address in the requester space where the signature must be stored the signature S=(c,d) is stored as $c  d  $ Isb_y in case of compressed point signature, $c  d $ otherwhise.
message_size	lenght in bytes of the input
signature_size	lenght in bytes of the output - it must contains additional 32bits where to store the Ry last significant bit
flags	bitmap specifying the operation attributes

# Returns

error code

# 6.1.5.15 hsm\_close\_signature\_generation\_service()

Terminate a previously opened signature generation service flow

#### **Parameters**

signature_gen_hdl	handle identifying the signature generation service flow to be closed.

#### Returns

error code

6.1 Hsm\_api 25

#### 6.1.5.16 hsm\_open\_fast\_signature\_generation\_service()

#### Open a fast signature generation service flow

User can call this function only after having opened a key store service flow. User must open this service in order to perform several signature generation by using the same private key.

#### **Parameters**

key_store_hdl	handle indentifing the key store service flow.
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.
key_identifier	identifier of the private key to be used for the subsequent operations
flags	bitmap indicating the service flow properties - not supported in current release, any value accepted.
fast_signature_gen_hdl	pointer to where the fast signature generation service flow handle must be written.

# Returns

error code

# 6.1.5.17 hsm\_fast\_signature\_generation()

# Generate a digital signature according to the signature scheme

User can call this function only after having opened a fast signature generation service flow (key\_identifier is omitted in the command)

fast_signature_gen_hdl	handle identifying the fast signature generation service flow
scheme_id	identifier of the digital signature scheme to be used for the operation
message	LSB of the address in the requester space where the input to be processed
	(message or message digest) can be found.

#### **Parameters**

signature	LSB of the address in the requester space where the signature must be stored the signature $S=(c,d)$ is stored as $c  d  sb_y$ in case of compressed point signature, $c  d $ otherwhise.
message_size	lenght in bytes of the input
signature_size	lenght in bytes of the output - In case of compressed point signature additional 32bit must be provided.
flags	bitmap specifying the operation attributes

#### Returns

error code

# 6.1.5.18 hsm\_close\_fast\_signature\_generation\_service()

Terminate a previously opened fast signature generation service flow

#### **Parameters**

fast_signature_gen_hdl	handle identifying the signature service flow to be closed.
------------------------	---

## Returns

error code

# 6.1.5.19 hsm\_open\_signature\_verification\_service()

#### Open a signature verification service flow

User can call this function only after having opened a session. User must open this service in order to perform signature verification operations.

session_hdl	handle indentifing the current session.
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the
	requester address space for the operations handled by the service flow.

#### **Parameters**

output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.
flags	bitmap indicating the service flow properties - not supported in current release, any value accepted.
error_code	pointer to where the error code should be written.
signature_ver_hdl	pointer to where the signature verification service flow handle must be written.

#### Returns

error code

# 6.1.5.20 hsm\_signature\_verification()

Verify a digital signature according to the signature scheme
User can call this function only after having opened a signature verification service flow

signature_ver_hdl	handle identifying the signature verification service flow.			
key_address	pointer to the key to be used for the operation			
key_identifier	identifier of the key to be used for the operation			
ecc_domain_id	identifier of the supported ECC domains to be used for the operation			
message	LSB of the address in the requester space where the input (message or message digest) to be processed can be found			
signature	LSB of the address in the requester space where the signature can be found the signature S=(c,d) must be in the format $c  d$ .			
message_size	lenght in bytes of the input			
signature_size	lenght in bytes of the output - it must contains additional 32bits where to store the Ry last significant bit			
status	pointer to where the verification status must be stored if the verification suceed the value HSM_OP_SIGNATURE_VERIFICATION_STATUS_SUCCESS is returned.			
flags	bitmap specifying the operation attributes			

#### Returns

error code

#### 6.1.5.21 hsm\_close\_signature\_verification\_service()

Terminate a previously opened signature verification service flow

#### **Parameters**

tifying the signature verification service flow to be closed.	signature_ver_hdl
---	-------------------

#### Returns

error code

# 6.1.5.22 hsm\_open\_fast\_signature\_verification\_service()

```
hsm_err_t hsm_open_fast_signature_verification_service (
    hsm_hdl_t session_hdl,
    hsm_addr_msb_t input_address_ext,
    hsm_addr_msb_t output_address_ext,
    hsm_addr_msb_t key_address_ext,
    hsm_addr_lsb_t key_address,
    hsm_svc_fast_signature_verification_flags_t flags,
    hsm_signature_scheme_id_t scheme_id,
    hsm_hdl_t * fast_signature_ver_hdl )
```

### Open a fast signature verification service flow

User can call this function only after having opened a session. User must open this service in order to perform several signature verification by using the same oublic key.

session_hdl	handle indentifing the current session.
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.
key_identifier	identifier of the private key to be used for the subsequent operations
flags	bitmap indicating the service flow properties - not supported in current release, any value accepted.
fast_signature_ver_hdl	pointer to where the fast signature verification service flow handle must be written.

#### Returns

error code

# 6.1.5.23 hsm\_fast\_signature\_verification()

```
hsm_err_t hsm_fast_signature_verification (
    hsm_hdl_t fast_signature_ver_hdl,
    hsm_addr_lsb_t message,
    hsm_addr_lsb_t signature,
    uint32_t message_size,
    uint32_t signature_size,
    hsm_verification_status_t * status,
    hsm_op_fast_signature_ver_flags_t flags )
```

Verify a digital signature according to the signature scheme
User can call this function only after having opened a signature service flow

#### **Parameters**

signature_hdl	handle identifying the signature service flow.				
key_address	pointer to the key to be used for the operation				
key_identifier	identifier of the key to be used for the operation				
ecc_domain⊷ _id	identifier of the supported ECC domains to be used for the operation				
message	LSB of the address in the requester space where the input to be processed (message or message digest) can be found.				
signature	message LSB of the address in the requester space where the signature can be foundmust be stored the signature $S=(c,d)$ must be in the $c  d$ format.				
message_size	lenght in bytes of the input				
signature_size	lenght in bytes of the signature.				
status	pointer to where the verification status must be stored if the verification suceed the value HSM_OP_SIGNATURE_VERIFICATION_STATUS_SUCCESS is returned.				
flags	bitmap specifying the operation attributes.				

#### Returns

error code

# 6.1.5.24 hsm\_close\_fast\_signature\_verification\_service()

```
\label{local_local_local_local} hsm\_err\_t \ hsm\_close\_fast\_signature\_verification\_service \ ( \\ hsm\_hdl\_t \ fast\_signature\_ver\_hdl \ )
```

Terminate a previously opened fast signature verification service flow

#### **Parameters**

fast signature ver hdl	handle identifying the fast signature verification service flow to be closed.
------------------------	---

# Returns

error code

# 6.1.5.25 hsm\_open\_rng\_service()

# Open a random number generation service flow

User can call this function only after having opened a session. User must open this service in order to perform rng operations.

#### **Parameters**

session_hdl	handle indentifing the current session.		
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.		
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.		
flags	bitmap indicating the service flow properties		
rng_hdl	pointer to where the rng service flow handle must be written.		

# Returns

error code

# 6.1.5.26 hsm\_rng\_get\_random()

# Get a freshly generated random number

User can call this function only after having opened a rng service flow

rng_hdl	handle identifying the rng service flow.	
output	LSB of the address in the requester space where random number must be stored.	<u></u>
output_size	length of the random number in bytes	nerated by Doxygen

#### Returns

error code

# 6.1.5.27 hsm\_close\_rng\_service()

Terminate a previously opened rng service flow

# **Parameters**

r	ng_hdl	handle identifying the rng service flow to be closed.
---	--------	---

#### Returns

error code

# 6.1.5.28 hsm\_open\_hash\_service()

#### Open an hash service flow

User can call this function only after having opened a session. User must open this service in order to perform an hash operations.

#### **Parameters**

session_hdl	handle indentifing the current session.	
input_address_ext	most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the operations handled by the service flow.	
output_address_ext	most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the opeartion handled by the service flow.	
flags	bitmap indicating the service flow properties	
hash_hdl	pointer to where the hash service flow handle must be written.	

# Returns

error code

#### 6.1.5.29 hsm\_hash\_one\_go()

Perform the hash operation on a given input

User can call this function only after having opened a hash service flow

#### **Parameters**

hash_hdl	handle identifying the hash service flow.
input	LSB of the address in the requester space where message to be hashed can be found.
output	LSB of the address in the requester space where the resulting hash must be stored.
input_size	lenght in bytes of the input
output_size	lenght in bytes of the output.
algo	algorithm to be used for the operation

#### Returns

error code

# 6.1.5.30 hsm\_close\_hash\_service()

Terminate a previously opened hash service flow

# **Parameters**

hash_hdl handle identifying the hash service flow to be closed.
---

# Returns

error code

# 7 Class Documentation

# 7.1 op\_generate\_key\_args\_t Struct Reference

# **Public Attributes**

• uint32\_t key\_identifier

- uint16\_t output\_size
- hsm\_op\_key\_gen\_flags\_t flags
- hsm\_key\_type\_t key\_type
- hsm\_key\_info\_t key\_info

#### 7.1.1 Member Data Documentation

# 7.1.1.1 key\_identifier

```
uint32_t op_generate_key_args_t::key_identifier
```

pointer to the identifier of the key to be used for the operation. In case of create operation the new key identifier will be stored in this location.

# 7.1.1.2 output\_size

```
uint16_t op_generate_key_args_t::output_size
```

lenght in bytes of the output area, if the size is 0, no key is copied in the output.

#### 7.1.1.3 flags

```
hsm_op_key_gen_flags_t op_generate_key_args_t::flags
```

bitmap specifying the operation properties

#### 7.1.1.4 key\_type

```
hsm_key_type_t op_generate_key_args_t::key_type
```

indicates which type of key must be generated

# 7.1.1.5 key\_info

```
hsm_key_info_t op_generate_key_args_t::key_info
```

bitmap specifying the properties of the key

# 7.2 open\_session\_args\_t Struct Reference

**Public Attributes** 

- uint8\_t session\_priority
- uint8\_t operating\_mode
- uint16\_t rsv

#### 7.2.1 Member Data Documentation

#### 7.2.1.1 session\_priority

```
uint8_t open_session_args_t::session_priority
```

not supported in current release, any value accepted.

#### 7.2.1.2 operating\_mode

```
uint8_t open_session_args_t::operating_mode
```

not supported in current release, any value accepted.

#### 7.2.1.3 rsv

```
uint16_t open_session_args_t::rsv
```

# 7.3 open\_svc\_key\_management\_args\_t Struct Reference

# **Public Attributes**

- hsm\_addr\_msb\_t input\_address\_ext
- hsm\_addr\_msb\_t output\_address\_ext
- hsm\_svc\_key\_management\_flags\_t flags
- uint8\_t rsv [3]

#### 7.3.1 Member Data Documentation

#### 7.3.1.1 input\_address\_ext

```
hsm\_addr\_msb\_t \ open\_svc\_key\_management\_args\_t::input\_address\_ext
```

most significant 32 bits address to be used by HSM for input memory transactions in the requester address space for the commands handled by the service flow.

# 7.3.1.2 output\_address\_ext

```
hsm_addr_msb_t open_svc_key_management_args_t::output_address_ext
```

most significant 32 bits address to be used by HSM for output memory transactions in the requester address space for the commands handled by the service flow.

#### 7.3.1.3 flags

```
hsm_svc_key_management_flags_t open_svc_key_management_args_t::flags
```

bitmap specifying the services properties

#### 7.3.1.4 rsv

```
uint8_t open_svc_key_management_args_t::rsv[3]
```

# 7.4 open\_svc\_key\_store\_args\_t Struct Reference

#### **Public Attributes**

- uint32\_t key\_store\_identifier
- uint32\_t authentication\_nonce
- · uint16 t max updates number
- hsm\_svc\_key\_store\_flags\_t flags
- uint8\_t rsv

#### 7.4.1 Member Data Documentation

# 7.4.1.1 key\_store\_identifier

```
\verb"uint32_t open_svc_key_store_args_t:: key_store_identifier"
```

user defined id identifying the key store.

#### 7.4.1.2 authentication\_nonce

```
uint32_t open_svc_key_store_args_t::authentication_nonce
```

user defined nonce used as authentication proof for accesing the key storage.

## 7.4.1.3 max\_updates\_number

```
uint16_t open_svc_key_store_args_t::max_updates_number
```

maximum number of updates authorized for the storage. Valid only for create operation.

# 7.4.1.4 flags

```
hsm_svc_key_store_flags_t open_svc_key_store_args_t::flags
```

bitmap specifying the services properties.

#### 7.4.1.5 rsv

```
uint8_t open_svc_key_store_args_t::rsv
```

# Index

authentication_nonce	HSM KEY TYPE AES 256,8
open_svc_key_store_args_t, 35	HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224,
flags	HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256,
op_generate_key_args_t, 33	7
open_svc_key_management_args_t, 34	HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384,
open_svc_key_store_args_t, 35	7
hsm_addr_lsb_t	HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224,
Hsm_api, 15	
hsm_addr_msb_t	HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256,
Hsm_api, 15	7
Hsm_api, 2	HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384,
hsm_addr_lsb_t, 15	7
hsm_addr_msb_t, 15	HSM_KEY_TYPE_ECDSA_NIST_P224, 7
hsm_butterfly_key_expansion, 20	HSM_KEY_TYPE_ECDSA_NIST_P256, 7
hsm_cipher_one_go, 22	HSM_KEY_TYPE_ECDSA_NIST_P384, 7
HSM CIPHER ONE GO ALGO AES CBC, 9	hsm_key_type_t, 15
HSM_CIPHER_ONE_GO_ALGO_AES_CCM, 9	hsm_manage_key, 19
HSM CIPHER ONE GO ALGO AES ECB, 9	HSM_NO_ERROR, 16
HSM_CIPHER_ONE_GO_FLAGS_DECRYPT, 10	HSM_NVM_ERROR, 16
HSM CIPHER ONE GO FLAGS ENCRYPT, 9	hsm_op_but_key_exp_flags_t, 14
hsm_close_cipher_service, 23	hsm_op_cipher_one_go_algo_t, 14
hsm_close_fast_signature_generation_service, 26	hsm_op_cipher_one_go_flags_t, 14
hsm_close_fast_signature_verification_service, 29	hsm_op_fast_signature_gen_flags_t, 14
hsm_close_hash_service, 32	HSM_OP_FAST_SIGNATURE_GENERATION_COMPRESSED_PO
hsm_close_key_management_service, 21	11
hsm_close_key_store_service, 18	HSM_OP_FAST_SIGNATURE_GENERATION_INPUT_DIGEST,
hsm_close_rng_service, 31	11
hsm_close_session, 16	HSM_OP_FAST_SIGNATURE_GENERATION_INPUT_MESSAGE,
hsm_close_signature_generation_service, 24	11
hsm_close_signature_verification_service, 28	hsm_op_fast_signature_ver_flags_t, 14
HSM_CMD_NOT_SUPPORTED, 16	HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_DIGEST,
hsm_err_t, 15	12
hsm_fast_signature_generation, 25	HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_MESSAGE,
hsm_fast_signature_verification, 29	12
HSM_GENERAL_ERROR, 16	hsm_op_key_gen_flags_t, 14
hsm_generate_key, 19	HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT,
HSM_HASH_ALGO_SHA2_224, 12	8
HSM_HASH_ALGO_SHA2_256, 12	HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT,
HSM_HASH_ALGO_SHA2_384, 12	8
hsm_hash_algo_t, 15	HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION,
hsm_hash_one_go, 31	8
hsm_hdl_t, 13	HSM_OP_KEY_GENERATION_FLAGS_UPDATE,
HSM_ID_CONFLICT, 16	8
HSM_INVALID_ADDRESS, 16	HSM_OP_MANAGE_KEY_FLAGS_DELETE, 9
HSM INVALID LIFECYCLE, 16	HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION,
HSM INVALID MESSAGE, 16	9
HSM INVALID PARAM, 16	hsm_op_manage_key_flags_t, 14
HSM_KEY_INFO_PERMANENT, 8	HSM_OP_MANAGE_KEY_FLAGS_UPDATE, 9
hsm_key_info_t, 15	hsm_op_signature_gen_flags_t, 14
HSM_KEY_STORAGE_ERROR, 16	HSM_OP_SIGNATURE_GENERATION_COMPRESSED_POINT,
HSM_KEY_STORE_AUTH, 16	10
HSM KEY STORE CONFLICT, 16	HSM_OP_SIGNATURE_GENERATION_INPUT_DIGEST,
HSM KEY TYPE AES 128, 8	10
HSM KEY TYPE AES 192 8	HSM OP SIGNATURE GENERATION INPUT MESSAGE

10	Hsm_api, 20
	hsm_cipher_one_go
HSM_OP_SIGNATURE_VERIFICATION_INPUT_DIC	
11	HSM_CIPHER_ONE_GO_ALGO_AES_CBC
HSM_OP_SIGNATURE_VERIFICATION_INPUT_ME	
12	HSM_CIPHER_ONE_GO_ALGO_AES_CCM
hsm_open_cipher_service, 21	Hsm_api, 9
hsm_open_fast_signature_generation_service, 24	HSM_CIPHER_ONE_GO_ALGO_AES_ECB
hsm_open_fast_signature_verification_service, 28	Hsm_api, 9
hsm_open_hash_service, 31	HSM_CIPHER_ONE_GO_FLAGS_DECRYPT
hsm_open_key_management_service, 18	Hsm_api, 10
hsm_open_key_store_service, 18	HSM_CIPHER_ONE_GO_FLAGS_ENCRYPT
hsm_open_rng_service, 30	Hsm_api, 9
hsm_open_session, 16	hsm_close_cipher_service
hsm_open_signature_generation_service, 23	Hsm_api, 23
hsm_open_signature_verification_service, 26	hsm_close_fast_signature_generation_service
HSM OUT OF MEMORY, 16	Hsm api, 26
	— · ·
hsm_rng_get_random, 30	hsm_close_fast_signature_verification_service
HSM_RNG_NOT_STARTED, 16	Hsm_api, 29
hsm_signature_generation, 23	hsm_close_hash_service
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	:
10	hsm_close_key_management_service
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	R1_ <del>l2\\$16</del> \ <u>_</u> 2\piA_2\256,
10	hsm_close_key_store_service
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	_R1_ <b>H3S</b> 44_SabilA <mark>18</mark> 84,
11	hsm_close_rng_service
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	
11	hsm close session
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	
11	hsm_close_signature_generation_service
HSM_SIGNATURE_SCHEME_ECDSA_BRAINPOOL	
11	· · _
HSM_SIGNATURE_SCHEME_ECDSA_NIST_P224_	hsm_close_signature_verification_service
	·
10	HSM_CMD_NOT_SUPPORTED
HSM_SIGNATURE_SCHEME_ECDSA_NIST_P256_	·
10	hsm_err_t
HSM_SIGNATURE_SCHEME_ECDSA_NIST_P384_	_SHA_ <del>H</del> \$\$14,_api, 15
10	hsm_fast_signature_generation
hsm_signature_scheme_id_t, 15	Hsm_api, 25
hsm_signature_verification, 27	hsm_fast_signature_verification
hsm_svc_cipher_flags_t, 13	Hsm_api, 29
hsm_svc_fast_signature_generation_flags_t, 13	HSM_GENERAL_ERROR
hsm_svc_fast_signature_verification_flags_t, 13	Hsm_api, 16
hsm_svc_hash_flags_t, 13	hsm generate key
	_ <u> </u>
hsm_svc_key_management_flags_t, 13	Hsm_api, 19
HSM_SVC_KEY_STORE_FLAGS_CREATE, 6	HSM_HASH_ALGO_SHA2_224
HSM_SVC_KEY_STORE_FLAGS_DELETE, 6	Hsm_api, 12
hsm_svc_key_store_flags_t, 13	HSM_HASH_ALGO_SHA2_256
HSM_SVC_KEY_STORE_FLAGS_UPDATE, 6	Hsm_api, 12
hsm_svc_rng_flags_t, 13	HSM_HASH_ALGO_SHA2_384
hsm_svc_signature_flags_t, 13	Hsm_api, 12
HSM UNKNOWN HANDLE, 16	hsm_hash_algo_t
HSM_UNKNOWN_ID, 16	Hsm_api, 15
HSM_UNKNOWN_KEY_STORE, 16	hsm_hash_one_go
	<del>-</del>
HSM_VERIFICATION_STATUS_FAILURE, 12	Hsm_api, 31
HSM_VERIFICATION_STATUS_SUCCESS, 12	hsm_hdl_t
hsm_verification_status_t, 15	Hsm_api, 13
_butterfly_key_expansion	HSM_ID_CONFLICT

Hsm api, 16	Hsm_api, 14
HSM_INVALID_ADDRESS	HSM_OP_FAST_SIGNATURE_GENERATION_COMPRESSED_POINT
Hsm_api, 16	Hsm_api, 11
_ ·	_ •
HSM_INVALID_LIFECYCLE	HSM_OP_FAST_SIGNATURE_GENERATION_INPUT_DIGEST
Hsm_api, 16	Hsm_api, 11
HSM_INVALID_MESSAGE	HSM_OP_FAST_SIGNATURE_GENERATION_INPUT_MESSAGE
Hsm_api, 16	Hsm_api, 11
HSM_INVALID_PARAM	hsm_op_fast_signature_ver_flags_t
Hsm_api, 16	Hsm_api, 14
HSM_KEY_INFO_PERMANENT	HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_DIGEST
Hsm_api, 8	Hsm_api, 12
hsm_key_info_t	HSM_OP_FAST_SIGNATURE_VERIFICATION_INPUT_MESSAGE
Hsm_api, 15	Hsm_api, 12
HSM_KEY_STORAGE_ERROR	hsm_op_key_gen_flags_t
Hsm_api, 16	Hsm_api, 14
HSM_KEY_STORE_AUTH	HSM_OP_KEY_GENERATION_FLAGS_CREATE_PERSISTENT
Hsm_api, 16	
HSM_KEY_STORE_CONFLICT	HSM_OP_KEY_GENERATION_FLAGS_CREATE_TRANSIENT
Hsm_api, 16	Hsm_api, 8
HSM_KEY_TYPE_AES_128	HSM_OP_KEY_GENERATION_FLAGS_STRICT_OPERATION
Hsm_api, 8	Hsm_api, 8
_ •	HSM_OP_KEY_GENERATION_FLAGS_UPDATE
HSM_KEY_TYPE_AES_192	
Hsm_api, 8	Hsm_api, 8
HSM_KEY_TYPE_AES_256	HSM_OP_MANAGE_KEY_FLAGS_DELETE
Hsm_api, 8	Hsm_api, 9
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_224	HSM_OP_MANAGE_KEY_FLAGS_STRICT_OPERATION
Hsm_api, 7	Hsm_api, 9
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_256	hsm_op_manage_key_flags_t
Hsm_api, 7	Hsm_api, 14
HSM_KEY_TYPE_ECDSA_BRAINPOOL_R1_384	HSM_OP_MANAGE_KEY_FLAGS_UPDATE
Hsm_api, 7	Hsm_api, 9
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_224	hsm_op_signature_gen_flags_t
Hsm_api, 7	Hsm_api, 14
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_256	HSM_OP_SIGNATURE_GENERATION_COMPRESSED_POINT
Hsm_api, 7	Hsm_api, 10
HSM_KEY_TYPE_ECDSA_BRAINPOOL_T1_384	HSM_OP_SIGNATURE_GENERATION_INPUT_DIGEST
Hsm_api, 7	Hsm api, 10
HSM_KEY_TYPE_ECDSA_NIST_P224	HSM_OP_SIGNATURE_GENERATION_INPUT_MESSAGE
Hsm_api, 7	Hsm_api, 10
HSM_KEY_TYPE_ECDSA_NIST_P256	hsm_op_signature_ver_flags_t
Hsm api, 7	Hsm api, 14
HSM_KEY_TYPE_ECDSA_NIST_P384	HSM_OP_SIGNATURE_VERIFICATION_INPUT_DIGEST
Hsm_api, 7	Hsm_api, 11
hsm_key_type_t	HSM_OP_SIGNATURE_VERIFICATION_INPUT_MESSAGE
Hsm_api, 15	Hsm_api, 12
hsm_manage_key	hsm_open_cipher_service
Hsm_api, 19	Hsm_api, 21
HSM_NO_ERROR	hsm_open_fast_signature_generation_service
Hsm_api, 16	Hsm_api, 24
HSM_NVM_ERROR	hsm_open_fast_signature_verification_service
Hsm_api, 16	Hsm_api, 28
hsm_op_but_key_exp_flags_t	hsm_open_hash_service
Hsm_api, 14	Hsm_api, 31
hsm_op_cipher_one_go_algo_t	hsm_open_key_management_service
Hsm_api, 14	Hsm_api, 18
hsm_op_cipher_one_go_flags_t	hsm_open_key_store_service
Hsm_api, 14	Hsm_api, 18
hsm_op_fast_signature_gen_flags_t	hsm_open_rng_service

Hans sui	00		Hama ani 40
Hsm_api,		LICA	Hsm_api, 13
hsm_open_ses		HOIV	1_UNKNOWN_HANDLE
Hsm_api,		LICA	Hsm_api, 16
	nature_generation_service	поіч	I_UNKNOWN_ID
Hsm_api,		LICA	Hsm_api, 16
	nature_verification_service	HOIV	I_UNKNOWN_KEY_STORE
Hsm_api,		LICA	Hsm_api, 16
HSM_OUT_OF		поіч	1_VERIFICATION_STATUS_FAILURE
Hsm_api,		LICA	Hsm_api, 12
hsm_rng_get_i		ПЭІ	1_VERIFICATION_STATUS_SUCCESS
Hsm_api,		hem	Hsm_api, 12 _verification_status_t
HSM_RNG_NO		115111	
Hsm_api,			Hsm_api, 15
hsm_signature	<del></del>	innu	t_address_ext
Hsm_api,			
		_224	<u>-ФНА_256_коу_тападоттотт_агдо_к, о г</u>
Hsm_api,	IU	kev.	identifier-
	URE_SCHEME_ECDSA_BRAINPOOL_R1	_23 <del>6</del>	- SHA_256 op_generate_key_args_t, 33
Hsm_api,	IU	kev,	
	URE_SCHEME_ECDSA_BRAINPOOL_R1	_384	_SHA_384 op_generate_key_args_t, 33
Hsm_api,	III	kev.	
	URE_SCHEME_ECDSA_BRAINPOOL_T1	224	open_svc_key_store_args_t, 35
Hsm_api,	III	kev.	. – – . – . – .
	URE_SCHEME_ECDSA_BRAINPOOL_T1	256	TSHA_256 Top_generate_key_args_t, 33
Hsm_api,	11	004	
HSM_SIGNAL	URE_SCHEME_ECDSA_BRAINPOOL_T1	max	SHA 384 Tupdates number
Hsm_api,	11 URE_SCHEME_ECDSA_NIST_P224_SHA	050	open_svc_key_store_args_t, 35
HSM_SIGNAL	URE_SCHEME_ECDSA_NIST_P224_SHA	_256	
Hsm_api,	TO URE_SCHEME_ECDSA_NIST_P256_SHA	op_c	generate_key_args_t, 32
HSM_SIGNAL	URE_SCHEME_ECDSA_NIST_P256_SHA	_256	flags, 33
Hsm_api,		004	key_identifier, 33
	URE_SCHEME_ECDSA_NIST_P384_SHA	_384	key_info, 33
Hsm_api,			key_type, 33
hsm_signature			output_size, 33
Hsm_api,		oper	n_session_args_t, <mark>33</mark>
hsm_signature			operating_mode, 34
Hsm_api,			rsv, 34
hsm_svc_ciphe			session_priority, 34
Hsm_api,		oper	n_svc_key_management_args_t, 34
	_signature_generation_flags_t		flags, 34
Hsm_api,			input_address_ext, 34
	_signature_verification_flags_t		output_address_ext, 34
Hsm_api,			rsv, 35
hsm_svc_hash		oper	n_svc_key_store_args_t, 35
Hsm_api,			authentication_nonce, 35
	management_flags_t		flags, 35
Hsm_api,			key_store_identifier, 35
	Y_STORE_FLAGS_CREATE		max_updates_number, 35
Hsm_api,			rsv, 35
	Y_STORE_FLAGS_DELETE	oper	ating_mode
Hsm_api,			open_session_args_t, 34
hsm_svc_key_		outp	ut_address_ext
Hsm_api,			open_svc_key_management_args_t, 34
	EY_STORE_FLAGS_UPDATE	outp	ut_size
Hsm_api,			op_generate_key_args_t, 33
hsm_svc_rng_			
Hsm_api,		rsv	
hsm_svc_signa	ature_tlags_t		open_session_args_t, 34

```
open_svc_key_management_args_t, 35
open_svc_key_store_args_t, 35
session_priority
open_session_args_t, 34
```