

Basic Communication Manager Design

By: Nadeen Adel

Table Of Content:


Table Of Content:	1
1. Introduction:	2
1. High Level Design:	3
2.1 Layered Architecture:	3
2.2 Modules Description:	3
2.3 Drivers' Documentation:	4
2.3.1 DIO:	4
2.3.2 UART:	5
2.3.3 LED:	5
3. Low Level Design:	6
3.1Flowcharts:	6
3.2 Configurations:	9
3.2.1 DIO:	9
3.2.3 UART:	12
3.2.3 LED:	16
BCM APIs:	17
UML:	20
BCM State Machine:	20
BCM Sequence Diagram:	21

1. Introduction:

This project involves designing essential functions and APIs (Application Programming Interfaces) for the BCM, ensuring its initialization, proper termination, single-byte data transmission, and multi-byte data transfer capabilities. The BCM's functionalities will be managed through a series of well-defined functions that follow the specifications provided in the tables. These functions aim to make the BCM easy to integrate into a wide range of embedded systems, enabling developers to harness the full potential of this versatile communication module.

1. High Level Design:

2.1 Layered Architecture:



2.2 Modules Description:

• **DIO**: controls GPIO pins.

• UART:

to send / receive (communicate) with other MCUs.

• LED:

controls led state in the program.

BCM:

communication manager that manages communicating between different MCUs.

• App:

Contains main logic of the code.

2.3 Drivers' Documentation:

2.3.1 DIO:

```
* Initializes a specific digital pin based on the provided configuration.

* Operam config_ptr: Pointer to the configuration structure for the pin.
* Greturn: function error state.
EN_dioError_t DIO_Initpin(ST_DIO_ConfigType *config_ptr);
^{\star} Writes a digital value (HIGH or LOW) to a specific digital pin on a given port.
* @param port: Port to which the pin belongs.
* @param pin: Specific pin to write to.
* @param value: Value to be written (HIGH or LOW).
* @return: function error state.
EN_dioError_t DIO_WritePin(EN_dio_port_t port, EN_dio_pin_t pin, EN_dio_value_t value);
\star Reads the digital value from a specific digital pin on a given port and stores it in the specified location.
* @param port: Port from which the pin should be read.
 * @param pin: Specific pin to read.
* @param value: Pointer to store the read value.
* @return: function error state.
EN_dioError_t DIO_read(EN_dio_port_t port, EN_dio_pin_t pin, u8 *value);
^{\star} Toggles the state of a specific digital pin on a given port.
* @param port: Port to which the pin belongs.
* @param pin: Specific pin to toggle.
* Greturn: function error state.
EN_dioError_t DIO_toggle(EN_dio_port_t port, EN_dio_pin_t pin);
```

2.3.2 UART:

```
/*this function initailizes uart
-return: error state of the UART module*/
enu_uartErrorState_t MUART_init(const ST_USART_CONFIG *config);

//*this function is used to send a byte of data via UART
-return: error state of the UART module*/
enu_uartErrorState_t MUART_sendByte(u8 u8_a_data);

//*this function is used to receive a byte of data via UART
-return: error state of the UART module*/
enu_uartErrorState_t MUART_receiveByte(u8* pdata);

//*this function is used to send a string of data via UART
-return: error state of the UART module*/
enu_uartErrorState_t MUART_sendString(u8* pdata);
```

2.3.3 LED:


```
/*Enum for error state*/
typedef enum
] {
    LED OK,
    LED NOK
    }EN ledError t;
    /*struct to store led attributes*/
typedef struct LEDS{
    u8 port;
    u8 pin;
    u8 state;
}LEDS;
/*initializes led according to given arguments */
EN ledError t HLED init(LEDS *led);
/*function to turn the LED on*/
EN ledError t HLED on (LEDS *led);
/*function to turn the LED off*/
EN ledError t HLED off(LEDS *led);
/*function to toggle the LED state*/
EN ledError t HLED toggle(LEDS *led);
```

3. Low Level Design:


3.1Flowcharts:

3.1.1 DIO:


EN_dioError_t DIO_WritePin(EN_dio_port_t port, EN_dio_pin_t pin, EN_dio_value_t value)



EN_dioError_t DIO_read(EN_dio_port_t port, EN_dio_pin_t pin, u8 *value)




3.1.2 **UART**:




3.1.3 LED:


EN_ledError_t HLED_init(LEDS *led)




EN_ledError_t HLED_on(LEDS *led)




EN_ledError_t HLED_off(LEDS *led)



EN_ledError_t HLED_toggle(LEDS *led)



Flowchart for the whole driver:



3.2 Configurations:

3.2.1 DIO:

```
typedef struct{
   EN_dio_port_t dio_port;
   EN_dio_pin_t dio_pin;
EN_dio_mode_t dio_mode;
EN_dio_value_t dio_initial_value;
    EN_dio_pullup_t dio_pullup_resistor;
-}ST_DIO_ConfigType;
ST_DIO_ConfigType DIO_ConfigArray[];
ENUMS DIO PRECOMPILED
/*****************************
typedef enum{
   PA=0,
    PB,
    PC,
   PD
- }EN_DIO_Port_type;
!typedef enum{
   OUTPUT,
   INFREE,
   INPULL
-}EN_DIO_PinStatus_type;
typedef enum{
   LOW=0,
   HIGH,
-}EN_DIO_PinVoltage_type;
```

```
Pin modes
#define DIOMODE_INPUT 0
#define DIOMODE_OUTPUT 1
/* Pin Direction Setting
#define DIOOUTPUT_LOW 0
#define DIOOUTPUT_HIGH 1
/* Pin Pull Up Value
#define DIOINPUT_FLOATING 0
#define DIOINPUT_PULLUP 1
/* Pin Pull Up Configuration
#define DIOPULLUP_DISABLED 0
#define DIOPULLUP_ENABLED 1
```

```
typedef enum{
  DIO PORTA,
  DIO PORTB,
  DIO PORTC,
  DIO PORTD
-}EN dio port t;
/******************************
             DIO PINS
typedef enum{
  DIO PINO,
  DIO PIN1,
  DIO PIN2,
  DIO PIN3,
  DIO PIN4,
  DIO PIN5,
  DIO PIN6,
  DIO PIN7
-}EN_dio_pin_t;
/*****************************
             DIO PIN MODE DIRECTION
/************************
typedef enum{
  DIO MODE INPUT,
  DIO MODE OUTPUT
- }EN_dio_mode_t;
DIO PIN VALUE
/*****************************
typedef enum{
  DIO HIGH,
  DIO LOW
-}EN_dio_value_t;
/*****************************
             DIO PIN PULL UP CONFIG
typedef enum{
  DIO PULLUP DISABLED,
  DIO PULLUP ENABLED
-}EN dio pullup t;
```

3.2.3 UART:

```
/*USART SYNCHRONIZATION MODE OPTIONS:
USART ASYNC MODE
USART SYNC MODE
_*/
#define USART SET SYNCH MODE USART SYNC MODE
]/*USART SPEED MODE OPTIONS:
 USART NORMAL SPEED
 USART DOUBLE SPEED
_*/
#define USART SET SPEED USART NORMAL SPEED
]/*USART PARITY OPTIONS :
USART NO PARITY
USART_ODD_PARITY
USART EVEN PARITY
_*/
1/*USART DATA SIZE OPTIONS :
USART DATA SIZE 5
USART DATA SIZE 6
 USART DATA SIZE 7
 USART DATA SIZE 8
 USART DATA SIZE 9
1/*USART STOP BITS OPTIONS :
USART ONE STOP BIT
 USART TWO STOP BITS
#define USART SET STOP BITS USART TWO STOP BITS
]/*USART BAUD RATE OPTIONS
 BAUD 2400
 BAUD 4800
 BAUD 9600
 BAUD 14400
 BAUD 19200
 BAUD 28800
 BAUD 38400
_*/
#define USART SET BAUD RATE BAUD 9600
```

```
//*USART SYNCHRONIZATION MODE OPTIONS:
 USART ASYNC MODE
 USART SYNC MODE
-*/
typedef enum EN_USART_SET_MODE{
    USART ASYNC MODE=0,
     USART SYNC MODE
     }EN USART SET MODE;
-/*USART SPEED MODE OPTIONS:
 USART NORMAL SPEED
 USART DOUBLE SPEED
*/
typedef enum EN USART SET SPEED{
 USART NORMAL SPEED=0,
 USART DOUBLE SPEED
}EN USART SET SPEED;
USART NO PARITY
 USART ODD PARITY
 USART EVEN PARITY
typedef enum EN_USART_SET_PARITY{
 USART NO PARITY=0,
 USART ODD PARITY,
 USART EVEN PARITY
}EN USART SET PARITY;
USART DATA SIZE 5
 USART DATA SIZE 6
 USART DATA SIZE 7
 USART DATA SIZE 8
 USART DATA SIZE 9
-*/
typedef enum EN USART SET DATA SIZE {
      USART DATA SIZE 5=0,
      USART DATA SIZE 6,
      USART DATA SIZE 7,
     USART DATA SIZE 8,
     USART DATA SIZE 9
     }EN USART SET DATA SIZE;
```

```
typedef enum EN USART SET STOP BITS{
    USART ONE STOP BIT=0,
    USART TWO STOP BITS
    }EN USART SET STOP BITS;
-/*USART BAUD RATE OPTIONS
 BAUD 2400
 BAUD 4800
 BAUD 9600
 BAUD 14400
 BAUD 19200
_*/
typedef enum EN USART SET BAUD RATE {
     BAUD 2400=2400,
     BAUD 4800=4800,
     BAUD_9600=9600,
     BAUD 14400=14400,
     BAUD 19200=19200
}EN USART SET BAUD RATE;
]/*CPU FREQUENCY OPTIONS
 FCPU 4MHZ
 FCPU 8MHZ
 FCPU 16MHZ
_*/
typedef enum EN USART SET FCPU{
    FCPU 4MHZ=4000000,
    FCPU 8MHZ=8000000,
    FCPU 16MHZ=16000000
     }EN USART SET FCPU;
jtypedef struct ST USART CONFIG{
        EN USART SET MODE SYNC MODE;
        EN USART SET FCPU FCPU;
        EN USART SET BAUD RATE BAUD RATE;
        EN USART SET SPEED SPEED MODE;
        EN USART SET PARITY PARITY MODE;
        EN USART SET STOP BITS STOP BIT;
         EN USART SET DATA SIZE DATA SIZE;
     }ST_USART_CONFIG;
```

```
const ST USART CONFIG st g USARTconf = {
    .SYNC MODE = USART SYNC MODE,
    .FCPU = FCPU 8MHZ,
    .BAUD_RATE = BAUD_9600,
    .SPEED_MODE = USART_NORMAL_SPEED,
    .PARITY MODE = USART EVEN PARITY,
    .STOP_BIT = USART_TWO_STOP_BITS,
    .DATA_SIZE = USART_DATA_SIZE_8,
};
3.2.3 LED:
茴 /********************************
                    Typedefs
/*Enum for error state*/
 typedef enum
∃ {
    LED OK,
    LED NOK
    }EN ledError t;
    /*struct to store led attributes*/
typedef struct LEDS{
    u8 port;
    u8 pin;
   u8 state;
-}LEDS;
```

BCM APIs:

BCM_init()

Function Name	bcm_init
Syntax	enu_system_status_t bcm_init (str_bcm_instance_t* ptr_str_bcm_instance);
Sync/Async	Synchronous
Reentrancy	Non Reentrant
Parameters (in):	ptr_str_bcm_instance: Address of the BCM Instance
Parameters (out):	None
Parameters (in, out):	None
Return:	BCM_STATUS_SUCCESS: In case of Successful Operation BCM_STATUS_INVALID_STATE: In case of Failed Operation

BCM_deinit()

Function Name	bcm_deinit
Syntax	enu_system_status_t bcm_init (str_bcm_instance_t* ptr_str_bcm_instance);
Sync/Async	Synchronous
Reentrancy	Non Reentrant
Parameters (in):	ptr_str_bcm_instance: Address of the BCM Instance
Parameters (out):	None
Parameters (in, out):	None
Return:	BCM_STATUS_SUCCESS: In case of Successful Operation BCM_STATUS_INVALID_STATE: In case of Failed Operation

BCM_send()

Function Name	BCM_send
Syntax	enu_system_status_t bcm_init (str_bcm_instance_t* ptr_str_bcm_instance,u8* ptr_u8_a_byte);
Sync/Async	Asynchronous
Reentrancy	Reentrant
Parameters (in):	ptr_str_bcm_instance: Address of the BCM Instance ptr_u8_a_byte : Address of the sending byte
Parameters (out):	None
Parameters (in, out):	None
Return:	BCM_STATUS_SUCCESS: In case of Successful Operation BCM_STATUS_INVALID_STATE: In case of Failed Operation

BCM_send_n()


Function Name	BCM_send_n
Syntax	enu_system_status_t bcm_init (str_bcm_instance_t* ptr_str_bcm_instance,u8* ptr_u8_a_byte ,uint16 uint16_a_size);
Sync/Async	Asynchronous
Reentrancy	Reentrant
Parameters (in):	ptr_str_bcm_instance: Address of the BCM Instance ptr_u8_a_byte: Address of the sending bytes uint16_a_size: Variable contains data size
Parameters (out):	None
Parameters (in, out):	None
Return:	BCM_STATUS_SUCCESS: In case of Successful Operation BCM_STATUS_INVALID_STATE: In case of Failed Operation

bcm_dispatcher ()


Function Name	BCM_dispatcher
Syntax	enu_system_status_t BCM_dispatcher(str_bcm_instance_t* ptr_str_bcm_instance)
Sync/Async	Synchronous
Reentrancy	Non Reentrant
Parameters (in):	ptr_str_bcm_instance: Address of the BCM Instance
Parameters (out):	None
Parameters (in, out):	None
Return:	BCM_STATUS_SUCCESS: In case of Successful Operation BCM_STATUS_INVALID_STATE: In case of Failed Operation

UML:

BCM State Machine:



BCM Class Diagram:



BCM Sequence Diagram:

