Ex. No. 5 CONNECT ARDUINO BOARD AND GLOW LED, READ ANALOG AND DIGITAL SENSORS SUCH AS RELAY, TEMPERATURE, HUMIDITY

AIM:

To connect an Arduino board with a DHT sensor and read the temperature and humidity.

REQUIREDCOMPONENTS:

- Arduino board (e.g., Arduino Uno)
- LED
- Resistor
- Relay module
- DHT11 or DHT22 Temperature and Humidity Sensor
- Jumper wires
- Breadboard

•

Experimental Setup:

Connecting the LED:

- Connect the longer leg (anode) of the LED to digital pin 13 on the Arduino.
- Connect the shorter leg (cathode) of the LED to a current-limiting resistor.
- Connect the other end of the resistor to the ground (GND) pin on the Arduino.

Connecting the Relay Module:

- Connect the signal pin of the relay module to digital pin 7 on the Arduino.
- Connect the VCC and GND of the relay module to the 5V and GND pins on the Arduino.

Connecting the DHT Sensor:

- Connect the sensor's VCC to the 5V pin on the Arduino.
- Connect the sensor's GND to the GND pin on the Arduino.
- Connect the sensor's data pin to digital pin 2 on the Arduino.

Programming the Arduino:

- Use the provided Arduino code to control the LED and read temperature and humidity data from the sensor.
- Upload the code to the Arduino board using the Arduino IDE.

```
Arduino code:
#include <DHT.h>
// Define the type of DHT sensor you're using (DHT11 or DHT22)
#define DHT TYPE DHT11
#define DHT PIN 2 // Connect the DHT sensor data pin to digital pin 2
int ledPin = 13; // LED connected to digital pin 13
int relayPin = 7; // Relay connected to digital pin 7
DHT dht(DHT PIN, DHT TYPE);
void setup() {
 pinMode(ledPin, OUTPUT);
 pinMode(relayPin, OUTPUT);
 Serial.begin(9600);
 dht.begin();
void loop() {
 // Read temperature and humidity from DHT sensor
 float temperature = dht.readTemperature();
 float humidity = dht.readHumidity();
 // Control LED based on temperature
 if (temperature > 25.0) {
  digitalWrite(ledPin, HIGH);
 } else {
  digitalWrite(ledPin, LOW);
 // Control relay based on humidity
 if (humidity > 60.0) {
  digitalWrite(relayPin, HIGH); // Turn on the relay
 } else {
  digitalWrite(relayPin, LOW); // Turn off the relay
 // Print temperature and humidity to Serial Monitor
 Serial.print("Temperature: ");
 Serial.print(temperature);
 Serial.print(" °C, Humidity: ");
 Serial.print(humidity);
```

```
Serial.println(" %");

delay(2000); // Delay for 2 seconds
}
```

Instructions:

- Make sure you have the necessary libraries installed. You can install the DHT sensor library through the Arduino Library Manager.
- Connect your Arduino board to your computer and upload the code using the Arduino IDE.
- Open the Serial Monitor in the Arduino IDE to see the temperature and humidity readings.
- Observe the LED and relay behavior based on the temperature and humidity conditions.

Note: Adjust the pin numbers in the code if you have connected the components to different pins on the Arduino.

Observations:

Observe the LED blinking at pin 13.

Monitor the Serial Monitor for temperature and humidity readings.

Analysis:

Interpret the temperature and humidity data obtained from the sensor.

Discuss how the LED behavior can be modified based on the temperature readings.

Pre-Lab Questions:

- 1. How can a temperature and humidity sensor be used in an industrial climate control system?
- 2. What are the advantages of using a relay in home automation applications?
- 3. How does reading sensor data through an Arduino help in smart agriculture?
- 4. What modifications would be needed to connect these sensors to an IoT-based monitoring system?
- 5. How would you design an automated emergency system using relays and temperature sensors?

Post-Lab Questions:

- 1. How can you improve this system to send real-time sensor data to a cloud server for remote monitoring?
- 2. What challenges did you face while interfacing sensors, and how can they be resolved in large-scale applications?
- 3. How would you modify this setup to create an energy-efficient smart lighting system?
- 4. What steps would be required to integrate an alert system (like a buzzer or SMS notification) when abnormal sensor readings are detected?
- 5. If the relay failed to switch ON/OFF a device, what could be the possible reasons, and how would you debug the issue?

ONCLUSION: hus the connection of an Arduino board with a DHT sensor was completed successfully.