

Sidebar▼

Home → Tutorials → Linux → Device Drivers → Linux Device Driver
Tutorial Part 19 - Kernel Thread

Device Drivers



Linux Device Driver Tutorial Part 19 - Kernel Thread

This is the Series on Linux Device Driver. The aim of this series is to provide easy and practical examples that anyone can understand. This is the Linux Device Driver Tutorial Part 19 - Kernel Thread.

Post Contents [hide]

- 1 Process
- 2 Threads
- 3 Thread Management
- 4 Types of Thread
 - 4.1 User Level Thread
 - 4.2 Kernel Level Thread
- 5 Kernel Thread Management Functions
 - 5.1 Create Kernel Thread
 - 5.1.1 kthread create
 - 5.2 Start Kernel Thread
 - 5.2.1 wake up process
 - 5.3 Stop Kernel Thread
 - 5.3.1 kthread stop
 - 5.4 Other functions in Kernel Thread
 - 5.4.1 kthread should stop
 - 5.4.2 kthread bind
- 6 Implementation
 - 6.1 Thread Function
 - 6.2 Creating and Starting Kernel Thread
 - 6.2.1 kthread run
 - 6.3 Stop Kernel Thread
- 7 Driver Source Code Kthread in Linux
- 8 MakeFile
- 9 Building and Testing Driver
 - 9.0.1 Share this:
 - 9.0.2 Like this:
 - 9.0.3 Related

Process

An executing instance of a program is called a process. Some operating systems use the term 'task' to refer to a program that is being executed. **Process** is a heavyweight process. The context switch between the process is time-consuming.

Threads

A *thread* is an independent flow of control that operates within the same address space as other independent flows of control within a process.

One process can have multiple threads, with each thread executing different code concurrently, while sharing data and synchronizing much more easily than cooperating processes. Threads require fewer system resources than processes and can start more quickly. Threads, also known as lightweight processes.

Some of the advantages of the thread, is that since all the threads within the processes share the same address space, the communication between the threads is far easier and less time consuming as compared to processes. This approach has one disadvantage also. It leads to several concurrency issues and require the synchronization mechanisms to handle the same.

Thread Management

Whenever we are creating a thread, it has to manage by someone. So that management follows like below.

- A thread is a sequence of instructions.
- CPU can handle one instruction at a time.
- To switch between instructions on parallel threads, the execution state needs to be saved.
- Execution state in its simplest form is a program counter and CPU registers.
- The program counter tells us what instruction to execute next.
- CPU registers hold execution arguments, for example, addition operands.
- This alternation between threads requires management.
- Management includes saving state, restoring state, deciding what thread to pick next.

Types of Thread

There are two types of threads.

- 1. User Level Thread
- 2. Kernel Level Thread

User Level Thread

In this type, the kernel is not aware of these threads. Everything is maintained by the user thread library. That thread library contains code for creating and destroying threads, for passing message and data between threads, for scheduling thread execution and for saving and restoring thread contexts. So all will be in User Space.

Kernel Level Thread

Kernel level threads are managed by the OS, therefore, thread operations are implemented in the kernel code. There is no thread management code in the application area.

Anyhow each type of thread has advantages and disadvantages too.

Now we will move into Kernel Thread Programming. First, we will see the functions used in a kernel thread.

Kernel Thread Management Functions

There are many functions used in Kernel Thread. We will see one by one. We can classify those functions based on functionalities.

- Create Kernel Thread
- Start Kernel Thread
- Stop Kernel Thread
- Other functions in Kernel Thread

For use the below functions you should include linux/kthread.h header file.

Create Kernel Thread kthread_create

```
create a kthread.
```

Where.

threadfn - the function to run until signal_pending(current).


data - data ptr for threadfn.

namefmt[] - printf-style name for the thread.

... - variable arguments

This helper function creates and names a kernel thread. But we need to wake up that thread manually. When woken, the thread will run **threadfn()** with data as its argument.

threadfn can either call do_exit directly if it is a standalone thread for which no one will call kthread_stop, or return when 'kthread_should_stop' is true (which means kthread_stop has been called). The return value should be zero or a negative error number; it will be passed to kthread_stop.



Start Kernel Thread wake_up_process

This is used to Wake up a specific process.

int wake_up_process (struct task_struct * p);

4

The process to be woken up.

Attempt to wake up the nominated process and move it to the set of runnable processes.

It **returns 1** if the process was woken up, **0** if it was already running.

It may be assumed that this function implies a write memory barrier before changing the task state if and only if any tasks are woken up.

Stop Kernel Thread kthread_stop

It stops a thread created by kthread create.

```
int kthread stop ( struct task struct *k);
```

Where,

k - thread created by **kthread_create**.

Sets **kthread_should_stop** for **k** to return **true**, wakes it and waits for it to exit. Your **threadfn** must not call **do_exit** itself if you use this function! This can also be called after **kthread_create** instead of calling **wake_up_process**: the thread will exit without calling **threadfn**.

It **Returns** the result of **threadfn**, or **-EINTR** if **wake_up_process** was never called.

Other functions in Kernel Thread kthread should stop

should this kthread return now?

```
int kthread should stop (void);
```

When someone calls **kthread_stop** on your kthread, it will be woken and this will return true. You should then return, and your return value will be passed through to **kthread_stop**.

kthread_bind

```
This is used to bind a just-created kthread to a cpu.

void kthread_bind (struct task_struct *k, unsigned int cpu);

Where,

k - thread created by kthread_create.

cpu - cpu (might not be online, must be possible) for k to run on.
```

Implementation Thread Function

First, we have to create our thread which has the argument of **void** * and should return **int** value. We should follow some conditions in our thread function. It is advisable.

- If that thread is a long run thread, we need to check kthread_should_stop() every time as because any function may call kthread_stop. If any function called kthread_stop, that time kthread_should_stop. We have to exit our thread function if true value been returned by kthread_should_stop.
- But if your thread function is not running long, then let that thread finish its task and kill itself using do_exit.

In my thread function, lets print something every minute and it is a continuous process. So let's check the **kthread_should_stop** every time. See the below snippet to understand.

```
1 int thread_function(void *pv)
2 {
3     int i=0;
4     while(!kthread_should_stop()) {
5         printk(KERN_INFO "In EmbeTronicX Thread Function %d\n", i++);
         msleep(1000);
7     }
8     return 0;
9 }
```

Creating and Starting Kernel Thread

So as of now, we have our thread function to run. Now, we will create

kernel thread using kthread_create and start the kernel thread using wake up process.

```
1 static struct task_struct *etx_thread;
2
3 etx_thread = kthread_create(thread_function,NULL,"eTx Thread");
4 if(etx_thread) {
5    wake_up_process(etx_thread);
6 } else {
7    printk(KERN_ERR "Cannot create kthread\n");
8 }
```

There is another function that does both processes (create and start). That is kthread_run(). You can replace both kthread_create and wake_up_process using this function.

kthread run

```
This is used to create and wake a thread.

kthread_run (threadfn, data, namefmt, ...);

Where,

threadfn - the function to run until signal_pending(current).

data - data ptr for threadfn.

namefmt - printf-style name for the thread.

... - variable arguments

Convenient wrapper for kthread_create followed by wake_up_process.

It returns the kthread or ERR_PTR(-ENOMEM).
```

You can see the below snippet which is using kthread_run.

```
1 stacic struct task_struct *etx_thread;
2
3 etx_thread = kthread_run(thread_function, NULL, "eTx Thread");
4 if(etx_thread) {
5    printk(KERN_ERR "Kthread Created Successfully...\n");
6 } else {
```

```
7  printk(KERN_ERR "Cannot create kthread\n");
8 }
```

Stop Kernel Thread

You can stop the kernel thread using **kthread_stop**. Use the below snippet to stop.

```
1 kthread_stop(etx_thread);
```

Driver Source Code - Kthread in Linux

Kernel thread will start when we insert the kernel module. It will print something every second. When we remove the module that time it stops the kernel thread. Let's see the source code.

```
#include <linux/kernel.h>
2 #include <linux/init.h>
3 #include <linux/module.h>
4 #include <linux/kdev t.h>
5 #include <linux/fs.h>
6 #include <linux/cdev.h>
7 #include <linux/device.h>
8 #include<linux/slab.h>
                                      //kmalloc()
9 #include<linux/uaccess.h>
                                       //copy_to/from_user()
10 #include <linux/kthread.h>
                                       //kernel threads
11 #include <linux/sched.h>
                                       //task_struct
12 #include <linux/delay.h>
13
14
15 dev_t dev = 0;
16 static struct class *dev_class;
17 static struct cdev etx_cdev;
18
19 static int __init etx_driver_init(void);
20 static void __exit etx_driver_exit(void);
21
22 static struct task struct *etx thread;
23
24
25 /********* Driver Fuctions **************/
26 static int etx open(struct inode *inode, struct file *file);
27 static int etx_release(struct inode *inode, struct file *file);
28 static ssize_t etx_read(struct file *filp,
                  char __user *buf, size_t len,loff_t * off);
29
30<sup>4</sup> static ssize_t etx_write(struct file *filp,
                  const char *buf, size_t len, loff_t * off);
       thread_function(void *pv);
35
36
   int thread_function(void *pv)
37
38
       int i=0;
39
       while(!kthread should stop()) {
```

```
40
             printk(KERN INFO "In EmbeTronicX Thread Function %d\n", i++);
41
            msleep(1000);
42
        }
43
        return 0;
44
    }
45
    static struct file_operations fops =
46
47
48
                             = THIS_MODULE,
             .owner
49
                             = etx_read,
             .read
50
                             = etx_write,
             .write
51
                             = etx_open,
             .open
52
                             = etx_release,
             .release
53
    };
54
55
    static int etx_open(struct inode *inode, struct file *file)
56
             printk(KERN_INFO "Device File Opened...!!!\n");
57
58
             return 0;
    }
59
60
    static int etx_release(struct inode *inode, struct file *file)
61
62
             printk(KERN_INFO "Device File Closed...!!!\n");
63
64
             return 0;
65
    }
66
67
    static ssize_t etx_read(struct file *filp,
                     char __user *buf, size_t len, loff_t *off)
68
69
    {
             printk(KERN_INFO "Read function\n");
70
71
72
             return 0;
73
74
    static ssize_t etx_write(struct file *filp,
75
                     const char __user *buf, size_t len, loff_t *off)
76
    {
77
             printk(KERN_INFO "Write Function\n");
78
             return len;
79
    }
80
    static int __init etx_driver_init(void)
81
82
    {
83
             /*Allocating Major number*/
84
             if((alloc_chrdev_region(&dev, 0, 1, "etx_Dev")) <0){</pre>
85
                     printk(KERN_INFO "Cannot allocate major number\n");
86
                     return -1;
87
88
             printk(KERN INFO "Major = %d Minor = %d \n", MAJOR(dev), MINOR(dev));
89
90
             /*Creating cdev structure*/
91
            cdev_init(&etx_cdev,&fops);
924
03
             /*Adding character device to the system*/
             if((cdev add(\&etx cdev, dev, 1)) < 0){
                 printk(KERN_INFO "Cannot add the device to the system\n");
                 goto r_class;
98
99
             /*Creating struct class*/
100
             if((dev_class = class_create(THIS_MODULE, "etx_class")) == NULL){
101
                 printk(KERN_INFO "Cannot create the struct class\n");
102
                 goto r class:
```

```
103
            }
104
             /*Creating device*/
105
106
            if((device_create(dev_class,NULL,dev,NULL,"etx_device")) == NULL){
107
                 printk(KERN INFO "Cannot create the Device \n");
108
                 goto r_device;
109
            }
110
111
            etx_thread = kthread_create(thread_function, NULL, "eTx Thread");
112
            if(etx_thread) {
                 wake_up_process(etx_thread);
113
114
            } else {
115
                 printk(KERN_ERR "Cannot create kthread\n");
116
                 goto r_device;
117
118 #if 0
            /* You can use this method to create and run the thread */
119
120
            etx_thread = kthread_run(thread_function, NULL, "eTx Thread");
121
            if(etx_thread) {
122
                 printk(KERN_ERR "Kthread Created Successfully...\n");
123
            } else {
124
                 printk(KERN_ERR "Cannot create kthread\n");
125
                  goto r_device;
126
127 #endif
            printk(KERN INFO "Device Driver Insert...Done!!!\n");
128
129
        return 0;
130
131
132 r_device:
133
            class_destroy(dev_class);
134 r_class:
135
            unregister_chrdev_region(dev,1);
136
            cdev_del(&etx_cdev);
137
            return -1;
138 }
139
140 void __exit etx_driver_exit(void)
141 {
142
            kthread_stop(etx_thread);
143
            device_destroy(dev_class,dev);
144
            class_destroy(dev_class);
145
            cdev_del(&etx_cdev);
146
            unregister_chrdev_region(dev, 1);
147
            printk(KERN_INFO "Device Driver Remove...Done!!\n");
148 }
149
150 module_init(etx_driver_init);
151 module_exit(etx_driver_exit);
152
153 MODULE LICENSE("GPL");
154 MODULE AUTHOR("EmbeTronicX <embetronicx@gmail.com or admin@embetronicx.com>");
1551 MODULE DESCRIPTION("A simple device driver - Kernel Thread");
156 MODULE VERSION("1.14");
```

MakeFile

```
1 obj-m += driver.o
2
3 KDIR = /lib/modules/$(shell uname -r)/build
```

```
4
5 all:
6 make -C $(KDIR) M=$(shell pwd) modules
7
8 clean:
9 make -C $(KDIR) M=$(shell pwd) clean
```


Building and Testing Driver


- Build the driver by using Makefile (sudo make)
- Load the driver using sudo insmod driver.ko
- Then Check the dmesg


```
Major = 246 Minor = 0
Device Driver Insert...Done!!!
In EmbeTronicX Thread Function 0
In EmbeTronicX Thread Function 1
In EmbeTronicX Thread Function 2
In EmbeTronicX Thread Function 3
```


- So our thread is running now.
- Remove the driver using **sudo rmmod driver** to stop the thread.


In our next tutorial, we will discuss tasklet in the Linux device driver.











ü

