
NeoCharge BLE WiFi Setup (BETA)

To connect your NeoCharge Smart Splitter running firmware version 1900 and later, please follow the steps below.

To Identify if this guide will work for you, please make sure that the Smart Splitter is in Pairing mode (indicated by a flashing blue light).



Step 1:

Download the Espressif Development Provisioning app from the iOS or Android app stores:

iOS: App Store

Android: Play Store



Step 2:

Launch the app and click on "Provision Device" to get started

Provision Device


Looking for QR Code

Please position the camera to point at the QR Code.

Step 3:

Click on "I don't have a QR code" to manually search for devices.

I don't have a QR code




NeoCharge-DEV-6

Devices

Step 4:

Choose the device that starts with the prefix "NeoCharge" and matches the serial number of the Smart Splitter you are setting up

If you can't find anything, try re-booting your Smart Splitter or try moving closer (< 5ft) to your SmartSplitter.



Select Wi-Fi Network


Cancel

Step 6:

To continue setup of your device NeoCharge-DEV-6, please provide your Home Network's

credentials.

Choose your WiFi Network from the list or select "Join Other Network" if you don't see your network in the list



Step 7:

Your Smart Splitter will try to connect to your WiFi Network once you type in the password.

Sending Wi-Fi credentials.

Once your Smart Splitter is connected, you can return to the NeoCharge app to continue setup.

Confirming Wi-Fi connection.

Note: If the connection fails, please re-boot your Smart Splitter and re-start this guide from the beginning.

Ok