
NeoCharge BLE WiFi Setup (BETA)

To connect your NeoCharge Smart Splitter running firmware version 1900 and later, please follow the steps below.

To identify if this guide will work for you, please make sure that your Smart Splitter's serial number begins with P7. If your device's serial number begins with P6 and includes a R in the bottom right corner of the product label, your Smart Splitter is also running BLE firmware.



Step 1:

Download the Espressif Development Provisioning app from the iOS or Android app stores:


iOS: App Store

Android: Play Store



Step 2:


Launch the app and click on "Provision Device" to get started



Step 3:

Click on "I don't have a QR code" to manually search for devices.






Step 4:

Search NeoCharge in the prefix.

Choose the device that starts with the prefix "NeoCharge" and matches the serial number of the Smart Splitter you are setting up

If you can't find anything, try re-booting your Smart Splitter or try moving within 5ft of your SmartSplitter.



Step 5:


Enter the Proof of Possession code as "nema1450"

If you accidentally mis-type the proof of possession code, you will need to re-boot your Smart Splitter to re-try connection



Step 6:

Choose your WiFi Network from the list or select "Join Other Network" if you don't see your network in the list



Step 7:

Your Smart Splitter will try to connect to your WiFi Network once you type in the password.

Once your Smart Splitter is connected, you can return to the NeoCharge app to continue setup.

Note: If the connection fails, please reboot your Smart Splitter and re-start this guide from the beginning.