MAD

(Micro-Assembler/Disassembler)

MAD consists of two subprograms, the first is the assembler which converts your source code into machine code which can be understood by the 6809 micro-oricessor. The second part of MAD is the dis-assembler which converts machine code stored in RAM back into source code.

The advantages of using MAD over higher level languages such as BASIC, or PASCAL are firstly that the resulting programs run faster than their high level language counterparts, and secondly that they take up a much smaller area in RAM.

The MAD eprom resides at address 0000 and is designed to interface with a debug eprom.

ASSEMBLY

Once the MAD eprom is in place, and the Pegasus turned on, the menu should show "Assembler" as one of the options. - Simply type 'A' to invoke the assembler and it will then prompt for a starting address which should be given in the form of a four digit hexadecimal value.

At the beginning of each line, the hexadecimal address at which you are assembling is displayed. To leave the assembler type the (break) button which will return you to the menu. Otherwise the assembler will wait for a source code line.

Entering a Source Line

This is given in the form of a mnemonic, immediately followed by the register-designation if there is one (i.e. a register lable from the list: A,B,C,D,S,U,X, or Y where C represents the condition code register). Then type a space and the assembler will reply "HUH?" if they are an impossible cor ination, otherwise it will check to see if they are inherent, if so then the next line will be displayed and a source code line will be expected as before.

E.G. FROM BØØØ

BØØØ TSTA (sp)

BØØl RTB (sp)

HUH?

BØØ1 RTS (sp)

BØØ2 (break)

(returns to display menu)

If the command was not inherent then the cursor will move to the right and the assembler will wait for an operand. The parts of a source line are as follows:

BØØØ CMPA BC34

Address Mnemonic Register-designation Operand

again, end the argument with a space and the assembler will attempt to assemble the instruction and either return "HUH?" or wait for the next source code line.

E.G. BØØØ LDA #BØ Load the A accumulator with BØ (base 16)

BØØ2 BTS Incorrect mnemonic

HUH? Assembler returns for correct line B##2 BITA B300 Bit with contents of location B300

BØØ5

Register-designations

The optional register immediately following the mnemonic can be an accumulator (A,B, or D), and index register (Y, or Y), a stack pointer (S, or U), or the condition code register (C).

Note that in a transfer, or exchange instruction there is no register designation, and that the two registers involved comprise the operand.

Operands

Instructions can be one of seven basic types:

Inherent, Immediate, Extended, Direct, Pegister, Relative, or Indexed.

The type of the instruction specifies the form of operand used.

Inherent

Inherent has no operand, the assembler will not prompt for one. The mnemonic and the optional register designation comprise the complete instruction.

E.G. BBBB SYN .Synchronise to interrupt
BBB1 COMA .Compliment the A accumulator
BBB2 SW3 .Software interrupt 3

BØØ4

Immediate

Immediate addressing is specified by a # at the beginning of the operand. It means that the operand specifies a particular value to be used, not the address at which it can be found.

In all cases an operand must be specified for an immediate instruction. Various commands which are available in most addressing modes are not available in immediate mode as they would be meaningless e.g. STA #30, or COM #16.

The argument need not be a hexadecimal value, it can also be one or two ASCII characters. This is defined by a "immediately following the # and the number of characters should correspond to the size of the register.

i.e. for a 16 bit register use two characters and for an 8 bit register use only one character. Remember that these characters will have the most significant bit set to 0.

E.G. BØØØ LDA #30 . Load the A accumulator with 30 (HEX) BØØ2 CWA #20 . And the condition code register with . 20 and wait for interrupt

BØØ4 LDD #1010 . Load D with 1010 hex

B##7 LDA #"F . Load A with ASCII character'F' (=46hex)

B\$\$9 LDS #"EG . Load S with 'EG'

. Note that this is a suicidal instruction

B99D COM #B000 . Impossible instruction

Extended Addressing

BAND

Extended addressing defines an absolute address and is signified by a four digit hexadecimal number, which is used as an address. The byte which is stored at that address will be changed or used. See DIRECT, and SET.

E.G. B000 COM B300 Compliment byte at B300 B003 LDA B300 Load A from B300 B006 STD 1000 Store D at 1000 and 1001 (combined) B009

Direct Addressing

Direct addressing produces only one postbyte unlike extended addressing which uses two, thus direct addressing is more compact in RAM. The most significant byte of the address is defined by the direct page register. For both direct and extended addressing, type the full four character hexadecimal address then the assembler will compare the most significant

byte of the address with the direct page register defined in the SET command. If the most significant byte corresponds then direct addressing will be used, otherwise extended will be used. If you type a before the address then direct addressing will be used meaning that you are responsible for the direct page register holding the correct value. Likewise a before the address will force extended addressing regardless of the direct page register.

E.G.	B000	LDA	#10	
D. G.	THE RESERVE THE PERSON NAMED IN			
	B002	4.E.B	A, DP	Put 10 into direct page register
	В004	SET	10	Inform assembler that it can
				expect the direct page register
				to be 10
	B004	LDA	1632	Load A from 1632 - extended
	B007	STA	1032	Store A at 1032 - direct
The sales	B009	LDS	>1032	Load A from 1032 - extended
				(extra byte used unnecessarily)
	B00C	STA	<1632	Store A at 1632 - direct
				(actually this will access 1032
				NOT 1632)
				NOT 1032)

Register Addressing

Register addressing is used by the PSH, PUL, TFR, and EXG instructions. Transfer and exchange are both followed by a pair of equally sized registers separated by a comma. It should be noted that the assembler will not detect different sized registers and will attempt to assemble, but the disassembler will show an error if two unequally sized registers are transferred or exchanged.

The operand of Push or Pull instruction consists of a series of varied length registers separated by commas and may not contain the register pointing to the stack being used.

Only the direct page register is referred to by two characters while the rest are represented by a single letter as follows: A,B,C,D,X,Y,S,U,P, or DP

E.G.	B000	TFR A,B	Put A into B without changing A
	B002	EXG B, X	Exchange two different sized
			registers which is impossible.
	B004	EXG D, X	Exchange the content of D, and X
	B006	PULS A, B, U	Pull A,B,and U, off the S stack
	B008	PSHU D,S	Push D, and S onto user stack
	BOOD		

Relative Addressing

Relative addressing is used by the branch instructions, and requires a one or two byte offset for short or long branches respectively. Simply type the address to be branched to as the operand and the assembler will decide upon whether a short or long branch is required depending upon the difference between the current address and the address being branched to.

As for direct/extended decisions the assembler can be forced to use a small branch by a < sign preceding the address, or a long branch can be forced by a > sign.

E.G.	B000	BRA	B000	Short branch to B000
	B002	BRA	>B000	Long branch to B000
	B005	BRA	0000	Long branch to 0000
	B008	BRA	<0000	Short branch supposedly to 0000
				but will actually equal BRA Boon

Indexed addressing

The assembler uses indexed addressing as specified by Motorola barring a few exceptions. Firstly, as this assembler always assumes a hexadecimal value, the \$ used by them is unnecessary but the values A, B, and D(10,11), and 13 in decimal) must be specified as: OA, OB, and OD so that the assembler will recognize them as offsets rather than the registers A, B, and D.

Another difference between MAD indexed modes and Motorola modes is that, PCR for program counter relative is shortened to ,P. The final difference is that you can request 8, or 16 bit postbytes. To force a 16 bit offset to be used, precede the whole operant with a >. To request an 8 bit postbyte a <sign should be used.

X)
(X, O

Assembler Directives

Other than the standard set of mnemonics available in the 6809 there are five assembler directives to give the assembler instructions which are themselves not encoded into RAM but are operated upon instead, these are: FCB, FCC, SET, ORG and DIS.

FCB

FCB (form constant bytes) is used to store hexadecimal values, the final one terminating with a space.

E.G. B005 FCB 27,3B,(sp) Places the two bytes into RAM
Note that the commas are automatic

FCC

FCC (Form constant characters) is used to put a sequence of characters into RAM, it will echo a "symbol before the string. Note that spaces cannot be created by this command and should be done by FCB 20.

E.G. B000 FCC *Hello B005 Places characters H,e,l,l, and 0 in RAM with most significant bit = 0

SET

SET (Set direct page register). This directive is used to inform the assembler where it can assume the direct page register to be. The assembler will use this to decide upon whether it can use direct or extended addressing, as discussed under DIRECT. When the assembler is initially started the direct page register is assumed to be pointing to $\emptyset\emptyset$, so unless you have defined the direct page register, any addressing of the 00 page should be forced to be extended.

E.G. B000 LDA 0033

Remember that the SET command does not affect the direct page register as such, and this can only be done using a register mode instruction.

E.G. B000 SET B3 B000 Informs the assembler that it can assume the direct page register to be B3

ORG

ORG (origin) changes the address at which you are assembling without, affecting the memory into which you are about to assemble.

E.G. B080 ORG B000 B000 Stop assembling at B080 and continue at B000

DIS

DIS (Disassemble) enables you to invoke the disassembler without leaving the assembler. The start and end addresses are requested as usual for disassembly, and when the disassembly is finished, or a (break) is typed control is returned to the assembler without changing the address at which you were assembling.

E/G. B000 DIS FORM? B020 TO? B020 B020 NEG 00 B000 Invoke disassembler Start disassembling from B020 Stop disassembling after B020 Output from disassembler

Lables

Stored in MAD, is the complete list of user system monitor subroutines and system RAM allocation as defined elsewhere in the manual. When using these subroutines and RAM locations you are do not need to remember the address at which they reside.

To use these addresses simply type the first four letters of the location or subroutine desired instead of its address.

To use these addresses simply type the first four letters of the location or subroutine desired instead of its address.

E.G. B000 LDA INBU B003 JSR ECHO B006 Load A from input buffer Echo character

Note as you type this that after each line the label is removed and the hexadecimal address is inserted instead so do not type more than the first four letters. The labels stored in MAD can only be used for immediate direct, extended, and extended-indirect instructions. Contrary to the method shown in the system monitor subroutine list you do not need to jump via a lookup table.

i.e. instead of typing JMP F800 simply type JMP ECHO

This means that the labels will rarely used other than in direct mode.

DISASSEMBLY

The Disassembler is used to convert machine code stored in RAM into source code as would have been entered into the assembler with a few minor differences.

To start the disassembler ensure that the MAD EPROM is in place and that "Disassembler" appears in the menu, then type D and it will prompt for start and end addresses to be given in the form of two four digit hexadecimal values.

The first visible differences are that any ASCII characters that have been typed in under immediate mode will appear as hexadecimal. Long and Short branches will be indiscernable other than by examining the differences between the addresses

of two adjacent instructions, anything entered under the FCB, or FCC directives will appear ridiculous instructions, and direct instructions will only give the least significant byte as the address.

The final difference is that in PSH or PUL instructions the registers will appear in a specific order, not that which you specified, and the D register will appear as A,B.

If an impossible instruction is disassembled the mnemonic will appear as *** followed by the hexadecimal equivalent of the first byte of the instruction then the disassembler will attempt disassembling from the next byte onwards.

E.G. FROM? B000
TO? B001
B000 *** 71
B001 LDA ,X+ (cr)
(returns to menu)

Example Program

The following program will repeatedly output alphabets until the (break) key is typed.

A			
FROM?	B000		
B000	LDA .	#"A .	Load "A" into the A accumulator
B002	BSR	ECHO	Echo the character to the screen
B005	INCA		Increment the character
B005	CMPA	#"Z	Is the end of the alphabet reached
B008	BLS	B 0 02	If not them echo next character
BOGA	BRA	D-000	Otherwise reset A and continue
B 0 0C	(brea)	k)	

(returns to MENU)

Type M to enter Monitor Type G to start program Then type B000(.)

(the address of the program)