# ROBOTICS


Lecture 4 (W2L2)

Developing your own ROS Nodes

## Learning outcomes for today

# After attending this lecture and doing any associated reading you should be able to:

- Understand what a ROS Node/Nodelet is and how it fits into ROS's distributed architecture
- Understand and use Publishers, Subscribers and Callbacks
- Develop your own ROS nodes/Nodelets
- Visualise your ROS Nodes/Nodelets
- Understand Services and Action Servers



#### What is a ROS Node?

- Recall: ROS is a peer-to-peer network made up of a Master, Nodes, Messages and Services.
- **Nodes:** Independent processes that "do the actual work". Types of nodes include:
  - Low-level: "firmware" for sensors/actuators like LiDAR, Cameras, IMUs, Wheels, etc.
  - Mid-Level: "middleware" for things like pointcloud filtering, image processing, etc.
  - **High-level:** "software" like sensor fusion, navigation, localisation, etc.



•			
•			
,			


## Why Nodes?

#### Modular

- Each node has a single job
- Development is easier
- Enforces good design principles

#### Distributed

- Each node is its own process
- No single point of failure
- Nodes can restart automatically



### Low-Level Nodes

- Interface with Sensors
- Normally a ROS "wrapper" on the sensor's SDK
- "Real-Time"
- Perform low-level operations:
  - Get Sensor Data
  - Parse into ROS standards
  - Articulate Motors
- Have clear boundaries between nodes









,			
•			

## Node Example: Low-Level Driver


- Velodyne LiDAR Driver
  - Wrapper for Velodyne SDK
  - Exposes basic parameters
  - Converts raw data to ROS
     Messages (sensor\_msgs/Scan,
     sensor\_msgs/Pointcloud2)





#### Mid-Level Nodes

- "Glue" between other Nodes (lowhigh and high-high)
- Perform basic, well-defined operations:
  - Image Processing
  - Perception
  - Sensor Fusion
- No sensor interfaces, heavy processes
- "Real-Time"
- Ideal for Nodelets!




## Node Example: Kinect Processing

- Receive from Low-Level node:
  - Colour Image
  - Depth Image
- Mid-Node does processing:
  - Take depth Image
  - Match Pixels to Colour
  - Convert to 3D Pointcloud



## High-Level Nodes

- Perform more complex operations like:
  - Robot Position Estimation
  - Grasping
  - Pathplanning
- Have less well-defined node boundaries




## Node Example: Vel Processing

Could we split

• RTabMap

Huge node that do

- Receives Data from:
  - Low-Level Nodes:
    - Camera
    - IMU
    - LiDAR
  - Mid-Level Nodes:
    - Image Processing
    - Sensor Fusion
    - Transform Tree
  - High-Level Nodes:
    - Pathplanning
    - Exploration



What is a ROS Node

Nodes exist in "packages"


• A Package is:


The software organization unit of ROS code.

- A collection of nodes that perform similar or related tasks.
- Libraries, scripts, and/or other taskrelated artefacts (messages, services, etc.)
- Each node is a separate executable in the package




## Node Overview





## Communicating between Nodes

- ROS uses a Publish-Subscribe model.
- Typical Communication:
  - 1. Node A advertises topic
  - 2. Node B subscribes to topic
  - 3. Master handles setup (checking datatypes, establishing link, etc.)
  - 4. Node A publishes message to topic
  - 5. Message triggers callback in Node B




https://commons.wikimedia.org/wiki/File:ROS-master-node-topic.r

## Communicating between Nodes

#### **Message Examples:**

- geometry\_msgs
  - Represent common geometric primitives (Point, Quaternion, Pose, Twist, etc.)
- sensor\_msgs
  - Represent Sensor Data (Image, JointState, Pointcloud, etc.)
- nav msgs
  - Messages for Navigation (Odometry, Path, etc.)
- actionlib msgs
  - Messages that represent actions (GoalID, GoalStatus, etc.)
- Custom Messages
  - You can define your own messages
- ...etc




https://commons.wikimedia.org/wiki/File:ROS-master-node-topic.r

## Communicating between Nodes

ROS Provides other ways of passing information:


- Services
  - Allow nodes to send a request and receive a response
- Parameter Server
  - Allows parameters to be stored globally
- Action Server
  - Allows execution of long-running goals that can be cancelled, overwritten or introspected.



https://commons.wikimedia.org/wiki/File:ROS-master-node-topic.r

# Nodes in Code

How do I actually write a node?



#### Node Basics

• Creating a workspace:

```
% mkdir -p ~/ros_ws/src
% cd ~/ros_ws/src
```

• Creating a Package:


```
% catkin_create_pkg [package_name] rospy roscpp [other dependencies]
```

• Compiling Workspace (from ws root):

```
% cd ~/ros_ws % catkin_make
```


• Running a Node:

```
% rosrun [package_name] [node_name]
```



## Developing a Node

- Now our workspace is complied, we can begin coding!
- Lets work through an example...



## Node Example: Chatter C++

#### **Publisher**

```
#include "ros/ros.h"
#include "std_msgs/String.h"
#include <sstream>
int main(int argc, char **argv)
 ros::init(argc, argv, "talker");
 ros::NodeHandle n;
 ros::Publisher chatter pub =
n.advertise<std_msgs::String>("chatter", 1000);
 ros::Rate loop_rate(10);
 int count = 0;
 while (ros::ok())
   std_msgs::String msg;
   std::stringstream ss;
   ss << "hello world " << count;
   msg.data = ss.str();
   ROS_INFO("%s", msg.data.c_str());
   chatter_pub.publish(msg);
   ros::spinOnce();
   loop_rate.sleep();
   ++count;
 return 0;
```


#### Subscriber

```
#include "ros/ros.h"
#include "std_msgs/String.h"

void chatterCallback(const std_msgs::String::ConstPtr& msg)
{
   ROS_INFO("I heard: [%s]", msg->data.c_str());
}

int main(int argc, char **argv)
{
   ros::init(argc, argv, "listener");
   ros::NodeHandle n;
   ros::Subscriber sub = n.subscribe("chatter", 1000, chatterCallback);

   ros::spin();
   return 0;
}
```



ROS specific includes, "ros/ros.h" is the main ROS header file all ROS nodes include it. "std\_msgs/String.h" is the header file for the message type used here

- The "ros::init()" function needs to see argc and argv so that it can perform any ROS arguments and name remapping that were provided at the command line.
- The third argument to init() is the name of the node. You must call ros::init() before using any other part of the ROS system.

```
#include "ros/ros.h"
#include "std msgs/String.h"
#include <sstream>
int main(int argc, char **argv)
 ros::init(argc, argv, "talker");
  ros::NodeHandle n;
  ros::Publisher chatter pub =
n.advertise<std msgs::String>("chatter", 1000);
 ros::Rate loop rate(10);
  int count = 0;
  while (ros::ok())
    std msgs::String msg;
    std::stringstream ss;
    ss << "hello world " << count;
    msq.data = ss.str();
    ROS INFO("%s", msg.data.c str());
    chatter pub.publish (msq);
    ros::spinOnce();
    loop rate.sleep();
    ++count;
  return 0;
```


- **NodeHandle** is the main access point to communications with the ROS system.
- The first NodeHandle constructed will fully initialize this node, and the last NodeHandle destructed will close down the node.



- The advertise() function is how you tell ROS that you want to publish on a given topic name.
- After this advertise() call is made, the master node will notify anyone who is trying to subscribe to this topic name, and they will in turn negotiate a peerto-peer connection with this node.
- advertise() returns a Publisher object which allows you to publish messages on that topic through a call to publish().
- Once all copies of the returned Publisher object are destroyed, the topic will be automatically unadvertised.
- The second parameter to advertise() is the size of the message queue used for publishing messages.
   If messages are published more quickly than we can send them, the number here specifies how many messages to buffer up before throwing some away.

```
#include "ros/ros.h"
#include "std msgs/String.h"
#include <sstream>
int main(int argc, char **argv)
  ros::init(argc, argv, "talker");
  ros::NodeHandle n;
  ros::Publisher chatter pub =
a.advertise<std msgs::String>("chatter", 1000);
  ros::Rate loop rate(10);
  int count = 0;
  while (ros::ok())
    std msgs::String msg;
    std::stringstream ss;
    ss << "hello world " << count;
    msg.data = ss.str();
    ROS INFO("%s", msg.data.c str());
    chatter pub.publish (msq);
    ros::spinOnce();
    loop rate.sleep();
    ++count;
  return 0;
```

- A **ros::Rate** object allows you to specify a frequency that you would like to loop at.
- It will keep track of how long it has been since the last call to **Rate::sleep()**, and sleep for the correct amount of time.
- The constructor parameter is the frequency in Hz.



_			
_			
_			
_			
_			
_			
_			


- ros::ok() monitors that state of the ROS node.
- If the node gets a **shutdown call** (from either an internal or an external source), this returns **FALSE**.
- Otherwise, returns **TRUE**.


```
#include "ros/ros.h"
#include "std msgs/String.h"
#include <sstream>
int main(int argc, char **argv)
 ros::init(argc, argv, "talker");
  ros::NodeHandle n;
 ros::Publisher chatter pub =
n.advertise<std msgs::String>("chatter", 1000);
 ros::Rate loop rate(10);
  int count = 0;
  while (ros::ok())
    std msgs::String msg;
    std::stringstream ss;
    ss << "hello world " << count;
    msq.data = ss.str();
    ROS INFO("%s", msg.data.c str());
    chatter pub.publish(msg);
    ros::spinOnce();
    loop rate.sleep();
    ++count;
  return 0;
```

- This is a message object.
- You put your **data** here and **publish** it using the publisher
- Each message object has a header file.





- The **publish()** function is how you **send messages**.
- The parameter is the message object.
- The type of this object must agree with the type given as a template parameter to the advertise<>() call, as was done in the constructor above.





- Checks for any outstanding ROS operations.
- Not doing anything at the moment
- Will trigger "callbacks" when we have a subscriber.





#### Code Breakdown: Subscriber

- Subscribe to the chatter topic with the master.
- ROS will call the chatterCallback() function whenever a new message arrives.
- The 2nd argument is the queue size, in case we are not able to process messages fast enough we will start throwing away old messages as new ones arrive.
- NodeHandle::subscribe() returns a ros::Subscriber object, that you must hold on to until you want to unsubscribe. When the Subscriber object is destructed, it will automatically unsubscribe from the chatter topic.
- There are versions of the NodeHandle::subscribe()
  function which allow you to specify a class member
  function, or even anything callable by a
  Boost.Function object.

```
#include "ros/ros.h"
#include "std_msgs/String.h"

void chatterCallback(const std_msgs::String::ConstPtr& msg)
{
   ROS_INFO("I heard: [%s]", msg->data.c_str());
}

int main(int argc, char **argv)
{
   ros::init(argc, argv, "listener");
   ros::NodeHandle n;
   ros::Subscriber sub = n.subscribe("chatter", 1000, chatterCallback);

   ros::spin();
   return 0;
}
```



### Code Breakdown: Subscriber

- ros::spin() will enter a loop, pumping callbacks.
- With this version, all callbacks will be called from within this thread (the main one).
- ros::spin() will exit when Ctrl-C is pressed, or the node is shutdown by the master.

```
#include "ros/ros.h"
#include "std_msgs/String.h"

void chatterCallback(const std_msgs::String::ConstPtr& msg)
{
   ROS_INFO("I heard: [%s]", msg->data.c_str());
}

int main(int argc, char **argv)
{
   ros::init(argc, argv, "listener");
   ros::NodeHandle n;
   ros::Subscriber sub = n.subscribe("chatter", 1000, chatterCallback);

   ros::spin();
   return 0;
}
```

### Code Breakdown: Subscriber

- This is the callback function that will get called when a new message has arrived on the chatter topic.
- The message is passed in a boost shared\_ptr, which means you can store it off if you want, without worrying about it getting deleted underneath you, and without copying the underlying data.

```
#include "ros/ros.h"
#include "std_msgs/String.h"

void chatterCallback(const std_msgs::String::ConstPtr& msg)
{
    ROS_INFO("I heard: [%s]", msg->data.c_str());
}

int main(int argc, char **argv)
{
    ros::init(argc, argv, "listener");
    ros::NodeHandle n;
    ros::Subscriber sub = n.subscribe("chatter", 1000, chatterCallback);

    ros::spin();
    return 0;
}
```

## Compiling C++ Code

• All C++ code needs these three lines to compile:

\$ rosrun <package name> <exe name>

Creates **executable** to be compile

Adds "dependencies" to executable, these are things that must be compiled BEFORE the executable

Links libraries to executable

## Node Example: Chatter Python

Can we find the same elements as the C++ here?

#### **Publisher**

```
talker.py
#!/usr/bin/env python
import rospy
from std msgs.msg import String
    pub = rospy.Publisher('chatter', String, queue size=10)
    rospy.init node('talker', anonymous=True)
    rate = rospy.Rate(10) # 10hz
    while not rospy.is shutdown():
       hello str = "hello world %s" % rospy.get time()
       rospy.loginfo(hello str)
       pub.publish(hello_str)
       rate.sleep()
if name == ' main ':
   try:
        talker()
    except rospy.ROSInterruptException:
```

```
$ chmod +x talker.py
$ rosrun <package name> talker.py
```



listener.py

```
#!/usr/bin/env python
import rospy
from std_msgs.msg import String

def callback(data):
    rospy.loginfo(rospy.get_caller_id() + "I heard %s", data.data)

def listener():
    rospy.init_node('listener', anonymous=True)
    rospy.Subscriber("chatter", String, callback)
    rospy.spin()

if __name__ == '__main__':
    listener()
```

```
$ chmod +x listener.py
$ rosrun <package name> listener.py
```

### Launch Files: Basic

Assume we have a "rospy\_tutorials" package, with a "listener" node:

```
$ rosrun rospy_tutorials listener
```

#### OR

~/catkin\_ws/rospy\_tutorials/launch/listener.launch

```
<launch>
  <!-- a basic listener node -->
  <node name="listener-1" pkg="rospy_tutorials" type="listener" />
  </launch>
```

\$ roslaunch rospy\_tutorials listener.launch

•		
•		
•		
,		
•		
-		

#### Launch Files: Basic

```
launch>
    <!-- a basic listener node -->
    <node name="listener-1" pkg="rospy_tutorials" type="listener" />
    <!-- pass args to the listener node -->
    <node name="listener-2" pkg="rospy_tutorials" type="listener" args="-foo arg2" />
    <!-- a respawn-able listener node -->
    <node name="listener-3" pkg="rospy_tutorials" type="listener" respawn="true" />
    <!-- start listener node in the 'wg1' namespace -->
    <node ns="wg1" name="listener-wg1" pkg="rospy_tutorials" type="listener" respawn="true" /
    /launch>
```

## Launch Files: Arguments, Params and Remaps

```
<launch>
 <!-- declare arg to be passed in (with default value) -->
 <arg name="my arg" default="my value"/>
 <!-- a basic listener node with parameters -->
 <node name="listener-1" pkg="rospy tutorials" type="listener" respawn="true">
         <!-- read value of arg into private parameter -->
         <param name="my param" value="$(arg my arg)"/>
         <!-- nodes can have their own remap args -->
         <remap from="chatter" to="hello-1"/>
         <!-- you can set environment variables for a node -->
         <env name="ENV EXAMPLE" value="some value" />
  </node>
</launch>
```


More At: http://wiki.ros.org/roslaunch,


Limitations of Node Paradigm



#### **Nodelets**

- Cost-Free Message Passing
- Single Process with Shared Memory
- Good for closely related tasks
- Nodes can be ported to nodelets
- More Info: <a href="http://wiki.ros.org/nodelet/Tutorials">http://wiki.ros.org/nodelet/Tutorials</a>






•			
•			
•			
•			
_			


## Limitations of Publish/Subscribe Model




#### Services and Actions

- ROS provides alternative communication options:
  - Services:
    - Simple Request/Response interface
  - Actions:
    - More complex interface that includes cancellation requests, periodic feedback, etc.
    - Used for time consuming and complex services






,			
•			
•			
•			

## Visualising in RViz


- What is RVIZ?
  - ROS's standard visualisation tool
- What can it do?
  - Visualise most default ROS messages (std\_msgs, geometry\_msgs, nav\_msgs, etc.)
- Common Problems:
  - TF Errors: The <a href="mailto:frame\_id">frame\_id</a> of your message has to be in the TF tree for rviz to work.
- Should I use it?
  - YES! It's one of ROS's best features

#### • Running Rviz:

% rosrun rviz rviz



## In case you are feeling overwhelmed...




_
_


## Summary

# After attending this lecture and doing any associated reading you should be able to:

- Understand what a ROS Node/Nodelet is and how it fits into ROS's distributed architecture
- Understand and use Publishers, Subscribers and Callbacks
- Develop your own ROS nodes/Nodelets
- Visualise your ROS Nodes/Nodelets
- Understand Services and Action Servers



## Further reading




• Ch. 2 – Preliminaries

• Ch. 3 – Topics

• Ch. 4 – Services

• Ch. 5 - Actions



Ch. 2.6 - 2.7 – Nodes
 Topics and Messages

• Ch. 3 – Writing ROS Programs

• Ch. 6 – Launch Files



- Core Tutorials <a href="http://wiki.ros.org/ROS/Tutorials">http://wiki.ros.org/ROS/Tutorials</a>
- ActionLib Tutorials <a href="http://wiki.ros.org/actionlib\_tutorials/Tut
- Nodelet Tutorials <a href="http://wiki.ros.org/nodelet/Tutorials">http://wiki.ros.org/nodelet/Tutorials</a>