■ NetApp

Manage storage file clones

ONTAP 9.12.1 REST API reference

NetApp February 13, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9121/ontap/storage_file_clone_endpoint_overview.html on February 13, 2024. Always check docs.netapp.com for the latest.

Table of Contents

nage storage file clones	
Storage file clone endpoint overview	1
Create a clone of the file	1
Retrieve the clone split load of a node	9
Retrieve the volume file clone split load	16
Jpdate the maximum split load	20
Retrieve file clone split status of all volumes in the node	24
Retrieve file clone split status of all volumes	32
Retrieve information for a token	38
Create a new token to reserve the split load	44
Delete a specific file clone token	50
Retrieve a file clone token	53
Jpdate a file clone token	58

Manage storage file clones

Storage file clone endpoint overview

Overview

You can use these API's to create file clones, retrieve split status and manage split loads. These endpoints are used for cloning files within a volume, without taking much of extra space. Child and parent clones shares the unchanged blocks of data.

A file clone split operation detach child clone from its parent. Split operations use space. To ensure that file clone create operation is not affected by split, file clone tokens are use to reserve space. API endpoints can be used to update the validity and space reserved by token.

File clone APIs

The following APIs are used to perform the following operations:

– POST /api/storage/file/clone

– GET /api/storage/file/clone/split-status

– PATCH /api/storage/file/clone/split-loads/{node.uuid}

– GET /api/storage/file/clone/split-loads/{node.uuid}

– GET /api/storage/file/clone/split-loads

– GET /api/storage/file/clone/tokens/

– DELETE /api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

– PATCH /api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

Create a clone of the file

POST /storage/file/clone

Introduced In: 9.6

Creates a clone of the file.

Required Properties

- * source path
- destination path
- volume.uuid and volume.name Instance UUID and name of volume in which to create clone.

Optional Properties

- range Required only in the case of a sub file clone.
- autodelete Marks a cloned file for auto deletion.
- backup Cloned file is used as a backup.

Related Ontap commands

• volume file clone create

Creating file clones

The POST operation is used to create file clones with the specified attributes in body. Set the volume.name and volume.uuid to identify the volume.

Set source_path and destination_path to identify the file path of original and copied file. In case of full file clone, the new file is created using destination_path.

In case of a sub file clone, set range in the format source-file-block-number:

destination-file-block-number:

block-count. The API returns an error for the following overlapping conditions:

(a) if source and destination files are same and any of the source ranges overlap with any of the destination ranges.

(b) if any of the source ranges overlap amongst themselves.

If not provided, full file cloning is assumed.

Learn More

• [DOC /storage/file/clone]

Parameters

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When doing a POST, PATCH, or DELETE operation on a single record, the default is 0 seconds. This means that if an asynchronous operation is started, the server immediately returns HTTP code 202 (Accepted) along with a link to the job. If a non-zero value is specified for POST, PATCH, or DELETE operations, ONTAP waits that length of time to see if the job completes so it can return something other than 202. • Default value: 1 • Max value: 120 • Min value: 0
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Туре	Description
autodelete	boolean	Mark clone file for auto deletion.

Name	Туре	Description
destination_path	string	Relative path of the clone/destination file in the volume.
is_backup	boolean	Mark clone file for backup.
overwrite_destination	boolean	Destination file gets overwritten.
range	array[string]	List of block ranges for sub-file cloning in the format "source-file-block-number:destination-file-block-number:block-count"
source_path	string	Relative path of the source file in the volume.
token_uuid	string	UUID of existing clone token with reserved split load.
volume	volume	

Example request

Response

```
Status: 202, Accepted
```

Name	Туре	Description
job	job_link	

Example response

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

volume

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. • example: 028baa66-41bd- 11e9-81d5-00a0986138f7 • Introduced in: 9.6

file_clone

File clone

Name	Туре	Description
autodelete	boolean	Mark clone file for auto deletion.
destination_path	string	Relative path of the clone/destination file in the volume.
is_backup	boolean	Mark clone file for backup.
overwrite_destination	boolean	Destination file gets overwritten.

Name	Туре	Description
range	array[string]	List of block ranges for sub-file cloning in the format "source-file-block-number:destination-file-block-number:block-count"
source_path	string	Relative path of the source file in the volume.
token_uuid	string	UUID of existing clone token with reserved split load.
volume	volume	

job_link

Name	Туре	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve the clone split load of a node

GET /storage/file/clone/split-loads

Introduced In: 9.10

Retrieves the clone split load of a node.

Related Ontap Commands

• volume file clone split load show

Retrieving file clone split load related information

The GET operation can be used to retrieve information about clone split load data. Split load data is the data currently undergoing the split. There is a limit on split load data. This API communicates how much data is undergoing split and how much can still be processed.


```
# The API:
/api/storage/file/clone/split-loads
# The call:
curl -X GET "https://<mgmt ip>/api/storage/file/clone/split-loads" -H
"accept: application/hal+json"
# The response:
{
"records": [
    "node": {
      "uuid": "158d592f-a829-11eb-a47b-005056bb46d7",
      "name": "node1",
      " links": {
        "self": {
          "href": "/api/cluster/nodes/158d592f-a829-11eb-a47b-
005056bb46d7"
      }
    },
    "load": {
      "maximum": 35184372088832,
      "current": 0,
      "token reserved": 0,
      "allowable": 35184372088832
    },
    " links": {
      "self": {
```

```
"href": "/api/storage/file/clone/split-loads/158d592f-a829-11eb-
a47b-005056bb46d7"
  }
   }
  },
    "node": {
      "uuid": "9686b8d1-a828-11eb-80d8-005056bbe7b6",
      "name": "node2",
      " links": {
        "self": {
          "href": "/api/cluster/nodes/9686b8d1-a828-11eb-80d8-
005056bbe7b6"
       }
     }
    },
    "load": {
      "maximum": 35184372088832,
      "current": 0,
      "token reserved": 0,
      "allowable": 35184372088832
    },
    " links": {
      "self": {
        "href": "/api/storage/file/clone/split-loads/9686b8d1-a828-11eb-
80d8-005056bbe7b6"
     }
   }
 }
"num records": 2,
" links":
 "self": {
    "href": "/api/storage/file/clone/split-loads"
 }
}
}
```

Learn More

• [DOC /storage/file/clone]

Parameters

Name	Туре	In	Required	Description
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name
load.token_reserved	integer	query	False	Filter by load.token_reserved
load.allowable	integer	query	False	Filter by load.allowable
load.current	integer	query	False	Filter by load.current
load.maximum	integer	query	False	Filter by load.maximum
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0

Name	Туре	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	collection_links	
num_records	integer	Number of records.
records	array[split_load]	

Example response

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "load": {
   "allowable": 0,
   "current": 0,
   "token reserved": 0
  },
  "node": {
   " links": {
    "self": {
       "href": "/api/resourcelink"
     }
   },
    "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

1_	
n	rat
	101

Name	Туре	Description
href	string	

collection_links

Name	Туре	Description
next	href	
self	href	

self_link

Name	Туре	Description
self	href	

load

Name	Туре	Description
allowable	integer	Specifies the available file clone split load on the node.
current	integer	Specifies the current on-going file clone split load on the node.
maximum	integer	Specifies the maximum allowable file clone split load on the node at any point in time.
token_reserved	integer	Specifies the file clone split load on the node reserved for tokens.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	

Name	Туре	Description
uuid	string	

split_load

Name	Туре	Description
_links	self_link	
load	load	
node	node_reference	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description	
arguments	array[error_arguments]	Message arguments	
code	string	Error code	
message	string	Error message	
target	string	The target parameter that caused the error.	

Retrieve the volume file clone split load

GET /storage/file/clone/split-loads/{node.uuid}

Introduced In: 9.10

Retrieve Volume File Clone Split Load REST

Parameters

Name	Туре	In	Required	Description
node.uuid	string	path	True	Node Uuid

Name	Туре	In	Required	Description
fields	array[string]	query	False	Specify the fields to return.

Response

```
Status: 200, Ok
```

Name	Туре	Description
_links	self_link	
load	load	
node	node_reference	

Example response

```
" links": {
   "self": {
    "href": "/api/resourcelink"
   }
  },
 "load": {
   "allowable": 0,
  "current": 0,
   "token reserved": 0
 },
 "node": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
    },
   "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
}
```

Error

Status: Default, Error

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

self_link

Na	me	Туре	Description
sel	f	href	

load

Name	Туре	Description
allowable	integer	Specifies the available file clone split load on the node.
current	integer	Specifies the current on-going file clone split load on the node.
maximum	integer	Specifies the maximum allowable file clone split load on the node at any point in time.
token_reserved	integer	Specifies the file clone split load on the node reserved for tokens.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

error_arguments

Name	Туре	Description
code	string	Argument code

Name	Туре	Description
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update the maximum split load

PATCH /storage/file/clone/split-loads/{node.uuid}

Introduced In: 9.10

Updates the maximum split load.

Related Ontap command

volume file clone split load modify

Learn More

• [DOC /storage/file/clone]

```
# The call:
curl -X PATCH "https://<mgmt_IP>/api/storage/file/clone/split-
loads/9686b8d1-a828-11eb-80d8-005056bbe7b6" -d '{"load": {"maximum":
"16TB" } }'
# The response to successful patch is empty body
```

Parameters

Name	Туре	In	Required	Description
node.uuid	string	path	True	Node UUID

Request Body

Name	Туре	Description
_links	self_link	
load	load	
node	node_reference	

Example request

```
" links": {
  "self": {
    "href": "/api/resourcelink"
   }
 },
 "load": {
   "allowable": 0,
  "current": 0,
   "token reserved": 0
 },
 "node": {
   " links": {
     "self": {
      "href": "/api/resourcelink"
    }
   },
   "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

Definitions

See Definitions

1_		
n	r	דב
	1	-1

Name	Туре	Description
href	string	

self_link

Name	Туре	Description
self	href	

load

Name	Туре	Description
allowable	integer	Specifies the available file clone split load on the node.
current	integer	Specifies the current on-going file clone split load on the node.
maximum	integer	Specifies the maximum allowable file clone split load on the node at any point in time.
token_reserved	integer	Specifies the file clone split load on the node reserved for tokens.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

split_load

Name	Туре	Description
_links	self_link	

Name	Туре	Description
load	load	
node	node_reference	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve file clone split status of all volumes in the node

GET /storage/file/clone/split-status

Introduced In: 9.10

Retrieves file clone split status of all volumes in the node.

Learn More

• [DOC /storage/file/clone]

```
# The API:
/api/storage/file/clone/split-status

# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/split-status" -H
"accept: application/hal+json"

# The response:
```

```
"records": [
    "volume": {
      "uuid": "ac559964-57a3-40cf-b5cb-f3cb99151a7d",
      "name": "vol1",
      " links": {
        "self": {
          "href": "/api/storage/volumes/ac559964-57a3-40cf-b5cb-
f3cb99151a7d"
       }
     }
    } ,
    "svm": {
     "name": "vs1"
    "pending splits": 0,
    "unsplit clone size": 0,
    " links": {
      "self": {
        "href": "/api/storage/file/clone/split-status/ac559964-57a3-40cf-
b5cb-f3cb99151a7d"
   }
  },
    "volume": {
      "uuid": "32d95d48-d8b7-11eb-a41d-005056bb3837",
      "name": "vs1 root",
      " links": {
        "self": {
          "href": "/api/storage/volumes/32d95d48-d8b7-11eb-a41d-
005056bb3837"
     }
    },
    "svm": {
     "name": "vs1"
    "pending splits": 0,
    "unsplit clone size": 0,
    " links": {
      "self": {
        "href": "/api/storage/file/clone/split-status/32d95d48-d8b7-11eb-
a41d-005056bb3837"
      }
```

```
}
}

],
"num_records": 2,
"_links": {
    "self": {
        "href": "/api/storage/file/clone/split-status"
    }
}
```

Parameters

Name	Туре	In	Required	Description
pending_splits	integer	query	False	Filter by pending_splits
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
unsplit_clone_size	integer	query	False	Filter by unsplit_clone_size
volume.uuid	string	query	False	Filter by volume.uuid
volume.name	string	query	False	Filter by volume.name
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	collection_links	
num_records	integer	Number of Records
records	array[split_status]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
   },
   "self": {
    "href": "/api/resourcelink"
   }
 },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    "pending splits": 0,
    "svm": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     "name": "svm1",
     "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "unsplit clone size": 0,
    "volume": {
      " links": {
        "self": {
         "href": "/api/resourcelink"
       }
      "name": "volume1",
      "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
}
```

Error

Status: Default, Error

Name	Туре	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

href	
------	--

Name	Туре	Description
href	string	

collection_links

Name	}	Туре	Description
next		href	
self		href	

self_link

Name	Туре	Description
self	href	

_links

Name	Туре	Description
self	href	

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

volume

Name	Туре	Description
_links	_links	
name	string	The name of the volume.

Name	Туре	Description
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move. • example: 028baa66-41bd- 11e9-81d5-00a0986138f7 • Introduced in: 9.6

split_status

Name	Туре	Description
_links	self_link	
pending_splits	integer	Specifies the number of pending file clone split operations in the volume.
svm	svm	
unsplit_clone_size	integer	Specifies the space occupied by unsplit file clones in the volume.
volume	volume	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description	
arguments	array[error_arguments]	Message arguments	
code	string	Error code	
message	string	Error message	
target	string	The target parameter that caused the error.	

Retrieve file clone split status of all volumes

GET /storage/file/clone/split-status/{volume.uuid}

Introduced In: 9.10

Retrieves file clone split status of all volumes in the node.

Related Ontap commands

• volume file clone split status

Learn More

• [DOC /storage/file/clone]

Retrieves the information of split status.

The GET operation retrieves information about split processes in the volume.

splits is the number of files for which file clone split is not yet completed.

split-size is the sum of all sizes, in bytes in the volume that is not split.

splits

```
# The API:
/api/storage/file/clone/split-status/{volume.uuid}
# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/split-
status/ac559964-57a3-40cf-b5cb-f3cb99151a7d" -H "accept:
application/hal+json"
# The response:
"volume": {
 "uuid": "ac559964-57a3-40cf-b5cb-f3cb99151a7d",
 "name": "vol1",
 " links": {
   "self": {
      "href": "/api/storage/volumes/ac559964-57a3-40cf-b5cb-f3cb99151a7d"
   }
  }
} ,
"svm": {
 "name": "vs1"
"pending splits": 0,
"unsplit clone size": 0,
" links": {
 "self": {
    "href": "/api/storage/file/clone/split-status/ac559964-57a3-40cf-b5cb-
f3cb99151a7d"
 }
}
}
```

Parameters

Name	Туре	In	Required	Description
volume.uuid	string	path	True	Volume Instance UUID
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Туре	Description
_links	self_link	
pending_splits	integer	Specifies the number of pending file clone split operations in the volume.
svm	svm	
unsplit_clone_size	integer	Specifies the space occupied by unsplit file clones in the volume.
volume	volume	

Example response

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  } ,
  "pending_splits": 0,
 "svm": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
   },
    "name": "svm1",
   "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  "unsplit clone size": 0,
 "volume": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
   "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
}
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Name	Туре	Description
href	string	

self_link

Name	Туре	Description
self	href	

_links

Name	Туре	Description
self	href	

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

volume

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance-unid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.
		 example: 028baa66-41bd- 11e9-81d5-00a0986138f7
		• Introduced in: 9.6

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve information for a token

GET /storage/file/clone/tokens

Introduced In: 9.10

Retrieves information for the specified token.

Related Ontap command

• volume file clone token show

Learn More

• [DOC /storage/file/clone]

Retrieving information on clone tokens

```
# The API:
/api/storage/file/clone/tokens
# The call:
curl -X GET "https://<mgmt_ip>/api/storage/file/clone/tokens" -H "accept:
application/hal+json"
# The response:
{
"records": [
    "node": {
      "uuid": "97255711-alad-11eb-92b2-0050568eb2ca",
      "name": "node1",
      " links": {
        "self": {
          "href": "/api/cluster/nodes/97255711-a1ad-11eb-92b2-
0050568eb2ca"
     }
    "uuid": "905c42ce-a74b-11eb-bd86-0050568ec7ae",
    "reserve size": 10240,
    "expiry time": {
      "limit": "PT1H10M",
      "left": "PT1H9M"
    " links": {
      "self": {
        "href": "/api/storage/file/clone/tokens/97255711-alad-11eb-92b2-
0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"
   }
 }
],
"num records": 1,
" links": {
 "self": {
    "href": "/api/storage/file/clone/tokens"
 }
}
}
```

Parameters

Name	Туре	In	Required	Description
expiry_time.left	string	query	False	Filter by expiry_time.left
expiry_time.limit	string	query	False	Filter by expiry_time.limit
uuid	string	query	False	Filter by uuid
reserve_size	integer	query	False	Filter by reserve_size
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	collection_links	
num_records	integer	Number of records.
records	array[token]	

Example response

```
{
   "_links": {
        "next": {
             "href": "/api/resourcelink"
        },
        "self": {
             "href": "/api/resourcelink"
        }
   },
   "num_records": 1,
   "records": {
    }
}
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
        }
}
```

href	
------	--

Name	Туре	Description
href	string	

collection_links

Name	Туре	Description
next	href	
self	href	

self_link

Name	Туре	Description
self	href	

expiry_time

Name	Туре	Description
left	string	Specifies the time remaining before the given token expires in ISO-8601 format.
limit	string	Specifies when the given token expires in ISO-8601 format.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

token

token

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	
node	node_reference	
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description	
arguments	array[error_arguments]	Message arguments	
code	string	Error code	
message	string	Error message	
target	string	The target parameter that caused the error.	

Create a new token to reserve the split load

POST /storage/file/clone/tokens

Introduced In: 9.10

Creates a new token to reserve the split load.

Required Properties

- node.uuid
- reserve-size

Optional Propeties

- expiry time.limit
- expiry time.left

Related Ontap Commands

• volume file clone token create

Learn More

• [DOC /storage/file/clone]

Creating clone tokens to reserve space for clone creation on the node

There is a limit on the amount of clone data that can undergo a split at a point of time on the node (clone split load). Clone tokens are used to reserve space from clone split load for clone creation. The POST operation is used to create clone tokens with reserve-size and expiry-time.limit in the body.


```
# The API
/api/storage/file/clone/tokens
# The call
curl -X POST "https://<mgmt_ip>/api/storage/file/clone/tokens" -H "accept:
application/hal+json" -d '{"node": {"uuid": "97255711-a1ad-11eb-92b2-
0050568eb2ca"}, "reserve size": "40M", "expiry time": { "limit": "4200"}
} '
# The response
"num records": 1,
"records": [
    "node": {
     "name": "node1"
    },
    "uuid": "286f6ae4-c94d-11eb-adb5-005056bbeb0b",
    "reserve_size": 41943040,
    " links": {
     "self": {
        "href": "/api/storage/file/clone/tokens/97255711-alad-11eb-92b2-
0050568eb2ca"
     }
 }
]
}
```

Parameters

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned.
				Default value:

Request Body

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	

Name	Туре	Description
node	node_reference	
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

Response

```
Status: 201, Created
```

Name	Туре	Description
_links	collection_links	
num_records	integer	Number of records.
records	array[token]	

Example response

```
{
  "_links": {
     "next": {
        "href": "/api/resourcelink"
     },
     "self": {
        "href": "/api/resourcelink"
     }
  },
  "num_records": 1,
  "records": {
     }
}
```

Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

1_		
n	r	דב
	1	-1

Name	Туре	Description
href	string	

self_link

Name	Туре	Description
self	href	

expiry_time

Name	Туре	Description
left	string	Specifies the time remaining before the given token expires in ISO-8601 format.
limit	string	Specifies when the given token expires in ISO-8601 format.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

token

token

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	
node	node_reference	

Name	Туре	Description
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

collection_links

Name	Туре	Description
next	href	
self	href	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Delete a specific file clone token

DELETE /storage/file/clone/tokens/{node.uuid}/{uuid}

Introduced In: 9.10

Deletes a specific file clone token.

Related Ontap command

• volume file clone token delete

Delete specific clone token.

```
# The API:
/api/storage/file/clone/tokens/{node.uuid}/{token.uuid}

# The call:
curl -X DELETE "https://<mgmt_ip>/api/storage/file/clone/tokens/97255711-
alad-11eb-92b2-0050568eb2ca/909c42ce-a74b-11eb-bd86-0050568ec7ae"

# The successful response is empty body.
```

Learn More

• [DOC /storage/file/clone]

Parameters

Name	Туре	In	Required	Description
node.uuid	string	path	True	Node UUID
uuid	string	path	True	Token UUID

Response

```
Status: 200, Ok
```

Name	Туре	Description
job	job_link	

Example response

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

job_link

Name	Туре	Description
_links	_links	
uuid	string	The UUID of the asynchronous job that is triggered by a POST, PATCH, or DELETE operation.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Retrieve a file clone token

GET /storage/file/clone/tokens/{node.uuid}/{uuid}

Retrieves a file clone token

Related Ontap command

• volume file clone token show

Retrieve information for single token.

```
# The call:
curl -X GET "https://<mgmt ip>/api/storage/file/clone/tokens/97255711-
alad-11eb-92b2-0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"
# The response:
"node": {
 "uuid": "97255711-a1ad-11eb-92b2-0050568eb2ca",
 "name": "node1",
  " links": {
    "self": {
      "href": "/api/cluster/nodes/97255711-a1ad-11eb-92b2-0050568eb2ca"
  }
"uuid": "905c42ce-a74b-11eb-bd86-0050568ec7ae",
"reserve size": 41943040,
"expiry time": {
 "limit": "PT1H10M",
 "left": "PT1H9M"
},
" links": {
  "self": {
    "href": "/api/storage/file/clone/tokens/97255711-alad-11eb-92b2-
0050568eb2ca/905c42ce-a74b-11eb-bd86-0050568ec7ae"
 }
}
}
```

Learn More

• [DOC /storage/file/clone]

Parameters

Name	Туре	In	Required	Description
node.uuid	string	path	True	Node UUID
uuid	string	path	True	Token UUID
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	
node	node_reference	
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

Error

Status: Default, Error

Name	Туре	Description
error	error	

Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Name	Туре	Description
href	string	

self_link

Name	Туре	Description
self	href	

expiry_time

Name	Туре	Description
left	string	Specifies the time remaining before the given token expires in ISO-8601 format.
limit	string	Specifies when the given token expires in ISO-8601 format.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update a file clone token

PATCH /storage/file/clone/tokens/{node.uuid}/{uuid}

Introduced In: 9.10

Updates a file clone token.

Related Ontap commands

volume file clone token modify

Modify clone token

```
# The call:
curl -X PATCH "https://<mgmt_ip>/api/storage/file/clone/tokens/97255711-
alad-1leb-92b2-0050568eb2ca/905c42ce-a74b-1leb-bd86-0050568ec7ae" -d
   '{"expiry_time": {"limit": "5400"} }'
# The response for successful PATCH is empty.
```

Learn More

• [DOC /storage/file/clone]

Parameters

Name	Туре	In	Required	Description
node.uuid	string	path	True	Node UUID
uuid	string	path	True	Token UUID

Request Body

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	
node	node_reference	
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

Response

```
Status: 200, Ok
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

Name	Туре	Description
href	string	

self_link

Name	Туре	Description
self	href	

expiry_time

Name	Туре	Description
left	string	Specifies the time remaining before the given token expires in ISO-8601 format.
limit	string	Specifies when the given token expires in ISO-8601 format.

_links

Name	Туре	Description
self	href	

node_reference

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

token

token

Name	Туре	Description
_links	self_link	
expiry_time	expiry_time	
node	node_reference	

Name	Туре	Description
reserve_size	integer	Specifies the available reserve in the file clone split load for the given token.
uuid	string	Token UUID.

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.