■ NetApp

Manage disks

ONTAP 9.12.1 REST API reference

NetApp February 13, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9121/ontap/storage_disks_endpoint_overview.html on February 13, 2024. Always check docs.netapp.com for the latest.

Table of Contents

Manage disks		 	 	 	 	 1
Storage disks endpoint overview		 	 	 	 	 1
Retrieve a collection of disks		 	 	 	 	 12
Update disk ownership, change authentication keys, or sanitize disks	S	 	 	 	 	 33
Retrieve a specific disk		 	 	 	 	 48

Manage disks

Storage disks endpoint overview

Retrieving storage disk information

The storage disk GET API retrieves all of the disks in the cluster.

Examples

1) Retrieve a list of disks from the cluster.

The following example shows the response with a list of disks in the cluster:

```
# The API:
/api/storage/disks
# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks" -H "accept:
application/hal+json"
# The response:
"records": [
    "name": "1.24.4",
    " links": {
     "self": {
        "href": "/api/storage/disks/1.24.4"
  },
    "name": "1.24.3",
    " links": {
     "self": {
        "href": "/api/storage/disks/1.24.3"
  },
    "name": "1.24.5",
    " links": {
```

```
"self": {
        "href": "/api/storage/disks/1.24.5"
      }
    }
  } ,
    "name": "1.24.0",
    " links": {
      "self": {
        "href": "/api/storage/disks/1.24.0"
    }
  },
    "name": "1.24.2",
    " links": {
      "self": {
        "href": "/api/storage/disks/1.24.2"
    }
  },
    "name": "1.24.1",
    " links": {
      "self": {
        "href": "/api/storage/disks/1.24.1"
  }
],
"num_records": 6,
" links": {
 "self": {
    "href": "/api/storage/disks"
}
}
```

2) Retrieve a specific disk from the cluster.

The following example shows the response of the requested disk. If there is no disk with the requested name, an error is returned:

```
# The API:
/api/storage/disks/{name}
# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks/1.24.3" -H "accept:
application/hal+json"
# The response:
"name": "1.24.3",
"uid":
0000000:00000000",
"serial number": "EC47PC5021SW",
"model": "X421 FAL12450A10",
"vendor": "NETAPP",
"firmware version": "NA02",
"usable size": 438304768000,
"rpm": 10000,
"type": "sas",
"effective type": "sas",
"class": "performance",
"container type": "aggregate",
"pool": "pool0",
"state": "present",
"node": {
 "uuid": "3a89ed49-8c6d-11e8-93bc-00a0985a64b6",
 "name": "node-2",
 " links": {
   "self": {
     "href": "/api/cluster/nodes/3a89ed49-8c6d-11e8-93bc-00a0985a64b6"
 }
},
"home node": {
 "uuid": "3a89ed49-8c6d-11e8-93bc-00a0985a64b6",
 "name": "node-2",
 " links": {
   "self": {
     "href": "/api/cluster/nodes/3a89ed49-8c6d-11e8-93bc-00a0985a64b6"
 }
},
"aggregates": [
   "uuid": "3fd9c345-ba91-4949-a7b1-6e2b898d74e3",
```

```
"name": "node 2 SAS 1",
    " links": {
     "self": {
        "href": "/api/storage/aggregates/3fd9c345-ba91-4949-a7b1-
6e2b898d74e3"
     }
    }
 }
],
"shelf": {
  "uid": "10318311901725526608",
 " links": {
   "self": {
      "href": "/api/storage/shelves/10318311901725526608"
 }
},
"local": true,
"paths": [
   "initiator": "3a",
   "port name": "B",
   "port type": "sas",
   "wwnn": "5000cca02f0e6768",
   "wwpn": "5000cca02f0e676a",
   "node": {
     "name": "vsim3",
     "uuid": "3f7fa09a-5c56-11ec-b366-005056bbbb3f",
     " links": {
          "href": "/api/cluster/nodes/3f7fa09a-5c56-11ec-b366-
005056bbbb3f"
     }
  }
 },
  "initiator": "3d",
   "port name": "A",
   "port type": "sas",
   "wwnn": "5000cca02f0e6768",
   "wwpn": "5000cca02f0e6769",
   "node": {
     "name": "vsim4",
     "uuid": "4f7fa09a-5c56-11ec-b366-005056bbbb3f",
     " links": {
```

```
"href": "/api/cluster/nodes/4f7fa09a-5c56-11ec-b366-
005056bbbb3f"
        }
     }
  }
},
{
   "initiator": "3d",
   "port name": "A",
   "port type": "sas",
   "wwnn": "5000cca02f0e6768",
   "wwpn": "5000cca02f0e6769",
   "node": {
     "name": "vsim3",
     "uuid": "3f7fa09a-5c56-11ec-b366-005056bbbb3f",
     " links": {
        "self": {
          "href": "/api/cluster/nodes/3f7fa09a-5c56-11ec-b366-
005056bbbb3f"
       }
     }
},
{
   "initiator": "3a",
   "port name": "B",
   "port type": "sas",
   "wwnn": "5000cca02f0e6768",
   "wwpn": "5000cca02f0e676a",
   "node": {
     "name": "vsim4",
     "uuid": "4f7fa09a-5c56-11ec-b366-005056bbbb3f",
     " links": {
        "self": {
          "href": "/api/cluster/nodes/4f7fa09a-5c56-11ec-b366-
005056bbbb3f"
     }
  }
}
],
"outage": {
  "persistently failed": true,
  "reason": {
    "message": "Failed disk. Reason: \"admin failed\".",
```

```
"code": "721081"
  }
},
"bay": 3,
" links": {
 "self": {
    "href": "/api/storage/disks/1.24.3"
 }
},
"error": [
  "reason": {
    "message": "\"The node is configured with All-Flash Optimized
personality and this disk is not an SSD. The disk needs to be removed from
the system.\"",
    "code": "721082"
  },
  "type": "notallflashdisk"
}
],
"bytes per sector": 512,
"sector count": 1172123568,
"right size sector count": 5579776,
"physical size": 438804988000,
"stats": {
  "average latency": 6,
  "throughput": 1957888,
  "iops total": 12854,
  "path error count": 0,
  "power on hours": 11797
 }
}
```

3) Retrieving a specific disk from the hypervisor

The following example shows the response of the requested disk. If there is no disk with the requested name, an error is returned:

```
# The API:
/api/storage/disks/{name}

# The call:
curl -X GET "https://<mgmt-ip>/api/storage/disks/NET-3.2" -H "accept:
```

```
application/hal+json"
# The response:
"name": "NET-3.2",
"uid":
0000000:00000000",
"serial number": "3234363765386464",
"model": "PHA-DISK",
"vendor": "NETAPP",
"firmware version": "0001",
"type": "vmdisk",
"class": "virtual",
"container type": "mediator",
"pool": "pool0",
"node": {
   "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
   "name": "aws-43905099-44129379-awsha-vm1",
   " links": {
   "self": {
         "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
    }
},
"home node": {
"uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
"name": "aws-43905099-44129379-awsha-vm1",
" links": {
      "self": {
         "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
  }
},
"local": true,
"paths": [
{
   "initiator": "0f",
   "port name": "A",
   "port type": "sas",
   "wwnn": "53059d50444f5476",
   "wwpn": "53059d50444f5476",
   "vmdisk hypervisor file name": "LUN 4.0",
   "node": {
```

```
"name": "aws-43905099-44129379-awsha-vm1",
      "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
      " links": {
         "self": {
           "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
        }
      }
    }
},
 {
    "initiator": "Of",
    "port name": "A",
    "port type": "sas",
    "wwnn": "53059d50444f5476",
    "wwpn": "53059d50444f5476",
    "vmdisk hypervisor file name": "LUN 2.0",
    "node": {
      "name": "aws-43905099-44129379-awsha-vm1",
      "uuid": "f4cb78ba-5841-11ec-80c4-916f62b4cd44",
      " links": {
         "self": {
           "href": "/api/cluster/nodes/f4cb78ba-5841-11ec-80c4-
916f62b4cd44"
      }
    }
}
],
"outage": {
    "persistently failed": false,
    "reason": {
    "message": "Failed disk. Reason: \"\".",
      "code": "721081"
   }
},
"self encrypting": false,
"fips certified": false,
"bytes per sector": 512,
"sector count": 204808,
"right size sector count": 5579776,
"physical size": 204808,
"stats": {
    "average latency": 2157188883,
    "throughput": 4096,
    "iops total": 1,
```

```
"path_error_count": 0,
    "power_on_hours": 0
},

"_links": {
    "self": {
        "href": "/api/storage/disks/NET-3.2"
     }
}
```

Modifying storage disk

The storage disk PATCH API modifies disk ownership, unfails a disk, or updates encrypting drive authentication keys (AKs) in the cluster. The storage disk API currently supports patching one attribute at a time.

Updating the disk ownership for a specified disk

1. When the disk is not assigned

When the disk is a spare (or unowned) disk and node name is specified, the PATCH opertaion assigns the disk to the specified node.

2. When the disk is already assigned

When the disk is already assigned (aleady has a owner), and a new node is specified, the PATCH operation changes the ownership to the new node.

Removing the disk ownership for a specified disk

When the disk is already assigned, and node name is specified as null (no-quotes), the PATCH operation removes the owner.

Examples

1. Update the disk ownership for an unowned disk

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks/<disk-name>" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json" -d
'{"node": {"name": "node-name"}}'

# The response:
{
}
```

2. Update the disk ownership for an already owned disk

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks/<disk-name>" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json" -d
'{"node": {"name": "node-name"}}'

# The response:
{
}
```

3. Rekey the data AK of all encrypting drives to an AK selected automatically by the system

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-
ip>/api/storage/disks?name=*&encryption_operation=rekey_data_auto_id" -H
"accept: application/hal+json" -H "Content-Type: application/hal+json"

# The response contains the number of disks attempted.
{
   "num_records": 32
}
```

4. Cryptographically sanitize a spare or broken disk

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-
name>&encryption_operation=sanitize_disk" -H "accept:
application/hal+json" -H "Content-Type: application/hal+json"

# The response contains the number of disks attempted.
{
    "num_records": 1
}
```

5. Unfailing a disk to a spare.

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-name>" -d
'{"state": "spare"}' -H "accept: application/hal+json" -H "Content-Type:
application/hal+json"

# The response:
{
}
```

6. Unfailing a disk and attempting to reassimilate filesystem labels.

If unable or unnecessary to reassimilate filesystem labels, the disk will be set as spare.

```
# The API:
/api/storage/disks

# The call:
curl -X PATCH "https://<mgmt-ip>/api/storage/disks?name=<disk-name>" -d
'{"state": "present"}' -H "accept: application/hal+json" -H "Content-Type:
application/hal+json"

# The response:
{
}
```

Retrieve a collection of disks

GET /storage/disks

Introduced In: 9.6

Retrieves a collection of disks.

Related ONTAP commands

storage disk show

Learn more

• DOC /storage/disks

Parameters

Name	Туре	In	Required	Description
key_id.fips	string	query	False	Filter by key_id.fips • Introduced in: 9.7
key_id.data	string	query	False	• Introduced in: 9.7
state	string	query	False	Filter by state
storage_pool.uuid	string	query	False	Filter by storage_pool.uuid • Introduced in: 9.11
storage_pool.name	string	query	False	Filter by storage_pool.name • Introduced in: 9.11
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name
compliance_standar d	string	query	False	Filter by compliance_standar d • Introduced in: 9.11
pool	string	query	False	Filter by pool
shelf.uid	string	query	False	Filter by shelf.uid

Name	Туре	In	Required	Description
sector_count	integer	query	False	Filter by sector_count • Introduced in: 9.9
local	boolean	query	False	• Introduced in: 9.9
bytes_per_sector	integer	query	False	Filter by bytes_per_sector • Introduced in: 9.9
effective_type	string	query	False	Filter by effective_type • Introduced in: 9.9
usable_size	integer	query	False	Filter by usable_size
outage.reason.target	string	query	False	Filter by outage.reason.target • Introduced in: 9.10
outage.reason.argu ments.message	string	query	False	Filter by outage.reason.argu ments.message • Introduced in: 9.10
outage.reason.argu ments.code	string	query	False	Filter by outage.reason.argu ments.code • Introduced in: 9.10

Name	Туре	In	Required	Description
outage.reason.code	string	query	False	Filter by outage.reason.code • Introduced in: 9.9
outage.reason.mess age	string	query	False	Filter by outage.reason.mess age • Introduced in: 9.9
outage.persistently_f ailed	boolean	query	False	Filter by outage.persistently_f ailed • Introduced in: 9.9
bay	integer	query	False	Filter by bay
class	string	query	False	Filter by class
aggregates.name	string	query	False	Filter by aggregates.name
aggregates.uuid	string	query	False	Filter by aggregates.uuid
type	string	query	False	Filter by type
right_size_sector_co unt	integer	query	False	Filter by right_size_sector_co unt • Introduced in: 9.11
protection_mode	string	query	False	Filter by protection_mode • Introduced in: 9.7
vendor	string	query	False	Filter by vendor

Name	Туре	In	Required	Description
dr_node.name	string	query	False	Filter by dr_node.name
dr_node.uuid	string	query	False	Filter by dr_node.uuid
model	string	query	False	Filter by model
name	string	query	False	Filter by name
physical_size	integer	query	False	Filter by physical_size • Introduced in: 9.11
paths.vmdisk_hyper visor_file_name	string	query	False	Filter by paths.vmdisk_hyper visor_file_name • Introduced in: 9.11
paths.wwnn	string	query	False	Filter by paths.wwnn • Introduced in: 9.9
paths.port_type	string	query	False	Filter by paths.port_type • Introduced in: 9.9
paths.node.name	string	query	False	Filter by paths.node.name • Introduced in: 9.11
paths.port_name	string	query	False	Filter by paths.port_name • Introduced in: 9.9

Name	Туре	In	Required	Description
paths.wwpn	string	query	False	• Introduced in: 9.9
paths.node.uuid	string	query	False	Filter by paths.node.uuid • Introduced in: 9.11
paths.initiator	string	query	False	Filter by paths.initiator • Introduced in: 9.9
drawer.slot	integer	query	False	Filter by drawer.slot
drawer.id	integer	query	False	Filter by drawer.id
container_type	string	query	False	Filter by container_type
serial_number	string	query	False	Filter by serial_number
self_encrypting	boolean	query	False	Filter by self_encrypting • Introduced in: 9.7
error.reason.target	string	query	False	Filter by error.reason.target • Introduced in: 9.10
error.reason.argume nts.message	string	query	False	Filter by error.reason.argume nts.message • Introduced in: 9.10

Name	Туре	In	Required	Description
error.reason.argume nts.code	string	query	False	Filter by error.reason.argume nts.code • Introduced in: 9.10
error.reason.code	string	query	False	Filter by error.reason.code • Introduced in: 9.9
error.reason.messag e	string	query	False	Filter by error.reason.messag e • Introduced in: 9.9
error.type	string	query	False	• Introduced in: 9.9
firmware_version	string	query	False	Filter by firmware_version
uid	string	query	False	Filter by uid
fips_certified	boolean	query	False	Filter by fips_certified • Introduced in: 9.7
rpm	integer	query	False	Filter by rpm
virtual.storage_acco unt	string	query	False	Filter by virtual.storage_account • Introduced in: 9.11

Name	Туре	In	Required	Description
virtual.object	string	query	False	Filter by virtual.object • Introduced in: 9.11
virtual.container	string	query	False	Filter by virtual.container • Introduced in: 9.11
stats.path_error_cou nt	integer	query	False	Filter by stats.path_error_count • Introduced in: 9.9
stats.power_on_hours	integer	query	False	Filter by stats.power_on_hou rs • Introduced in: 9.9
stats.iops_total	integer	query	False	Filter by stats.iops_total • Introduced in: 9.9
stats.throughput	integer	query	False	Filter by stats.throughput • Introduced in: 9.9
stats.average_latenc y	integer	query	False	Filter by stats.average_latenc y • Introduced in: 9.9
home_node.uuid	string	query	False	Filter by home_node.uuid

Name	Туре	In	Required	Description
home_node.name	string	query	False	Filter by home_node.name
overall_security	string	query	False	Filter by overall_security • Introduced in: 9.11
control_standard	string	query	False	Filter by control_standard • Introduced in: 9.11
rated_life_used_perc ent	integer	query	False	Filter by rated_life_used_per cent
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned. • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached. • Default value: 1 • Max value: 120 • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	Number of records
records	array[disk]	

```
" links": {
  "next": {
    "href": "/api/resourcelink"
  },
  "self": {
   "href": "/api/resourcelink"
  }
},
"num records": 1,
"records": {
  "aggregates": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
      }
    },
    "name": "aggr1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "bay": 1,
  "bytes per sector": 520,
  "class": "solid state",
  "compliance standard": "FIPS 140-2",
  "container type": "spare",
  "control standard": "TCG Enterprise",
  "dr node": {
    "name": "node1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "effective type": "vmdisk",
  "error": {
    "reason": {
      "arguments": {
        "code": "string",
        "message": "string"
      },
      "code": "4",
      "message": "entry doesn't exist",
     "target": "uuid"
    "type": "notallflashdisk"
  },
  "firmware version": "NA51",
```

```
"home node": {
  " links": {
   "self": {
      "href": "/api/resourcelink"
   }
 },
  "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
"model": "X421 HCOBE450A10",
"name": "1.0.1",
"node": {
 " links": {
    "self": {
      "href": "/api/resourcelink"
   }
 },
  "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"outage": {
 "reason": {
    "arguments": {
     "code": "string",
     "message": "string"
    } ,
    "code": "4",
    "message": "entry doesn't exist",
   "target": "uuid"
 }
},
"overall security": "Level 2",
"paths": {
  "initiator": "3a",
 "node.name": "vsim4",
  "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
 "port name": "A",
 "port type": "sas",
 "vmdisk hypervisor file name": "xvds vol0a0567ae156ca59f6",
 "wwnn": "5000c2971c1b2b8c",
  "wwpn": "5000c2971c1b2b8d"
},
"physical size": 228930,
"pool": "pool0",
"protection mode": "data",
"rated life used percent": 10,
```

```
"right size sector count": 1172123568,
   "rpm": 15000,
   "sector count": 1172123568,
   "serial number": "KHG2VX8R",
   "shelf": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "uid": "7777841915827391056"
   "state": "present",
   "stats": {
     "average latency": 3,
     "iops total": 12854,
     "path error count": 0,
     "power on hours": 21016,
     "throughput": 1957888
   },
   "storage pool": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "storage pool 1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   },
   "type": "ssd",
   "uid":
0:00000000:00000000",
   "usable size": 959934889984,
   "vendor": "NETAPP",
   "virtual": {
     "container": "nviet12122018113936-rg",
     "object": "f1fu63se",
     "storage account": "nviet12122018113936ps"
 }
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
{
    "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

Definitions

See Definitions

Name	Туре	Description
href	string	

_links

Name	Туре	Description
next	href	
self	href	

_links

Name	Туре	Description
self	href	

aggregates

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

dr_node

Name	Туре	Description
name	string	
uuid	string	

drawer

Name	Туре	Description
id	integer	
slot	integer	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

The message and code detailing the error state of this disk.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

disk_error_info

Name	Туре	Description
reason	error	The message and code detailing the error state of this disk.
type	string	Disk error type.

home_node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

key_id

Name	Туре	Description
data	string	Key ID of the data authentication key
fips	string	Key ID of the FIPS authentication key

node

Name	Туре	Description
_links	_links	
name	string	

Name	Туре	Description
uuid	string	

error

This error message and code explaining the disk failure.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

Name	Туре	Description
persistently_failed	boolean	Indicates whether RAID maintains the state of this disk as failed accross reboots.
reason	error	This error message and code explaining the disk failure.

disk_path_info

Name	Туре	Description
initiator	string	Initiator port.
node.name	string	Controller with the initiator port for this path.
node.uuid	string	Controller UUID, to identify node for this path.
port_name	string	Name of the disk port.
port_type	string	Disk port type.

Name	Туре	Description
vmdisk_hypervisor_file_name	string	Virtual disk hypervisor file name.
wwnn	string	Target device's World Wide Node Name.
wwpn	string	Target device's World Wide Port Name.

shelf

Shelf

Name	Туре	Description
_links	_links	
uid	string	

stats

Name	Туре	Description
average_latency	integer	Average I/O latency across all active paths, in milliseconds.
iops_total	integer	Total I/O operations per second read and written to this disk across all active paths.
path_error_count	integer	Disk path error count; failed I/O operations.
power_on_hours	integer	Hours powered on.
throughput	integer	Total disk throughput per second across all active paths, in bytes.

storage_pool

Shared Storage Pool

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

virtual

Information about backing storage for disks on cloud platforms.

Name	Туре	Description
container	string	Container name of the virtual disk.
object	string	Object name of the virtual disk.
storage_account	string	Storage account name of the virtual disk.

disk

Name	Туре	Description
aggregates	array[aggregates]	List of aggregates sharing this disk
bay	integer	Disk shelf bay
bytes_per_sector	integer	Bytes per sector.
class	string	Disk class
compliance_standard	string	Security standard that the device is certified to.
container_type	string	Type of overlying disk container
control_standard	string	Standard that the device supports for encryption control.
dr_node	dr_node	
drawer	drawer	
effective_type	string	Effective Disk type
encryption_operation	string	This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET.
error	array[disk_error_info]	List of disk errors information.
fips_certified	boolean	
firmware_version	string	

Name	Туре	Description
home_node	home_node	
key_id	key_id	
local	boolean	Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.
model	string	
name	string	Cluster-wide disk name
node	node	
outage	outage	Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.
overall_security	string	Overall Security rating, for FIPS-certified devices.
paths	array[disk_path_info]	List of paths to a disk
physical_size	integer	Physical size, in units of bytes
pool	string	Pool to which disk is assigned
protection_mode	string	Mode of drive data protection and FIPS compliance. Possible values are:
		• open - Data is unprotected
		 data - Data protection only, without FIPS compliance
		 part - Data is unprotected; other FIPS compliance settings present
		 full - Full data and FIPS compliance protection
		 miss - Protection mode information is not available
rated_life_used_percent	integer	Percentage of rated life used

Name	Туре	Description
right_size_sector_count	integer	Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk.
rpm	integer	Revolutions per minute
sector_count	integer	Number of sectors on the disk.
self_encrypting	boolean	
serial_number	string	
shelf	shelf	Shelf
state	string	State
stats	stats	
storage_pool	storage_pool	Shared Storage Pool
type	string	Disk interface type
uid	string	The unique identifier for a disk
usable_size	integer	
vendor	string	
virtual	virtual	Information about backing storage for disks on cloud platforms.

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Update disk ownership, change authentication keys, or sanitize disks

PATCH /storage/disks

Introduced In: 9.7

Updates disk ownership, changes authentication keys, or sanitizes disks.

Related ONTAP commands

- storage disk assign
- storage disk removeowner
- * storage encryption disk modify -data-key-id
- storage encryption disk sanitize
- security key-manager key query -key-type NSE-AK
- storage disk unfail

Learn more

• DOC /storage/disks

Parameters

Name	Туре	In	Required	Description
name	string	query	False	Disk name
node	string	query	False	Node to assign disk Introduced in: 9.8
pool	string	query	False	Pool to assign disk to • Introduced in: 9.11

encryption_operation string query False Name of the operation to apply to encrypting disks. * rekey_data_defa_ult changes the data authentication key (AK) to the drive-unique Manufacture Secure ID (MSID) value. Allows the drive to be attached to other clusters. Disables data-at-rest protection without erasing the data. * rekey_data_auto_ic changes the data authentication key (AK) to an AK the cluster selects automatically. Enables data-at-rest protection. * sanitize_disk cryptographically erases all user data from a spare or broken drive by altering the data encryption key. Resets the data encryp	Name	Туре	In	Required	Description
"rekey_data_aut		-		-	Name of the operation to apply to encrypting disks. rekey_data_defa ult changes the data authentication key (AK) to the drive-unique Manufacture Secure ID (MSID) value. Allows the drive to be attached to other clusters. Disables data-at-rest protection without erasing the data. rekey_data_auto _id changes the data authentication key (AK) to an AK the cluster selects automatically. Enables data-at-rest protection. rekey_disk cryptographically erases all user data from a spare or broken drive by altering the data encryption key. Resets the data AK to the drive-unique MSID value and disables data-at-rest protection. Used when a drive is being repurposed or returned. el"rekey_data_def
↑ Id"	34				"rekey_data_aut o_id",

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned. • Default value:

Request Body

Name	Туре	Description
aggregates	array[aggregates]	List of aggregates sharing this disk
bay	integer	Disk shelf bay
bytes_per_sector	integer	Bytes per sector.
class	string	Disk class
compliance_standard	string	Security standard that the device is certified to.
container_type	string	Type of overlying disk container
control_standard	string	Standard that the device supports for encryption control.
dr_node	dr_node	
drawer	drawer	
effective_type	string	Effective Disk type
encryption_operation	string	This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET.
error	array[disk_error_info]	List of disk errors information.
fips_certified	boolean	
firmware_version	string	
home_node	home_node	
key_id	key_id	

Name	Туре	Description
local	boolean	Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.
model	string	
name	string	Cluster-wide disk name
node	node	
outage	outage	Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.
overall_security	string	Overall Security rating, for FIPS-certified devices.
paths	array[disk_path_info]	List of paths to a disk
physical_size	integer	Physical size, in units of bytes
pool	string	Pool to which disk is assigned
protection_mode	string	Mode of drive data protection and FIPS compliance. Possible values are: • open - Data is unprotected • data - Data protection only, without FIPS compliance • part - Data is unprotected; other FIPS compliance settings present • full - Full data and FIPS compliance protection • miss - Protection mode information is not available
rated_life_used_percent	integer	Percentage of rated life used
right_size_sector_count	integer	Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk.

Name	Туре	Description
rpm	integer	Revolutions per minute
sector_count	integer	Number of sectors on the disk.
self_encrypting	boolean	
serial_number	string	
shelf	shelf	Shelf
state	string	State
stats	stats	
storage_pool	storage_pool	Shared Storage Pool
type	string	Disk interface type
uid	string	The unique identifier for a disk
usable_size	integer	
vendor	string	
virtual	virtual	Information about backing storage for disks on cloud platforms.

```
"aggregates": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
  },
  "name": "aggr1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"bay": 1,
"bytes per sector": 520,
"class": "solid state",
"compliance standard": "FIPS 140-2",
"container type": "spare",
"control standard": "TCG Enterprise",
"dr node": {
 "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
"effective type": "vmdisk",
"error": {
  "reason": {
    "arguments": {
     "code": "string",
     "message": "string"
   },
   "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
 },
  "type": "notallflashdisk"
"firmware version": "NA51",
"home node": {
 " links": {
    "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"model": "X421 HCOBE450A10",
```

```
"name": "1.0.1",
"node": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"outage": {
 "reason": {
    "arguments": {
      "code": "string",
     "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
   "target": "uuid"
 }
},
"overall security": "Level 2",
"paths": {
  "initiator": "3a",
  "node.name": "vsim4",
  "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
  "port name": "A",
  "port type": "sas",
  "vmdisk hypervisor file name": "xvds vol0a0567ae156ca59f6",
  "wwnn": "5000c2971c1b2b8c",
 "wwpn": "5000c2971c1b2b8d"
},
"physical size": 228930,
"pool": "pool0",
"protection mode": "data",
"rated life used percent": 10,
"right size sector count": 1172123568,
"rpm": 15000,
"sector count": 1172123568,
"serial number": "KHG2VX8R",
"shelf": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
```

```
"uid": "7777841915827391056"
 "state": "present",
 "stats": {
   "average latency": 3,
   "iops total": 12854,
   "path error count": 0,
   "power on hours": 21016,
   "throughput": 1957888
 } ,
 "storage pool": {
   " links": {
     "self": {
      "href": "/api/resourcelink"
    }
   },
   "name": "storage pool 1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 "type": "ssd",
 "uid":
0:00000000:00000000",
 "usable size": 959934889984,
 "vendor": "NETAPP",
 "virtual": {
   "container": "nviet12122018113936-rg",
   "object": "flfu63se",
   "storage account": "nviet12122018113936ps"
 }
}
```

Response

```
Status: 200, Ok
```

Error

```
Status: Default
```

ONTAP Error Response Codes

Error Code	Description
720951	Unable to unfail the disk.
721066	Node is outside the list of controllers for disk.
1441795	Setting the data key ID to the manufacture secure ID is not allowed when in FIPS-compliance mode.
14155777	The operation failed on one or more disks.
14155778	No self-encrypting disks were specified.
14155779	Status from a node shows that a conflicting operation has occurred. Some disk controls might have changed.
14155780	Could not retrieve the required key ID from the key manager.

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

aggregates

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

dr_node

Name	Туре	Description
name	string	
uuid	string	

drawer

Name	Туре	Description
id	integer	
slot	integer	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

The message and code detailing the error state of this disk.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

disk_error_info

Name	Туре	Description
reason	error	The message and code detailing the error state of this disk.
type	string	Disk error type.

home_node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

key_id

Name	Туре	Description
data	string	Key ID of the data authentication key
fips	string	Key ID of the FIPS authentication key

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

error

This error message and code explaining the disk failure.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

Name	Туре	Description
persistently_failed	boolean	Indicates whether RAID maintains the state of this disk as failed accross reboots.
reason	error	This error message and code explaining the disk failure.

disk_path_info

Name	Туре	Description
initiator	string	Initiator port.
node.name	string	Controller with the initiator port for this path.
node.uuid	string	Controller UUID, to identify node for this path.
port_name	string	Name of the disk port.
port_type	string	Disk port type.
vmdisk_hypervisor_file_name	string	Virtual disk hypervisor file name.
wwnn	string	Target device's World Wide Node Name.

Name	Туре	Description
wwpn	string	Target device's World Wide Port Name.

shelf

Shelf

Name	Туре	Description
_links	_links	
uid	string	

stats

Name	Туре	Description
average_latency	integer	Average I/O latency across all active paths, in milliseconds.
iops_total	integer	Total I/O operations per second read and written to this disk across all active paths.
path_error_count	integer	Disk path error count; failed I/O operations.
power_on_hours	integer	Hours powered on.
throughput	integer	Total disk throughput per second across all active paths, in bytes.

storage_pool

Shared Storage Pool

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

virtual

Information about backing storage for disks on cloud platforms.

Name	Туре	Description
container	string	Container name of the virtual disk.
object	string	Object name of the virtual disk.
storage_account	string	Storage account name of the virtual disk.

disk

Name	Туре	Description
aggregates	array[aggregates]	List of aggregates sharing this disk
bay	integer	Disk shelf bay
bytes_per_sector	integer	Bytes per sector.
class	string	Disk class
compliance_standard	string	Security standard that the device is certified to.
container_type	string	Type of overlying disk container
control_standard	string	Standard that the device supports for encryption control.
dr_node	dr_node	
drawer	drawer	
effective_type	string	Effective Disk type
encryption_operation	string	This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET.
error	array[disk_error_info]	List of disk errors information.
fips_certified	boolean	
firmware_version	string	
home_node	home_node	

Name	Туре	Description
key_id	key_id	
local	boolean	Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.
model	string	
name	string	Cluster-wide disk name
node	node	
outage	outage	Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.
overall_security	string	Overall Security rating, for FIPS-certified devices.
paths	array[disk_path_info]	List of paths to a disk
physical_size	integer	Physical size, in units of bytes
pool	string	Pool to which disk is assigned
protection_mode	string	Mode of drive data protection and FIPS compliance. Possible values are: • open - Data is unprotected
		data - Data protection only, without FIPS compliance
		 part - Data is unprotected; other FIPS compliance settings present
		full - Full data and FIPS compliance protection
		miss - Protection mode information is not available
rated_life_used_percent	integer	Percentage of rated life used

Name	Туре	Description
right_size_sector_count	integer	Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk.
rpm	integer	Revolutions per minute
sector_count	integer	Number of sectors on the disk.
self_encrypting	boolean	
serial_number	string	
shelf	shelf	Shelf
state	string	State
stats	stats	
storage_pool	storage_pool	Shared Storage Pool
type	string	Disk interface type
uid	string	The unique identifier for a disk
usable_size	integer	
vendor	string	
virtual	virtual	Information about backing storage for disks on cloud platforms.

Retrieve a specific disk

GET /storage/disks/{name}

Introduced In: 9.6

Retrieves a specific disk.

Related ONTAP commands

• storage disk show

Learn more

• DOC /storage/disks

Parameters

Name	Туре	In	Required	Description
name	string	path	True	Disk name
fields	array[string]	query	False	Specify the fields to return.

Response

Status: 200, Ok

Name	Туре	Description
aggregates	array[aggregates]	List of aggregates sharing this disk
bay	integer	Disk shelf bay
bytes_per_sector	integer	Bytes per sector.
class	string	Disk class
compliance_standard	string	Security standard that the device is certified to.
container_type	string	Type of overlying disk container
control_standard	string	Standard that the device supports for encryption control.
dr_node	dr_node	
drawer	drawer	
effective_type	string	Effective Disk type
encryption_operation	string	This field should only be set as a query parameter in a PATCH operation. It is input only and won't be returned by a subsequent GET.
error	array[disk_error_info]	List of disk errors information.
fips_certified	boolean	
firmware_version	string	
home_node	home_node	

Name	Туре	Description
key_id	key_id	
local	boolean	Indicates if a disk is locally attached versus being remotely attached. A locally attached disk resides in the same proximity as the host cluster versus been attached to the remote cluster.
model	string	
name	string	Cluster-wide disk name
node	node	
outage	outage	Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.
overall_security	string	Overall Security rating, for FIPS-certified devices.
paths	array[disk_path_info]	List of paths to a disk
physical_size	integer	Physical size, in units of bytes
pool	string	Pool to which disk is assigned
protection_mode	string	Mode of drive data protection and FIPS compliance. Possible values are:
		• open - Data is unprotected
		 data - Data protection only, without FIPS compliance
		 part - Data is unprotected; other FIPS compliance settings present
		full - Full data and FIPS compliance protection
		miss - Protection mode information is not available
rated_life_used_percent	integer	Percentage of rated life used

Name	Туре	Description
right_size_sector_count	integer	Number of usable disk sectors that remain after subtracting the right-size adjustment for this disk.
rpm	integer	Revolutions per minute
sector_count	integer	Number of sectors on the disk.
self_encrypting	boolean	
serial_number	string	
shelf	shelf	Shelf
state	string	State
stats	stats	
storage_pool	storage_pool	Shared Storage Pool
type	string	Disk interface type
uid	string	The unique identifier for a disk
usable_size	integer	
vendor	string	
virtual	virtual	Information about backing storage for disks on cloud platforms.

```
"aggregates": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
  },
  "name": "aggr1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"bay": 1,
"bytes per sector": 520,
"class": "solid state",
"compliance standard": "FIPS 140-2",
"container type": "spare",
"control standard": "TCG Enterprise",
"dr node": {
 "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
"effective type": "vmdisk",
"error": {
  "reason": {
    "arguments": {
     "code": "string",
     "message": "string"
   },
   "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
 },
  "type": "notallflashdisk"
"firmware version": "NA51",
"home node": {
 " links": {
    "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"model": "X421 HCOBE450A10",
```

```
"name": "1.0.1",
"node": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "name": "node1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"outage": {
 "reason": {
    "arguments": {
      "code": "string",
     "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
   "target": "uuid"
 }
},
"overall security": "Level 2",
"paths": {
  "initiator": "3a",
  "node.name": "vsim4",
  "node.uuid": "cf7fe057-526d-11ec-af4e-0050568e9df0",
  "port name": "A",
  "port type": "sas",
  "vmdisk hypervisor file name": "xvds vol0a0567ae156ca59f6",
  "wwnn": "5000c2971c1b2b8c",
 "wwpn": "5000c2971c1b2b8d"
},
"physical size": 228930,
"pool": "pool0",
"protection mode": "data",
"rated life used percent": 10,
"right size sector count": 1172123568,
"rpm": 15000,
"sector count": 1172123568,
"serial number": "KHG2VX8R",
"shelf": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
```

```
"uid": "7777841915827391056"
 "state": "present",
 "stats": {
   "average latency": 3,
   "iops total": 12854,
   "path error count": 0,
   "power on hours": 21016,
   "throughput": 1957888
 } ,
 "storage pool": {
   " links": {
    "self": {
      "href": "/api/resourcelink"
    }
   },
   "name": "storage pool 1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 "type": "ssd",
 "uid":
0:00000000:00000000",
 "usable size": 959934889984,
 "vendor": "NETAPP",
 "virtual": {
   "container": "nviet12122018113936-rg",
   "object": "f1fu63se",
   "storage account": "nviet12122018113936ps"
 }
}
```

Error

```
Status: Default, Error
```

Name	Туре	Description
error	error	

Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

Definitions

See Definitions

href

Name	Туре	Description
href	string	

_links

Name	Туре	Description
self	href	

aggregates

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

dr_node

Name	Туре	Description
name	string	
uuid	string	

drawer

Name	Туре	Description
id	integer	
slot	integer	

error_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

The message and code detailing the error state of this disk.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

disk_error_info

Name	Туре	Description
reason	error	The message and code detailing the error state of this disk.
type	string	Disk error type.

home_node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

key_id

Name	Туре	Description
data	string	Key ID of the data authentication key
fips	string	Key ID of the FIPS authentication key

node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

error

This error message and code explaining the disk failure.

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

outage

Indicates if a disk has an entry in the failed disk registry, along with the reason for the failure.

Name	Туре	Description
persistently_failed	boolean	Indicates whether RAID maintains the state of this disk as failed accross reboots.
reason	error	This error message and code explaining the disk failure.

disk_path_info

Name	Туре	Description
initiator	string	Initiator port.
node.name	string	Controller with the initiator port for this path.
node.uuid	string	Controller UUID, to identify node for this path.
port_name	string	Name of the disk port.
port_type	string	Disk port type.
vmdisk_hypervisor_file_name	string	Virtual disk hypervisor file name.
wwnn	string	Target device's World Wide Node Name.

Name	Туре	Description
wwpn	string	Target device's World Wide Port Name.

shelf

Shelf

Name	Туре	Description
_links	_links	
uid	string	

stats

Name	Туре	Description
average_latency	integer	Average I/O latency across all active paths, in milliseconds.
iops_total	integer	Total I/O operations per second read and written to this disk across all active paths.
path_error_count	integer	Disk path error count; failed I/O operations.
power_on_hours	integer	Hours powered on.
throughput	integer	Total disk throughput per second across all active paths, in bytes.

storage_pool

Shared Storage Pool

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

virtual

Information about backing storage for disks on cloud platforms.

Name	Туре	Description
container	string	Container name of the virtual disk.
object	string	Object name of the virtual disk.
storage_account	string	Storage account name of the virtual disk.

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

Trademark information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.