# **■** NetApp

# **NVMe**

ONTAP 9.12.1 REST API reference

NetApp February 13, 2024

This PDF was generated from https://docs.netapp.com/us-en/ontap-restapi-9121/ontap/nvme\_overview.html on February 13, 2024. Always check docs.netapp.com for the latest.

# **Table of Contents**

le	1
VMe overview	1
ew NVMe interfaces	2
anage NVMe services	24
ew NVMe subsystem controllers	134
anage NVMe subsystem maps	159
anage NVMe subsystems	195
anage NVMe namespaces	290

# **NVMe**

# **NVMe** overview

#### **Overview**

The Non-Volatile Memory Express (NVMe) API endpoints and objects provide for configuration, provisioning and management of the NVMe-related objects. NVMe over Fabrics (NVMe-oF) refers to the extensions and changes to the base NVMe command set to support NVMe commands over a fabric interconnect and from multiple hosts simultaneously. ONTAP implements elements of both NVMe and NVMe-oF. Throughout this documentation, NVMe is generally used to refer to both NVMe and NVMe-oF.

#### **Fibre Channel Logins**

Fibre Channel logins represent connections, formed by Fibre Channel initiators, that have successfully logged in to ONTAP. This represents the Fibre Channel login on which higher-level protocols such as Fibre Channel Protocol (FCP) and Non-Volatile Memory Express over Fibre Channel (NVMe over FC) rely.

The Fibre Channel logins REST API provides information about active Fibre Channel logins.

#### **NVMe Interfaces**

NVMe interfaces are network interfaces configured to support an NVMe over Fabrics protocol. The NVMe interfaces are Fibre Channel interfaces supporting an NVMe-oF data protocol. Regardless of the underlying physical and data protocol, NVMe interfaces are treated equally for the host-side application configuration. This endpoint provides a consolidated view of all NVMe interfaces for the purpose of configuring host-side applications.

The NVMe interfaces REST API provides NVMe-specific information about network interfaces configured to support an NVMe-oF protocol.

#### **Learn More**

• Fibre Channel Interfaces found in the *networking* section. Fibre Channel interfaces are the logical endpoints for Fibre Channel network connections to an SVM.

#### **NVMe Services**

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for a given SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

The Non-Volatile Memory Express (NVMe) service REST API allows you to create, update, delete, and discover NVMe services for SVMs.

#### **NVMe Subsystem Controllers**

Non-Volatile Memory Express (NVMe) subsystem controllers represent dynamic connections between hosts and a storage solution.

The NVMe subsystem controllers REST API provides information about connected hosts.

#### **NVMe Subsystem Maps**

An NVMe subsystem map is an association of an NVMe namespace with an NVMe subsystem. When an NVMe namespace is mapped to an NVMe subsystem, the NVMe subsystem's hosts are granted access to the NVMe namespace. The relationship between an NVMe subsystem and an NVMe namespace is one subsystem to many namespaces.

The NVMe subsystem map REST API allows you to create, delete, and discover NVMe subsystem maps.

#### **NVMe Subsystems**

An NVMe subsystem maintains configuration state and namespace access control for a set of NVMeconnected hosts.

The NVMe subsystem REST API allows you to create, update, delete, and discover NVMe subsystems. It also allows you to add and remove NVMe hosts that can access the subsystem and associated namespaces.

#### **NVMe Namespaces**

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

The NVMe namespace REST API allows you to create, update, delete, and discover NVMe namespaces.

# **View NVMe interfaces**

# **Protocols NVMe interfaces endpoint overview**

#### Overview

NVMe interfaces are network interfaces configured to support an NVMe over Fabrics (NVMe-oF) protocol. The NVMe interfaces are Fibre Channel (FC) interfaces supporting an NVMe-oF data protocol. Regardless of the underlying physical and data protocol, NVMe interfaces are treated equally for host-side application configuration. This endpoint provides a consolidated view of all NVMe interfaces for the purpose of configuring host-side applications.

The NVMe interfaces REST API provides NVMe-specific information about network interfaces configured to support an NVMe-oF protocol.

NVMe interfaces must be created using the protocol-specific endpoints for FC interfaces. See POST /network/fc/interfaces . After creation, the interfaces are available via this interface.

#### **Examples**

#### Retrieving summary information for all NVMe interfaces

```
# The API:
GET /api/protocols/nvme/interfaces

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/interfaces' -H 'Accept:
application/hal+json'
```

```
# The response:
{
"records": [
    "svm": {
      "uuid": "013e2c44-0d30-11e9-a684-005056bbdb14",
      "name": "svm1",
      " links": {
       "self": {
          "href": "/api/svm/svms/013e2c44-0d30-11e9-a684-005056bbdb14"
        }
     }
    },
    "uuid": "74d69872-0d30-11e9-a684-005056bbdb14",
    "name": "nvme1",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/interfaces/74d69872-0d30-11e9-a684-
005056bbdb14"
     }
  },
    "svm": {
      "uuid": "013e2c44-0d30-11e9-a684-005056bbdb14",
      "name": "svm1",
      " links": {
        "self": {
          "href": "/api/svm/svms/013e2c44-0d30-11e9-a684-005056bbdb14"
      }
    "uuid": "77ded991-0d30-11e9-a684-005056bbdb14",
    "name": "nvme2",
    " links": {
        "href": "/api/protocols/nvme/interfaces/77ded991-0d30-11e9-a684-
005056bbdb14"
      }
    }
],
"num records": 2,
" links": {
 "self": {
```

```
"href": "/api/protocols/nvme/interfaces"
}
}
}
```

#### Retrieving detailed information for a specific NVMe interface

```
# The API:
GET /api/protocols/nvme/interfaces/{uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/interfaces/77ded991-
0d30-11e9-a684-005056bbdb14' -H 'Accept: application/hal+json'
# The response:
"svm": {
 "uuid": "013e2c44-0d30-11e9-a684-005056bbdb14",
 "name": "svm1",
 " links": {
    "self": {
      "href": "/api/svm/svms/013e2c44-0d30-11e9-a684-005056bbdb14"
  }
},
"uuid": "77ded991-0d30-11e9-a684-005056bbdb14",
"name": "nvme2",
"enabled": true,
"node": {
 "name": "node1",
 "uuid": "cd4d47fd-0d2e-11e9-a684-005056bbdb14",
 " links": {
    "self": {
      "href": "/api/cluster/nodes/cd4d47fd-0d2e-11e9-a684-005056bbdb14"
 }
"transport address": "nn-0x2003005056bbdb14:pn-0x2005005056bbdb14",
"fc interface": {
  "wwnn": "20:03:00:50:56:bb:db:14",
  "wwpn": "20:05:00:50:56:bb:db:14",
  "port": {
    "name": "1a",
    "uuid": "081ec491-0d2f-11e9-a684-005056bbdb14",
```

```
"node": {
      "name": "node1"
    },
    " links": {
      "self": {
        "href": "/api/network/fc/ports/081ec491-0d2f-11e9-a684-
005056bbdb14"
     }
    }
  },
  " links": {
   "self": {
      "href": "/api/network/fc/interfaces/77ded991-0d30-11e9-a684-
005056bbdb14"
   }
  }
},
" links": {
 "self": {
    "href": "/api/protocols/nvme/interfaces/77ded991-0d30-11e9-a684-
005056bbdb14"
 }
}
}
```

# **Retrieve NVMe interfaces**

GET /protocols/nvme/interfaces

Introduced In: 9.6

Retrieves NVMe interfaces.

#### **Related ONTAP commands**

• vserver nvme show-interface

# Learn more

• DOC /protocols/nvme/interfaces

#### **Parameters**

Name	Туре	In	Required	Description
fc_interface.port.nod e.name	string	query	False	Filter by fc_interface.port.nod e.name
fc_interface.port.na me	string	query	False	Filter by fc_interface.port.na me
fc_interface.port.uuid	string	query	False	Filter by fc_interface.port.uui d
fc_interface.wwnn	string	query	False	Filter by fc_interface.wwnn
fc_interface.wwpn	string	query	False	Filter by fc_interface.wwpn
ip_interface.ip.addre ss	string	query	False	Filter by ip_interface.ip.addre ss  • Introduced in: 9.10
ip_interface.location. port.uuid	string	query	False	Filter by ip_interface.location. port.uuid  • Introduced in: 9.10
ip_interface.location. port.name	string	query	False	Filter by ip_interface.location. port.name  • Introduced in: 9.10
ip_interface.location. port.node.name	string	query	False	Filter by ip_interface.location. port.node.name  • Introduced in: 9.10

Name	Туре	In	Required	Description
interface_type	string	query	False	Filter by interface_type  • Introduced in: 9.10
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
transport_protocols	string	query	False	Filter by transport_protocols  • Introduced in: 9.10
enabled	boolean	query	False	Filter by enabled
name	string	query	False	Filter by name
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name
transport_address	string	query	False	Filter by transport_address
uuid	string	query	False	Filter by uuid
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_interface]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "fc interface": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    } ,
    "port": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "0a",
      "node": {
       "name": "node1"
      },
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "wwnn": "20:00:00:50:56:b4:13:a9",
    "wwpn": "20:00:00:50:56:b4:13:a8"
  "interface type": "fc_interface",
  "ip interface": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
      }
```

```
"ip": {
        "address": "10.10.10.7"
      },
      "location": {
        "port": {
          " links": {
            "self": {
             "href": "/api/resourcelink"
           }
          },
          "name": "e1b",
          "node": {
          "name": "node1"
          },
         "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
        }
     }
    "name": "lif1",
    "node": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "svm": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
     "name": "svm1",
     "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
    },
    "transport address": "nn-0x200a00a0989062da:pn-0x200100a0989062da",
    "transport protocols": {
   },
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
}
```

# **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

# **Definitions**

#### **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

# node

The node on which the FC port is located.

Name	Туре	Description
name	string	The name of the node on which the FC port is located.

# port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Туре	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

# fc\_interface

The attributes specific to a Fibre Channel-based NVMe interface.

This is populated when interface type is fc\_interface.

Name	Туре	Description
_links	_links	
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
wwnn	string	The WWNN (world wide node name) of the Fibre Channel NVMe interface.
wwpn	string	The WWPN (world wide port name) of the Fibre Channel NVMe interface.

# self\_link

Name	Туре	Description
self	href	

# iр

Name	Туре	Description
address	string	IPv4 or IPv6 address

# node

Name	Туре	Description
name	string	Name of node on which the port is located.

# port\_reference

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Туре	Description
_links	_links	
name	string	
node	node	
uuid	string	

# location

Name	Туре	Description
port	port_reference	Port UUID along with readable names. Either the UUID or both names may be supplied on input.

# ip\_interface

The attributes specific to an IP-based NVMe interface.

This is populated when interface type is *ip\_interface*.

Name	Туре	Description
_links	self_link	
ip	ip	
location	location	

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

# nvme\_interface

NVMe interfaces are network interfaces configured to support an NVMe over Fabrics (NVMe-oF) protocol. The NVMe interfaces are Fibre Channel interfaces supporting an NVMe-oF data protocol. Regardless of the underlying physical and data protocol, NVMe interfaces are treated equally for host-side application configuration. This endpoint provides a consolidated view of all NVMe interfaces for the purpose of configuring host-side applications.

NVMe interfaces must be created using the protocol-specific endpoints for Fibre Channel interfaces. See POST /network/fc/interfaces . After creation, the interfaces are available via this interface.

Name	Туре	Description
_links	_links	

Name	Туре	Description
enabled	boolean	The administrative state of the NVMe interface.
fc_interface	fc_interface	The attributes specific to a Fibre Channel-based NVMe interface.  This is populated when interface_type is fc_interface.
interface_type	string	The underlying interface type of the NVMe interface. This property identifies which of <i>fc_interface</i> and <i>ip_interface</i> will be further populated.
ip_interface	ip_interface	The attributes specific to an IP-based NVMe interface.  This is populated when interface_type is ip_interface.
name	string	The name of the NVMe interface.
node	node	
svm	svm	
transport_address	string	The transport address of the NVMe interface.
transport_protocols	array[string]	The transport protocols supported by the NVMe interface.
uuid	string	The unique identifier of the NVMe interface.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve an NVMe interface

GET /protocols/nvme/interfaces/{uuid}

Introduced In: 9.6

Retrieves an NVMe interface.

# **Related ONTAP commands**

• vserver nvme show-interface

# Learn more

• DOC /protocols/nvme/interfaces

# **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe interface.
fields	array[string]	query	False	Specify the fields to return.

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	

Name	Туре	Description
enabled	boolean	The administrative state of the NVMe interface.
fc_interface	fc_interface	The attributes specific to a Fibre Channel-based NVMe interface.  This is populated when interface_type is fc_interface.
interface_type	string	The underlying interface type of the NVMe interface. This property identifies which of <i>fc_interface</i> and <i>ip_interface</i> will be further populated.
ip_interface	ip_interface	The attributes specific to an IP-based NVMe interface.  This is populated when interface_type is ip_interface.
name	string	The name of the NVMe interface.
node	node	
svm	svm	
transport_address	string	The transport address of the NVMe interface.
transport_protocols	array[string]	The transport protocols supported by the NVMe interface.
uuid	string	The unique identifier of the NVMe interface.

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"fc interface": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "port": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "0a",
    "node": {
     "name": "node1"
    },
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  "wwnn": "20:00:00:50:56:b4:13:a9",
  "wwpn": "20:00:00:50:56:b4:13:a8"
"interface type": "fc interface",
"ip interface": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "ip": {
   "address": "10.10.10.7"
  },
  "location": {
   "port": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
```

```
"name": "e1b",
      "node": {
       "name": "node1"
      } ,
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
},
"name": "lif1",
"node": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "node1",
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"svm": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
 },
  "name": "svm1",
 "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
"transport address": "nn-0x200a00a0989062da:pn-0x200100a0989062da",
"transport protocols": {
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

# **Error**

```
Status: Default
```

# **ONTAP Error Response Codes**

Error Code	Description
2621462	The supplied SVM does not exist.

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

# **Definitions**

# **See Definitions**

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

#### node

The node on which the FC port is located.

Name	Туре	Description
name	string	The name of the node on which the FC port is located.

# port

An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.

Name	Туре	Description
_links	_links	
name	string	The name of the FC port.
node	node	The node on which the FC port is located.
uuid	string	The unique identifier of the FC port.

# fc\_interface

The attributes specific to a Fibre Channel-based NVMe interface.

This is populated when interface type is fc\_interface.

Name	Туре	Description
_links	_links	

Name	Туре	Description
port	port	An FC port is the physical port of an FC adapter on a cluster node that can be connected to an FC network.
wwnn	string	The WWNN (world wide node name) of the Fibre Channel NVMe interface.
wwpn	string	The WWPN (world wide port name) of the Fibre Channel NVMe interface.

# self\_link

Name	Туре	Description
self	href	

ip

Name	Туре	Description
address	string	IPv4 or IPv6 address

# node

Name	Туре	Description
name	string	Name of node on which the port is located.

# port\_reference

Port UUID along with readable names. Either the UUID or both names may be supplied on input.

Name	Туре	Description
_links	_links	
name	string	
node	node	
uuid	string	

# location

Name	Туре	Description
port		Port UUID along with readable names. Either the UUID or both names may be supplied on input.

# ip\_interface

The attributes specific to an IP-based NVMe interface.

This is populated when  $interface\_type$  is  $ip\_interface$ .

Name	Туре	Description
_links	self_link	
ip	ip	
location	location	

# node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

# svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

# error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Manage NVMe services

# **Protocols NVMe services endpoint overview**

#### Overview

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

The Non-Volatile Memory Express (NVMe) service REST API allows you to create, update, delete, and discover NVMe services for SVMs.

# **Performance monitoring**

Performance of the SVM can be monitored by the metric.\* and statistics.\* properties. These show the performance of the SVM in terms of IOPS, latency and throughput. The metric.\* properties denote an average whereas statistics.\* properties denote a real-time monotonically increasing value aggregated across all nodes.

# **Examples**

#### Creating an NVMe service for an SVM

The simpliest way to create an NVMe service is to specify only the SVM, either by name or UUID. By default, the new NVMe service is enabled.

In this example, the return\_records query parameter is used to retrieve the new NVMe service object in the REST response.

```
# The API:
POST /api/protocols/nvme/services
# The call:
curl -X POST 'https://<mgmt-</pre>
ip>/api/protocols/nvme/services?return records=true' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" } }'
# The response:
"num records": 1,
"records": [
    "svm": {
      "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
      "name": "svm1",
      " links": {
        "self": {
          "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
     }
    },
    "enabled": true,
    " links": {
      "self": {
        "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
 }
1
}
```

# Retrieving the NVMe services for all SVMs in the cluster

```
# The API:
GET /api/protocols/nvme/services

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services' -H 'Accept:
application/hal+json'

# The response:
```

```
"records": [
  {
    "svm": {
      "uuid": "ab60c350-dc68-11e8-9711-005056bbe408",
      "name": "svm0",
      " links": {
        "self": {
          "href": "/api/svm/svms/ab60c350-dc68-11e8-9711-005056bbe408"
      }
    },
    " links": {
      "self": {
        "href": "/api/protocols/nvme/services/ab60c350-dc68-11e8-9711-
005056bbe408"
    }
  },
    "svm": {
      "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
      "name": "svm1",
      " links": {
        "self": {
          "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
     }
    },
    " links": {
      "self": {
        "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
   }
}
],
"num records": 2,
" links": {
 "self": {
    "href": "/api/protocols/nvme/services"
 }
}
}
```

#### Retrieving details for a specific NVMe service

The NVMe service is identified by the UUID of its SVM.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-
11e8-b29f-005056bb7341' -H 'Accept: application/hal+json'
# The response:
{
"svm": {
  "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
  "name": "svm1",
  " links": {
    "self": {
      "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
  }
},
"enabled": true,
" links": {
  "self": {
    "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
  }
}
}
```

#### Disabling an NVMe service

Disabling an NVMe service shuts down all active NVMe connections for the SVM and prevents the creation of new NVMe connections.

The NVMe service to update is identified by the UUID of its SVM.

```
# The API:
PATCH /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/protocols/nvme/services/bfblbeb0-
dc69-11e8-b29f-005056bb7341' -H 'Accept: application/hal+json' -d '{
"enabled": "false" }'
```

You can retrieve the NVMe service to confirm the change.

```
# The API:
GET /api/protocols/nvme/services/{svm.uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-dc69-
11e8-b29f-005056bb7341' -H 'Accept: application/hal+json'
# The response:
"svm": {
  "uuid": "bfb1beb0-dc69-11e8-b29f-005056bb7341",
  "name": "svm1",
  " links": {
    "self": {
      "href": "/api/svm/svms/bfb1beb0-dc69-11e8-b29f-005056bb7341"
    }
  }
},
"enabled": false,
" links": {
    "href": "/api/protocols/nvme/services/bfb1beb0-dc69-11e8-b29f-
005056bb7341"
 }
}
}
```

#### **Deleting an NVMe service**

The NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

The NVMe service to delete is identified by the UUID of its SVM.

```
# The API:
DELETE /api/protocols/nvme/services/{svm.uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/services/bfb1beb0-
dc69-11e8-b29f-005056bb7341' -H 'Accept: application/hal+json'
```

# **Retrieve NVMe services**

GET /protocols/nvme/services

Introduced In: 9.6

Retrieves NVMe services.

# **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

- statistics.\*
- metric.\*

#### **Related ONTAP commands**

vserver nvme show

#### Learn more

• DOC /protocols/nvme/services

#### **Parameters**

Name	Туре	In	Required	Description
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
metric.duration	string	query	False	Filter by metric.duration  • Introduced in: 9.7

Name	Туре	In	Required	Description
metric.status	string	query	False	Filter by metric.status  • Introduced in: 9.7
metric.iops.total	integer	query	False	Filter by metric.iops.total  • Introduced in: 9.7
metric.iops.read	integer	query	False	Filter by metric.iops.read  • Introduced in: 9.7
metric.iops.write	integer	query	False	Filter by metric.iops.write  • Introduced in: 9.7
metric.iops.other	integer	query	False	Filter by metric.iops.other  • Introduced in: 9.7
metric.fc.latency.total	integer	query	False	Filter by metric.fc.latency.tota I  • Introduced in: 9.10
metric.fc.latency.rea	integer	query	False	Filter by metric.fc.latency.rea d  • Introduced in: 9.10

Name	Туре	In	Required	Description
metric.fc.latency.writ e	integer	query	False	Filter by metric.fc.latency.writ e  • Introduced in: 9.10
metric.fc.latency.oth er	integer	query	False	Filter by metric.fc.latency.oth er  • Introduced in: 9.10
metric.fc.duration	string	query	False	Filter by metric.fc.duration  • Introduced in: 9.10
metric.fc.throughput. read	integer	query	False	Filter by metric.fc.throughput. read  • Introduced in: 9.10
metric.fc.throughput. total	integer	query	False	Filter by metric.fc.throughput. total  • Introduced in: 9.10
metric.fc.throughput. write	integer	query	False	Filter by metric.fc.throughput. write  • Introduced in: 9.10
metric.fc.status	string	query	False	Filter by metric.fc.status  • Introduced in: 9.10

Name	Туре	In	Required	Description
metric.fc.iops.total	integer	query	False	Filter by metric.fc.iops.total  • Introduced in: 9.10
metric.fc.iops.read	integer	query	False	Filter by metric.fc.iops.read  • Introduced in: 9.10
metric.fc.iops.write	integer	query	False	Filter by metric.fc.iops.write  • Introduced in: 9.10
metric.fc.iops.other	integer	query	False	Filter by metric.fc.iops.other  • Introduced in: 9.10
metric.fc.timestamp	string	query	False	Filter by metric.fc.timestamp  • Introduced in: 9.10
metric.throughput.re ad	integer	query	False	Filter by metric.throughput.re ad  • Introduced in: 9.7
metric.throughput.tot	integer	query	False	Filter by metric.throughput.tot al  • Introduced in: 9.7

Name	Туре	In	Required	Description
metric.throughput.wri te	integer	query	False	Filter by metric.throughput.wr ite  • Introduced in: 9.7
metric.latency.total	integer	query	False	Filter by metric.latency.total  • Introduced in: 9.7
metric.latency.read	integer	query	False	Filter by metric.latency.read  • Introduced in: 9.7
metric.latency.write	integer	query	False	Filter by metric.latency.write  • Introduced in: 9.7
metric.latency.other	integer	query	False	Filter by metric.latency.other  • Introduced in: 9.7
metric.tcp.latency.tot al	integer	query	False	Filter by metric.tcp.latency.tot al  • Introduced in: 9.10
metric.tcp.latency.re ad	integer	query	False	Filter by metric.tcp.latency.re ad  • Introduced in: 9.10

Name	Туре	In	Required	Description
metric.tcp.latency.wri te	integer	query	False	Filter by metric.tcp.latency.wr ite  • Introduced in: 9.10
metric.tcp.latency.ot her	integer	query	False	Filter by metric.tcp.latency.ot her  • Introduced in: 9.10
metric.tcp.duration	string	query	False	Filter by metric.tcp.duration  • Introduced in: 9.10
metric.tcp.throughpu t.read	integer	query	False	Filter by metric.tcp.throughpu t.read  • Introduced in: 9.10
metric.tcp.throughpu t.total	integer	query	False	Filter by metric.tcp.throughpu t.total  • Introduced in: 9.10
metric.tcp.throughpu t.write	integer	query	False	Filter by metric.tcp.throughpu t.write  • Introduced in: 9.10
metric.tcp.status	string	query	False	Filter by metric.tcp.status  • Introduced in: 9.10

Name	Туре	In	Required	Description
metric.tcp.iops.total	integer	query	False	Filter by metric.tcp.iops.total  • Introduced in: 9.10
metric.tcp.iops.read	integer	query	False	Filter by metric.tcp.iops.read  • Introduced in: 9.10
metric.tcp.iops.write	integer	query	False	Filter by metric.tcp.iops.write  • Introduced in: 9.10
metric.tcp.iops.other	integer	query	False	Filter by metric.tcp.iops.other  • Introduced in: 9.10
metric.tcp.timestamp	string	query	False	Filter by metric.tcp.timestamp  • Introduced in: 9.10
metric.timestamp	string	query	False	Filter by metric.timestamp  • Introduced in: 9.7
statistics.timestamp	string	query	False	Filter by statistics.timestamp  • Introduced in: 9.7
statistics.status	string	query	False	Filter by statistics.status  • Introduced in: 9.7

Name	Туре	In	Required	Description
statistics.fc.throughp ut_raw.read	integer	query	False	Filter by statistics.fc.throughp ut_raw.read • Introduced in: 9.10
statistics.fc.throughp ut_raw.total	integer	query	False	Filter by statistics.fc.throughp ut_raw.total  • Introduced in: 9.10
statistics.fc.throughp ut_raw.write	integer	query	False	Filter by statistics.fc.throughp ut_raw.write  • Introduced in: 9.10
statistics.fc.latency_r aw.total	integer	query	False	Filter by statistics.fc.latency_r aw.total  • Introduced in: 9.10
statistics.fc.latency_r aw.read	integer	query	False	Filter by statistics.fc.latency_r aw.read • Introduced in: 9.10
statistics.fc.latency_r aw.write	integer	query	False	Filter by statistics.fc.latency_r aw.write  • Introduced in: 9.10
statistics.fc.latency_r aw.other	integer	query	False	Filter by statistics.fc.latency_r aw.other  • Introduced in: 9.10

Name	Туре	In	Required	Description
statistics.fc.iops_raw .total	integer	query	False	Filter by statistics.fc.iops_raw .total  • Introduced in: 9.10
statistics.fc.iops_raw .read	integer	query	False	Filter by statistics.fc.iops_raw .read  • Introduced in: 9.10
statistics.fc.iops_raw .write	integer	query	False	Filter by statistics.fc.iops_raw .write  • Introduced in: 9.10
statistics.fc.iops_raw .other	integer	query	False	Filter by statistics.fc.iops_raw .other  • Introduced in: 9.10
statistics.fc.timestam p	string	query	False	Filter by statistics.fc.timestam p  • Introduced in: 9.10
statistics.fc.status	string	query	False	Filter by statistics.fc.status  • Introduced in: 9.10
statistics.latency_ra w.total	integer	query	False	Filter by statistics.latency_ra w.total  • Introduced in: 9.7

Name	Туре	In	Required	Description
statistics.latency_ra w.read	integer	query	False	Filter by statistics.latency_ra w.read  • Introduced in: 9.7
statistics.latency_ra w.write	integer	query	False	Filter by statistics.latency_ra w.write  • Introduced in: 9.7
statistics.latency_ra w.other	integer	query	False	Filter by statistics.latency_ra w.other  • Introduced in: 9.7
statistics.throughput _raw.read	integer	query	False	Filter by statistics.throughput _raw.read  • Introduced in: 9.7
statistics.throughput _raw.total	integer	query	False	Filter by statistics.throughput _raw.total  • Introduced in: 9.7
statistics.throughput _raw.write	integer	query	False	Filter by statistics.throughput _raw.write  • Introduced in: 9.7
statistics.tcp.through put_raw.read	integer	query	False	Filter by statistics.tcp.through put_raw.read  • Introduced in: 9.10

Name	Туре	In	Required	Description
statistics.tcp.through put_raw.total	integer	query	False	Filter by statistics.tcp.through put_raw.total  • Introduced in: 9.10
statistics.tcp.through put_raw.write	integer	query	False	Filter by statistics.tcp.through put_raw.write  • Introduced in: 9.10
statistics.tcp.latency _raw.total	integer	query	False	Filter by statistics.tcp.latency _raw.total  • Introduced in: 9.10
statistics.tcp.latency _raw.read	integer	query	False	Filter by statistics.tcp.latency _raw.read  • Introduced in: 9.10
statistics.tcp.latency _raw.write	integer	query	False	Filter by statistics.tcp.latency _raw.write  • Introduced in: 9.10
statistics.tcp.latency _raw.other	integer	query	False	Filter by statistics.tcp.latency _raw.other  • Introduced in: 9.10
statistics.tcp.iops_ra w.total	integer	query	False	Filter by statistics.tcp.iops_ra w.total  • Introduced in: 9.10

Name	Туре	In	Required	Description
statistics.tcp.iops_ra w.read	integer	query	False	Filter by statistics.tcp.iops_ra w.read  • Introduced in: 9.10
statistics.tcp.iops_ra w.write	integer	query	False	Filter by statistics.tcp.iops_ra w.write  • Introduced in: 9.10
statistics.tcp.iops_ra w.other	integer	query	False	Filter by statistics.tcp.iops_ra w.other  • Introduced in: 9.10
statistics.tcp.timesta mp	string	query	False	Filter by statistics.tcp.timesta mp  • Introduced in: 9.10
statistics.tcp.status	string	query	False	Filter by statistics.tcp.status  • Introduced in: 9.10
statistics.iops_raw.to tal	integer	query	False	Filter by statistics.iops_raw.to tal  • Introduced in: 9.7
statistics.iops_raw.re ad	integer	query	False	Filter by statistics.iops_raw.r ead  • Introduced in: 9.7

Name	Туре	In	Required	Description
statistics.iops_raw.w rite	integer	query	False	Filter by statistics.iops_raw.w rite  • Introduced in: 9.7
statistics.iops_raw.ot her	integer	query	False	Filter by statistics.iops_raw.ot her  • Introduced in: 9.7
enabled	boolean	query	False	Filter by enabled
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0

Name	Туре	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_service]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "metric": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
    "fc": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "duration": "PT15S",
      "iops": {
       "read": 200,
       "total": 1000,
       "write": 100
      },
      "latency": {
       "read": 200,
       "total": 1000,
       "write": 100
      } ,
      "status": "ok",
      "throughput": {
       "read": 200,
       "total": 1000,
```

```
"write": 100
 },
  "timestamp": "2017-01-25T11:20:13Z"
},
"iops": {
 "read": 200,
 "total": 1000,
 "write": 100
},
"latency": {
 "read": 200,
 "total": 1000,
 "write": 100
},
"status": "ok",
"tcp": {
 " links": {
   "self": {
    "href": "/api/resourcelink"
   }
 },
  "duration": "PT15S",
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput": {
  "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"throughput": {
 "read": 200,
 "total": 1000,
 "write": 100
"timestamp": "2017-01-25T11:20:13Z"
```

```
} ,
"statistics": {
 "fc": {
    "iops raw": {
     "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency raw": {
    "read": 200,
    "total": 1000,
     "write": 100
   } ,
   "status": "ok",
   "throughput raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    "timestamp": "2017-01-25T11:20:13Z"
 },
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 } ,
 "latency_raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "tcp": {
   "iops raw": {
    "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "status": "ok",
    "throughput raw": {
     "read": 200,
```

```
"total": 1000,
       "write": 100
      },
      "timestamp": "2017-01-25T11:20:13Z"
    "throughput raw": {
      "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "timestamp": "2017-01-25T11:20:13Z"
  } ,
  "svm": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

# Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

# **Definitions**

# **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

fc

The NVMe/FC portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_ delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

tcp

The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

# metric

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	

Name	Туре	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
fc	fc	The NVMe/FC portion of the aggregated metrics.
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated metrics.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
timestamp	string	The timestamp of the performance data.

# iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

fc

The NVMe/FC portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

# tcp

The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

# statistics

These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated statistics.
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

# nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# **Create an NVMe service**

POST /protocols/nvme/services

Introduced In: 9.6

Creates an NVMe service.

# **Required properties**

• svm.uuid or svm.name - The existing SVM in which to create the NVMe service.

# **Related ONTAP commands**

• vserver nvme create

# Learn more

• DOC /protocols/nvme/services

# **Parameters**

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned.  • Default value:

# **Request Body**

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"metric": {
 " links": {
  "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "fc": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
    "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
  "read": 200,
   "total": 1000,
  "write": 100
  },
  "latency": {
```

```
"read": 200,
   "total": 1000,
   "write": 100
  },
  "status": "ok",
  "tcp": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
   "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
   "status": "ok",
   "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
   },
   "timestamp": "2017-01-25T11:20:13Z"
  } ,
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"statistics": {
 "fc": {
   "iops raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    "latency raw": {
     "read": 200,
```

```
"total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"iops raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
"latency raw": {
"read": 200,
"total": 1000,
"write": 100
} ,
"status": "ok",
"tcp": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"throughput raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
```

# Response

```
Status: 201, Created
```

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_service]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "metric": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
    "fc": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "duration": "PT15S",
      "iops": {
       "read": 200,
       "total": 1000,
       "write": 100
      },
      "latency": {
       "read": 200,
       "total": 1000,
       "write": 100
      } ,
      "status": "ok",
      "throughput": {
       "read": 200,
        "total": 1000,
```

```
"write": 100
 },
  "timestamp": "2017-01-25T11:20:13Z"
},
"iops": {
 "read": 200,
 "total": 1000,
 "write": 100
},
"latency": {
 "read": 200,
 "total": 1000,
 "write": 100
},
"status": "ok",
"tcp": {
 " links": {
   "self": {
    "href": "/api/resourcelink"
   }
 },
  "duration": "PT15S",
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput": {
  "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"throughput": {
 "read": 200,
 "total": 1000,
 "write": 100
"timestamp": "2017-01-25T11:20:13Z"
```

```
} ,
"statistics": {
 "fc": {
    "iops raw": {
     "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency raw": {
    "read": 200,
     "total": 1000,
     "write": 100
   } ,
   "status": "ok",
   "throughput raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    "timestamp": "2017-01-25T11:20:13Z"
 },
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 } ,
 "latency_raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "tcp": {
   "iops raw": {
    "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "status": "ok",
    "throughput raw": {
     "read": 200,
```

```
"total": 1000,
       "write": 100
      },
      "timestamp": "2017-01-25T11:20:13Z"
    },
    "throughput raw": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "timestamp": "2017-01-25T11:20:13Z"
  } ,
  "svm": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  }
}
```

#### Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

#### **Error**

```
Status: Default
```

#### ONTAP Error Response Codes

Error Code	Description
1115127	The cluster lacks a valid NVMe license.
2621462	The supplied SVM does not exist.
2621507	NVMe is not allowed for the specified SVM.
2621706	The specified svm.uuid and svm.name do not refer to the same SVM.

Error Code	Description
2621707	No SVM was specified. Either svm.name or svm.uuid must be supplied.
5374893	The SVM is stopped. The SVM must be running to create an NVMe service.
72089650	An NVMe service already exists for the specified SVM.
72089900	An NVMe service cannot be creating in an SVM that is configured for a SAN protocol.

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

# **Definitions**

# **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### fc

The NVMe/FC portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## metric

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated metrics.
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated metrics.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## fc

The NVMe/FC portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

### statistics

These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated statistics.
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

### nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	

### \_links

Name	Туре	Description
next	href	
self	href	

### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

### **Delete an NVMe service**

DELETE /protocols/nvme/services/{svm.uuid}

Introduced In: 9.6

Deletes an NVMe service. An NVMe service must be disabled before it can be deleted. In addition, all NVMe interfaces, subsystems, and subsystem maps associated with the SVM must first be deleted.

### **Related ONTAP commands**

• vserver nvme delete

### Learn more

• DOC /protocols/nvme/services

#### **Parameters**

Name	Туре	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM whose NVMe service is to be deleted.

## Response

Status: 200, Ok

#### **Error**

Status: Default

## **ONTAP Error Response Codes**

Error Code	Description
2621462	The supplied SVM does not exist.
72089651	The supplied SVM does not have an NVMe service.
72089653	There are subsystems associated with the NVMe service SVM. The subsystems must be removed before deleting the NVMe service.
72089654	There are NVMe-oF LIFs associated with the NVMe service SVM. The LIFs must be removed before deleting the NVMe service.
72090028	The NVMe service is enabled. The NVMe service must be disabled before it can be deleted.

Name	Туре	Description
error	error	

### **Example error**

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

#### **Definitions**

#### **See Definitions**

error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

### Retrieve an NVMe service

GET /protocols/nvme/services/{svm.uuid}

Introduced In: 9.6

Retrieves an NVMe service.

## **Related ONTAP commands**

• vserver nvme show

### Learn more

• DOC /protocols/nvme/services

### **Parameters**

Name	Туре	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM whose NVMe service is to be retrieved.
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
svm	svm	

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"metric": {
 " links": {
  "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "fc": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
    "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "status": "ok",
    "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
```

```
"read": 200,
   "total": 1000,
   "write": 100
  },
  "status": "ok",
  "tcp": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
    "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
   },
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
    "status": "ok",
   "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
   },
   "timestamp": "2017-01-25T11:20:13Z"
  },
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"statistics": {
 "fc": {
   "iops raw": {
      "read": 200,
     "total": 1000,
     "write": 100
    "latency raw": {
     "read": 200,
```

```
"total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 "timestamp": "2017-01-25T11:20:13Z"
},
"iops raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
"latency raw": {
"read": 200,
"total": 1000,
"write": 100
} ,
"status": "ok",
"tcp": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"throughput raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
```

#### **Error**

```
Status: Default
```

## **ONTAP Error Response Codes**

Error Code	Description
2621462	The supplied SVM does not exist.
72089651	The supplied SVM does not have an NVMe service.

Name	Туре	Description
error	error	

### **Example error**

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

## **Definitions**

### **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

fc

The NVMe/FC portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## metric

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated metrics.
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated metrics.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## fc

The NVMe/FC portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

### statistics

These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated statistics.
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

## error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# **Update an NVMe service**

PATCH /protocols/nvme/services/{svm.uuid}

Introduced In: 9.6

Updates an NVMe service.

### **Related ONTAP commands**

vserver nvme modify

### Learn more

• DOC /protocols/nvme/services

### **Parameters**

Name	Туре	In	Required	Description
svm.uuid	string	path	True	The unique identifier of the SVM whose NVMe service is to be updated.

## **Request Body**

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"metric": {
 " links": {
  "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "fc": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    } ,
    "duration": "PT15S",
    "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "timestamp": "2017-01-25T11:20:13Z"
  },
  "iops": {
  "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
```

```
"read": 200,
   "total": 1000,
   "write": 100
  },
  "status": "ok",
  "tcp": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "duration": "PT15S",
   "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
   } ,
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    } ,
   "status": "ok",
   "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
   },
   "timestamp": "2017-01-25T11:20:13Z"
  } ,
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"statistics": {
 "fc": {
   "iops raw": {
      "read": 200,
     "total": 1000,
     "write": 100
    "latency raw": {
     "read": 200,
```

```
"total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
  "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
},
"iops raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
"latency raw": {
"read": 200,
"total": 1000,
"write": 100
} ,
"status": "ok",
"tcp": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"throughput raw": {
"read": 200,
 "total": 1000,
 "write": 100
},
```

### Response

```
Status: 200, Ok
```

#### **Error**

```
Status: Default
```

## ONTAP Error Response Codes

Error Code	Description
1115127	The cluster lacks a valid NVMe license.
2621462	The supplied SVM does not exist.
5374893	The SVM is stopped. The SVM must be running to create an NVMe service.
72089651	The supplied SVM does not have an NVMe service.

Name	Туре	Description
error	error	

## Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

## **Definitions**

## **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## fc

The NVMe/FC portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## metric

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated metrics.
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated metrics.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## fc

The NVMe/FC portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

## tcp

The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

## statistics

These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
fc	fc	The NVMe/FC portion of the aggregated statistics.
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
tcp	tcp	The NVMe/TCP portion of the aggregated statistics.

Name	Туре	Description
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## nvme\_service

A Non-Volatile Memory Express (NVMe) service defines the properties of the NVMe controller target for an SVM. There can be at most one NVMe service for an SVM. An SVM's NVMe service must be created before NVMe host initiators can connect to the SVM.

An NVMe service is identified by the UUID of its SVM.

Name	Туре	Description
_links	_links	
enabled	boolean	The administrative state of the NVMe service. The NVMe service can be disabled to block all NVMe connectivity to the SVM.  This is optional in POST and PATCH. The default setting is <i>true</i> (enabled) in POST.
metric	metric	Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput for SVM protocols. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
svm	svm	

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve NVMe protocol historical performance metrics

GET /protocols/nvme/services/{svm.uuid}/metrics

Introduced In: 9.7

Retrieves historical performance metrics for NVMe protocol of an SVM.

## **Parameters**

Name	Туре	In	Required	Description
fc.duration	string	query	False	• Introduced in: 9.10
fc.latency.total	integer	query	False	Filter by fc.latency.total  • Introduced in: 9.10
fc.latency.read	integer	query	False	Filter by fc.latency.read  • Introduced in: 9.10
fc.latency.write	integer	query	False	Filter by fc.latency.write  • Introduced in: 9.10
fc.latency.other	integer	query	False	Filter by fc.latency.other  • Introduced in: 9.10
fc.throughput.read	integer	query	False	Filter by fc.throughput.read  • Introduced in: 9.10
fc.throughput.total	integer	query	False	Filter by fc.throughput.total  • Introduced in: 9.10
fc.throughput.write	integer	query	False	Filter by fc.throughput.write  • Introduced in: 9.10

Name	Туре	In	Required	Description
fc.iops.total	integer	query	False	• Introduced in: 9.10
fc.iops.read	integer	query	False	Filter by fc.iops.read  • Introduced in: 9.10
fc.iops.write	integer	query	False	Filter by fc.iops.write  • Introduced in: 9.10
fc.iops.other	integer	query	False	Filter by fc.iops.other  • Introduced in: 9.10
fc.status	string	query	False	Filter by fc.status  • Introduced in: 9.10
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
throughput.write	integer	query	False	Filter by throughput.write
status	string	query	False	Filter by status
iops.total	integer	query	False	Filter by iops.total
iops.read	integer	query	False	Filter by iops.read
iops.write	integer	query	False	Filter by iops.write
iops.other	integer	query	False	Filter by iops.other
duration	string	query	False	Filter by duration

Name	Туре	In	Required	Description
timestamp	string	query	False	Filter by timestamp
tcp.duration	string	query	False	• Introduced in: 9.10
tcp.latency.total	integer	query	False	Filter by tcp.latency.total  • Introduced in: 9.10
tcp.latency.read	integer	query	False	Filter by tcp.latency.read  • Introduced in: 9.10
tcp.latency.write	integer	query	False	Filter by tcp.latency.write  • Introduced in: 9.10
tcp.latency.other	integer	query	False	Filter by tcp.latency.other  • Introduced in: 9.10
tcp.throughput.read	integer	query	False	Filter by tcp.throughput.read  • Introduced in: 9.10
tcp.throughput.total	integer	query	False	Filter by tcp.throughput.total  • Introduced in: 9.10
tcp.throughput.write	integer	query	False	Filter by tcp.throughput.write  • Introduced in: 9.10

Name	Туре	In	Required	Description
tcp.iops.total	integer	query	False	Filter by tcp.iops.total  • Introduced in: 9.10
tcp.iops.read	integer	query	False	Filter by tcp.iops.read  • Introduced in: 9.10
tcp.iops.write	integer	query	False	Filter by tcp.iops.write  • Introduced in: 9.10
tcp.iops.other	integer	query	False	Filter by tcp.iops.other  • Introduced in: 9.10
tcp.status	string	query	False	Filter by tcp.status  • Introduced in: 9.10
latency.total	integer	query	False	Filter by latency.total
latency.read	integer	query	False	Filter by latency.read
latency.write	integer	query	False	Filter by latency.write
latency.other	integer	query	False	Filter by latency.other
svm.uuid	string	path	True	Unique identifier of the SVM.

Name	Туре	In	Required	Description
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows:
				<ul> <li>1h: Metrics over the most recent hour sampled over 15 seconds.</li> </ul>
				<ul> <li>1d: Metrics over the most recent day sampled over 5 minutes.</li> </ul>
				<ul> <li>1w: Metrics over the most recent week sampled over 30 minutes.</li> </ul>
				<ul> <li>1m: Metrics over the most recent month sampled over 2 hours.</li> </ul>
				<ul> <li>1y: Metrics over the most recent year sampled over a day.</li> </ul>
				Default value: 1
				• enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "fc": {
   "duration": "PT15S",
   "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "latency": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput": {
     "read": 200,
     "total": 1000,
     "write": 100
   }
  },
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  "latency": {
   "read": 200,
    "total": 1000,
```

```
"write": 100
    },
    "status": "ok",
    "svm": {
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
   },
    "tcp": {
     "duration": "PT15S",
     "iops": {
      "read": 200,
       "total": 1000,
      "write": 100
     },
     "latency": {
       "read": 200,
       "total": 1000,
       "write": 100
     },
     "status": "ok",
     "throughput": {
       "read": 200,
       "total": 1000,
       "write": 100
     }
    },
   "throughput": {
    "read": 200,
    "total": 1000,
     "write": 100
   "timestamp": "2017-01-25T11:20:13Z"
 }
}
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

## Definitions

## **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

fc

The NVMe/FC portion of the aggregated metrics.

Name	Туре	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.

## svm

Name	Туре	Description
uuid	string	The unique identifier of the SVM.

## tcp

The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.

## records

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	

Name	Туре	Description
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
fc	fc	The NVMe/FC portion of the aggregated metrics.
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
svm	svm	
tcp	tcp	The NVMe/TCP portion of the aggregated metrics.

Name	Туре	Description
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# View NVMe subsystem controllers

# Protocols NVMe subsystem-controllers endpoint overview

#### Overview

Non-Volatile Memory Express (NVMe) subsystem controllers represent dynamic connections between hosts and a storage solution.

The NVMe subsystem controllers REST API provides information about connected hosts.

#### **Examples**

Retrieving the NVMe subsystem controllers for the entire system

```
# The API:
GET /api/protocols/nvme/subsystem-controllers
```

```
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystem-controllers'
-H 'Accept: application/hal+json'
# The response:
"records": [
    "svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
        "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
    "subsystem": {
      "uuid": "14875240-2594-11e9-abde-00a098984313",
      "name": "symmcon symmcon fcnvme vserver 0 subsystem 0",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/14875240-2594-11e9-abde-
00a098984313"
      }
    "id": "0040h",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-
11e9-abde-00a098984313/0040h"
   }
  },
    "svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
       "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
      }
    },
```

```
"subsystem": {
      "uuid": "14875240-2594-11e9-abde-00a098984313",
      "name": "symmcon symmcon fcnvme vserver 0 subsystem 0",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/14875240-2594-11e9-abde-
00a098984313"
      }
    },
    "id": "0041h",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-
11e9-abde-00a098984313/0041h"
   }
  },
    "svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
        "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
      }
    },
    "subsystem": {
      "uuid": "1489d0d5-2594-11e9-94c4-00a0989a1c8e",
      "name": "symmcon symmcon fcnvme vserver 0 subsystem 1",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/1489d0d5-2594-11e9-94c4-
00a0989a1c8e"
       }
     }
    "id": "0040h",
    " links": {
        "href": "/api/protocols/nvme/subsystem-controllers/1489d0d5-2594-
11e9-94c4-00a0989a1c8e/0040h"
     }
   }
  },
```

```
"svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
        "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
    },
    "subsystem": {
      "uuid": "1489d0d5-2594-11e9-94c4-00a0989a1c8e",
      "name": "symmcon symmcon fcnvme vserver 0 subsystem 1",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/1489d0d5-2594-11e9-94c4-
00a0989a1c8e"
      }
    "id": "0041h",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/1489d0d5-2594-
11e9-94c4-00a0989a1c8e/0041h"
    }
 }
],
"num records": 4,
" links": {
 "self": {
    "href": "/api/protocols/nvme/subsystem-controllers"
}
}
```

#### Retrieving the NVMe subsystem controllers for a specific subsystem

```
# The API:
GET /api/protocols/nvme/subsystem-controllers

# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystem-
```

```
controllers?subsystem.uuid=14875240-2594-11e9-abde-00a098984313' -H
'Accept: application/hal+json'
# The response:
"records": [
    "svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
        "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
      }
    },
    "subsystem": {
      "uuid": "14875240-2594-11e9-abde-00a098984313",
      "name": "symmcon symmcon fcnvme vserver 0 subsystem 0",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/14875240-2594-11e9-abde-
00a098984313"
       }
    "id": "0040h",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-
11e9-abde-00a098984313/0040h"
  },
    "svm": {
      "uuid": "f0f5b928-2593-11e9-94c4-00a0989a1c8e",
      "name": "symmcon fcnvme vserver 0",
      " links": {
        "self": {
          "href": "/api/svm/svms/f0f5b928-2593-11e9-94c4-00a0989a1c8e"
      }
    "subsystem": {
      "uuid": "14875240-2594-11e9-abde-00a098984313",
```

```
"name": "symmcon symmcon fcnvme vserver 0 subsystem 0",
      " links": {
        "self": {
          "href": "/api/protocols/nvme/subsystems/14875240-2594-11e9-abde-
00a098984313"
       }
      }
    },
    "id": "0041h",
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-
11e9-abde-00a098984313/0041h"
    }
  }
],
"num records": 2,
" links": {
 "self": {
    "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-11e9-
abde-00a098984313"
  }
}
}
```

#### Retrieving a specific NVMe subsystem controller

```
},
"subsystem": {
  "uuid": "14875240-2594-11e9-abde-00a098984313",
 "name": "symmcon symmcon fcnvme vserver 0 subsystem 0",
  " links": {
    "self": {
      "href": "/api/protocols/nvme/subsystems/14875240-2594-11e9-abde-
00a098984313"
 }
},
"id": "0040h",
"interface": {
  "name": "symmcon lif fcnvme symmcon fcnvme vserver 0 3a 0",
 "uuid": "fa1c5941-2593-11e9-94c4-00a0989a1c8e",
 "transport address": "nn-0x200400a0989a1c8d:pn-0x200500a0989a1c8d",
 " links": {
    "self": {
      "href": "/api/protocols/nvme/interfaces/fa1c5941-2593-11e9-94c4-
00a0989a1c8e"
 }
},
"node": {
  "name": "ssan-8040-94a",
 "uuid": "ebf66f05-2590-11e9-abde-00a098984313",
 " links": {
    "self": {
      "href": "/api/cluster/nodes/ebf66f05-2590-11e9-abde-00a098984313"
   }
 }
},
"host": {
  "transport address": "nn-0x20000090fae00806:pn-0x10000090fae00806",
 "ngn": "ngn.2014-08.org.nvmexpress:uuid:c2846cb1-89d2-4020-a3b0-
71ce907b4eef",
  "id": "b8546ca6097349e5b1558dc154fc073b"
},
"io queue": {
 "count": 4,
 "depth": [
    32,
    32,
    32,
```

```
32
]
},
"admin_queue": {
    "depth": 32
},
"dh_hmac_chap": {
    "mode": "none"
},
"_links": {
    "self": {
        "href": "/api/protocols/nvme/subsystem-controllers/14875240-2594-11e9-abde-00a098984313/0040h"
    }
}
```

# **Retrieve NVMe subsystem controllers**

GET /protocols/nvme/subsystem-controllers

Introduced In: 9.6

Retrieves NVMe subsystem controllers.

#### **Related ONTAP commands**

vserver nvme subsystem controller show

#### Learn more

• DOC /protocols/nvme/subsystem-controllers

#### **Parameters**

Name	Туре	In	Required	Description
host.id	string	query	False	Filter by host.id
host.transport_addre ss	string	query	False	Filter by host.transport_addre ss
host.nqn	string	query	False	<ul><li>Filter by host.nqn</li><li>maxLength: 223</li><li>minLength: 1</li></ul>

Name	Туре	In	Required	Description
dh_hmac_chap.mod e	string	query	False	Filter by dh_hmac_chap.mod e  • Introduced in: 9.12
dh_hmac_chap.grou p_size	string	query	False	Filter by dh_hmac_chap.grou p_size • Introduced in: 9.12
dh_hmac_chap.hash _function	string	query	False	Filter by dh_hmac_chap.has h_function  • Introduced in: 9.12
admin_queue.depth	integer	query	False	Filter by admin_queue.depth
interface.transport_a ddress	string	query	False	Filter by interface.transport_a ddress
interface.name	string	query	False	Filter by interface.name
interface.uuid	string	query	False	Filter by interface.uuid
id	string	query	False	Filter by id
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
subsystem.name	string	query	False	Filter by subsystem.name  • maxLength: 96  • minLength: 1

Name	Туре	In	Required	Description
subsystem.uuid	string	query	False	Filter by subsystem.uuid
io_queue.depth	integer	query	False	Filter by io_queue.depth
io_queue.count	integer	query	False	Filter by io_queue.count
node.uuid	string	query	False	Filter by node.uuid
node.name	string	query	False	Filter by node.name
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0

Name	Туре	In	Required	Description
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_controller]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
    },
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    },
    "admin queue": {
     "depth": 0
    },
    "dh hmac chap": {
      "group size": "none",
      "hash function": "sha 256",
      "mode": "bidirectional"
    },
    "host": {
      "id": "b8546ca6097349e5b1558dc154fc073b",
      "ngn": "ngn.2014-08.org.nvmexpress:uuid:c2846cb1-89d2-4020-a3b0-
71ce907b4eef",
      "transport address": "nn-0x20000090fae00806:pn-
0x10000090fae00806"
   },
    "id": "0040h",
    "interface": {
     "name": "lif1",
      "transport address": "nn-0x200400a0989a1c8d:pn-
0x200500a0989a1c8d",
      "uuid": "fa1c5941-2593-11e9-94c4-00a0989a1c8e"
    },
    "io queue": {
     "count": 0,
     "depth": {
     }
    },
    "node": {
```

```
" links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
     "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
    "subsystem": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    } ,
    "svm": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "svm1",
     "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
 }
}
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

#### Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

## **Definitions**

#### **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

## admin\_queue

Name	Туре	Description
depth	integer	The depth of the admin queue for the controller.

## dh\_hmac\_chap

A container for properties of the NVMe in-band authentication DH-HMAC-CHAP protocol used by the the host connection to the controller.

Name	Туре	Description
group_size	string	The Diffie-Hellman group size used for NVMe in-band authentication.
hash_function	string	The hash function used for NVMe in-band authentication.

Name	Туре	Description
mode	string	The NVMe in-band authentication mode used for the host connection. When set to:
		none: Neither the host nor controller was authenticated.
		unidirectional: The controller authenticated the host.
		<ul> <li>bidirectional: The controller authenticated the host and the host authenticated the controller.</li> </ul>

#### host

Properties of the connected host.

Name	Туре	Description
id	string	The host identifier registered with the controller.
nqn	string	The NVMe qualified name of the host.
transport_address	string	The transport address of the host.

## interface

The logical interface through which the host is connected.

Name	Туре	Description
name	string	The name of the logical interface.
transport_address	string	The transport address of the logical interface.
uuid	string	The unique identifier of the logical interface.

## io\_queue

Properties of the I/O queues available to the controller.

Name	Туре	Description
count	integer	The number of I/O queues available to the controller.
depth	array[integer]	The depths of the I/O queues.

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

## subsystem

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

nvme\_subsystem\_controller

A Non-Volatile Memory Express (NVMe) subsystem controller represents a connection between a host and a storage solution.

An NVMe subsystem controller is identified by the NVMe subsystem UUID and the controller ID.

Name	Туре	Description
_links	_links	
admin_queue	admin_queue	

Name	Туре	Description
dh_hmac_chap	dh_hmac_chap	A container for properties of the NVMe in-band authentication DH-HMAC-CHAP protocol used by the the host connection to the controller.
host	host	Properties of the connected host.
id	string	The identifier of the subsystem controller. This field consists of 4 zero-filled hexadecimal digits followed by an 'h'.
interface	interface	The logical interface through which the host is connected.
io_queue	io_queue	Properties of the I/O queues available to the controller.
node	node	
subsystem	subsystem	
svm	svm	

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Retrieve an NVMe subsystem controller

GET /protocols/nvme/subsystem-controllers/{subsystem.uuid}/{id}

Introduced In: 9.6

Retrieves an NVMe subsystem controller.

#### **Related ONTAP commands**

• vserver nvme subsystem controller show

#### Learn more

• DOC /protocols/nvme/subsystem-controllers

#### **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
id	string	path	True	The unique identifier of the NVMe subsystem controller.
fields	array[string]	query	False	Specify the fields to return.

#### Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
admin_queue	admin_queue	
dh_hmac_chap	dh_hmac_chap	A container for properties of the NVMe in-band authentication DH-HMAC-CHAP protocol used by the the host connection to the controller.
host	host	Properties of the connected host.

Name	Туре	Description
id	string	The identifier of the subsystem controller. This field consists of 4 zero-filled hexadecimal digits followed by an 'h'.
interface	interface	The logical interface through which the host is connected.
io_queue	io_queue	Properties of the I/O queues available to the controller.
node	node	
subsystem	subsystem	
svm	svm	

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "admin queue": {
   "depth": 0
  "dh hmac chap": {
   "group size": "none",
   "hash function": "sha 256",
   "mode": "bidirectional"
  },
 "host": {
    "id": "b8546ca6097349e5b1558dc154fc073b",
    "ngn": "ngn.2014-08.org.nvmexpress:uuid:c2846cb1-89d2-4020-a3b0-
71ce907b4eef",
    "transport address": "nn-0x20000090fae00806:pn-0x10000090fae00806"
 "id": "0040h",
 "interface": {
    "name": "lif1",
   "transport address": "nn-0x200400a0989a1c8d:pn-0x200500a0989a1c8d",
    "uuid": "fa1c5941-2593-11e9-94c4-00a0989a1c8e"
  },
  "io queue": {
   "count": 0,
   "depth": {
   }
  } ,
  "node": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "subsystem": {
    " links": {
     "self": {
        "href": "/api/resourcelink"
```

#### **Error**

```
Status: Default
```

#### **ONTAP Error Response Codes**

Error Code	Description
72090001	The supplied subsystem identifier does not exist.

Name	Туре	Description
error	error	

#### **Example error**

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

#### **Definitions**

#### **See Definitions**

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

## admin\_queue

Name	Туре	Description
depth	integer	The depth of the admin queue for the controller.

## dh\_hmac\_chap

A container for properties of the NVMe in-band authentication DH-HMAC-CHAP protocol used by the the host connection to the controller.

Name	Туре	Description
group_size	string	The Diffie-Hellman group size used for NVMe in-band authentication.
hash_function	string	The hash function used for NVMe in-band authentication.
mode	string	The NVMe in-band authentication mode used for the host connection. When set to:  • none: Neither the host nor controller was authenticated.  • unidirectional: The controller authenticated the host.  • bidirectional: The controller authenticated the host and the host authenticated the controller.

#### host

Properties of the connected host.

Name	Туре	Description
id	string	The host identifier registered with the controller.
nqn	string	The NVMe qualified name of the host.
transport_address	string	The transport address of the host.

## interface

The logical interface through which the host is connected.

Name	Туре	Description
name	string	The name of the logical interface.
transport_address	string	The transport address of the logical interface.
uuid	string	The unique identifier of the logical interface.

## io\_queue

Properties of the I/O queues available to the controller.

Name	Туре	Description
count	integer	The number of I/O queues available to the controller.
depth	array[integer]	The depths of the I/O queues.

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

## subsystem

Name	Туре	Description
_links	_links	

Name	Туре	Description
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

#### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Manage NVMe subsystem maps

## Protocols NVMe subsystem-maps endpoint overview

#### Overview

An NVMe subsystem map is an association of an NVMe namespace with an NVMe subsystem. When an NVMe namespace is mapped to an NVMe subsystem, the NVMe subsystem's hosts are granted access to the

NVMe namespace. The relationship between an NVMe subsystem and an NVMe namespace is one subsystem to many namespaces.

The NVMe subsystem map REST API allows you to create, delete and discover NVMe subsystem maps.

#### **Examples**

#### Creating an NVMe subsystem map

```
# The API:
POST /api/protocols/nvme/subsystem-maps

# The call:
curl -X POST 'https://<mgmt-ip>/api/protocols/nvme/subsystem-maps' -H
'Accept: application/hal+json' -d '{ "svm": { "name": "svm1" },
    "subsystem": { "name": "subsystem1" }, "namespace": { "name":
    "/vol/vol1/namespace1" } }'
```

#### Retrieving all of the NVMe subsystem maps

```
# The API:
GET /api/protocols/nvme/subsystem-maps
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystem-maps' -H
'Accept: application/hal+json'
# The response:
{
"records": [
    "svm": {
      "uuid": "0e91b214-fe40-11e8-91a0-005056a79967",
      "name": "svm1",
      " links": {
        "self": {
          "href": "/api/svm/svms/0e91b214-fe40-11e8-91a0-005056a79967"
        }
      }
    },
    "subsystem": {
      "uuid": "580a6b1e-fe43-11e8-91a0-005056a79967",
      "name": "subsystem1",
      " links": {
        "self": {
```

```
"href": "/api/protocols/nvme/subsystems/580a6b1e-fe43-11e8-91a0-
005056a79967"
       }
      }
    },
    "namespace": {
      "uuid": "3ccdedc6-2519-4206-bc1f-b0f4adab6f89",
      "name": "/vol/vol1/namespace1",
      " links": {
       "self": {
          "href": "/api/storage/namespaces/3ccdedc6-2519-4206-bc1f-
b0f4adab6f89"
      }
    },
    " links": {
      "self": {
        "href": "/api/protocols/nvme/subsystem-maps/580a6b1e-fe43-11e8-
91a0-005056a79967/3ccdedc6-2519-4206-bc1f-b0f4adab6f89"
  }
1,
"num records": 1,
" links": {
 "self": {
    "href": "/api/protocols/nvme/subsystem-maps"
  }
}
}
```

#### Retrieving a specific NVMe subsystem map

The NVMe subsystem map is identified by the UUID of the NVMe subsystem followed by the UUID of the NVMe namespace.

```
# The API:
GET /api/protocols/nvme/subsystem-maps/{subsystem.uuid}/{namespace.uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystem-maps/580a6ble-
fe43-11e8-91a0-005056a79967/3ccdedc6-2519-4206-bc1f-b0f4adab6f89' -H
'Accept: application/hal+json'
```

```
# The response:
"svm": {
  "uuid": "0e91b214-fe40-11e8-91a0-005056a79967",
  "name": "svm1",
  " links": {
    "self": {
      "href": "/api/svm/svms/0e91b214-fe40-11e8-91a0-005056a79967"
 }
},
"subsystem": {
  "uuid": "580a6b1e-fe43-11e8-91a0-005056a79967",
  "name": "subsystem1",
 " links": {
    "self": {
      "href": "/api/protocols/nvme/subsystems/580a6b1e-fe43-11e8-91a0-
005056a79967"
   }
 }
},
"namespace": {
  "uuid": "3ccdedc6-2519-4206-bc1f-b0f4adab6f89",
  "name": "/vol/vol1/namespace1",
  "node": {
    "name": "node1",
    "uuid": "012b4508-67d6-4788-8c2d-801f254ce976",
    " links": {
      "self": {
        "href": "/api/cluster/nodes/012b4508-67d6-4788-8c2d-801f254ce976"
    }
  },
  " links": {
   "self": {
      "href": "/api/storage/namespaces/3ccdedc6-2519-4206-bc1f-
b0f4adab6f89"
   }
 }
},
"nsid": "00000001h",
" links": {
 "self": {
    "href": "/api/protocols/nvme/subsystem-maps/580a6b1e-fe43-11e8-91a0-
005056a79967/3ccdedc6-2519-4206-bc1f-b0f4adab6f89"
```

```
}
}
```

#### Deleting an NVMe subsystem map

```
# The API:
DELETE /api/protocols/nvme/subsystem-
maps/{subsystem.uuid}/{namespace.uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/subsystem-
maps/580a6b1e-fe43-11e8-91a0-005056a79967/3ccdedc6-2519-4206-bc1f-
b0f4adab6f89' -H 'Accept: application/hal+json'
```

## **Retrieve NVMe subsystem maps**

GET /protocols/nvme/subsystem-maps

Introduced In: 9.6

Retrieves NVMe subsystem maps.

#### **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

• anagrpid

#### **Related ONTAP commands**

vserver nvme subsystem map show

#### Learn more

DOC /protocols/nvme/subsystem-maps

#### **Parameters**

Name	Туре	In	Required	Description
nsid	string	query	False	Filter by nsid
anagrpid	string	query	False	Filter by anagrpid

Name	Туре	In	Required	Description
subsystem.name	string	query	False	Filter by subsystem.name  • maxLength: 96  • minLength: 1
subsystem.uuid	string	query	False	Filter by subsystem.uuid
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
namespace.uuid	string	query	False	Filter by namespace.uuid
namespace.name	string	query	False	Filter by namespace.name
namespace.node.uui d	string	query	False	Filter by namespace.node.uu id
namespace.node.na me	string	query	False	Filter by namespace.node.na me
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_map]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
   "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  "anagrpid": "00103050h",
  "namespace": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    "name": "/vol/vol1/namespace1",
    "node": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  "nsid": "00000001h",
  "subsystem": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
      }
    },
    "name": "subsystem1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

#### Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

#### **Definitions**

#### **See Definitions**

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

### namespace

The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.

Name	Туре	Description
_links	_links	
name	string	The fully qualified path name of the NVMe namespace composed from the volume name, qtree name, and file name of the NVMe namespace. Valid in POST.
node	node	
uuid	string	The unique identifier of the NVMe namespace. Valid in POST.

#### subsystem

The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either

subsystem.uuid, subsystem.name or both.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

#### nvme subsystem map

An NVMe subsystem map is an association of an NVMe namespace with an NVMe subsystem. When an NVMe namespace is mapped to an NVMe subsystem, the NVMe subsystem's hosts are granted access to the NVMe namespace. The relationship between an NVMe subsystem and an NVMe namespace is one subsystem to many namespaces.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.
		The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
		There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
namespace	namespace	The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.
svm	svm	

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

## Create an NVMe subsystem map

POST /protocols/nvme/subsystem-maps

Introduced In: 9.6

Creates an NVMe subsystem map.

#### **Required properties**

- svm.uuid or svm.name Existing SVM in which to create the NVMe subsystem map.
- namespace.uuid or namespace.name Existing NVMe namespace to map to the specified NVme subsystem.
- subsystem.uuid or subsystem.name Existing NVMe subsystem to map to the specified NVMe namespace.

#### **Related ONTAP commands**

• vserver nvme subsystem map create

#### Learn more

• DOC /protocols/nvme/subsystem-maps

#### **Parameters**

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned.  • Default value:

### **Request Body**

Name	Туре	Description
_links	_links	

Name	Туре	Description
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
namespace	namespace	The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.
svm	svm	

Example request	

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"anagrpid": "00103050h",
"namespace": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
  },
  "name": "/vol/vol1/namespace1",
  "node": {
    " links": {
      "self": {
        "href": "/api/resourcelink"
     }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
"nsid": "00000001h",
"subsystem": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "subsystem1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
} ,
"svm": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
}
```

## Response

Status: 201, Created

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_map]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
   "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  "anagrpid": "00103050h",
  "namespace": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    "name": "/vol/vol1/namespace1",
    "node": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  "nsid": "00000001h",
  "subsystem": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
      }
    },
    "name": "subsystem1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

#### Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

#### **Error**

```
Status: Default
```

## ONTAP Error Response Codes

Error Code	Description	
72089790	The supplied NVMe namespace is already mapped to the supplied NVMe subsystem.	
72089793	An NVMe namespace in a Snapshot copy cannot be mapped.	
72089799	The NVMe namespace is the destination of an ongoing restore operation and is inaccessible for I/O and management.	
72089902	A node does not have an NVMe interface configured.	
72089903	Multiple nodes do not have an NVMe interface configured.	
72089904	The aggregate must be given back to its home node prior to mapping the NVMe namespace it contains.	
72090001	The NVMe subsystem specified by subsystem.uuid was not found.	

Error Code	Description	
72090005	The specified namespace.uuid and namespace.name refer to different NVMe namespaces.	
72090006	The NVMe namespace specified by namespace.uuid was not found.	
72090007	The NVMe namespace specified by namespace.name was not found.	
72090020	The specified subsystem.uuid and subsystem.name refer to different NVMe subsystems.	
72090021	The NVMe subsystem specified by subsystem.name was not found.	

Name	Туре	Description
error	error	

## Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
}
```

#### **Definitions**

## **See Definitions**

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

## namespace

The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.

Name	Туре	Description
_links	_links	
name	string	The fully qualified path name of the NVMe namespace composed from the volume name, qtree name, and file name of the NVMe namespace. Valid in POST.
node	node	
uuid	string	The unique identifier of the NVMe namespace. Valid in POST.

# subsystem

The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.

Name	Туре	Description
_links	_links	

Name	Туре	Description
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## nvme\_subsystem\_map

An NVMe subsystem map is an association of an NVMe namespace with an NVMe subsystem. When an NVMe namespace is mapped to an NVMe subsystem, the NVMe subsystem's hosts are granted access to the NVMe namespace. The relationship between an NVMe subsystem and an NVMe namespace is one subsystem to many namespaces.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
namespace	namespace	The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.

Name	Туре	Description
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.
svm	svm	

# \_links

Name	Туре	Description
next	href	
self	href	

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

## error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Delete an NVMe subsystem map

DELETE /protocols/nvme/subsystem-maps/{subsystem.uuid}/{namespace.uuid}

Introduced In: 9.6

Deletes an NVMe subsystem map.

## **Related ONTAP commands**

• vserver nvme subsystem map delete

## Learn more

• DOC /protocols/nvme/subsystem-maps

## **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
namespace.uuid	string	path	True	The unique identifier of the NVMe namespace.

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_map]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
  "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  "anagrpid": "00103050h",
  "namespace": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    "name": "/vol/vol1/namespace1",
    "node": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  "nsid": "00000001h",
  "subsystem": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
      }
    },
    "name": "subsystem1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
```

#### **Error**

```
Status: Default
```

## **ONTAP Error Response Codes**

Error Code	Description
72090019	The specified NVMe namespace is not mapped to the specified NVMe subsystem.

Name	Туре	Description
error	error	

## **Example error**

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

# **Definitions**

## **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

## namespace

The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.

Name	Туре	Description
_links	_links	
name	string	The fully qualified path name of the NVMe namespace composed from the volume name, qtree name, and file name of the NVMe namespace. Valid in POST.
node	node	
uuid	string	The unique identifier of the NVMe namespace. Valid in POST.

## subsystem

The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either

subsystem.uuid, subsystem.name or both.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## nvme subsystem map

An NVMe subsystem map is an association of an NVMe namespace with an NVMe subsystem. When an NVMe namespace is mapped to an NVMe subsystem, the NVMe subsystem's hosts are granted access to the NVMe namespace. The relationship between an NVMe subsystem and an NVMe namespace is one subsystem to many namespaces.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.
		The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
		There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
namespace	namespace	The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.
svm	svm	

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

## error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve an NVMe subsystem map

GET /protocols/nvme/subsystem-maps/{subsystem.uuid}/{namespace.uuid}

Introduced In: 9.6

Retrieves an NVMe subsystem map.

## **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

• anagrpid

#### **Related ONTAP commands**

vserver nvme subsystem map show

#### Learn more

• DOC /protocols/nvme/subsystem-maps

#### **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
namespace.uuid	string	path	True	The unique identifier of the NVMe namespace.
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	

Name	Туре	Description
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
namespace	namespace	The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.
svm	svm	

Example response	

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"anagrpid": "00103050h",
"namespace": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
  },
  "name": "/vol/vol1/namespace1",
  "node": {
    " links": {
      "self": {
        "href": "/api/resourcelink"
     }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
"nsid": "00000001h",
"subsystem": {
  " links": {
    "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "subsystem1",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"svm": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "name": "svm1",
  "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
}
```

## **Error**

```
Status: Default
```

# **ONTAP Error Response Codes**

Error Code	Description
72090019	The specified NVMe namespace is not mapped to the specified NVMe subsystem.

Name	Туре	Description
error	error	

# **Example error**

```
{
    "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

## **Definitions**

#### **See Definitions**

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
self	href	

#### node

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

## namespace

The NVMe namespace to which the NVMe subsystem is mapped. Required in POST by supplying either the UUID, name, or both.

Name	Туре	Description
_links	_links	
name	string	The fully qualified path name of the NVMe namespace composed from the volume name, qtree name, and file name of the NVMe namespace. Valid in POST.
node	node	
uuid	string	The unique identifier of the NVMe namespace. Valid in POST.

# subsystem

The NVMe subsystem to which the NVMe namespace is mapped. Required in POST by supplying either subsystem.uuid, subsystem.name or both.

Name	Туре	Description
_links	_links	

Name	Туре	Description
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Manage NVMe subsystems

# Protocols NVMe subsystems endpoint overview

## Overview

An NVMe subsystem maintains configuration state and namespace access control for a set of NVMe-connected hosts.

The NVMe subsystem REST API allows you to create, update, delete, and discover NVMe subsystems as well as add and remove NVMe hosts that can access the subsystem and associated namespaces.

#### **Examples**

#### Creating an NVMe subsystem

```
# The API:
POST /api/protocols/nvme/subsystems

# The call:
curl -X POST 'https://<mgmt-ip>/api/protocols/nvme/subsystems' -H 'Accept:
application/json' -d '{ "svm": { "name": "svm1" }, "name": "subsystem1",
"os_type": "linux" }'
```

#### Creating an NVMe subsystem with multiple NVMe subsystem hosts

```
# The API:
POST /api/protocols/nvme/subsystems

# The call:
curl -X POST 'https://<mgmt-ip>/api/protocols/nvme/subsystems' -H 'Accept:
application/json' -d '{ "svm": { "name": "svm1" }, "name": "subsystem2",
   "os_type": "vmware", "hosts": [ { "nqn": "nqn.1992-01.example.com:host1"
}, { "nqn": "nqn.1992-01.example.com:host2" } ] }'
```

#### Retrieving all NVMe subsystems

```
# The API:
GET /api/protocols/nvme/subsystems
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystems' -H 'Accept:
application/json'
# The response:
{
"records": [
    "svm": {
      "uuid": "a009a9e7-4081-b576-7575-ada21efcaf16",
     "name": "svm1",
    "uuid": "acde901a-a379-4a91-9ea6-1b728ed6696f",
   "name": "subsystem1",
  },
    "svm": {
     "uuid": "a009a9e7-4081-b576-7575-ada21efcaf16",
      "name": "svm1",
    },
    "uuid": "bcde901a-a379-4a91-9ea6-1b728ed6696f",
    "name": "subsystem2",
 }
],
"num records": 2,
```

### Retrieving all NVMe subsystems with OS type linux

Note that the os type query parameter is used to perform the query.

```
# The API:
GET /api/protocols/nvme/subsystems
# The call:
curl -X GET 'https://<mgmt-</pre>
ip>/api/protocols/nvme/subsystems?os type=linux' -H 'Accept:
application/json'
# The response:
"records": [
    "svm": {
      "uuid": "a009a9e7-4081-b576-7575-ada21efcaf16",
      "name": "svm1",
    },
    "uuid": "acde901a-a379-4a91-9ea6-1b728ed6696f",
    "name": "subsystem1",
   "os_type": "linux",
 }
],
"num_records": 1,
}
```

Retrieving a specific NVMe subsystem

```
# The API:
GET /api/protocols/nvme/subsystems/{uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f' -H 'Accept: application/json'
# The response:
{
"svm": {
  "uuid": "a009a9e7-4081-b576-7575-ada21efcaf16",
 "name": "svm1",
},
"uuid": "acde901a-a379-4a91-9ea6-1b728ed6696f",
"name": "subsystem1",
"os type": "linux",
"target nqn": "nqn.1992-
08.com.netapp:sn.d04594ef915b4c73b642169e72e4c0b1:subsystem.subsystem1",
"serial number": "wtJNKNKD-uPLAAAAAAD",
"io queue": {
 "default": {
    "count": 4,
    "depth": 32
  }
}
}
```

#### Retrieving the NVMe namespaces mapped to a specific NVMe subsystem

Note that the fields query parameter is used to specify the desired properties.

```
# The API:
GET /api/protocols/nvme/subsystems/{uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f?fields=subsystem maps' -H 'Accept:
application/json'
# The response:
"svm": {
 "uuid": "a009a9e7-4081-b576-7575-ada21efcaf16",
 "name": "svm1",
},
"uuid": "acde901a-a379-4a91-9ea6-1b728ed6696f",
"name": "subsystem1",
"subsystem maps": [
    "anagrpid": "00000001h",
    "namespace": {
      "uuid": "eeaaca23-128d-4a7d-be4a-dc9106705799",
      "name": "/vol/vol1/namespace1"
   },
    "nsid": "00000001h"
  },
    "anagrpid": "00000002h",
    "namespace": {
      "uuid": "feaaca23-83a0-4a7d-beda-dc9106705799",
     "name": "/vol/vol1/namespace2"
    },
    "nsid": "00000002h"
 }
]
}
```

Adding a comment about an NVMe subsystem

```
# The API:
PATCH /api/protocols/nvme/subsystems/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f' -H 'Accept: application/json' -d '{
"comment": "A brief comment about the subsystem" }'
```

#### Deleting an NVMe subsystem

```
# The API:
DELETE /api/protocols/nvme/subsystems/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f' -H 'Accept: application/json'
```

#### Deleting an NVMe subsystem with mapped NVMe namespaces

Normally, deleting an NVMe subsystem that has mapped NVMe namespaces is not allowed. The deletion can be forced using the allow delete while mapped query parameter.

```
# The API:
DELETE /api/protocols/nvme/subsystems/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f?allow_delete_while_mapped=true' -H 'Accept:
application/json'
```

#### Delete an NVMe subsystem with NVMe subsystem hosts

Normally, deleting an NVMe subsystem with NVMe subsystem hosts is disallowed. The deletion can be forced using the allow delete with hosts query parameter.

```
# The API:
DELETE /api/protocols/nvme/subsystems/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f?allow_delete_with_hosts=true' -H 'Accept:
application/json'
```

#### **An NVMe Subsystem Host**

An NVMe subsystem host is a network host provisioned to an NVMe subsystem to access namespaces mapped to that subsystem.

## **Examples**

#### Adding an NVMe subsystem host to an NVMe subsystem

```
# The API:
POST /protocols/nvme/subsystems/{subsystem.uuid}/hosts

# The call:
curl -X POST 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f/hosts' -H 'Accept: application/json' -d '{
"nqn": "nqn.1992-01.com.example:subsys1.host1" }'
```

#### Adding multiple NVMe subsystem hosts to an NVMe subsystem

```
# The API:
POST /protocols/nvme/subsystems/{subsystem.uuid}/hosts

# The call:
curl -X POST 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f/hosts' -H 'Accept: application/json' -d '{
   "records": [ { "nqn": "nqn.1992-01.com.example:subsys1.host2" }, { "nqn":
   "nqn.1992-01.com.example:subsys1.host3" } ] }'
```

#### Retrieving all NVMe subsystem hosts for an NVMe subsystem

Retrieving a specific NVMe subsystem host for an NVMe subsystem

```
# The API:
GET /protocols/nvme/subsystems/{subsystem.uuid}/hosts/{nqn}
# The call:
curl -X GET 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-
a379-4a91-9ea6-1b728ed6696f/hosts/nqn.1992-01.com.example:subsys1.host1'
-H 'Accept: application/json'
# The response:
"subsystem": {
 "uuid": "acde901a-a379-4a91-9ea6-1b728ed6696f",
"nqn": "nqn.1992-01.com.example:subsys1.host1",
"dh hmac chap": {
 "node": "none"
},
"io queue": {
 "count": 4,
 "depth": 32
},
}
```

## Deleting an NVMe subsystem host from an NVMe subsystem

```
# The API:
DELETE /protocols/nvme/subsystems/{subsystem.uuid}/hosts/{nqn}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/protocols/nvme/subsystems/acde901a-a379-4a91-9ea6-1b728ed6696f/hosts/nqn.1992-01.com.example:subsys1.host1'
-H 'Accept: application/json'
```

# Retrieve NVMe subsystems

GET /protocols/nvme/subsystems

Introduced In: 9.6

Retrieves NVMe subsystems.

## **Related ONTAP commands**

- vserver nvme subsystem host show
- vserver nvme subsystem map show
- vserver nvme subsystem show

## Learn more

• DOC /protocols/nvme/subsystems

## **Parameters**

Name	Туре	In	Required	Description
comment	string	query	False	<ul><li>Filter by comment</li><li>maxLength: 255</li><li>minLength: 0</li></ul>
serial_number	string	query	False	Filter by serial_number  • maxLength: 20  • minLength: 20
target_nqn	string	query	False	<ul><li>Filter by target_nqn</li><li>maxLength: 223</li><li>minLength: 1</li></ul>
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
io_queue.default.dep th	integer	query	False	Filter by io_queue.default.de pth  • Max value: 128  • Min value: 16
io_queue.default.cou nt	integer	query	False	Filter by io_queue.default.co unt  • Max value: 15  • Min value: 1

Name	Туре	In	Required	Description
name	string	query	False	<ul><li>Filter by name</li><li>maxLength: 96</li><li>minLength: 1</li></ul>
hosts.nqn	string	query	False	Filter by hosts.nqn
hosts.dh_hmac_cha p.mode	string	query	False	Filter by hosts.dh_hmac_cha p.mode  • Introduced in: 9.12
hosts.dh_hmac_cha p.group_size	string	query	False	Filter by hosts.dh_hmac_cha p.group_size  • Introduced in: 9.12
hosts.dh_hmac_cha p.hash_function	string	query	False	Filter by hosts.dh_hmac_cha p.hash_function  • Introduced in: 9.12
os_type	string	query	False	Filter by os_type
delete_on_unmap	boolean	query	False	Filter by delete_on_unmap  • Introduced in: 9.7
subsystem_maps.nsi d	string	query	False	Filter by subsystem_maps.ns id
subsystem_maps.an agrpid	string	query	False	Filter by subsystem_maps.an agrpid
subsystem_maps.na mespace.uuid	string	query	False	Filter by subsystem_maps.na mespace.uuid

Name	Туре	In	Required	Description
subsystem_maps.na mespace.name	string	query	False	Filter by subsystem_maps.na mespace.name
uuid	string	query	False	Filter by uuid
vendor_uuids	string	query	False	Filter by vendor_uuids • Introduced in: 9.9
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Max value: 120 • Min value: 0 • Default value: 1
order_by	array[string]	query	False	Order results by specified fields and optional [asc

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
   },
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    "comment": "string",
    "hosts": {
      "dh hmac chap": {
        "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "group size": "none",
        "hash function": "sha 256",
        "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "mode": "bidirectional"
      "ngn": "ngn.1992-01.example.com:string"
    },
    "io queue": {
     "default": {
       "count": 4,
       "depth": 16
     }
    },
    "name": "subsystem1",
    "os type": "aix",
    "serial number": "wCVsgFMiuMhVAAAAAAB",
    "subsystem maps": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
        }
```

```
"anagrpid": "00103050h",
    "namespace": {
     " links": {
        "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "/vol/vol1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    } ,
   "nsid": "00000001h"
  } ,
  "svm": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "svm1",
   "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
  } ,
  "target nqn": "nqn.1992-01.example.com:string",
  "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
  "vendor uuids": {
}
```

## **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

## Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

## **Definitions**

## **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

#### hosts

Name	Туре	Description
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.

## default

The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

Name	Туре	Description
count	integer	The number of host I/O queue pairs.
depth	integer	The host I/O queue depth.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
default	default	The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

# namespace

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe namespace.
uuid	string	The unique identifier of the NVMe namespace.

# subsystem\_maps

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPIP is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
namespace	namespace	An NVMe namespace mapped to the NVMe subsystem.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

# nvme\_subsystem

An NVMe subsystem maintains configuration state and namespace access control for a set of NVMe-connected hosts.

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to false when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.
serial_number	string	The serial number of the NVMe subsystem.

Name	Туре	Description
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9 • readCreate: 1

error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Create an NVMe subsystem

POST /protocols/nvme/subsystems

Introduced In: 9.6

Creates an NVMe subsystem.

### **Required properties**

- svm.uuid or svm.name Existing SVM in which to create the NVMe subsystem.
- name Name for NVMe subsystem. Once created, an NVMe subsytem cannot be renamed.
- os type Operating system of the NVMe subsystem's hosts.

#### **Related ONTAP commands**

• vserver nvme subsystem create

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
return_records	boolean	query	False	The default is false. If set to true, the records are returned.  • Default value:

# **Request Body**

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to false when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.
serial_number	string	The serial number of the NVMe subsystem.

Name	Туре	Description
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9  • readCreate: 1

```
" links": {
    "self": {
      "href": "/api/resourcelink"
   }
  } ,
  "comment": "string",
  "hosts": {
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "nqn": "nqn.1992-01.example.com:string"
  } ,
  "io queue": {
    "default": {
     "count": 4,
      "depth": 16
  },
  "name": "subsystem1",
  "os type": "aix",
  "serial number": "wCVsqFMiuMhVAAAAAAB",
  "subsystem maps": {
    " links": {
     "self": {
        "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "namespace": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
        }
      "name": "/vol/vol1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
```

```
"nsid": "00000001h"
},

"svm": {
    "_links": {
        "self": {
             "href": "/api/resourcelink"
        }
    },
    "name": "svm1",
    "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
    "target_nqn": "nqn.1992-01.example.com:string",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
    "vendor_uuids": {
    }
}
```

#### Response

```
Status: 201, Created
```

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
   },
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    "comment": "string",
    "hosts": {
      "dh hmac chap": {
        "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "group size": "none",
        "hash function": "sha 256",
        "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "mode": "bidirectional"
      "ngn": "ngn.1992-01.example.com:string"
    },
    "io queue": {
     "default": {
       "count": 4,
       "depth": 16
     }
    },
    "name": "subsystem1",
    "os type": "aix",
    "serial number": "wCVsgFMiuMhVAAAAAAB",
    "subsystem maps": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
        }
```

```
"anagrpid": "00103050h",
  "namespace": {
   " links": {
      "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "/vol/vol1/namespace1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 },
 "nsid": "00000001h"
},
"svm": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
 "name": "svm1",
 "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
"target_nqn": "nqn.1992-01.example.com:string",
"uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
"vendor uuids": {
```

#### Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

#### **Error**

```
Status: Default
```

### **ONTAP Error Response Codes**

Error Code	Description
2621462	The supplied SVM does not exist.

Error Code	Description
2621706	The specified svm.uuid and svm.name do not refer to the same SVM.
2621707	The svm.uuid or svm.name must be provided.
72089635	Setting vendor-specific UUIDs on NVMe subsystems is not supported until the effective cluster version is 9.9 or later.
72089709	The NVMe subsystem name contains an invalid character.
72089711	An invalid vendor-specific UUID was specified.
72089712	A duplicate vendor-specific UUID was specific.
72089713	Too many vendor UUIDs were supplied.
72089771	The NQN is invalid. A non-empty qualifier is required after the prefix. An example of a valid NQN is nqn.1992-01.com.example:string.
72089772	The NQN is invalid. Add the prefix 'nqn'. An example of a valid NQN is nqn.1992-01.com.example:string.
72089773	The NQN is invalid. The date field must be formatted yyyy-mm. An example of a valid NQN is nqn.1992-01.com.example:string.
72090003	A host to be added to an NVMe subsystem is missing the "nqn" property.
72090025	The NVMe subsystem already exists for the SVM.
72090029	The NVMe service does not exist.
72090030	A partial success occured while adding multiple NVMe subsystem hosts to an NVMe subsystem.
72090036	An NVMe subsystem host NQN was duplicated in the input.
72090042	The dh_hmac_chap.host_secret_key property is required when setting any other NVMe in-band authentication properties for a host.

Name	Туре	Description
error	error	

### Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

# Definitions

### **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.

Name	Туре	Description
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

#### hosts

Name	Туре	Description
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.

### default

The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

Name	Туре	Description
count	integer	The number of host I/O queue pairs.
depth	integer	The host I/O queue depth.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
default	default	The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

# namespace

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe namespace.
uuid	string	The unique identifier of the NVMe namespace.

# subsystem\_maps

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPIP is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
namespace	namespace	An NVMe namespace mapped to the NVMe subsystem.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

# nvme\_subsystem

An NVMe subsystem maintains configuration state and namespace access control for a set of NVMe-connected hosts.

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to false when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.
serial_number	string	The serial number of the NVMe subsystem.

Name	Туре	Description
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9 • readCreate: 1

\_links

Name	Туре	Description
next	href	
self	href	

#### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve NVMe subsystem hosts

GET /protocols/nvme/subsystems/{subsystem.uuid}/hosts

Introduced In: 9.6

Retrieves the NVMe subsystem hosts of an NVMe subsystem.

### **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

• subsystem maps.\*

#### **Related ONTAP commands**

- vserver nvme subsystem map show
- vserver nvme subsystem show

### Learn more

• DOC /protocols/nvme/subsystems

# **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0
order_by	array[string]	query	False	Order results by specified fields and optional [asc

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_host]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
    },
    "self": {
     "href": "/api/resourcelink"
  },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    },
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "io queue": {
     "count": 4,
     "depth": 32
    },
    "ngn": "ngn.1992-01.example.com:string",
    "records": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
       }
      },
      "dh hmac chap": {
        "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "group size": "none",
        "hash function": "sha 256",
        "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "mode": "bidirectional"
```

```
},
    "io_queue": {
     "count": 4,
     "depth": 32
    "nqn": "nqn.1992-01.example.com:string",
    "subsystem": {
      " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "subsystem": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "subsystem1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

#### **Error**

```
Status: Default
```

### **ONTAP Error Response Codes**

Error Code	Description
72090001	The NVMe subsystem does not exist.

Name	Туре	Description
error	error	

### Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

# Definitions

### **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.
		This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
count	integer	The number of I/O queue pairs. The default value is inherited from the owning NVMe subsystem.
depth	integer	The I/O queue depth. The default value is inherited from the owning NVMe subsystem.

# subsystem

The NVMe subsystem to which the NVMe host has been provisioned.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.

Name	Туре	Description
uuid	string	The unique identifier of the NVMe subsystem.

#### records

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

# nvme\_subsystem\_host

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
records	array[records]	An array of NVMe hosts specified to add multiple NVMe hosts to an NVMe subsystem in a single API call. Valid in POST only.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Add NVMe subsystem hosts

POST /protocols/nvme/subsystems/{subsystem.uuid}/hosts

Introduced In: 9.6

Adds NVMe subsystem host(s) to an NVMe subsystem.

# Required properties

• nqn or records . nqn - NVMe host(s) NQN(s) to add to the NVMe subsystem.

### **Related ONTAP commands**

• vserver nvme subsystem host add

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
return_records	boolean	query	False	The default is false. If set to true, the records are returned.  • Default value:

# **Request Body**

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
records	array[records]	An array of NVMe hosts specified to add multiple NVMe hosts to an NVMe subsystem in a single API call. Valid in POST only.

Name	Туре	Description
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "dh hmac chap": {
    "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
    "group size": "none",
    "hash function": "sha 256",
    "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
    "mode": "bidirectional"
  },
  "io queue": {
   "count": 4,
   "depth": 32
  "nqn": "nqn.1992-01.example.com:string",
 "records": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
     }
    },
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "io queue": {
     "count": 4,
     "depth": 32
    },
    "ngn": "ngn.1992-01.example.com:string",
    "subsystem": {
     " links": {
       "self": {
          "href": "/api/resourcelink"
```

### Response

```
Status: 201, Created
```

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_subsystem_host]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
    },
    "self": {
     "href": "/api/resourcelink"
  },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    },
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "io queue": {
     "count": 4,
     "depth": 32
    },
    "ngn": "ngn.1992-01.example.com:string",
    "records": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
       }
      },
      "dh hmac chap": {
        "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "group size": "none",
        "hash function": "sha 256",
        "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
        "mode": "bidirectional"
```

```
},
    "io queue": {
     "count": 4,
     "depth": 32
    "ngn": "ngn.1992-01.example.com:string",
    "subsystem": {
     " links": {
       "self": {
        "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "subsystem": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
   "name": "subsystem1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

#### Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

#### **Error**

```
Status: Default
```

### ONTAP Error Response Codes

Error Code	Description
262186	The "records" array and other host properties are mutually exclusive.

Error Code	Description
72089705	The NVMe subsystem host already exists for the NVMe subsystem.
72089771	The NQN is invalid. A non-empty qualifier is required after the prefix. An example of a valid NQN is nqn.1992-01.com.example:string.
72089772	The NQN is invalid. Add the prefix 'nqn'. An example of a valid NQN is nqn.1992-01.com.example:string.
72089773	The NQN is invalid. The date field must be formatted yyyy-mm. An example of a valid NQN is nqn.1992-01.com.example:string.
72090001	The NVMe subsystem does not exist.
72090003	A host to be added to an NVMe subsystem is missing the "nqn" property.
72090041	An element in the "records" array contains an invalid property.
72090042	The dh_hmac_chap.host_secret_key property is required when setting any other NVMe in-band authentication properties for a host.

Name	Туре	Description
error	error	

# Example error

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

### **Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.

Name	Туре	Description
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
count	integer	The number of I/O queue pairs. The default value is inherited from the owning NVMe subsystem.
depth	integer	The I/O queue depth. The default value is inherited from the owning NVMe subsystem.

# subsystem

The NVMe subsystem to which the NVMe host has been provisioned.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.

Name	Туре	Description
uuid	string	The unique identifier of the NVMe subsystem.

### records

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

# nvme\_subsystem\_host

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
records	array[records]	An array of NVMe hosts specified to add multiple NVMe hosts to an NVMe subsystem in a single API call. Valid in POST only.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

# \_links

Name	Туре	Description
next	href	
self	href	

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# **Delete an NVMe subsystem host**

DELETE /protocols/nvme/subsystems/{subsystem.uuid}/hosts/{nqn}

Introduced In: 9.6

Deletes an NVMe subsystem host from an NVMe subsystem.

### **Related ONTAP commands**

vserver nvme subsystem host remove

#### Learn more

• DOC /protocols/nvme/subsystems

#### **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.
nqn	string	path	True	The NVMe qualified name (NQN) used to identify the NVMe subsystem host.

### Response

Status: 200, Ok

#### **Error**

Status: Default

### **ONTAP Error Response Codes**

Error Code	Description
72089771	The NQN is invalid. A non-empty qualifier is required after the prefix. An example of a valid NQN is nqn.1992-01.com.example:string.
72089772	The NQN is invalid. Add the prefix 'nqn'. An example of a valid NQN is nqn.1992-01.com.example:string.

Error Code	Description
72089773	The NQN is invalid. The date field must be formatted <i>yyyy-mm</i> . An example of a valid NQN is <i>nqn.</i> 1992-01.com.example:string.
72090001	The NVMe subsystem does not exist.

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

### **Definitions**

### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve an NVMe subsystem host

GET /protocols/nvme/subsystems/{subsystem.uuid}/hosts/{nqn}

Introduced In: 9.6

Retrieves an NVMe subsystem host of an NVMe subsystem.

### **Related ONTAP commands**

vserver nvme subsystem host show

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
subsystem.uuid	string	path	True	The unique identifier of the NVMe subsystem.

Name	Туре	In	Required	Description
nqn	string	path	True	The NVMe qualified name (NQN) used to identify the NVMe subsystem host.
fields	array[string]	query	False	Specify the fields to return.

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
records	array[records]	An array of NVMe hosts specified to add multiple NVMe hosts to an NVMe subsystem in a single API call. Valid in POST only.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
  "dh hmac chap": {
    "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
    "group size": "none",
    "hash function": "sha 256",
    "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
    "mode": "bidirectional"
  },
  "io queue": {
   "count": 4,
   "depth": 32
  "nqn": "nqn.1992-01.example.com:string",
 "records": {
    " links": {
      "self": {
       "href": "/api/resourcelink"
     }
    },
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "io queue": {
     "count": 4,
     "depth": 32
    },
    "ngn": "ngn.1992-01.example.com:string",
    "subsystem": {
     " links": {
       "self": {
          "href": "/api/resourcelink"
```

#### **Error**

```
Status: Default
```

### **ONTAP Error Response Codes**

Error Code	Description
72090001	The NVMe subsystem does not exist.

Name	Туре	Description
error	error	

### Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

# Definitions

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.

Name	Туре	Description
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
count	integer	The number of I/O queue pairs. The default value is inherited from the owning NVMe subsystem.
depth	integer	The I/O queue depth. The default value is inherited from the owning NVMe subsystem.

# subsystem

The NVMe subsystem to which the NVMe host has been provisioned.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.

Name	Туре	Description
uuid	string	The unique identifier of the NVMe subsystem.

### records

The NVMe host provisioned to access NVMe namespaces mapped to a subsystem.

Name	Туре	Description
_links	_links	
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target. Not allowed in POST when the records property is used.
subsystem	subsystem	The NVMe subsystem to which the NVMe host has been provisioned.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

Name	Туре	Description
target	string	The target parameter that caused the error.

# Remove an NVMe subsystem

DELETE /protocols/nvme/subsystems/{uuid}

Introduced In: 9.6

Removes an NVMe subsystem.

### **Related ONTAP commands**

• vserver nvme subsystem delete

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe subsystem.
allow_delete_while_ mapped	boolean	query	False	Allows for the deletion of a mapped NVMe subsystem.
allow_delete_with_h osts	boolean	query	False	Allows for the deletion of an NVMe subsystem with NVMe hosts.

### Response

Status: 200, Ok

#### **Error**

Status: Default

# **ONTAP Error Response Codes**

Error Code	Description
72090001	The NVMe subsystem does not exist.
72090023	The NVMe subsystem contains one or more mapped namespaces. Use the allow_delete_while_mapped query parameter to delete an NVMe subsystem with mapped NVMe namespaces.
72090024	The NVMe subsystem contains one or more NVMe hosts. Use the allow_delete_with_hosts query parameter to delete an NVMe subsystem with NVMe hosts.

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

### **Definitions**

### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve an NVMe subsystem

GET /protocols/nvme/subsystems/{uuid}

Introduced In: 9.6

Retrieves an NVMe subsystem.

### **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

• subsystem\_maps.\*

### **Related ONTAP commands**

- vserver nvme subsystem host show
- vserver nvme subsystem map show
- vserver nvme subsystem show

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe subsystem.
fields	array[string]	query	False	Specify the fields to return.

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to <i>false</i> when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.

Name	Туре	Description
serial_number	string	The serial number of the NVMe subsystem.
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9  • readCreate: 1

```
" links": {
   "self": {
     "href": "/api/resourcelink"
   }
  },
 "comment": "string",
 "hosts": {
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "nqn": "nqn.1992-01.example.com:string"
  } ,
  "io queue": {
   "default": {
     "count": 4,
     "depth": 16
  },
  "name": "subsystem1",
  "os type": "aix",
  "serial number": "wCVsqFMiuMhVAAAAAAB",
  "subsystem maps": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "namespace": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
        }
      "name": "/vol/vol1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

### **Example error**

```
{
  "error": {
     "arguments": {
        "code": "string",
        "message": "string"
     },
     "code": "4",
     "message": "entry doesn't exist",
     "target": "uuid"
     }
}
```

#### **Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.

Name	Туре	Description
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Type	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:  • none: The host has neither the host nor controller secret
		configured, and no authentication is performed.
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		<ul> <li>bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.</li> </ul>

#### hosts

Name	Туре	Description
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.

### default

The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

Name	Туре	Description
count	integer	The number of host I/O queue pairs.
depth	integer	The host I/O queue depth.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
default	default	The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

# namespace

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe namespace.
uuid	string	The unique identifier of the NVMe namespace.

# subsystem\_maps

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description	
_links	_links		
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPIP is hexadecimal digits (zero-filled) followed by a lower case "h".	
namespace	namespace	An NVMe namespace mapped to the NVMe subsystem.	
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".	

svm

Name	Туре	Description	
_links	_links		
name	string	The name of the SVM.	
uuid	string	The unique identifier of the SVM.	

# error\_arguments

Name	Type Description	
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description			
arguments	array[error_arguments]	Message arguments		Message arguments	
code	string	Error code			
message	string	Error message			
target	string	The target parameter that caused the error.			

# Update an NVMe subsystem

PATCH /protocols/nvme/subsystems/{uuid}

Introduced In: 9.6

Updates an NVMe subsystem.

### **Related ONTAP commands**

• vserver nvme subsystem modify

#### Learn more

• DOC /protocols/nvme/subsystems

### **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe subsystem.

# Request Body

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to <i>false</i> when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.
serial_number	string	The serial number of the NVMe subsystem.

Name	Туре	Description
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9  • readCreate: 1

```
" links": {
    "self": {
      "href": "/api/resourcelink"
   }
  } ,
  "comment": "string",
  "hosts": {
    "dh hmac chap": {
      "controller secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "group size": "none",
      "hash function": "sha 256",
      "host secret key": "DHHC-
1:00:ia6zGodOr4SEG0Zzaw398rpY0wqipUWj4jWjUh4HWUz6aQ2n:",
      "mode": "bidirectional"
    },
    "nqn": "nqn.1992-01.example.com:string"
  } ,
  "io queue": {
    "default": {
     "count": 4,
      "depth": 16
  },
  "name": "subsystem1",
  "os type": "aix",
  "serial number": "wCVsqFMiuMhVAAAAAAB",
  "subsystem maps": {
    " links": {
     "self": {
        "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "namespace": {
      " links": {
       "self": {
          "href": "/api/resourcelink"
        }
      "name": "/vol/vol1/namespace1",
      "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    },
```

```
"nsid": "00000001h"
},

"svm": {
    "_links": {
        "href": "/api/resourcelink"
        },
        "name": "svm1",
        "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
},
    "target_nqn": "nqn.1992-01.example.com:string",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412",
    "vendor_uuids": {
}

    "vendor_uuids": {
}
```

### Response

```
Status: 200, Ok
```

#### **Error**

```
Status: Default
```

### ONTAP Error Response Codes

Error Code	Description
72090001	The NVMe subsystem does not exist.

Name	Туре	Description
error	error	

### Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

### **Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
self	href	

dh\_hmac\_chap

A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.

Name	Туре	Description
controller_secret_key	string	The controller secret for NVMe inband authentication. The value of this property is used by the NVMe host to authenticate the NVMe controller while establishing a connection. If unset, the controller is not authenticated. When supplied, the property host_secret_key must also be supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a controller secret has been set for the host, but the controller secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.
group_size	string	The Diffie-Hellman group size for NVMe in-band authentication. When property host_secret_key is provided, this property defaults to 2048_bit. When supplied, the property host_secret_key must also be supplied. Optional in POST.

Name	Туре	Description
hash_function	string	The hash function for NVMe inband authentication. When property host_secret_key is provided, this property defaults to sha_256. When supplied, the property host_secret_key must also be supplied. Optional in POST.
host_secret_key	string	The host secret for NVMe in-band authentication. The value of this property is used by the NVMe controller to authenticate the NVMe host while establishing a connection. If unset, no authentication is performed by the host or controller. This property must be supplied if any other NVMe in-band authentication properties are supplied. Optional in POST.  This property is write-only. The mode property can be used to identify if a host secret has been set for the host, but the host secret value cannot be read. To change the value, the host must be deleted from the subsystem and re-added.

Name	Туре	Description
mode	string	The expected NVMe in-band authentication mode for the host. This property is an indication of which secrets are configured for the host. When set to:
		<ul> <li>none: The host has neither the host nor controller secret configured, and no authentication is performed.</li> </ul>
		<ul> <li>unidirectional: The host has a host secret configured. The controller will authenticate the host.</li> </ul>
		bidirectional: The host has both a host and controller secret configured. The controller will authenticate the host and the host will authenticate the controller.

#### hosts

Name	Туре	Description
dh_hmac_chap	dh_hmac_chap	A container for properties of NVMe in-band authentication with the DH-HMAC-CHAP protocol.
nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.

### default

The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

Name	Туре	Description
count	integer	The number of host I/O queue pairs.
depth	integer	The host I/O queue depth.

# io\_queue

The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.

Name	Туре	Description
default	default	The default I/O queue parameters inherited by NVMe hosts in the NVMe subsystem.

## namespace

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe namespace.
uuid	string	The unique identifier of the NVMe namespace.

## subsystem\_maps

An NVMe namespace mapped to the NVMe subsystem.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPIP is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
namespace	namespace	An NVMe namespace mapped to the NVMe subsystem.
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".

svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## nvme\_subsystem

An NVMe subsystem maintains configuration state and namespace access control for a set of NVMe-connected hosts.

Name	Туре	Description
_links	_links	
comment	string	A configurable comment for the NVMe subsystem. Optional in POST and PATCH.
delete_on_unmap	boolean	An option that causes the subsystem to be deleted when the last subsystem map associated with it is deleted. Optional in POST and PATCH. This property defaults to false when the subsystem is created.
hosts	array[hosts]	The NVMe hosts configured for access to the NVMe subsystem. Optional in POST.
io_queue	io_queue	The properties of the submission queue used to submit I/O commands for execution by the NVMe controller.
name	string	The name of the NVMe subsystem. Once created, an NVMe subsystem cannot be renamed. Required in POST.
os_type	string	The host operating system of the NVMe subsystem's hosts. Required in POST.
serial_number	string	The serial number of the NVMe subsystem.

Name	Туре	Description
subsystem_maps	array[subsystem_maps]	The NVMe namespaces mapped to the NVMe subsystem.  There is an added computational cost to retrieving property values for subsystem_maps. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
target_nqn	string	The NVMe qualified name (NQN) used to identify the NVMe storage target.
uuid	string	The unique identifier of the NVMe subsystem.
vendor_uuids	array[string]	Vendor-specific identifiers (UUIDs) optionally assigned to an NVMe subsystem when the subsystem is created. The identifiers are used to enable vendor-specific NVMe protocol features. The identifiers are provided by a host application vendor and shared with NetApp prior to a joint product release. Creating an NVMe subsystem with an unknown or non-specific identifier will have no effect on the NVMe subsystem. Refer to the ONTAP SAN Administration Guide for a list of the supported vendor-specific identifiers. After a subsystem is created, the vendor-specific identifiers cannot be changed or removed. Optional in POST.  • Introduced in: 9.9 • readCreate: 1

error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Manage NVMe namespaces

### Storage namespaces endpoint overview

#### Overview

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

The NVMe namespace REST API allows you to create, update, delete and discover NVMe namespaces.

In ONTAP, an NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. NVMe namespaces support being cloned. An NVMe namespace cannot be renamed, resized, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace. See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

#### **Performance monitoring**

Performance of an NVMe namespace can be monitored by observing the metric.\* and statistics.\* properties. These properties show the performance of an NVMe namespace in terms of IOPS, latency, and throughput. The metric.\* properties denote an average, whereas statistics.\* properties denote a real-time monotonically increasing value aggregated across all nodes.

#### **Examples**

#### Creating an NVMe namespace

This example creates a 300 gigabyte NVMe namespace, with 4096-byte blocks, in SVM *svm1*, volume *vol1*, configured for use by *linux* hosts. The return\_records query parameter is used to retrieve properties of the newly created NVMe namespace in the POST response.

```
# The API:
POST /api/storage/namespaces
# The call:
curl -X POST 'https://<mgmt-</pre>
ip>/api/storage/namespaces?return records=true' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "os type": "linux",
"space": { "block size": "4096", "size": "300G" }, "name" :
"/vol/vol1/namespace1" }'
# The response:
"num records": 1,
"records": [
    "uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
      "uuid": "6bf967fd-2a1c-11e9-b682-005056bbc17d",
      "name": "svm1",
      " links": {
        "self": {
          "href": "/api/svm/svms/6bf967fd-2a1c-11e9-b682-005056bbc17d"
      }
    },
    "name": "/vol/vol1/namespace1",
    "location": {
      "namespace": "namespace1",
      "volume": {
        "uuid": "71cd0dba-2a1c-11e9-b682-005056bbc17d",
        "name": "vol1",
        " links": {
          "self": {
            "href": "/api/storage/volumes/71cd0dba-2a1c-11e9-b682-
005056bbc17d"
          }
      }
    },
```

```
"enabled": true,
    "os_type": "linux",
    "space": {
      "block size": 4096,
      "size": 322122547200,
      "used": 0,
      "guarantee": {
        "requested": false,
        "reserved": false
      }
    },
    "status": {
      "container state": "online",
      "read only": false,
      "state": "online"
    " links": {
      "self": {
       "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-
f7897f945669"
     }
  }
]
}
```

### Updating an NVMe namespace comment

This example sets the comment property of an NVMe namespace.

```
# The API:
PATCH /api/storage/namespaces/{uuid}
# The call:
```

#### Updating the size of an NVMe namespace

This example increases the size of an NVMe namespace.

```
# The API:
PATCH /api/storage/namespaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-
498f-bec6-f7897f945669' -H 'Accept: application/hal+json' -d '{ "space": {
"size": "1073741824" } }'
```

### **Retrieving NVMe namespaces**

This example retrieves summary information for all online NVMe namespaces in SVM svm1. The svm.name and status.state query parameters are to find the desired NVMe namespaces.

```
# The API:
GET /api/storage/namespaces
# The call:
curl -X GET 'https://<mgmt-
ip>/api/storage/namespaces?svm.name=svm1&status.state=online' -H 'Accept:
application/hal+json'
# The response:
"records": [
    "uuid": "5c254d22-96a6-42ac-aad8-0cd9ebd126b6",
    "svm": {
      "name": "svm1"
    "name": "/vol/vol1/namespace2",
    "status": {
      "state": "online"
    },
    " links": {
      "self": {
        "href": "/api/storage/namespaces/5c254d22-96a6-42ac-aad8-
0cd9ebd126b6"
    }
  },
    "uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
    "svm": {
```

```
"name": "svm1"
    "name": "/vol/vol1/namespace1",
    "status": {
      "state": "online"
    " links": {
      "self": {
        "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-
f7897f945669"
     }
    }
  },
    "uuid": "be732687-20cf-47d2-a0e2-2a989d15661d",
    "svm": {
      "name": "svm1"
    "name": "/vol/vol2/namespace3",
    "status": {
      "state": "online"
    },
    " links": {
      "self": {
        "href": "/api/storage/namespaces/be732687-20cf-47d2-a0e2-
2a989d15661d"
    }
 }
],
"num records": 3,
" links": {
 "self": {
    "href": "/api/storage/namespaces?svm.name=svm1&status.state=online"
}
}
```

#### Retrieving details for a specific NVMe namespace

In this example, the fields query parameter is used to request all fields, including advanced fields, that would not otherwise be returned by default for the NVMe namespace.

```
# The API:
```

```
GET /api/storage/namespaces/{uuid}
# The call:
curl -X GET 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-498f-
bec6-f7897f945669?fields=**' -H 'Accept: application/hal+json'
# The response:
"uuid": "dccdc3e6-cf4e-498f-bec6-f7897f945669",
"svm": {
  "uuid": "6bf967fd-2a1c-11e9-b682-005056bbc17d",
  "name": "svm1",
  " links": {
    "self": {
      "href": "/api/svm/svms/6bf967fd-2a1c-11e9-b682-005056bbc17d"
 }
},
"name": "/vol/vol1/namespace1",
"location": {
  "namespace": "namespace1",
  "volume": {
    "uuid": "71cd0dba-2a1c-11e9-b682-005056bbc17d",
    "name": "vol1",
    " links": {
     "self": {
        "href": "/api/storage/volumes/71cd0dba-2a1c-11e9-b682-
005056bbc17d"
     }
    }
 }
},
"auto delete": false,
"enabled": true,
"comment": "Data for the research department.",
"os type": "linux",
"space": {
  "block size": 4096,
  "size": 322122547200,
 "used": 0,
  "quarantee": {
   "requested": false,
    "reserved": false
 }
},
"status": {
```

```
"container_state": "online",
  "mapped": true,
 "read only": false,
 "state": "online"
} ,
"subsystem map": {
  "nsid": "00000001h",
 "anagrpid": "00000001h",
  "subsystem": {
   "uuid": "01f17d05-2be9-11e9-bed2-005056bbc17d",
    "name": "subsystem1",
    " links": {
     "self": {
        "href": "/api/protocols/nvme/subsystems/01f17d05-2be9-11e9-bed2-
005056bbc17d"
     }
   }
 " links": {
    "self": {
      "href": "/api/protocols/nvme/subsystem-maps/dccdc3e6-cf4e-498f-bec6-
f7897f945669/01f17d05-2be9-11e9-bed2-005056bbc17d"
 }
},
"metric": {
  "timestamp": "2019-04-09T05:50:15Z",
 "duration": "PT15S",
 "status": "ok",
 "latency": {
   "other": 0,
   "total": 0,
   "read": 0,
    "write": 0
 },
 "iops": {
   "read": 0,
   "write": 0,
    "other": 0,
   "total": 0
  },
  "throughput": {
   "read": 0,
   "write": 0,
   "total": 0
```

```
},
"statistics": {
  "timestamp": "2019-04-09T05:50:42Z",
  "status": "ok",
  "latency raw": {
    "other": 38298,
    "total": 38298,
    "read": 0,
    "write": 0
  },
  "iops raw": {
    "read": 0,
    "write": 0,
    "other": 3,
    "total": 3
  },
  "throughput raw": {
    "read": 0,
    "write": 0,
    "total": 0
  }
},
" links": {
  "self": {
    "href": "/api/storage/namespaces/dccdc3e6-cf4e-498f-bec6-
f7897f945669?fields=**"
  }
}
}
```

#### **Cloning NVMe namespaces**

A clone of an NVMe namespace is an independent "copy" of the namespace that shares unchanged data blocks with the original. As blocks of the source and clone are modified, unique blocks are written for each. NVMe namespace clones can be created quickly and consume very little space initially. They can be created for the purpose of back-up, or to replicate data for multiple consumers.

An NVMe namespace clone can also be set to auto-delete by setting the auto\_delete property. If the namespace's volume is configured for automatic deletion, NVMe namespaces that have auto-delete enabled are deleted when a volume is nearly full to reclaim a target amount of free space in the volume.

#### Creating a new NVMe namespace clone

You create an NVMe namespace clone as you create any NVMe namespace — a POST to /storage/namespaces. Set clone.source.uuid or clone.source.name to identify the source NVMe namespace from which the clone is created. The NVMe namespace clone and its source must reside in the same volume.

The source NVMe namespace can reside in a Snapshot copy, in which case, the clone.source.name field must be used to identify it. Add /.snapshot/<snapshot\_name> to the path after the volume name to identify the Snapshot copy. For example /vol/vol1/.snapshot/snap1/namespace1.

```
# The API:
POST /api/storage/namespaces

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/namespaces' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "name":
"/vol/vol1/namespace2clone1", "clone": { "source": { "name":
"/vol/vol1/namespace2" } } }'
```

#### Over-writing an existing NVMe namespace's data as a clone of another

You can over-write an existing NVMe namespace as a clone of another. You do this as a PATCH on the NVMe namespace to overwrite — a PATCH to /storage/namespaces/{uuid}. Set the clone.source.uuid or clone.source.name property to identify the source NVMe namespace from which the clone data is taken. The NVMe namespace clone and its source must reside in the same volume.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto delete, subsystem map, status.state, and uuid.

```
# The API:
PATCH /api/storage/namespaces/{uuid}

# The call:
curl -X PATCH 'https://<mgmt-ip>/api/storage/namespaces/dccdc3e6-cf4e-
498f-bec6-f7897f945669' -H 'Accept: application/hal+json' -d '{ "clone": {
"source": { "name": "/vol/vol1/namespace2" } } }'
```

#### Converting a LUN into an NVMe namespace

An existing LUN can be converted in-place to an NVMe namespace with no modification to the data blocks. In other words, there is no additional copy created for the data blocks. There are certain requirements when converting a LUN to an NVMe namespace. For instance, the LUN should not be mapped to an initiator group, or exist as a protocol endpoint LUN, or in a foreign LUN import relationship. If the LUN exists as a VM volume, it should not be bound to a protocol endpoint LUN. Furthermore, only LUN with a supported operating system type for NVMe namespace can be converted.

The conversion process updates the metadata to the LUN, making it an NVMe namespace. The conversion is both time and space efficient. After conversion, the new namespace behaves as a regular namespace and may be mapped to an NVMe subsystem.

#### Convert a LUN into an NVMe namespace

You convert a LUN into an NVMe namespace by calling a POST to /storage/namespaces. Set convert.lun.uuid or convert.lun.name to identify the source LUN which is to be converted in-place into an NVMe namespace.

```
# The API:
POST /api/storage/namespaces

# The call:
curl -X POST 'https://<mgmt-ip>/api/storage/namespaces' -H 'Accept:
application/hal+json' -d '{ "svm": { "name": "svm1" }, "convert": { "lun":
{ "name": "/vol/vol1/lun1" } } }'
```

#### **Deleting an NVMe namespace**

```
# The API:
DELETE /api/storage/namespaces/{uuid}

# The call:
curl -X DELETE 'https://<mgmt-ip>/api/storage/namespaces/5c254d22-96a6-
42ac-aad8-0cd9ebd126b6' -H 'Accept: application/hal+json'
```

## **Retrieve NVMe namespaces**

GET /storage/namespaces

Introduced In: 9.6

Retrieves NVMe namespaces.

#### **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

```
auto_deletesubsystem_map.*status.mappedstatistics.*metric.*
```

### **Related ONTAP commands**

- vserver nvme namespace show
- vserver nvme subsystem map show

### Learn more

• DOC /storage/namespaces to learn more and examples.

### **Parameters**

Name	Туре	In	Required	Description
comment	string	query	False	<ul><li>Filter by comment</li><li>maxLength: 254</li><li>minLength: 0</li></ul>
svm.uuid	string	query	False	Filter by svm.uuid
svm.name	string	query	False	Filter by svm.name
metric.latency.total	integer	query	False	Filter by metric.latency.total  • Introduced in: 9.8
metric.latency.read	integer	query	False	Filter by metric.latency.read  • Introduced in: 9.8
metric.latency.write	integer	query	False	Filter by metric.latency.write  • Introduced in: 9.8
metric.latency.other	integer	query	False	Filter by metric.latency.other  • Introduced in: 9.8

Name	Туре	In	Required	Description
metric.duration	string	query	False	Filter by metric.duration  • Introduced in: 9.8
metric.throughput.re ad	integer	query	False	Filter by metric.throughput.re ad  • Introduced in: 9.8
metric.throughput.tot al	integer	query	False	Filter by metric.throughput.tot al  • Introduced in: 9.8
metric.throughput.wri te	integer	query	False	Filter by metric.throughput.wr ite  • Introduced in: 9.8
metric.iops.total	integer	query	False	Filter by metric.iops.total  • Introduced in: 9.8
metric.iops.read	integer	query	False	Filter by metric.iops.read  • Introduced in: 9.8
metric.iops.write	integer	query	False	Filter by metric.iops.write  • Introduced in: 9.8

Name	Туре	In	Required	Description
metric.iops.other	integer	query	False	Filter by metric.iops.other  • Introduced in: 9.8
metric.status	string	query	False	Filter by metric.status  • Introduced in: 9.8
metric.timestamp	string	query	False	Filter by metric.timestamp  • Introduced in: 9.8
space.used	integer	query	False	Filter by space.used
space.size	integer	query	False	• Max value: 1407374883553 28 • Min value: 4096
space.guarantee.res erved	boolean	query	False	Filter by space.guarantee.res erved
space.guarantee.req uested	boolean	query	False	Filter by space.guarantee.req uested
space.block_size	integer	query	False	Filter by space.block_size
auto_delete	boolean	query	False	Filter by auto_delete
uuid	string	query	False	Filter by uuid
os_type	string	query	False	Filter by os_type
name	string	query	False	Filter by name

Name	Туре	In	Required	Description
enabled	boolean	query	False	Filter by enabled
subsystem_map.nsi d	string	query	False	Filter by subsystem_map.nsi d
subsystem_map.ana grpid	string	query	False	Filter by subsystem_map.ana grpid
subsystem_map.sub system.name	string	query	False	Filter by subsystem_map.sub system.name  • maxLength: 96  • minLength: 1
subsystem_map.sub system.uuid	string	query	False	Filter by subsystem_map.sub system.uuid
status.read_only	boolean	query	False	Filter by status.read_only
status.mapped	boolean	query	False	Filter by status.mapped
status.state	string	query	False	Filter by status.state
status.container_stat e	string	query	False	Filter by status.container_stat e
location.volume.uuid	string	query	False	Filter by location.volume.uuid
location.volume.nam e	string	query	False	Filter by location.volume.nam e
location.qtree.id	integer	query	False	Filter by location.qtree.id  • Max value: 4994  • Min value: 0

Name	Туре	In	Required	Description
location.qtree.name	string	query	False	Filter by location.qtree.name
location.namespace	string	query	False	Filter by location.namespace
location.node.uuid	string	query	False	Filter by location.node.uuid  • Introduced in: 9.10
location.node.name	string	query	False	Filter by location.node.name • Introduced in: 9.10
create_time	string	query	False	• Introduced in: 9.7
statistics.iops_raw.to tal	integer	query	False	Filter by statistics.iops_raw.to tal  • Introduced in: 9.8
statistics.iops_raw.re ad	integer	query	False	Filter by statistics.iops_raw.r ead  • Introduced in: 9.8
statistics.iops_raw.w rite	integer	query	False	Filter by statistics.iops_raw.w rite  • Introduced in: 9.8

Name	Туре	In	Required	Description
statistics.iops_raw.ot her	integer	query	False	Filter by statistics.iops_raw.ot her  • Introduced in: 9.8
statistics.throughput _raw.read	integer	query	False	Filter by statistics.throughput raw.read  • Introduced in: 9.8
statistics.throughput _raw.total	integer	query	False	Filter by statistics.throughput _raw.total  • Introduced in: 9.8
statistics.throughput _raw.write	integer	query	False	Filter by statistics.throughput _raw.write  • Introduced in: 9.8
statistics.latency_ra w.total	integer	query	False	Filter by statistics.latency_ra w.total  • Introduced in: 9.8
statistics.latency_ra w.read	integer	query	False	Filter by statistics.latency_ra w.read  • Introduced in: 9.8
statistics.latency_ra w.write	integer	query	False	Filter by statistics.latency_ra w.write  • Introduced in: 9.8

Name	Туре	In	Required	Description
statistics.latency_ra w.other	integer	query	False	Filter by statistics.latency_ra w.other  • Introduced in: 9.8
statistics.status	string	query	False	Filter by statistics.status  • Introduced in: 9.8
statistics.timestamp	string	query	False	Filter by statistics.timestamp • Introduced in: 9.8
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
return_records	boolean	query	False	The default is true for GET calls. When set to false, only the number of records is returned.  • Default value: 1

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Max value: 120  • Min value: 0  • Default value: 1
order_by	array[string]	query	False	Order results by specified fields and optional [asc

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_namespace]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
   "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "clone": {
   "source": {
     "name": "/vol/volume1/namespace1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "comment": "string",
  "convert": {
   "lun": {
     "name": "/vol/volume1/lun1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "create time": "2018-06-04T19:00:00Z",
  "location": {
    "namespace": "namespace1",
    "node": {
      " links": {
        "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "qtree": {
     " links": {
        "self": {
```

```
"href": "/api/resourcelink"
    }
   },
   "id": 1,
   "name": "qt1"
 },
 "volume": {
   " links": {
     "self": {
      "href": "/api/resourcelink"
    }
   } ,
   "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
},
"metric": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
 },
 "duration": "PT15S",
 "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"name": "/vol/volume1/qtree1/namespace1",
"os type": "aix",
"space": {
 "block size": 512,
 "size": 1073741824,
```

```
"used": 0
},
"statistics": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 "timestamp": "2017-01-25T11:20:13Z"
},
"status": {
 "container state": "online",
 "state": "online"
},
"subsystem map": {
 " links": {
  "self": {
     "href": "/api/resourcelink"
   }
 },
 "anagrpid": "00103050h",
 "nsid": "00000001h",
 "subsystem": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
   },
   "name": "subsystem1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"svm": {
 " links": {
   "self": {
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

### **Example error**

```
{
  "error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

### **Definitions**

#### See Definitions

href

Name	Туре	Description
href	string	

links

Name	Туре	Description
next	href	
self	href	

links

Name	Туре	Description
self	href	

#### source

The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

Name	Туре	Description
name	string	The fully qualified path name of the clone source NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST and PATCH.
uuid	string	The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.

#### clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as

part of the PATCH: auto\_delete (unless specified in the request), subsystem\_map, status.state,
and uuid.

Name	Туре	Description
source	source	The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.  Valid in POST to create a new NVMe namespace as a clone of the source.  Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

#### lun

The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

Name	Туре	Description
name	string	The fully qualified path name of the source LUN composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the LUN. Valid in POST.
uuid	string	The unique identifier of the source LUN. Valid in POST.

#### convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

Name	Туре	Description
lun	lun	The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.
		Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

### node

The cluster node that hosts the NVMe namespace.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

#### qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

Name	Туре	Description
_links	_links	
id	integer	The identifier for the qtree, unique within the qtree's volume.
name	string	The name of the qtree.

#### volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.  • example: 028baa66-41bd- 11e9-81d5-00a0986138f7  • Introduced in: 9.6

## location

The location of the NVMe namespace within the ONTAP cluster. Valid in POST.

NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
namespace	string	The base name component of the NVMe namespace. Valid in POST.
		If properties name and location.namespace are specified in the same request, they must refer to the base name.  NVMe namespaces do not support rename.
node	node	The cluster node that hosts the NVMe namespace.

Name	Туре	Description
qtree	qtree	The qtree in which the NVMe namespace is optionally located. Valid in POST.  If properties name and
		location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.
		NVMe namespaces do not support rename.
volume	volume	The volume in which the NVMe namespace is located. Valid in POST.
		If properties name and location.volume.name and/or
		location.volume.uuid are specified in the same request, they must refer to the same volume.
		NVMe namespaces do not support movement between volumes.

## iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### metric

Performance numbers, such as IOPS latency and throughput

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## guarantee

Properties that request and report the space guarantee for the NVMe namespace.

Name	Туре	Description
requested	boolean	The requested space reservation policy for the NVMe namespace. If <i>true</i> , a space reservation is requested for the namespace; if <i>false</i> , the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.  The space reservation policy for an NVMe namespace is determined by ONTAP.  • readOnly: 1  • Introduced in: 9.6
reserved	boolean	Reports if the NVMe namespace is space guaranteed.  This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.

## space

The storage space related properties of the NVMe namespace.

Name	Туре	Description
block_size	integer	The size of blocks in the namespace in bytes.  Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.

guarantee guarantee Properties that request and report the space guarantee for the NVMe namespace.  size The total provisioned size of the NVMe namespace Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (1755757870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824  • format: int64  • Max value: 140737488355328  • Min value: 4096  • Introduced in: 9.6	Name	Туре	Description
NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (1755757870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824 • format: int64 • Max value: 140737488355328	guarantee	guarantee	the space guarantee for the
	size	integer	NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824  • format: int64  • Max value: 140737488355328  • Min value: 4096

Name	Туре	Description
used	integer	The amount of space consumed by the main data stream of the NVMe namespace.  This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • format: int64  • readOnly: 1  • Introduced in: 9.6

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description	
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.	
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.	
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.	
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.	
timestamp	string	The timestamp of the performance data.	

status

Status information about the NVMe namespace.

Name	Туре	Description
container_state	string	The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available.
mapped	boolean	Reports if the NVMe namespace is mapped to an NVMe subsystem.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
read_only	boolean	Reports if the NVMe namespace allows only read access.
state	string	The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors.

## subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

## subsystem\_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for subsystem map. They are not

populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

#### nvme namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

In ONTAP, an NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. NVMe namespaces support being cloned. An NVMe namespace cannot be renamed, resized, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace. See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

Name	Туре	Description
_links	_links	
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to true, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is false.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem_map, status.state, and uuid.
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.

Name	Туре	Description
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6  • readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.

Name	Туре	Description
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.
		There is an added computational cost to retrieving property values for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Create an NVMe namespace

POST /storage/namespaces

Introduced In: 9.6

Creates an NVMe namespace.

### Required properties

- svm.uuid or svm.name Existing SVM in which to create the NVMe namespace.
- name, location.volume.name or location.volume.uuid Existing volume in which to create the NVMe namespace.
- name or location.namespace Base name for the NVMe namespace.
- os\_type Operating system from which the NVMe namespace will be accessed. (Not used for clones, which are created based on the os\_type of the source NVMe namespace.)
- space.size Size for the NVMe namespace. (Not used for clones, which are created based on the size of the source NVMe namespace.)

### **Default property values**

If not specified in POST, the following default property values are assigned:

- auto delete false
- space.block\_size 4096 (512 when 'os\_type' is vmware)

#### **Related ONTAP commands**

- volume file clone autodelete
- volume file clone create
- vserver nvme namespace convert-from-lun
- vserver nvme namespace create

### Learn more

DOC /storage/namespaces

#### **Parameters**

Name Typ	pe	In	Required	Description
return_records boo	oolean	query		The default is false. If set to true, the records are returned.  • Default value:

#### **Request Body**

Name	Туре	Description
_links	_links	

Name	Туре	Description
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to <i>true</i> , the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i> .  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem_map, status.state, and uuid.

Name	Туре	Description
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6  • readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.  There is an added computational cost to retrieving property values for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
},
"clone": {
 "source": {
   "name": "/vol/volume1/namespace1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
"comment": "string",
"convert": {
 "lun": {
   "name": "/vol/volume1/lun1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
},
"create time": "2018-06-04T19:00:00Z",
"location": {
  "namespace": "namespace1",
  "node": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "qtree": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "id": 1,
    "name": "qt1"
  },
  "volume": {
   " links": {
     "self": {
        "href": "/api/resourcelink"
```

```
},
    "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
},
"metric": {
 " links": {
   "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
  "status": "ok",
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"name": "/vol/volume1/qtree1/namespace1",
"os type": "aix",
"space": {
 "block size": 512,
 "size": 1073741824,
 "used": 0
} ,
"statistics": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
  "latency raw": {
   "read": 200,
```

```
"total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput raw": {
     "read": 200,
    "total": 1000,
     "write": 100
   },
   "timestamp": "2017-01-25T11:20:13Z"
  },
 "status": {
   "container state": "online",
   "state": "online"
  },
 "subsystem map": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "nsid": "00000001h",
   "subsystem": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
 },
 "svm": {
   " links": {
    "self": {
       "href": "/api/resourcelink"
   },
   "name": "svm1",
   "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
 },
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

## Response

Status: 201, Created

Name	Туре	Description
_links	_links	
num_records	integer	The number of records in the response.
records	array[nvme_namespace]	

```
" links": {
  "next": {
   "href": "/api/resourcelink"
 },
 "self": {
   "href": "/api/resourcelink"
 }
},
"num records": 1,
"records": {
  " links": {
   "self": {
     "href": "/api/resourcelink"
  },
  "clone": {
   "source": {
     "name": "/vol/volume1/namespace1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "comment": "string",
  "convert": {
   "lun": {
     "name": "/vol/volume1/lun1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
  },
  "create time": "2018-06-04T19:00:00Z",
  "location": {
    "namespace": "namespace1",
    "node": {
      " links": {
        "self": {
         "href": "/api/resourcelink"
       }
      },
      "name": "node1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
    "qtree": {
     " links": {
        "self": {
```

```
"href": "/api/resourcelink"
    }
   },
   "id": 1,
   "name": "qt1"
 },
 "volume": {
   " links": {
     "self": {
      "href": "/api/resourcelink"
    }
   } ,
   "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
},
"metric": {
 " links": {
   "self": {
     "href": "/api/resourcelink"
   }
 },
 "duration": "PT15S",
 "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"name": "/vol/volume1/qtree1/namespace1",
"os type": "aix",
"space": {
 "block size": 512,
 "size": 1073741824,
```

```
"used": 0
},
"statistics": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "latency raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "status": "ok",
 "throughput raw": {
   "read": 200,
   "total": 1000,
   "write": 100
 "timestamp": "2017-01-25T11:20:13Z"
},
"status": {
 "container state": "online",
 "state": "online"
},
"subsystem map": {
 " links": {
  "self": {
     "href": "/api/resourcelink"
   }
 },
 "anagrpid": "00103050h",
 "nsid": "00000001h",
 "subsystem": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
   },
   "name": "subsystem1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
},
"svm": {
 " links": {
   "self": {
```

#### Headers

Name	Description	Туре
Location	Useful for tracking the resource location	string

## Error

```
Status: Default
```

## ONTAP Error Response Codes

Error Code	Description
917927	The specified volume was not found.
918236	The specified location.volume.uuid and location.volume.name do not refer to the same volume.
2621462	The supplied SVM does not exist.
2621706	The specified svm.uuid and svm.name do not refer to the same SVM.
2621707	No SVM was specified. Either svm.name or svm.uuid must be supplied.
5242927	The specified qtree was not found.
5242950	The specified location.qtree.id and location.qtree.name do not refer to the same qtree.
5374140	LUN has a non-zero prefix and/or suffix size.
5374141	LUN is part of a SnapMirror Business Continuity (SMBC) relationship.
5374156	A protocol endpoint LUN cannot be converted to an NVMe namespace.

Error Code	Description
5374157	LUN in an SVM with MetroCluster configured cannot be converted to an NVMe namespace.
5374158	LUN contains an operating system type that is not supported for NVMe namespace.
5374352	An invalid name was provided for the NVMe namespace.
5374858	The volume specified by name is not the same as that specified by location.volume.
5374860	The qtree specified by name is not the same as that specified by location.qtree.
5374861	The NVME namespace base name specified by name is not the same as that specified by location.name.
5374862	No NVMe namespace path base name was provided for the namespace.
13565952	The NVMe namespace clone request failed.
72089720	NVMe namespaces cannot be created in Snapshot copies.
72089721	The volume specified is in a load sharing mirror relationship. Namespaces are not supported in load sharing mirrors.
72089722	A negative size was provided for the NVMe namespace.
72089723	The specified size is too small for the NVMe namespace.
72089724	The specified size is too large for the NVMe namespace.
72089725	A LUN or NVMe namespace already exists at the specified path.
72089727	NVMe namespaces cannot be created on an SVM root volume.
72089728	NVMe namespaces cannot be created on a FlexGroup volume.
72089732	An NVMe namespace name can only contain characters A-Z, a-z, 0-9, "-", ".", "_", "{" and "}".
72090005	The specified clone.source.uuid and clone.source.name do not refer to the same NVMe namespace.
72090006	The specified clone.source was not found.
72090007	The specified clone.source was not found.

Error Code	Description
72090009	An error occurred after successfully creating the NVMe namespace. Some properties were not set.
72090012	The property cannot be specified when creating an NVMe namespace clone. The target property of the error object identifies the property.
72090013	The property is required except when creating an NVMe namespace clone. The target property of the error object identifies the property.
72090014	No volume was specified for the NVMe namespace.
72090015	An error occurred after successfully creating the NVMe namespace preventing the retrieval of its properties.
72090033	The clone.source.uuid property is not supported when specifying a source NVMe namespace from a Snapshot copy.
72090039	The property cannot be specified at the same time when creating an NVMe namespace as a clone. The target property of the error object identifies the other property given with clone.
72090040	The property cannot be specified when converting a LUN into an NVMe namespace. The target property of the error object identifies the property.

Name	Туре	Description
error	error	

## Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
      "code": "4",
      "message": "entry doesn't exist",
      "target": "uuid"
    }
}
```

## **Definitions**

#### See Definitions

#### href

Name	Туре	Description
href	string	

### links

Name	Туре	Description
self	href	

#### source

The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

Name	Туре	Description
name	string	The fully qualified path name of the clone source NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST and PATCH.
uuid	string	The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.

#### clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto\_delete (unless specified in the request), subsystem\_map, status.state, and uuid.

Name	Туре	Description
source	source	The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.  Valid in POST to create a new NVMe namespace as a clone of the source.  Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

#### lun

The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

Name	Туре	Description
name	string	The fully qualified path name of the source LUN composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the LUN. Valid in POST.
uuid	string	The unique identifier of the source LUN. Valid in POST.

#### convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

Name	Туре	Description
lun	lun	The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.
		Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

### node

The cluster node that hosts the NVMe namespace.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

#### qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

Name	Туре	Description
_links	_links	
id	integer	The identifier for the qtree, unique within the qtree's volume.
name	string	The name of the qtree.

#### volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.  • example: 028baa66-41bd- 11e9-81d5-00a0986138f7  • Introduced in: 9.6

## location

The location of the NVMe namespace within the ONTAP cluster. Valid in POST.

NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
namespace	string	The base name component of the NVMe namespace. Valid in POST.
		If properties name and location.namespace are specified in the same request, they must refer to the base name.  NVMe namespaces do not support rename.
node	node	The cluster node that hosts the NVMe namespace.

Name	Туре	Description
qtree	qtree	The qtree in which the NVMe namespace is optionally located. Valid in POST.  If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.  NVMe namespaces do not support rename.
volume	volume	The volume in which the NVMe namespace is located. Valid in POST.  If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.  NVMe namespaces do not support movement between volumes.

## iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## metric

Performance numbers, such as IOPS latency and throughput

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## guarantee

Properties that request and report the space guarantee for the NVMe namespace.

Name	Туре	Description
requested	boolean	The requested space reservation policy for the NVMe namespace. If <i>true</i> , a space reservation is requested for the namespace; if <i>false</i> , the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.  The space reservation policy for an NVMe namespace is determined by ONTAP.  • readOnly: 1  • Introduced in: 9.6
reserved	boolean	Reports if the NVMe namespace is space guaranteed.  This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.

## space

The storage space related properties of the NVMe namespace.

Name	Туре	Description
block_size	integer	The size of blocks in the namespace in bytes.  Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.

Name	Туре	Description
guarantee	guarantee	Properties that request and report the space guarantee for the NVMe namespace.
size	integer	The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824  • format: int64  • Max value: 140737488355328  • Min value: 4096  • Introduced in: 9.6

Name	Туре	Description
used	integer	The amount of space consumed by the main data stream of the NVMe namespace.  This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • format: int64  • readOnly: 1  • Introduced in: 9.6

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internation uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

status

Status information about the NVMe namespace.

Name	Туре	Description
container_state	string	The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available.
mapped	boolean	Reports if the NVMe namespace is mapped to an NVMe subsystem.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
read_only	boolean	Reports if the NVMe namespace allows only read access.
state	string	The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors.

## subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

## subsystem\_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for subsystem map. They are not

populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

#### nvme namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

In ONTAP, an NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. NVMe namespaces support being cloned. An NVMe namespace cannot be renamed, resized, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace. See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

Name	Туре	Description
_links	_links	
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to true, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is false.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem map,
		status.state, and uuid.
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.

Name	Туре	Description
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6  • readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.

Name	Туре	Description
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.
		There is an added computational cost to retrieving property values for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

## \_links

Name	Туре	Description
next	href	
self	href	

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message

Name	Туре	Description
target	string	The target parameter that caused the error.

# **Delete an NVMe namespace**

DELETE /storage/namespaces/{uuid}

Introduced In: 9.6

Deletes an NVMe namespace.

## **Related ONTAP commands**

• vserver nvme namespace delete

#### Learn more

• DOC /storage/namespaces

## **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe namespace to delete.
allow_delete_while_mapped	boolean	query	False	Allows deletion of a mapped NVMe namespace. A mapped NVMe namespace might be in use. Deleting a mapped namespace also deletes the namespace map and makes the data no longer available, possibly causing a disruption in the availability of data. This parameter should be used with caution.  • Default value:

## Response

```
Status: 200, Ok
```

### **Error**

```
Status: Default
```

## **ONTAP Error Response Codes**

Error Code	Description
72090006	The specified namespace was not found.
72090007	The specified namespace was not found.
72090016	The namespace's aggregate is offline. The aggregate must be online to modify or remove the namespace.
72090017	The namespace's volume is offline. The volume must be online to modify or remove the namespace.

Name	Туре	Description
error	error	

## **Example error**

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
      }
}
```

### **Definitions**

#### **See Definitions**

### error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve an NVMe namespace

GET /storage/namespaces/{uuid}

Introduced In: 9.6

Retrieves an NVMe namespace.

### **Expensive properties**

There is an added computational cost to retrieving values for these properties. They are not included by default in GET results and must be explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

- auto\_delete
- subsystem map.\*
- status.mapped
- statistics.\*
- metric.\*

#### **Related ONTAP commands**

vserver nvme namespace show

• vserver nvme subsystem map show

## Learn more

• DOC /storage/namespaces

## **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe namespace to retrieve.
fields	array[string]	query	False	Specify the fields to return.

## Response

Status: 200, Ok

Name	Туре	Description
_links	_links	

Name	Туре	Description
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to <i>true</i> , the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is <i>false</i> .  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem_map, status.state, and uuid.

Name	Туре	Description
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6  • readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.  There is an added computational cost to retrieving property values for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
} ,
"clone": {
 "source": {
   "name": "/vol/volume1/namespace1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
"comment": "string",
"convert": {
 "lun": {
   "name": "/vol/volume1/lun1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
},
"create time": "2018-06-04T19:00:00Z",
"location": {
  "namespace": "namespace1",
  "node": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "qtree": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "id": 1,
    "name": "qt1"
  },
  "volume": {
   " links": {
     "self": {
        "href": "/api/resourcelink"
```

```
},
    "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
},
"metric": {
 " links": {
   "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
  "status": "ok",
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"name": "/vol/volume1/qtree1/namespace1",
"os type": "aix",
"space": {
 "block size": 512,
 "size": 1073741824,
 "used": 0
} ,
"statistics": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
  "latency raw": {
   "read": 200,
```

```
"total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput raw": {
     "read": 200,
    "total": 1000,
     "write": 100
   "timestamp": "2017-01-25T11:20:13Z"
  },
 "status": {
   "container state": "online",
   "state": "online"
  },
 "subsystem map": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "nsid": "00000001h",
   "subsystem": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
 },
 "svm": {
   " links": {
    "self": {
       "href": "/api/resourcelink"
   },
   "name": "svm1",
   "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
 },
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

### **Error**

```
Status: Default
```

## ONTAP Error Response Codes

Error Code	Description
72090006	The specified namespace was not found.
72090007	The specified namespace was not found.

Name	Туре	Description
error	error	

## **Example error**

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

## **Definitions**

#### **See Definitions**

#### href

Name	Туре	Description
href	string	

#### links

Name	Туре	Description
self	href	

#### source

The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

Name	Туре	Description
name	string	The fully qualified path name of the clone source NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST and PATCH.
uuid	string	The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.

#### clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto\_delete (unless specified in the request), subsystem\_map, status.state, and uuid.

Name	Туре	Description
source	source	The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.  Valid in POST to create a new NVMe namespace as a clone of the source.  Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

#### lun

The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

Name	Туре	Description
name	string	The fully qualified path name of the source LUN composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the LUN. Valid in POST.
uuid	string	The unique identifier of the source LUN. Valid in POST.

#### convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

Name	Туре	Description
lun	lun	The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.  Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

### node

The cluster node that hosts the NVMe namespace.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

#### qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

Name	Туре	Description
_links	_links	
id	integer	The identifier for the qtree, unique within the qtree's volume.
name	string	The name of the qtree.

#### volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.  • example: 028baa66-41bd- 11e9-81d5-00a0986138f7  • Introduced in: 9.6

## location

The location of the NVMe namespace within the ONTAP cluster. Valid in POST.

NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
namespace	string	The base name component of the NVMe namespace. Valid in POST.
		If properties name and location.namespace are specified in the same request, they must refer to the base name.  NVMe namespaces do not support rename.
node	node	The cluster node that hosts the NVMe namespace.

Name	Туре	Description
qtree	qtree	The qtree in which the NVMe namespace is optionally located. Valid in POST.  If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.  NVMe namespaces do not support rename.
volume	volume	The volume in which the NVMe namespace is located. Valid in POST.  If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.  NVMe namespaces do not support movement between volumes.

# iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## metric

Performance numbers, such as IOPS latency and throughput

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

## guarantee

Properties that request and report the space guarantee for the NVMe namespace.

Name	Туре	Description
requested	boolean	The requested space reservation policy for the NVMe namespace. If <i>true</i> , a space reservation is requested for the namespace; if <i>false</i> , the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.  The space reservation policy for an NVMe namespace is determined by ONTAP.  • readOnly: 1  • Introduced in: 9.6
reserved	boolean	Reports if the NVMe namespace is space guaranteed.  This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.

## space

The storage space related properties of the NVMe namespace.

Name	Туре	Description
block_size	integer	The size of blocks in the namespace in bytes.  Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.

Name	Туре	Description
guarantee	guarantee	Properties that request and report the space guarantee for the NVMe namespace.
size	integer	The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824  • format: int64  • Max value: 140737488355328  • Min value: 4096  • Introduced in: 9.6

Name	Туре	Description
used	integer	The amount of space consumed by the main data stream of the NVMe namespace.  This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • format: int64  • readOnly: 1  • Introduced in: 9.6

## iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

status

Status information about the NVMe namespace.

Name	Туре	Description
container_state	string	The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available.
mapped	boolean	Reports if the NVMe namespace is mapped to an NVMe subsystem.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
read_only	boolean	Reports if the NVMe namespace allows only read access.
state	string	The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors.

## subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

## subsystem\_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for subsystem map. They are not

populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped.

### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

## error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Update an NVMe namespace

PATCH /storage/namespaces/{uuid}

Introduced In: 9.6

Updates an NVMe namespace.

### **Related ONTAP commands**

- volume file clone autodelete
- vserver nvme namespace modify

### Learn more

• DOC /storage/namespaces

### **Parameters**

Name	Туре	In	Required	Description
uuid	string	path	True	The unique identifier of the NVMe namespace to update.

## **Request Body**

Name	Туре	Description
_links	_links	

Name	Туре	Description
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to true, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is false.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem_map, status.state, and uuid.

Name	Туре	Description
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6  • readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.  There is an added computational cost to retrieving property values for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

```
" links": {
 "self": {
   "href": "/api/resourcelink"
 }
} ,
"clone": {
 "source": {
   "name": "/vol/volume1/namespace1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
"comment": "string",
"convert": {
 "lun": {
   "name": "/vol/volume1/lun1",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
},
"create time": "2018-06-04T19:00:00Z",
"location": {
  "namespace": "namespace1",
  "node": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "name": "node1",
    "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
  },
  "qtree": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "id": 1,
    "name": "qt1"
  },
  "volume": {
   " links": {
     "self": {
        "href": "/api/resourcelink"
```

```
},
    "name": "volume1",
   "uuid": "028baa66-41bd-11e9-81d5-00a0986138f7"
 }
},
"metric": {
 " links": {
   "self": {
    "href": "/api/resourcelink"
   }
  },
  "duration": "PT15S",
  "iops": {
   "read": 200,
   "total": 1000,
   "write": 100
  },
  "latency": {
   "read": 200,
   "total": 1000,
   "write": 100
  "status": "ok",
  "throughput": {
   "read": 200,
   "total": 1000,
   "write": 100
 },
 "timestamp": "2017-01-25T11:20:13Z"
"name": "/vol/volume1/qtree1/namespace1",
"os type": "aix",
"space": {
 "block size": 512,
 "size": 1073741824,
 "used": 0
} ,
"statistics": {
 "iops raw": {
   "read": 200,
   "total": 1000,
   "write": 100
  "latency raw": {
   "read": 200,
```

```
"total": 1000,
     "write": 100
    },
    "status": "ok",
    "throughput raw": {
     "read": 200,
    "total": 1000,
     "write": 100
   "timestamp": "2017-01-25T11:20:13Z"
  },
 "status": {
   "container state": "online",
   "state": "online"
  },
 "subsystem map": {
   " links": {
     "self": {
       "href": "/api/resourcelink"
     }
    },
    "anagrpid": "00103050h",
    "nsid": "00000001h",
   "subsystem": {
     " links": {
       "self": {
         "href": "/api/resourcelink"
       }
     },
     "name": "subsystem1",
     "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
   }
 },
 "svm": {
   " links": {
    "self": {
       "href": "/api/resourcelink"
   },
   "name": "svm1",
   "uuid": "02c9e252-41be-11e9-81d5-00a0986138f7"
 },
 "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
}
```

# Response

Status: 200, Ok

# Error

Status: Default

# ONTAP Error Response Codes

Error Code	Description
13565952	The namespace clone request failed.
72089724	The specified namespace size is too large.
72089730	The specified namespace cannot be updated as it resides in a Snapshot copy.
72090005	The specified clone.source.uuid and clone.source.name do not refer to the same LUN.
72090006	The specified namespace was not found. This can apply to clone.source or the target namespace. The target property of the error object identifies the property.
72090007	The specified namespace was not found. This can apply to clone.source or the target namespace. The target property of the error object identifies the property.
72090010	An error occurred after successfully overwriting data for the namespace as a clone. Some properties were not modified.
72090011	An error occurred after successfully modifying some of the properties of the namespace. Some properties were not modified.
72090016	The namespace's aggregate is offline. The aggregate must be online to modify or remove the namespace.
72090017	The namespace's volume is offline. The volume must be online to modify or remove the namespace.
72090038	An attempt was made to reduce the size of the specified namespace.

Name	Туре	Description
error	error	

## Example error

```
"error": {
    "arguments": {
        "code": "string",
        "message": "string"
    },
    "code": "4",
    "message": "entry doesn't exist",
    "target": "uuid"
    }
}
```

# Definitions

#### See Definitions

#### href

Name	Туре	Description
href	string	

## links

Name	Туре	Description
self	href	

#### source

The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.

Valid in POST to create a new NVMe namespace as a clone of the source.

Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

Name	Туре	Description
name	string	The fully qualified path name of the clone source NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST and PATCH.
uuid	string	The unique identifier of the clone source NVMe namespace. Valid in POST and PATCH.

#### clone

This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.

When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto\_delete (unless specified in the request), subsystem\_map, status.state, and uuid.

Name	Туре	Description
source	source	The source NVMe namespace for a namespace clone operation. This can be specified using property clone.source.uuid or clone.source.name. If both properties are supplied, they must refer to the same namespace.  Valid in POST to create a new NVMe namespace as a clone of the source.  Valid in PATCH to overwrite an existing NVMe namespace's data as a clone of another.

#### lun

The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.

Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

Name	Туре	Description
name	string	The fully qualified path name of the source LUN composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the LUN. Valid in POST.
uuid	string	The unique identifier of the source LUN. Valid in POST.

#### convert

This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.

Name	Туре	Description
lun	lun	The source LUN for convert operation. This can be specified using property convert.lun.uuid or convert.lun.name. If both properties are supplied, they must refer to the same LUN.  Valid in POST. A convert request from LUN to NVMe namespace cannot be combined with setting any other namespace properties. All other properties of the converted NVMe namespace comes from the source LUN.

## node

The cluster node that hosts the NVMe namespace.

Name	Туре	Description
_links	_links	
name	string	
uuid	string	

#### qtree

The qtree in which the NVMe namespace is optionally located. Valid in POST.

If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.

NVMe namespaces do not support rename.

Name	Туре	Description
_links	_links	
id	integer	The identifier for the qtree, unique within the qtree's volume.
name	string	The name of the qtree.

#### volume

The volume in which the NVMe namespace is located. Valid in POST.

If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.

NVMe namespaces do not support movement between volumes.

Name	Туре	Description
_links	_links	
name	string	The name of the volume.
uuid	string	Unique identifier for the volume. This corresponds to the instance- uuid that is exposed in the CLI and ONTAPI. It does not change due to a volume move.  • example: 028baa66-41bd- 11e9-81d5-00a0986138f7  • Introduced in: 9.6

## location

The location of the NVMe namespace within the ONTAP cluster. Valid in POST.

NVMe namespaces do not support rename, or movement between volumes.

Name	Туре	Description
namespace	string	The base name component of the NVMe namespace. Valid in POST.
		If properties name and location.namespace are specified in the same request, they must refer to the base name.  NVMe namespaces do not support rename.
node	node	The cluster node that hosts the NVMe namespace.

Name	Туре	Description
qtree	qtree	The qtree in which the NVMe namespace is optionally located. Valid in POST.  If properties name and location.qtree.name and/or location.qtree.uuid are specified in the same request, they must refer to the same qtree.  NVMe namespaces do not support rename.
volume	volume	The volume in which the NVMe namespace is located. Valid in POST.  If properties name and location.volume.name and/or location.volume.uuid are specified in the same request, they must refer to the same volume.  NVMe namespaces do not support movement between volumes.

# iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## metric

Performance numbers, such as IOPS latency and throughput

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:

Name	Туре	Description
iops	iops	The rate of I/O operations observed at the storage object.
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.

# guarantee

Properties that request and report the space guarantee for the NVMe namespace.

Name	Туре	Description
requested	boolean	The requested space reservation policy for the NVMe namespace. If <i>true</i> , a space reservation is requested for the namespace; if <i>false</i> , the namespace is thin provisioned. Guaranteeing a space reservation request for a namespace requires that the volume in which the namespace resides also be space reserved and that the fractional reserve for the volume be 100%.  The space reservation policy for an NVMe namespace is determined by ONTAP.  • readOnly: 1  • Introduced in: 9.6
reserved	boolean	Reports if the NVMe namespace is space guaranteed.  This property is <i>true</i> if a space guarantee is requested and the containing volume and aggregate support the request. This property is <i>false</i> if a space guarantee is not requested or if a space guarantee is requested and either the containing volume and aggregate do not support the request.

# space

The storage space related properties of the NVMe namespace.

Name	Туре	Description
block_size	integer	The size of blocks in the namespace in bytes.  Valid in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone. Valid in POST.

Name	Туре	Description
guarantee	guarantee	Properties that request and report the space guarantee for the NVMe namespace.
size	integer	The total provisioned size of the NVMe namespace. Valid in POST and PATCH. The NVMe namespace size can be increased but not be made smaller using the REST interface.  The maximum and minimum sizes listed here are the absolute maximum and absolute minimum sizes in bytes. The maximum size is variable with respect to large NVMe namespace support in ONTAP. If large namespaces are supported, the maximum size is 128 TB (140737488355328 bytes) and if not supported, the maximum size is just under 16 TB (17557557870592 bytes). The minimum size supported is always 4096 bytes.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • example: 1073741824  • format: int64  • Max value: 140737488355328  • Min value: 4096  • Introduced in: 9.6

Name	Type	Description
used	integer	The amount of space consumed by the main data stream of the NVMe namespace.  This value is the total space consumed in the volume by the NVMe namespace, including filesystem overhead, but excluding prefix and suffix streams. Due to internal filesystem overhead and the many ways NVMe filesystems and applications utilize blocks within a namespace, this value does not necessarily reflect actual consumption/availability from the perspective of the filesystem or application. Without specific knowledge of how the namespace blocks are utilized outside of ONTAP, this property should not be used and an indicator for an out-of-space condition.  For more information, see Size properties in the docs section of the ONTAP REST API documentation.  • format: int64  • readOnly: 1  • Introduced in: 9.6

# iops\_raw

The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.

Name	Туре	Description
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## latency\_raw

The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## throughput\_raw

Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

### statistics

These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.

Name	Туре	Description
iops_raw	iops_raw	The number of I/O operations observed at the storage object. This should be used along with delta time to calculate the rate of I/O operations per unit of time.
latency_raw	latency_raw	The raw latency in microseconds observed at the storage object. This should be divided by the raw IOPS value to calculate the average latency per I/O operation.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data".  "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated.  "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput_raw	throughput_raw	Throughput bytes observed at the storage object. This should be used along with delta time to calculate the rate of throughput bytes per unit of time.
timestamp	string	The timestamp of the performance data.

status

Status information about the NVMe namespace.

Name	Туре	Description
container_state	string	The state of the volume and aggregate that contain the NVMe namespace. Namespaces are only available when their containers are available.
mapped	boolean	Reports if the NVMe namespace is mapped to an NVMe subsystem.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
read_only	boolean	Reports if the NVMe namespace allows only read access.
state	string	The state of the NVMe namespace. Normal states for a namespace are <i>online</i> and <i>offline</i> . Other states indicate errors.

## subsystem

The NVMe subsystem to which the NVMe namespace is mapped.

Name	Туре	Description
_links	_links	
name	string	The name of the NVMe subsystem.
uuid	string	The unique identifier of the NVMe subsystem.

## subsystem\_map

The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.

There is an added computational cost to retrieving property values for subsystem map. They are not

populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
_links	_links	
anagrpid	string	The Asymmetric Namespace Access Group ID (ANAGRPID) of the NVMe namespace.  The format for an ANAGRPID is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
nsid	string	The NVMe namespace identifier. This is an identifier used by an NVMe controller to provide access to the NVMe namespace.  The format for an NVMe namespace identifier is 8 hexadecimal digits (zero-filled) followed by a lower case "h".
subsystem	subsystem	The NVMe subsystem to which the NVMe namespace is mapped.

#### svm

Name	Туре	Description
_links	_links	
name	string	The name of the SVM.
uuid	string	The unique identifier of the SVM.

#### nvme namespace

An NVMe namespace is a collection of addressable logical blocks presented to hosts connected to the storage virtual machine using the NVMe over Fabrics protocol.

In ONTAP, an NVMe namespace is located within a volume. Optionally, it can be located within a qtree in a volume.

An NVMe namespace is created to a specified size using thin or thick provisioning as determined by the volume on which it is created. NVMe namespaces support being cloned. An NVMe namespace cannot be renamed, resized, or moved to a different volume. NVMe namespaces do not support the assignment of a QoS policy for performance management, but a QoS policy can be assigned to the volume containing the namespace. See the NVMe namespace object model to learn more about each of the properties supported by the NVMe namespace REST API.

An NVMe namespace must be mapped to an NVMe subsystem to grant access to the subsystem's hosts. Hosts can then access the NVMe namespace and perform I/O using the NVMe over Fabrics protocol.

Name	Туре	Description
_links	_links	
auto_delete	boolean	This property marks the NVMe namespace for auto deletion when the volume containing the namespace runs out of space. This is most commonly set on namespace clones.  When set to true, the NVMe namespace becomes eligible for automatic deletion when the volume runs out of space. Auto deletion only occurs when the volume containing the namespace is also configured for auto deletion and free space in the volume decreases below a particular threshold.  This property is optional in POST and PATCH. The default value for a new NVMe namespace is false.  There is an added computational cost to retrieving this property's value. It is not populated for either a collection GET or an instance GET unless it is explicitly requested using the fields query parameter. See Requesting specific fields to learn more.

Name	Туре	Description
clone	clone	This sub-object is used in POST to create a new NVMe namespace as a clone of an existing namespace, or PATCH to overwrite an existing namespace as a clone of another. Setting a property in this sub-object indicates that a namespace clone is desired.  When used in a PATCH, the patched NVMe namespace's data is over-written as a clone of the source and the following properties are preserved from the patched namespace unless otherwise specified as part of the PATCH: auto_delete (unless specified in the request), subsystem map,
		status.state, and uuid.
comment	string	A configurable comment available for use by the administrator. Valid in POST and PATCH.
convert	convert	This sub-object is used in POST to convert a valid in-place LUN to an NVMe namespace. Setting a property in this sub-object indicates that a conversion from the specified LUN to NVMe namespace is desired.
create_time	string	The time the NVMe namespace was created.
enabled	boolean	The enabled state of the NVMe namespace. Certain error conditions cause the namespace to become disabled. If the namespace is disabled, you can check the state property to determine what error disabled the namespace. An NVMe namespace is enabled automatically when it is created.

Name	Туре	Description
location	location	The location of the NVMe namespace within the ONTAP cluster. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.  • Introduced in: 9.6
		• readCreate: 1
metric	metric	Performance numbers, such as IOPS latency and throughput
name	string	The fully qualified path name of the NVMe namespace composed of a "/vol" prefix, the volume name, the (optional) qtree name and base name of the namespace. Valid in POST.  NVMe namespaces do not support rename, or movement between volumes.
os_type	string	The operating system type of the NVMe namespace.  Required in POST when creating an NVMe namespace that is not a clone of another. Disallowed in POST when creating a namespace clone.
space	space	The storage space related properties of the NVMe namespace.
statistics	statistics	These are raw performance numbers, such as IOPS latency and throughput. These numbers are aggregated across all nodes in the cluster and increase with the uptime of the cluster.
status	status	Status information about the NVMe namespace.

Name	Туре	Description
subsystem_map	subsystem_map	The NVMe subsystem with which the NVMe namespace is associated. A namespace can be mapped to zero (0) or one (1) subsystems.  There is an added computational cost to retrieving property values
		for subsystem_map. They are not populated for either a collection GET or an instance GET unless explicitly requested using the fields query parameter. See Requesting specific fields to learn more.
svm	svm	
uuid	string	The unique identifier of the NVMe namespace.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

#### error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

# Retrieve historical performance metrics for an NVMe namespace

GET /storage/namespaces/{uuid}/metrics

Introduced In: 9.8

Retrieves historical performance metrics for an NVMe namespace.

# **Parameters**

Name	Туре	In	Required	Description
throughput.read	integer	query	False	Filter by throughput.read
throughput.total	integer	query	False	Filter by throughput.total
throughput.write	integer	query	False	Filter by throughput.write
iops.total	integer	query	False	Filter by iops.total
iops.read	integer	query	False	Filter by iops.read
iops.write	integer	query	False	Filter by iops.write
iops.other	integer	query	False	Filter by iops.other
status	string	query	False	Filter by status
duration	string	query	False	Filter by duration
timestamp	string	query	False	Filter by timestamp
latency.total	integer	query	False	Filter by latency.total
latency.read	integer	query	False	Filter by latency.read
latency.write	integer	query	False	Filter by latency.write
latency.other	integer	query	False	Filter by latency.other
uuid	string	path	True	Unique identifier of the NVMe namespace.

Name	Туре	In	Required	Description
interval	string	query	False	The time range for the data. Examples can be 1h, 1d, 1m, 1w, 1y. The period for each time range is as follows:  • 1h: Metrics over
				the most recent hour sampled over 15 seconds.
				<ul> <li>1d: Metrics over the most recent day sampled over 5 minutes.</li> </ul>
				<ul> <li>1w: Metrics over the most recent week sampled over 30 minutes.</li> </ul>
				<ul> <li>1m: Metrics over the most recent month sampled over 2 hours.</li> </ul>
				<ul> <li>1y: Metrics over the most recent year sampled over a day.</li> </ul>
				Default value: 1
				• enum: ["1h", "1d", "1w", "1m", "1y"]

Name	Туре	In	Required	Description
return_timeout	integer	query	False	The number of seconds to allow the call to execute before returning. When iterating over a collection, the default is 15 seconds. ONTAP returns earlier if either max records or the end of the collection is reached.  • Default value: 1  • Max value: 120  • Min value: 0
fields	array[string]	query	False	Specify the fields to return.
max_records	integer	query	False	Limit the number of records returned.
order_by	array[string]	query	False	Order results by specified fields and optional [asc
desc] direction. Default direction is 'asc' for ascending.	return_records	boolean	query	False

# Response

Status: 200, Ok

Name	Туре	Description
_links	_links	
num_records	integer	Number of records
records	array[records]	

```
" links": {
    "next": {
     "href": "/api/resourcelink"
   },
   "self": {
    "href": "/api/resourcelink"
   }
 },
  "num records": 1,
  "records": {
    " links": {
     "self": {
       "href": "/api/resourcelink"
    },
    "duration": "PT15S",
    "iops": {
     "read": 200,
     "total": 1000,
     "write": 100
    },
    "latency": {
    "read": 200,
    "total": 1000,
     "write": 100
    } ,
    "status": "ok",
    "throughput": {
     "read": 200,
     "total": 1000,
    "write": 100
    "timestamp": "2017-01-25T11:20:13Z",
   "uuid": "1cd8a442-86d1-11e0-ae1c-123478563412"
 }
}
```

#### **Error**

```
Status: Default, Error
```

Name	Туре	Description
error	error	

# Example error

```
{
   "error": {
        "arguments": {
            "code": "string",
            "message": "string"
        },
        "code": "4",
        "message": "entry doesn't exist",
        "target": "uuid"
     }
}
```

## **Definitions**

## **See Definitions**

href

Name	Туре	Description
href	string	

\_links

Name	Туре	Description
next	href	
self	href	

\_links

Name	Туре	Description
self	href	

iops

The rate of I/O operations observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# latency

The round trip latency in microseconds observed at the storage object.

Name	Туре	Description
other	integer	Performance metric for other I/O operations. Other I/O operations can be metadata operations, such as directory lookups and so on.
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

# throughput

The rate of throughput bytes per second observed at the storage object.

Name	Туре	Description
read	integer	Performance metric for read I/O operations.
total	integer	Performance metric aggregated over all types of I/O operations.
write	integer	Peformance metric for write I/O operations.

## records

Performance numbers, such as IOPS latency and throughput, for SVM protocols.

Name	Туре	Description
_links	_links	
duration	string	The duration over which this sample is calculated. The time durations are represented in the ISO-8601 standard format. Samples can be calculated over the following durations:
iops	iops	The rate of I/O operations observed at the storage object.

Name	Туре	Description
latency	latency	The round trip latency in microseconds observed at the storage object.
status	string	Any errors associated with the sample. For example, if the aggregation of data over multiple nodes fails then any of the partial errors might be returned, "ok" on success, or "error" on any internal uncategorized failure. Whenever a sample collection is missed but done at a later time, it is back filled to the previous 15 second timestamp and tagged with "backfilled_data". "Inconsistent_delta_time" is encountered when the time between two collections is not the same for all nodes. Therefore, the aggregated value might be over or under inflated. "Negative_delta" is returned when an expected monotonically increasing value has decreased in value. "Inconsistent_old_data" is returned when one or more nodes do not have the latest data.
throughput	throughput	The rate of throughput bytes per second observed at the storage object.
timestamp	string	The timestamp of the performance data.
uuid	string	The unique identifier of the NVMe namespace.

# error\_arguments

Name	Туре	Description
code	string	Argument code
message	string	Message argument

error

Name	Туре	Description
arguments	array[error_arguments]	Message arguments
code	string	Error code
message	string	Error message
target	string	The target parameter that caused the error.

### Copyright information

Copyright © 2024 NetApp, Inc. All Rights Reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

LIMITED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (b)(3) of the Rights in Technical Data -Noncommercial Items at DFARS 252.227-7013 (FEB 2014) and FAR 52.227-19 (DEC 2007).

Data contained herein pertains to a commercial product and/or commercial service (as defined in FAR 2.101) and is proprietary to NetApp, Inc. All NetApp technical data and computer software provided under this Agreement is commercial in nature and developed solely at private expense. The U.S. Government has a non-exclusive, non-transferrable, nonsublicensable, worldwide, limited irrevocable license to use the Data only in connection with and in support of the U.S. Government contract under which the Data was delivered. Except as provided herein, the Data may not be used, disclosed, reproduced, modified, performed, or displayed without the prior written approval of NetApp, Inc. United States Government license rights for the Department of Defense are limited to those rights identified in DFARS clause 252.227-7015(b) (FEB 2014).

#### **Trademark information**

NETAPP, the NETAPP logo, and the marks listed at <a href="http://www.netapp.com/TM">http://www.netapp.com/TM</a> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.