Dynamic Clustering in WSN

Software: NetSim Standard v14.2 (64 bit), Visual Studio 2022, MATLAB R2019 or higher

Project Download Link:

https://github.com/NetSim-TETCOS/Dynamic_Clustering_in_WSN-v14.2/archive/refs/heads/main.zip

Follow the instructions specified in the following link to download and set up the Project in NetSim:

https://support.tetcos.com/en/support/solutions/articles/14000128666-downloading-and-setting-up-netsim-file-exchange-projects

Clustering in WSN

Clustering in Wireless Sensor Networks (WSN) involves the division of a sensor group into smaller clusters. In environments with mobile sensors, static clusters are impractical. Cluster heads within each cluster are dynamically elected, and members in each cluster are identified dynamically. Consequently, the size of each cluster is not fixed and can vary based on sensor positions.

Dynamic Clustering efficiently groups sensors into clusters in real-time. There is no fixed cluster size, and sensors are divided into the required number of clusters with member assignments calculated dynamically.

Clustering using the k-means algorithm:

Kmeans(X,k) partitions the points in the n-by-p data matrix X into k clusters. This iterative partitioning minimizes the sum, over all clusters, of the within-cluster sums of point-to-cluster-centroid distances. Rows of X correspond to points, columns correspond to variables. kmeans returns an n-by-1 vector IDX containing the cluster indices of each point. By default, kmeans uses squared Euclidean distances. When X is a vector, kmeans treats it as an n-by-1 data matrix, regardless of its orientation. The sensor positions and number of clusters,

The sensor positions and number of clusters,

X - a matrix containing the x and y coordinates of the sensors in the scenario.

k- the number of clusters. are passed to the k-means algorithm. [IDX,C] = k-kmeans(X,k).

IDX – Contains the cluster IDs of each sensor (i.e.) the cluster to which the sensor belongs.

C - Centroids of each cluster.

Clustering using the Fuzzy C-Means Algorithm:

Fuzzy c-means (FCM) is a data clustering technique in which a dataset is grouped into n clusters with every data point in the dataset belonging to every cluster to a certain degree. For example, a certain data point that lies close to the centre of a cluster will have a high degree of belonging or membership to that cluster and another data point that lies far away from the centre of a cluster will have a low degree of belonging or membership to that cluster.

Cluster head election based on distance from Centroid:

After grouping the sensors into different clusters, the cluster heads are determined based on the distance between the sensor and the centroid of the cluster to which it belongs.

The sensor which is closer to the centroid will be elected as the cluster head. Here the position values (i.e., the value of the x-coordinate and y-coordinate) of each sensor are passed from NetSim to MATLAB as a sole parameter.

Cluster head election based on distance and power:

After grouping the sensors into different clusters, the cluster heads are determined based on the distance between the sensor and the remaining power of each sensor. After that, the sensors are assigned to the respective cluster.

The sensor which is closer to the centroid and has more power than other sensors will be elected as the cluster head. Here the position values (i.e., the value of the x-coordinate and y-coordinate) of each sensor and power are passed from NetSim to MATLAB as a sole parameter.

Dynamic Clustering in NetSim with MATLAB Interfacing:

Dynamic Clustering is implemented in NetSim by Interfacing with MATLAB for the purpose of mathematical calculation. The sensor coordinates are fed as input to MATLAB and the k-means algorithm that is implemented in MATLAB is used to dynamically perform clustering of the sensors into n number of clusters.

In addition to clustering, we also determine the cluster head of each cluster mathematically in MATLAB. The distance of each sensor from the centroid of the cluster to which it belongs is calculated. Then the sensor which has the least distance is elected as the cluster head.

From MATLAB we get the cluster id of each sensor, the cluster heads of each cluster, and the size of each cluster.

All the above steps are performed periodically which can be defined as per the implementation. Each time the cluster members and the cluster heads are determined based on the current position and they are not fixed.

The codes required for the mathematical calculations done in MATLAB are written to a clustering.m file and this file is available in the MATLAB folder under bin_x64 of Dynamic_Clustering_Workspace

Implementation

The **clustering.m** file can be run in four different modes of cluster head election.

A **Dynamic_Clustering.c** file is added to the DSR project which contains the following functions:

• fn_NetSim_dynamic_clustering_CheckDestination()//This function is used to determine

whether the current device is the destination.

- fn_NetSim_dynamic_clustering_GetNextHop()//This function statically defines the routes
 within the cluster and from the cluster to the sink node. It returns the next hop based on the
 static routing that is defined.
- fn_NetSim_dynamic_clustering_IdentifyCluster()//This function returns the cluster id of the cluster to which a sensor belongs.
- fn_NetSim_dynamic_clustering_run()//This function makes a call to MATLAB interfacing function and passes the inputs from NetSim (i.e) the sensor coordinates, number of clusters, and the sensor count.
- fn_netsim_dynamic_form_clusters()//This function assigns each sensor to its respective clusters based on the cluster IDs obtained from MATLAB.
- fn_netsim_assign_cluster_heads()//This function assigns the cluster heads for each cluster based on the cluster head IDs obtained from MATLAB.
- fn NetSim Dynamic Clustering Init()//This function initializes all parameter values.

Static Routing

Static Routing is defined in such a way that the sensors in the cluster send the packets to the cluster head. The cluster head then directly sends the packets to the destination (sink node).

If the current sensor is the source device and if it is not a cluster head, then its next hop is its cluster head.

If the current sensor is the source device and if it is a cluster head, then its next hop is the destination (i.e.) the sink node.

If the current sensor is not the source, then the packet is sent to the destination (i.e.) the sink node.

NOTE: To run this code 64- bit version of MATLAB must be installed in your system.

Configuring Environment for MATLAB Execution

- 1.In Control panel open>System>Advanced system settings>Edit the system environment variable>environment variables
- 2. Add the following MATLAB install directory path in the Environment PATH variable <MATLAB_INSTALL_DIRECTORY>\bin\win64

For eg: C:\Program Files\MATLAB\R2023a\bin\win64




Figure 1: Environment variable PATH

Note: If the machine has more than one MATLAB installed, the directory for the target platform must be ahead of any other MATLAB directory (for instance, when compiling a 64-bit application, the directory in the MATLAB 64-bit installation must be the first one on the PATH).

Example

- 1. Run NetSim in administrative mode.
- 2. Dynamic_Clustering_Workspace comes with a sample network configuration that is already saved. To open this example, go to Your work on the home screen of NetSim and click on the Dynamic_Clustering_Example from the list of experiments.
- 3. The saved network scenario consists of 64 sensors uniformly distributed in the grid environment along with a sink node forming a Wireless Sensor Network. Traffic is configured from each sensor node to the Sink Node.




Figure 2: Network Scenario in this project

- **4.** Run the simulation and press any key to continue. NetSim simulation console will show the following message in the console "Waiting for NetSim MATLAB Interface to connect...". NetSim will automatically open the MatlabInterface.exe console window.
- 5. It will open the MatlabInterface.exe console window. You will observe that as the simulation starts in NetSim, MATLAB gets initialized and the graph associated with energy consumption in the sensor network is plotted during runtime.

Results and discussion

A total of 64 sensors are placed evenly on the grid environment and each sensor is set to have equal initial energy.

At the end of the simulation, NetSim provides Battery Model Metrics which can be accessed by navigating to the additional metrics section, Here you can see the detailed information related to energy consumption in each sensor node with respect to transmission, reception, idle mode, sleep mode, etc. as shown below:

Device Name	Initial energy(mJ)	Consumed energy(mJ	Remaining Energy(mJ)	Harvested Energy(mJ)	Transmitting energy(m	Receiving energy(mJ)	ldle energy(mJ)	Sleep energy(mJ
VIRELESS_SENSOR_1	6480.000000	566.527976	5913.472024	0.000000	28.227292	0.252150	538.048534	0.000000
VIRELESS_SENSOR_2	6480.000000	567.400668	5912.599332	0.000000	29.190681	0.192430	538.017557	0.000000
VIRELESS_SENSOR_3	6480.000000	567.558004	5912.441996	0.000000	29.287020	0.258785	538.012200	0.000000
VIRELESS_SENSOR_4	6480.000000	562.574685	5917.425315	0.000000	24.181059	0.205701	538.187925	0.000000
VIRELESS_SENSOR_5	6480.000000	565.510803	5914.489197	0.000000	27.167564	0.258785	538.084454	0.000000
VIRELESS_SENSOR_6	6480.000000	561.711481	5918.288519	0.000000	23.314009	0.179159	538.218313	0.000000
VIRELESS_SENSOR_7	6480.000000	564.487203	5915.512797	0.000000	26.107836	0.258785	538.120 <u>5</u> 81+ivate W	0.000000 _S

Figure 3: NetSim provides Battery Model Metrics

This information can also be obtained at different points of simulation time either to log or to send to other external tools. The battery information and the position coordinates are passed to MATLAB

periodically for clustering (the number of clusters is set to 4), cluster head election and to obtain energy consumption plots.


The clustering method can be customized as needed by modifying the "clustering.m" file located in the MATLAB folder within the bin_x64 directory of the workspace.

```
Function [A,B,C] = clustering(x,scount,num cls,power,max energy)
                changed clustering function. New paramter power: column remaining power for each device
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
40
41
42
43
44
                s_count is sensor_count
                Clustering Method = 1
                                                            KMeans using distance
                                                             Fuzzy C Means using distance
                                                            KMeans using distance and power
                                                             Fuzzy C Means using distance and po
                                                                 The clustering method lets you easily switch
             Clustering Method = 1;
                                                                 between four different approache
methods 1, 2, 3, and 4.
               save dynamic clustering.mat
               change here for different algorithm
             if(Clustering Method == 1 || Clustering Method == 3)
   [IDX,C]= k_means(x,num_cls);
                    [IDX,C]= fuzzy(x,num_cls);
             cl count=zeros(1, num cls);
              cl_dist=zeros(1,scount);
             if(Clustering_Method > 2)
    cl_max_dist = zeros(1,num_cls);
    cl_max_power = zeros(1,num_cls);
                                                                         % only when method involves power
                                                                           max distance in each cluster
max device power left in each cluster
```

Figure 4: Clustering.m matlab file

Cluster head election using distance alone as a parameter:

Running simulations with Clustering Method set to 1 and 2 in the clustering.m file will provide energy consumption plots for k-means and fuzzy c-means algorithms respectively as shown below:







Figure 5: Energy consumption plots for k means and fuzzy c-means algorithms using methods 1 and 2

As it is seen from the plot, there are 4 peaks in the plot corresponding to higher energy consumption

in the nodes in the center of the cluster, as they always become the cluster heads. This is because the distance is used as a parameter for electing the cluster heads.

Cluster head election using distance and remaining energy as parameters:

Running simulations with the Clustering Method set to 3 and 4 in the **clustering.m** file will provide energy consumption plots for k-means and fuzzy c-means algorithms respectively as shown below:






Figure 6: Energy consumption plots for k means and fuzzy c-means algorithms using method 3 and 4

In the initial phase the plot resembles the previous one. However, as time passes, it can be observed that the power is consumed by all the sensors at approximately the same rate.

There are no sharp peaks in this plot unlike the previous one because modified K-means consider the power level of each sensor and thus sensors other than those in the center of the cluster will also get a chance to be elected as the cluster head in their respective cluster.