MIPS ISA Reference Sheet Nick DelBen

Instruction Types

R-Type (Register) Instruction					
Bit ₃₁₋₂₆	Bit ₂₅₋₂₁	Bit ₂₀₋₁₆	Bit ₁₅₋₁₁	Bit ₁₀₋₆	Bit ₅₋₀
opcode	register s	register t	register d	shift amount	function

I-Type (Immediate) Instruction				
Bit ₃₁₋₂₆	Bit ₂₅₋₂₁	Bit ₂₀₋₁₆	Bit ₁₅₋₀	
opcode	register s	register t	immediate	

J-Type (Jump) Instruction		
Bit ₃₁₋₂₆	Bit ₂₅₋₀	
opcode	target	

Registers

Register Number	Register Alias	Register Information	
0	\$0	Constant. Always holds the value 0.	
1	\$at	(assembler temporary) Reserved by the assembler.	
2 - 3	\$v0 - \$v1	(values) Results from expression evaluation and function returns.	
4 - 7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls.	
8 - 15	\$t0 - \$t7	(temporaries) Temporary registers for computation.	
16 - 23	\$s0 - \$s7	(saved values) Registers preserved across procedure calls. Must save and restore in subroutine.	
24 - 25	\$t8 - \$t9	(temporaries) Temporary registers for computation.	
26 - 27	\$k0 - \$k1	Reserved for use by interrupt / trap handler.	
28	\$gp	(global pointer) Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	(stack pointer) Points to last location on the stack.	
30	\$fp	(frame pointer) Must save and restore in subroutine.	
31	\$ra	(return address). Address to return to after subroutine.	

Instructions

Load Instructions (I-Type)

```
lw
   $t0 label
                 # $t0 = *label
                                               Loads word at label into a register
1 \text{w} $t0 off($t1) # $t0 = MEM[$t1 + off] Loads word from offset memory address in register to a register
1b
   $t0 label
                 # $t0 = *label
                                               Loads byte at label into a register
                                               Loads byte from offset memory address in register (sign padded)
1b
   $t0 off($t1) # $t0 = MEM[$t1 + off]
                                               Loads byte from offset memory address in register (0 padded)
lbu $t0 \text{ off}($t1) # $t0 = MEM[$t1 + off]
li
   $t0 imm
                   # $t0 = imm
                                               Loads constant value into a register
                  # $t0 = &label
                                               Loads the pointer to a label into a register
     $t0 label
```

```
Store Instructions (I-Type)
     $t0 label
                      # MEM[&label] = $t0
                                                  Stores a word into a labelled memory location
SW
     $t0 off($t1)
                     \# MEM[\$t1 + off] = \$t0
                                                 Stores a word into offset memory address from register
SW
sb
     $t0 label
                      # MEM[\&label] = $t0
                                                 Stores a byte into a labelled memory location
                     \# MEM[\$t1 + off] = \$t0
                                                 Stores a byte into offset memory address from register
     $t0 off($t1)
sb
Basic Arithmetic (R-Type)
add $t0 $t1 $t2
                     # $t0 = $t1 + $t2
                                                 Adds two signed (2's compliment) registers
addu $t0 $t1 $t2
                      # $t0 = $t1 + $t2
                                                 Adds two unsigned registers
addi $t0 $t1 imm
                      # $t0 = $t1 + imm
                                                 Adds a register and a constant (I-Type Instruction)
                     # $t0 = $t1 - $t2
sub $t0 $t1 $t2
                                                  Subtracts two signed (2's compliment) registers
subu $t0 $t1 $t2
                     # $t0 = $t1 - $t2
                                                 Subtracts two unsigned registers
                      # (Hi, Lo) = $t0 * $t1
                                                 Multiplies two registers. Stores first 32 bits in Hi and last in Lo
mult $t0 $t1
                      # Hi = |_$t0 / $t1_|
div $t0 $t1
                                                 Divides two registers. Stores the integer result in Hi
                      \# Lo = $t0 % $t2
                                                    Stores the remainder in Lo
mfhi $t0
                      # $t0 = Hi
                                                  Stores the Hi value in a register
mflo $t0
                      # $t0 = Lo
                                                  Stores the Lo value in a register
Bitwise Operations (R-Type)
and $t0 $t1 $t2
                      # $t0 = $t1 \land $t2
                                                 Performs bitwise and on two registers
                      # $t0 = $t1 \lor $t2
or
     $t0 $t1 $t2
                                                 Performs bitwise or on two registers
nor $t0 $t1 $t2
                      # $t0 = $t1 = $t2
                                                Performs bitwise nor on two registers
xor $t0 $t1 $t2
                      # $t0 = $t1 \( \Pi \) $t2
                                                Performs bitwise xor on two registers
Bitwise Operations (I-Type)
ori $t0 $t2 imm
                      # $t0 = $t1 \ imm
                                                 Performs bitwise and on a register and a constant
andi $t0 $t1 imm
                      # $t0 = $t1 \land imm
                                                 Performs bitwise and on a register and a constant
                     # $t0 = $t1 \( \text{\text{m}} \) imm
xori $t0 $t1 imm
                                                Performs bitwise xor on a register and a constant
BitShift Operations (R-Type)
                      # $t0 = $t1 << imm
                                                Shifts a register left by a constant amount (0 padded)
sll $t0 $t1 imm
sllv $t0 $t1 $t2
                     # $t0 = $t1 << $t2
                                                Shifts a register left by the amount in a register (0 padded)
srl $t0 $t1 imm
                     # $t0 = $t1 >> imm
                                                Shifts a register right by a constant amount (0 padded)
                     # $t0 = $t1 >> $t2
srlv $t0 $t1 $t2
                                                Shifts a register right by the amount in a register (0 padded)
sra $t0 $t1 imm
                      # $t0 = $t1 / (2^imm)
                                                Shifts a register right by an immediate value (sign padded)
srav $t0 $t1 $t2
                      # $t0 = $t1 / (2^{t2})
                                                Shifts a register right bt the amount in a register (sign padded)
Branch Operations (I-Type)
beq $t0 $t1 label # $t0 == $t1 ? goto label Branch to label if two registers are equal
bne $t0 $t1 label # $t0 != $t1 ? goto label Branch to label if two registers are not equal
bgt $t0 $t1 label # $t0 > $t1 ? goto label
                                                    Branch to label if one register is greater than another
bgtz $t0 label
                      # $t0 > 0 ? goto label
                                                    Branch to label if register is greater than zero
bge $t0 $t1 label # $t0 >= $t1 ? goto label Branch to label if one register is greater than or equal to another
bgez $t0 label
                     # $t0 >= 0 ? goto label
                                                    Branch to label if register is greater than or equal to zero
                                                    Branch to label if one register is less than another
blt $t0 $t1 label # $t0 < $t1 ? goto label
bltz $t0 label
                     # $t0 < 0 ? goto label
                                                    Branch to label if register is less than zero
ble $t0 $t1 label # $t0 <= $t1 ? goto label Branch to label if one register is less than or equal to another
blez $t0 label
                     # $t0 <= 0 ? goto label
                                                    Branch to label if register is less than or equal to zero
Jump Operations (J-Type)
     label
                      # goto label
                                                    Jumps to a label
i
jal label
                      # $ra = PC; goto label
                                                    Jumps to a label, storing location in return register
Jump Operations (I-Type)
                                                    Jumps to location stored in register
jr
     $t0
                     # goto $t0
```

Jumps to location stored in register, storing location in return register

jalr *\$t0*

\$ra = PC; goto \$t0