Category	ASM	OpCode	Layout			Description	Example		
			OpCode	posA	posB	posC			
None	NOP	0x00	NOP	pad	pad	pad	Does nothing; used for attaching a debugger, patching code, timing, byte alignment	NOP	0x00 00 00 00
Math (ALU)	ADD	0x10	ADD	R _{dest}	R _{src1}	R _{src2}	Adds contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register	ADD R1 R2 R3	0x10 01 02 03
Math (ALU)	SUB	0x11	SUB	R _{dest}	R _{src1}	Rsrc2	Subtracts contents of R_{src2} from contents of R_{src1} registers, and places result in R_{dest} register	SUB R1 R2 R3	0x11 01 02 03
Math (ALU)	MUL	0x12	MUL	R _{dest}	R _{src1}	Rsrc2	Multiplies contents of R_{src2} by contents of R_{src2} registers, and places result in R_{dest} register	MUL R1 R2 R3	0x12 01 02 03
Math (ALU)	DIV	0x13	DIV	R _{dest}	R _{src1}	R _{src2}	Divides contents of R_{src1} by contents of R_{src2} registers, and places result in R_{dest} register	DIV R1 R2 R3	0x13 01 02 03
Math (ALU)	MOD	0x14	MOD	R _{dest}	R _{src1}	R _{src2}	Returns the remainder of a division of contents of R_{src1} by contents of R_{src2} registers, and places result in R_{dest} register	MOD R1 R2 R3	0x14 01 02 03
Logic (ALU)	NOT	0x20	NOT	R _{dest}	R _{src}	pad	Performs bitwise negation of contents of R_{src} register, and places result in R_{dest} register	NOT R5 R6	0x20 05 06 00
Logic (ALU)	AND	0x21	AND	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise AND on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register	AND R2 R3 R5	0x21 02 03 05
Logic (ALU)	OR	0x22	OR	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise OR on contents of R_{Src1} and R_{Src2} registers, and places result in R_{dest} register	OR R2 R3 R5	0x22 02 03 05
Logic (ALU)	XOR	0x23	XOR	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise XOR on contents of R_{Src1} and R_{Src2} registers, and places result in R_{dest} register	XOR R2 R3 R5	0x23 02 03 05
Logic (ALU)	EQ	0x24	EQ	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the two values are equal; 0 if they are not	EQ R2 R3 R5	0x24 02 03 05
Logic (ALU)	NEQ	0x25	NEQ	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the two values are not equal; 0 if they are	NEQ R2 R3 R5	0x25 02 03 05
Logic (ALU)	GTE	0x26	GTE	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the value in $R_{src1} \ge$ value in R_{src2} ; 0 otherwise	GTE R2 R3 R5	0x26 02 03 05
Logic (ALU)	LTE	0x27	LTE	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the value in $R_{src1} \le$ value in R_{src2} ; 0 otherwise	LTE R2 R3 R5	0x27 02 03 05
Logic (ALU)	GT	0x28	GT	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the value in R_{src1} > value in R_{src2} , 0 otherwise	GT R2 R3 R5	0x28 02 03 05
Logic (ALU)	LT	0x29	LT	R _{dest}	R _{src1}	R _{src2}	Performs a bitwise comparison on contents of R_{src1} and R_{src2} registers, and places result in R_{dest} register; 1 if the value in R_{src1} < value in R_{src2} ; 0 otherwise	LT R2 R3 R5	0x29 02 03 05

Category	ASM	OpCode	Layout				Description	Example	
			OpCode	posA	posB	posC			
Flow Control	JMP	0x30	JMP	Addr _{hb}	Addr _{lb}	pad	Jumps to a memory location denoted by Addr _{hb} and Addr _{lb} bytes (big-endian). Supports labelName syntax instead of directly entering address.	JMP 0xBEEF JMP labelName	0x30 BE EF 00 0x30 ?? ?? 00
Flow Control	JMPi	0x31	JMPi	R _{loc}	pad	pad	Jumps to a memory location stored in R_{loc} register. Stored location is 2-bytes (big-endian)	JMPi R1	0x31 01 00 00
Flow Control	JMPT	0x32	JMPT	Addr _{hb}	Addr _{lb}	R _{condition}	Jumps to a memory location denoted by $Addr_{hb}$ and $Addr_{lb}$ bytes (big-endian) if the value in $R_{condition}$ register is not zero. Supports $labelName$ syntax instead of directly entering address.	JMPT 0xBEEF R0 JMPT labelName R0	0x32 BE EF 00 0x32 ?? ?? 00
Flow Control	JMPTi	0x33	JMPTi	R _{loc}	R _{condition}	pad	Jumps to a memory location stored in R_{loc} register if the value in $R_{condition}$ register is not zero. Stored location is 2-bytes (big-endian)	JMPTi R1 R0	0x33 01 00 00
Memory	SET	0x40	SET	R _{loc}	Val _{hb}	Val _{lb}	Sets a literal value specified by Val_{hb} and Val_{lb} (big endian) into R_{loc} register.	SET R1 0xBEEF	0x40 01 BE EF
Memory	СОРУ	0x41	СОРҮ	R _{dest}	R _{src}	pad	Copies contents of R_{src} register into R_{dest} register	COPY R5 R6	0x41 05 06 00
Memory	LOAD	0x42	LOAD	R _{dest}	Addr _{hb}	Addr _{lb}	Loads the value from a memory location denoted by $Addr_{hb}$ and $Addr_{lb}$ bytes (bigendian) into R_{dest} register	LOAD R4 0xBEEF	0x42 04 BE EF
Memory	LOADi	0x43	LOADi	R _{dest}	R _{src}	pad	Loads the value from a memory at the address stored in R_{src} into R_{dest} register	LOADi R4 R5	0x43 04 05 00
Memory	STR	0x44	STR	Addr _{hb}	Addr _{lb}	R _{src}	Stores the value from R_{src} register into memory location denoted by $Addr_{hb}$ and $Addr_{lb}$ bytes (big-endian)	STR 0xBEEF R1	0x44 BE EF 01
Memory	STRi	0x45	STRi	R _{dest}	R _{src}	pad	Stores the value from R_{src} register into memory location at the address of the value of R_{dest} .	STRi R4 R1	0x45 04 01 00
Memory	PUSH	0x46	PUSH	R _{src}	pad	pad	Pushes contents of the <i>R_{src}</i> register onto the stack	PUSH R5	0x46 05 00 00
Memory	POP	0x47	POP	R _{dest}	pad	pad	Pops the value on top of the stack into R_{dest} register	POP R6	0x47 06 00 00

Deviation from week 1 ISA:

- 8 addressable registers for simplicity, numbered 0 7 (this is easily extensible, but tedious)
- Dedicated Instruction Pointer (IP) Register, because it's interesting (not addressable in ASM, but technically settable via JMP instructions)
- Addressable Stack Pointer (SP) Register, as register 7, to show an alternative technique to a dedicated register
- Von Neumann (aka Princeton) architecture instead of Harvard, because separate ROM is nice; the architecture becomes simpler to implement in LogiSim
- RAM is now 64K of ushorts (16-bit values), for a total of 128KB, to ease the machine implementation in LogiSim)
- ROM is now 64K of uints (32-bit values), for a total of 256KB, to ease the machine implementation in LogiSim)
- More ALU instructions (such as EQ/NEQ, GTE/LTE, GT/LT, etc.) to reduce JMP instructions, as it's simpler to implement ALU instructions than branching instructions
- Drop shifting instructions (SHL/SHR) for simplicity (we have MUL and DIV); this can be implemented as an optional exercise
- Some instructions are re-numbered (Memory section pushed down by one, due to COPY; also, PUSH/POP are moved down, to order the instructions in order they should be implemented)
- Some instruction names might've changed (mnemonics)