

# Disabling/enabling the specified interrupt pointer

## SIMASK

FX5S FX5UJ FX5U FX5UC

This instruction enables or disables the interrupt pointer number specified by (I) according to the value of (s).

Ladder diagram	Structured text
	ENO:=SIMASK(EN,In,s);
FBD/LD	

### Setting data

#### ■ Descriptions, ranges, and data types

Operand	Description	Range	Data type	Data type (label)
(I) <sup>*1</sup>	Interrupt pointer number for which interrupts are enabled or disabled	■FX5S CPU module I0 to I31 ■FX5UJ/FX5U/FX5UC CPU module I0 to I177	Device name	POINTER
(s)	Enabled or disabled state of the specified interrupt pointer number	0: Disabled 1: Enabled	16-bit signed binary	ANY16
EN	Execution condition	—	Bit	BOOL
ENO	Execution result	—	Bit	BOOL

\*1 In the case of the ST language and the FBD/LD language, I displays as In.

8

#### ■ Applicable devices

Operand	Bit	Word			Double word		Indirect specification	Constant			Others
		X, Y, M, L, SM, F, B, SB, S	T, ST, C, D, W, SD, SW, R	U□\G□	Z	LC		K, H	E	\$	
(I)	—	—	—	—	—	—	—	—	—	—	○
(s)	○	○	○	○	—	—	○	○	—	—	—

### Processing details

- This instruction enables or disables the execution of the interrupt program with the interrupt pointer number specified by (I) according to the data specified by (s)
- When 1 is set in (s): The execution of the interrupt program is enabled.
- When 0 is set in (s): The execution of the interrupt program is disabled.
- When the power is turned on or the CPU module is reset, execution of the interrupt programs is enabled.

■FX5S CPU module

Interrupt program: I0 to I31

■FX5UJ/FX5U/FX5UC CPU module

Interrupt program: I0 to I177

- The execution-enabled/disabled states of interrupt pointers are stored in the IMASK instruction mask pattern.

■FX5S CPU module

IMASK instruction mask pattern: SD1400 to SD1401

■FX5UJ/FX5U/FX5UC CPU module

IMASK instruction mask pattern: SD1400 to SD1411

## Operation error

Error code (SD0/SD8067)	Description
3405H	<p>The interrupt pointer number specified by (l) exceeds the range of the interrupt pointer number (I0 to I177).</p> <p>The value in (s) is other than the interrupt disabled (0) or interrupt enabled (1).</p>