The next code examples show assembly and C functions for reading the EEPROM. The examples assume that interrupts are controlled so that no interrupts will occur during execution of these functions.

```
Assembly Code Example
   EEPROM_read:
     ; Wait for completion of previous write
     sbic EECR, EEPE
     rjmp EEPROM_read
     ; Set up address (r18:r17) in address register
     out EEARH, r18
     out EEARL, r17
     ; Start eeprom read by writing EERE
     sbi EECR, EERE
     ; Read data from Data Register
     in r16, EEDR
     ret
C Code Example
   unsigned char EEPROM_read(unsigned int uiAddress)
     /* Wait for completion of previous write */
     while (EECR & (1<<EEPE))
     /* Set up address register */
     EEAR = uiAddress;
     /* Start eeprom read by writing EERE */
     EECR = (1 << EERE);
     /* Return data from Data Register */
     return EEDR;
```

## 5.6.4 GPIOR2 – General Purpose I/O Register 2

Bit	7	6	5	4	3	2	1	0	
0x2B (0x4B)	MSB							LSB	GPIOR2
Read/Write	R/W								
Initial Value	0	0	0	0	0	0	0	0	

## 5.6.5 GPIOR1 – General Purpose I/O Register 1

Bit	7	6	5	4	3	2	1	0	_
0x2A (0x4A)	MSB							LSB	GPIOR1
Read/Write	R/W	_							
Initial Value	0	0	0	0	0	0	0	0	

## 5.6.6 GPIOR0 – General Purpose I/O Register 0

Bit	7	6	5	4	3	2	1	0	
0x1E (0x3E)	MSB							LSB	GPIOR0
Read/Write	R/W								
Initial Value	0	0	0	0	0	0	0	0	

