

Note Junction Best Note Provider



Note By: Roshan BiSt

Unit-1

Introduction

Page No.____

(Lesser imp chapter)

Introduction to microprocessor

A microprocessor is an integraled circuit that contains all the functions of a central processing unit of a computer. It is a semiconductor chip like solicon with combination of transistors.

It is an electronic component that performs the instructions and tasks involved in computer processing which is central unit and manages the logical instructions passed to it.

In short of processes on arithmetic and logical operations to provide desired subjust.

Evolution / History of microprocessor ut Marcian E. Hubb is the father of microprocessor. The first commercial microprocessor 1971, which was INTEL 4004 having 2300 transistors. It was 4-bit microprocessor. It was basically designed for calculators at that time. he next microprocessor was INTEL 8008 having 3500 transistors after this, INTEL 8080 having 4000 transistors and ZILOGI Z80 thaving 6000 transistors came for commercial purpose tillhe evolution of transistors continued and first 8-bit microprocessor was developed which is INTEL 8085. The next to this microprocessor was INTEL 8086 having 16-bet. This evolution of microprocessor continued upto INTEL Pentium III having 95 lakh ransistors and the next modern microprocessors came into existance like is, is and ist.

C. W.	
×	Components of microprocessor
	The hasic parts of microprocessor
	are CPU, Bus and Memory which are
-	described below-
· Ci	Sur Maria Sur
0	CPU-> CPU is fabricated as a very large scale. integrated circuit (VISI) whose parts are as
	integrated circuit (VISI) whose parts are as
	follows:
	P. Instruction register (IR): It holds the
	instructions to be executed
	Marie M. C. Sidor of Al Service De La Servic
	Decorder: It decodes converts to machine level
-	language) the instruction and sends to the
	O. O.ALD.
	ered ALU: It performs arithmetic , logical, memory,
3 30	register and program sequencing operators.
105	
	Register: It holds intermediate results obtained during program processing.
THA.	obtained during program processing.
(6)	Bus - The fine thin lines connecting the different
- 10	internal parts of the microprocessor chip is called bus.
* 197	There are three types of buses in a microprocessor.
	Ph. Data, bug - H
	Data bus . It carry data to and from memory.
A STATE OF	It is bidrectional bus with width eque to
144	er Address bus -> It is unidirectional bus. It carries address of a memory location or
The state of the s	I/O port from CPU to memory or I/O port.
H 428 - 11	

Date
Page No

Gentral bus -> It carry control signals
like clock signals, interrupt signal or reson
signal. It is also bidirectional.

(a) Memory -> Microprocessor has two types of memory

PRAM -> It is Random Access Memony. It is a.

will volatile memory. It is the working
or runtime memory of the computer.

ir ROM > It is Read Only Memony. It is a non-volatile memory. ROM comes programmed with most ressential data like booting sequence by the manufacturer.

€		Differences between Ho	Ui.V	ira architecture and
		Von Neumann archi	tec	fure with block diagrams
		the state of the s	1	· · · · · · · · · · · · · · · · · · ·
	31	Harvard architecture	SN	Von Neumann architecture
	1	Block diagram for	1.	Block diagram for Von
A un		Harvard architecture 18	(SE)	Neumann architecture is
	1	as follows:		as follows:-
		1 14 16	<u>a</u>	
		ALU		
		1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2		Control Unit
		Instruction Control Data		ALU
		memory Unit Memory	1	Input > CPU > Output
			-	
			1 1	
		1/0		Memory Unit
	2	It required tun memories	2	It required only one memory
		for their instruction and data	he	for their instruction and data
		The state of the s		July There instruction and data
	3	Design of Harvard	7	Danie P
		archetecture is complicated	<u> </u>	Design of von Neumann architecture 18 simple.
		and the contract of		architecture 48 simple.
	4	It required sonovale hus	A	H. marial
1		for incharaction and late	4.	It required only one bus for instruction and data
		joi 411stration and data.	-	for instruction and data.
-		0		
_	ے,	Processor can complete	্য,	Processor needs two clock
	i.	an instruction eycle in		cycles to complete an
		one cycle.		Instruction.
			1	
	6.	Eaiser to pipeline so	6.	how performance ne
		high pertormance can		compared to Harvara
		be achieved	The	architecture.

	Page No
	Microprocessor systems with bus organization.
7	Bus 18 a group of conducting wines which
	carries information, all the peripherals are connected
	to microprocessor through Bus.
	Let we take diagram of 8085 microprocessor
MACHINE TO SERVICE TO	to represent bus organization system as follows:
	\$19 2 har 5
	the application of the second second second second
	AAE Division All Andrews Andre
NATE:	ADDRESS BUS
	8085
17.1	2 07
	DATA BUS
H.H.	8500 77
	35
	CONTROL BUS
A STATE OF THE STA	Memory Input Output
	Trewong 1 + 14 contract
The Maria	fig. diagram for bus organization system of 8085 microprocessor
33644+	July Congress of Constant of C
	There are three types of buses
_ 1.	Address bus = It is a group of conducting wires which
Mr. vie	carries address only. Address bus 18 Junidirectional
10/10/11	because data flow an one direction from microprocessor
	to memory or from microprocessor to input/output
	devices. Length of Address bus of 8085 microprocessor
	is 16 bet. Length of Address bus vary with
The state of the s	I have a langth of the agaress bus
	determines the amount of memory a system can
	B. dovess.
1	

Scanned with CamScanner

Control bus -> It is a group of conducting wires, which is used to generate timing and control signals to control all the associated peripherals. Microprocess uses control bus to process data, that is what to do with selected memory location. Some control signals are: Memory read 12 Memory write read If one line of control bus may be read/write line. If a whe 18 low (no electricity flowing) then the memory is written. write etc.

memory block

Scanned with CamScanner

Date.	 _
Page No	_

The	rage no.
*	Control and Tening unit:
	It provides liming and control signal to
	the ming and control signal to
Zode I	the microprocessor to perform the various operation.
	It has three control signals. It controls all external
Ten I	and internal circuits. It operates with refrence
*	to clock signal. The three control signals are as
	follows:
	The same of the sa
pr	1) ALE (Arithmetic Latch Enable) -> It provides combol
	signal to synchronize the components of
	microprocessor
Dar-	
107	or late - This is used for wreting operation This is
41,	PY WR -> This is used for writing operation. This is active low.
A PARTY	active 100.
7	port por This so was I for more discon This es
	Pro RD - This is used for reading operation. This is active low.
-	active 20w.
	Handle Land
	There are three status signal used
	in microprocessor S, S, and IO/M. It changes
	it's status according to provided inputs to these
	pens. Below is the touth table for various combinations
	of status signals.
	IO/M S1 Sp Data bus staries (Output)
1.0	O O O Halt
	O 1 Memory write 90 1
	1 0 Memory read
V	1 0 1. IO write 101
	1 1 0 read (vil) 110
4	Opcode fetch
	Interrupt Acknowledge (1)
E MAI	
Market 1	No. of the second secon

	Page No.
Applications of microprocessors:	
Following are the applications of	microprocessons.
Instrumentation -> It is very useful i	n the field
of instrumentation. Frequency counters,	tunction
generators, frequency synthesize analyses and many instruments	
available only when microprocessors a controllers. It is used in medical inst	ue used
Control -> Microprocessor based controllers	
In home appliances, such as microway	ve over

Control -> Microprocessor based control in home appliances, such as mic washing machine etc. Microprocessors are being used controlling various parameters like speed pressure, tempreature etc. These are used with the her sustable transducers.

Communication -> Microprocessors are being widely used in communication équipments like telephone industry digital felephone sets, Telephone exchanges and modern. The use of microprocessor in felevision, satellite communication etc. 98 made. Railway reservation, air reservation, LAN and WAN for communication uses this technology.

Consumer -> The use of microprocessor in toys, entertainment equipment and home appliances is making them more ente trining with full of features. Now the microprocessors are used in calculators, Accounting systems, Traffic light control, Military applications, Complex Industrial