Cheby User Guide

CERN

Cheby User Guide ii

REVISION HISTORY

NUMBER	DATE	DESCRIPTION	NAME
1.5	2022-12-01		С

Cheby User Guide iii

Contents

1	Wha	at is Cheby ?	1
2	Use	r Starting Guide	2
	2.1	Memory map summary	4
	2.2	Registers description	4
		2.2.1 control	4
		2.2.2 value	5
		2.2.3 counter	5
3	Che	by File Format	6
	3.1	General Structure	6
	3.2	Header	6
	3.3	Registers	8
		3.3.1 Plain Registers	8
		3.3.2 Fields	9
	3.4	Blocks	10
	3.5	RAMs	10
	3.6	Repetition	11
	3.7	Submap	11
4	Gen	erated HDL	12
	4.1	Semantics	12
	4.2	AXI4-Lite	12
	4.3	Wishbone	12
5	Gen	a Compatibility	13
6	who	en Compatibility	14

Cheby User Guide iv

7	Che	by Command-Line Tool	15
	7.1	Generating HDL	15
	7.2	Generating EDGE file	15
	7.3	Generating C header	15
	7.4	Generating documentation	16
	7.5	Generating constants file	16
	7.6	Generating SILECS file	16
	7.7	Custom pass	16
	7.8	Generating text files	17



Cheby User Guide 1 / 17

Chapter 1

What is Cheby?

Cheby is both a text description of the interface between hardware and software, and a tool to automatically generate code or documentation from the text files.

In Cheby, the hardware appears to the software as a block of address in the physical memory space. There might be other way to interface hardware and software (for example through a standard serial bus like USB or through a network).

The block of address is named the memory map of the hardware. The memory map is a map between addresses and hardware elements like registers or memories.

The hardware elements supported by Cheby are:

- Registers. A register uses one word of memory (usually 32 bits) or two (so 64 bits), and is divided into fields (a group of bit). Some bits of the registers can be unused. The difference between a register and a memory is that hardware has direct access to a register, there are wires between the register and the hardware so as soon as the software writes to a register the hardware 'can' see the new value. A register is usually read-write: the value of the register is defined by the last write (from the software) and the software always reads the last value. A register can also be read-only: the hardware defines the value that is read. It is also possible that a read triggers some changes in the hardware. Finally a register can be write-only, and usually a write triggers an action. In that case, a value read has no meaning.
- Memories. A memory is like a RAM memory except that hardware also has access to it (through a second port, hence the
 name dual port). Memories are used when a certain amount of data has to be transfered or to configure hardware for data
 transfers (like DMA descriptors). To avoid possible conflicts, memories are usually one direction: the software can read and
 the hardware can write, or the software can write and the hardwire can read.
- Submap. A submap is a sub-block of the memory map (an aligned continuous range of address) either defined by an external file or will be available to the hardware designer. Submaps make possible to create a hierarchy of blocks and to create custom blocks

A fundamental feature of the Cheby text description is non-ambiguity: the memory map is defined by the file and there is only one way to assign addresses to hardware elements.

Once the text file is written it is possible to invoke the cheby tool to generate:

- · C headers
- · Device drivers
- HDL code
- · HTML documentation

The automatic generation of these files avoid a tedious work and ensure coherency between them.

Cheby User Guide 2 / 17

Chapter 2

User Starting Guide

Let's work on a very simple design: a counter. The hardware increments a countewr every cycle until it reaches a maximal value, then it starts again from 0.

As a designer, you have to implement the counter but you can use Cheby to generate the interface. The counter needs:

- A one bit register to enable/disable it.
- A 32-bit register containing the maximal value
- A 32-bit register with the current value.

In this user starting guide only the cheby command line tool is used, and the input file is created by any text editor.

Let's assume the design uses the wishbone bus, and create a Cheby file that describes the above elements.

```
memory-map:
 bus: wb-32-be
 name: counter
 description: A simple example of a counter
  children:
    - req:
        name: control
        comment: Counter control
        description: This register controls the counter activity.
        width: 32
        access: rw
        children:
          - field:
              name: enable
              comment: Set to enable the counter
              description: >
                If the bit is set, the counter is running.
                If the bit is cleared, the counter is frozen.
              range: 0
    - reg:
        name: value
        description: Maximum value of the counter
        width: 32
        access: rw
        name: counter
        description: Current value of the counter
        width: 32
        access: ro
```

Cheby User Guide 3 / 17

The description of the file format is documented later in this guide.

For the hardware designer, cheby can generate the hardware interface: for VHDL this is an entity and its associated architecture and for verilog this is a module. The hardware interface contains the wishbone bus, the registers described in the file, the decoding logic, and ports for the registers.

To generate VHDL:

```
cheby --gen-hdl=counter.vhdl -i counter.cheby
```

Here is the entity part generated by the tool:

```
entity counter is
 port (
   rst_n_i
                     : in std_logic;
                     : in std_logic;
   clk_i
   wb_cyc_i
                     : in std_logic;
   wb stb i
                     : in std_logic;
   wb_adr_i
                     : in std_logic_vector(3 downto 2);
   wb_sel_i
                     : in std_logic_vector(3 downto 0);
                      : in
   wb_we_i
                              std_logic;
                      : in
                              std_logic_vector(31 downto 0);
   wb_dat_i
                      : out std_logic;
   wb_ack_o
                      : out std_logic;
   wb_err_o
                      : out std_logic;
   wb_rty_o
                     : out std_logic;
   wb_stall_o
                      : out std_logic_vector(31 downto 0);
   wb_dat_o
   -- Counter control
   -- Set to enable the counter
   control_enable_o : out std_logic;
   -- Maximum value of the counter
                      : out std_logic_vector(31 downto 0);
   -- Current value of the counter
                     : in std_logic_vector(31 downto 0)
   counter_i
 );
end counter:
```

You can see the wishbone ports and the ports for the counter.

As an hardware designer, you have to write the HDL code for the counter logic. The enable and maximum value are given by the interface, and you should give the current value.

Because the interface is defined (and hopefully well documented), it is also possible for the software developer to start the software part. The SW developer needs to program the register and therefore to know the register map. So let's generate the corresponding C header:

```
#ifndef __CHEBY__COUNTER__H__
#define __CHEBY__COUNTER__H__
#define COUNTER_SIZE 12 /* 0xc */

/* This register controls the counter activity. */
#define COUNTER_CONTROL 0x0UL
#define COUNTER_CONTROL_ENABLE 0x1UL

/* Maximum value of the counter */
#define COUNTER_VALUE 0x4UL

/* Current value of the counter */
#define COUNTER_COUNTER 0x8UL
```

Cheby User Guide 4 / 17

```
#ifndef __ASSEMBLER__
struct counter {
    /* [0x0]: REG (rw) This register controls the counter activity. */
    uint32_t control;

    /* [0x4]: REG (rw) Maximum value of the counter */
    uint32_t value;

    /* [0x8]: REG (ro) Current value of the counter */
    uint32_t counter;
};
#endif /* !__ASSEMBLER__*/

#endif /* __CHEBY__COUNTER__H__ */
```

The absolute address of the counter is determined by the instantiation of this module, but you can refer directly to the registers.

In order for the end-user or a developper to have a better view of the design, it is better to read a documentation. A doc can be generated from the description file:

```
cheby --gen-doc=counter.html -i counter.cheby
```

For our example, the generated doc is:

2.1 Memory map summary

A simple example of a counter

HW address	Туре	Name	HDL name
0x0	REG	control	control
0x4	REG	value	value
0x8	REG	counter	counter

2.2 Registers description

2.2.1 control

HDL name	control
address	0x0
block offset	0x0
access mode	rw

Counter control

This register controls the counter activity.

31	30	29	28	27	26	25	24
-	-	-	-	-	-	-	-
23	22	21	20	19	18	17	16
-	-	-	-	-	-	-	_
15	14	13	12	11	10	9	8
-	-	-	-	-	-	-	_
7	6	5	4	3	2	1	0

Cheby User Guide 5 / 17

	-	-	-	-	-	-	-	enable
--	---	---	---	---	---	---	---	--------

enable

Set to enable the counter

If the bit is set, the counter is running. If the bit is cleared, the counter is frozen.

2.2.2 value

HDL name value address 0x4 block offset 0x4 access mode rw

Maximum value of the counter

31	30	29	28	27	26	25	24	
value[31:24]								
23	22	21	20	19	18	17	16	
value[23:16]								
15	14	13	12	11	10	9	8	
value[15:8]								
7	6	5	4	3	2	1	0	
			value	e[7:0]				

2.2.3 counter

HDL name counter address 0x8 block offset 0x8 access mode ro

Current value of the counter

31	30	29	28	27	26	25	24		
counter[31:24]									
23	22	21	20	19	18	17	16		
	counter[23:16]								
15	14	13	12	11	10	9	8		
	counter[15:8]								
7	6	5	4	3	2	1	0		
	•		count	er[7:0]					

Cheby User Guide 6 / 17

Chapter 3

Cheby File Format

3.1 General Structure

The Cheby file format represent a hierarchy of nodes. A node contains a list of attribute and children. An attribute is designated by a name and has a value (a string, a boolean or an integer). The children are nodes, organized as a list.

The Cheby file format described in this manual is based on YAML, so that there is no new format to invent and many text editors have already support for it. However the file extension is usually .cheby.

The nodes are memory-map, reg, field, memory, repeat, block and submap.

Some attributes are common to all nodes:

- name: The name of the node. This is required for all nodes. The name is also used to create HDL or C names in general files.
- comment: This should be a short text that explain the purpose of the node. The description is copied into the code (as a comment) to make it more readable. This attribute is not required but it is recommended to always provide it.
- description: This is a longer text that will be copied into the generated documentation.
- children: For nodes that have children, this is a list of the children.
- address: An optional byte address relative to the parent. The address must be correctly aligned. If not provided or it the value is next, then the address is computed using the previous one and the alignment. It is possible to go backward by providing explicit address (eg: the first child has address 4 and the second one has address 0), but this is not recommended and be a source of errors (in particular with automatic addresses that are always computed from the previous node). Overlapping addresses are detected by the tools.
- x-NAME: Extensions for tool or feature NAME. The Cheby file format is extensible so that new tools can be easily created without backward compatibility issues.
- x-hdl: Extensions for hdl generation.
- x-gena: Extensions for Gena compatibility.
- x-wbgen: Extensions for wbgen compatibility.

3.2 Header

A cheby file is an associative array named memory-map. The only purpose of this name is to easily refuse a random YAML file.

The bus attribute specifies which bus will be used to interface the CPU with the HW module. It can be:

Cheby User Guide 7 / 17

- wb-32-be: non-pipelined wishbone with 32 bit of data using the big-endian convention
- wb-16, wb-32: non-pipelined wishbone using 16 or 32 bit of data and big-endian convention by default
- axi4-lite-32: AIX4 lite bus with 32 bit of data
- avalon-lite-32: AVALON bus with 32 bit of data
- cern-be-vme-SZ: CERN VME-like bus using SZ data bit. SZ can be 8, 16 or 32.
- cern-be-vme-split-SZ: CERN vme-like bus with split read and write address lines

The attribute word-endian can be used to specify the word endianness (how multi-word registers are laid out in memory). It is optionnal, and the default is set according to the bus: big by default for wb-32-be and cern-be-vme, little for axi4-lite-32. It is also possible to use none to disallow any multi-word registers, and thus having a portable memory map.

If you need to reserve area in a module, you can use the size attribute to specify the size (in bytes) of the memory space used by the module. The suffixes k, M and G are allowed.

It is possible to specify a semantic version using the version attribute. The version consists of 3 numbers between 0 and 255 separated by comma. The version appears in generated files.

The following attributes under x-hdl are supported:

busgroup

Use an input and an output record (in vhdl) for the bus. The value is a boolean.

iogroup

Use an input and and output record (in vhdl) for the I/O. This will also generate a package to declare the records. The value of this attribute is the name of the port.

reg-prefix

If false, discard register prefix and every prefix before register. So only the name of the field is kept. This creates shorter names. This attribute is inherited.

block-prefix

If false, discard block prefix, in order to create shorter names. This attribute is inherited.

pipeline

Finely define the pipelining. In case of timing closure issues, you can set this value to "all". Possible values are "rd-in", "rd-out", "wr-in", "wr-out". Values starting with "wr-" act on signals for write commands, while values starting with "rd-" act on signals for read commands. Values finishing with "-in" acts on input signals, while values finishing with "-out" acts on output signals. So for example "wr-in" adds a registers on input signals for write commands. It is possible to use a set of values separated by commas. The default is "wr-in,rd-out". There are also aliases: "wr" is for "wr-in,wr-out", "rd" for "rd-in,rd-out", "in" for "wr-in,rd-in" and "out" for "wr-out,rd-out". Finally it is possible to use "none" not to use any pipelining. The pipelining is a single barrier of registers inserted on an internal bus, which is created from the external bus.

name-suffix

The name of the hdl entity or module is by default the name of the memory map. This attribute adds a suffix to those names.

bus-granularity

Specify the granularity of the addresses. If set to word, the address bus LSB bits are omitted. So if a word is 4 bytes, the address bus start at bit 2. If set to byte, the address bus start at 0 (but those extra bits are ignored). The default is word and this option is currently only supported by the axi4-lite bus and ignored by the other buses. The purpose of this option is for compatibility with Xilinx Vivado graphical tools.

Cheby User Guide 8 / 17

3.3 Registers

A register uses one (usual case) or two (for 64-bit registers) words address. It can be directly read or written by the CPU and each used bit or group of bits generates a port.

The access mode is defined from the point of view of the software. It slightly change the generated hardware:

- rw (read/write): This generates flip-flops whose value is directly available to the hardware. The software can write to modify the value or read the get the current value. The hardware cannot change the value.
- wo (write-only): Like rw, but the software cannot read the current value.
- ro (read-only): This creates no hardware but just a port. The software can read the current value of the port, and cannot modify it

The size (in bits) of the register can be specified by the width attribute. The size can be larger than a word (but then you have to consider word endianness issues).

It is possible to have fields in a register. A field is a group of consecutive bits and has a name.

If there is no field, this is a plain register.

The following attributes under x-hdl are supported:

write-strobe

True to generate an additional signal that is asserted when the register is written by the host. The name of the signal is '_wr_o' appended to the name of the register. The strobe signal is asserted for one cycle when a write request for this register is detected. If there are some outputs of type:reg, then the pulse is generated one cycle before the outputs are updated.

read-strobe

True to generate an additional signal that is asserted when the register is read by the host. The name of the signal is '_rd_o' appended to the name of the register. The strobe signal is asserted for one cycle.

write-ack

True to generate an additional signal for the write ack. The user must assert this signal for one cycle to acknowledge the write. It doesn't make sense to have this signal without the write strobe signal. The name of the signal is '_wack_i' appended to the name of the register.

read-ack

True to generate an additional signal for the read ack. The user must assert this signal for one cycle to acknowledge the read. It doesn't make sense to have this signal without the read strobe signal. The name of the signal is '_rack_i' appended to the name of the register.

port

Defines how ports are created and only when there are fields. When set to reg, only one port per direction is created using the size of the register. User has to extract the fields from this port. When set to field (the default), ports are created for each field.

type

Provide a default value for the type attribute of fields. A field can overwrite the value. See fields for the values.

3.3.1 Plain Registers

A plain register has a type, which could be unsigned (the default), signed or float. The type has no impact on the hardware, but changes the software view.

It is possible to define the initial (just after a reset) value of a register using the preset attribute. For 32 bit registers, you can also use the map version (set in the root) as the initial value by giving the value version to the preset attribute. Bits 0 to

Cheby User Guide 9 / 17

7 are set to the patch level, bits 8 to 15 to the minor version and bits 16 to 23 to the major. You cannot have both preset and constant attributes.

Using the constant attribute, you can also give the value of attributes from the root x-cern-info mapping. When the constant attribute of a register is set to map-version, the value of the register is set to the value of the map-version. Likewise for ident-code.

The type attribute within x-hdl is available and behaves as defined below in the section for fields.

Example of a plain register:

```
- reg:
   name: reg1
   description: a reg without fields
   width: 32
   access: rw
   type: unsigned
   preset: 0x123
```

3.3.2 Fields

There can be several fields in a register, and all of them have the same access right. Bits used by a field are specified by the range attribute. The range is a single number if the field is 1 bit, or in the form of lo-hi where lo is the lowest bit and hi is the highest bit. Bits are numbered using the little endian convention.

It is possible to define the initial value of a field using the preset attribute.

It is possible to use a different type than the register type (which acts as the default type). The float type is not available for fields. It is however possible to use an enumeration type by specifying enum. NAME, where NAME must be a name of an enumeration defined in the x-enums extension. The width of the field must be the same as the width of the enumeration.

The type attribute within x-hdl is available. It can be set to:

reg

A register is created which can be read or written from the bus. The value of the register is available on the ports. This is the default unless register access type is ro.

wire

No logic is created. In case of read from the bus, the current value on the input ports is returned. The output ports are directly connected to the data bus. It doesn't make sense not to also have a strobe port for write. This is the default when the access type is ro.

const

No output available, the value is a constant, set by the preset attribute.

autoclear

Only for outputs. In case of a write from the bus, the value is set on the output ports for only one clock cycle and then cleared.

or-clr

A register is created, and the current value is or-ed with the input port. The register is cleared on a write (when bits are 1). This allows to capture events. Software developers should be careful when using these registers: they should only clear bits that were read as 1; otherwise they could miss events.

Example of a register with two fields:

```
- reg:
   name: reg0
   description: a normal reg with some fields
   width: 32
   access: rw
```

Cheby User Guide 10 / 17

```
children:
    - field:
        name: field0
        description: 1-bit field
        range: 1
    - field:
        name: field1
        description: a field with a preset value
        range: 10-8
        preset: 2
```

3.4 Blocks

A block is simply a group of elements (registers, rams, submaps or blocks). This is used only to create a hierarchy, but also offers the possibility to specify an address or an alignment.

It is possible to reserve space at the end of a block with the size attribute. It specifies the size (in bytes) of the block. The suffixes k, M and G are allowed.

The block-prefix and reg-prefix attributes are available within x-hdl, to control name generation.

Example of a block:

```
- block:
   name: block1
   description: A block of registers
   children:
   - reg:
      name: blreg0
      access: wo
      width: 32
```

3.5 RAMs

A RAM is represented by an memory element with one register as a child. The size of the ram is specified by the memsize attribute (usually it should be a power of 2) and allows k, M or G suffixes. Note that the width of the ram (the number of address lines) is computed from the size of the ram and the size of the register.

Unless the attribute 'interface' is present, the memory is automatically instantiated. Otherwise the attribute specifies the type of bus, like for an external submap.

If the dual-clock attribute of x-hdl is set to True, the external memory port is clocked by an external input.

Example of a ram:

```
- memory:
   name: ram_ro1
   memsize: 16
   children:
    - reg:
        name: value
        access: rw
        width: 32
```

Cheby User Guide 11 / 17

3.6 Repetition

It is possible to replicate elements using repeat. The number of repetitions is set by the count attribute.

Be careful that such a repetition can generate a lot of hardware.

Example of a replication:

```
- repeat:
   name: arr1
   count: 2
   align: False
   children:
   - reg:
      name: areg1
      access: rw
      width: 32
```

3.7 Submap

If the filename attribute is not present, then this is a generic submap and a bus port is generated in the HDL. The size of the submap is required. The attribute interface specifies which interface is used for the connection.

Example of a generic submap:

```
- submap:
name: sub3
size: 0x1000
description: A bus
interface: wb-32-be
```

If the filename attribute is present, the size attribute is not allowed as the size of the submap is defined by the memory map given by the file. If the include attribute is present and set to True, then the memory map described by the file is included directly, otherwise a bus interface is generated in the HDL.

Example of a normal submap:

```
- submap:
    name: sub1
    description: A normal submap
    filename: demo_all_sub.cheby
```

Example of an included submap:

```
- submap:
   name: sub2
   description: An included submap
   filename: demo_all_sub.cheby
   include: True
```

Cheby User Guide 12 / 17

Chapter 4

Generated HDL

For all buses, only word accesses are supported. Sub-word (byte or half-word) accesses are considered as word accesses (which can lead to error when writting).

Addresses are byte addresses unless bus-granularity is set to word.

For registers longer than a word on a big-endian bus, the most significant word is at the lowest address. There is one bit per word for strobe bits, and they follow word order (bit 0 strobes the lowest word).

4.1 Semantics

The value of any unused field (within a defined register) is always read as 0. This is to allow future compatibility. However undefined addresses may return any value. In case of read or write to an undefined address, the transaction is acknowledge (or passed to a submodule or a submap). Code generated by Cheby never blocks a request.

4.2 AXI4-Lite

There are several restrictions from the AMBA AXI standard:

- There can be no combinatorial paths between input and output signals (A3.2.1). So there must be at least one register.
- A source is not permitted to wait until READY is asserted before asserting VALID. Likewise, a destination is permitted to wait for VALID to be assert before asserting the corresponding READY (A3.2.1).

There are registers for each channel. The AW and W channels wait until both have a request, handle the request and then become ready. The B channel becomes valid the next cycle, until ready is asserted.

Note that AXI4 addresses are byte addresses as specified in A3.4.1, but LSB bits may be omitted with the bus-granularity attribute.

4.3 Wishbone

The normal wishbone protocol is used (and not the pipelined one).

The err (error) and rty (retry) are always ignored (as inputs) and never asserted as output.

By default the wishbone interface uses one port per wishbone signal. It is possible to group all signals in one input and one output port by setting the x-hdl.busgroup attribute to True.

Cheby User Guide 13 / 17

Chapter 5

Gena Compatibility

For Cheburashka/Gena users, there is a simple transition path. You can convert a regular Cheburashka XML file to the cheby format using gena2cheby:

```
$ gena2cheby FILE.xml
```

This tool writes on the standard output a cheby file. Note that this file contains several extensions (under x-gena arrays) so that all the feature of the XML file are kept.

It is possible to generate a VHDL file (that is very similar to the VHDL file generated by Gena) using cheby:

```
$ cheby --gen-gena-regctrl=OUTPUT.vhdl -i INPUT.cheby
$ cheby --gen-gena-memmap=OUTPUT.vhdl -i INPUT.cheby
```

Use the --gena-commonvisual option of --gen-gena-regetrl to use components from the CommonVisual library instead of generating directly the code for them.

The cheby tool can also generate the C and header files for DSP access:

```
$ cheby --gen-gena-dsp -i INPUT.cheby
```

This will creates DSP/include/MemMapDSP_X.h, DSP/include/vmeacc_X.h and DSP/vmeacc_X.c (where X is the name of the design.

You can also gnerate each file individually:

```
$ cheby --gen-gena-dsp-map=OUTPUT.h -i INPUT.cheby
$ cheby --gen-gena-dsp-h=OUTPUT.h -i INPUT.cheby
$ cheby --gen-gena-dsp-c=OUTPUT.c -i INPUT.cheby
```

Cheby User Guide 14 / 17

Chapter 6

wbgen Compatibility

There is also a transition path for wbgen users. If you have a fully declarative and well formed wbgen file, you can convert it to the cheby file:

```
$ wbgen2cheby FILE.wb
```

This generate a cheby file on the standard output. Note that this file contains extensions using x-wbgen arrays.

It is possible to generate a VHDL file that is very similar to the VHDL file generated by wbgen using cheby:

```
$ cheby --gen-wbgen-hdl=OUTPUT.vhdl -i INPUT.cheby
```

Cheby User Guide 15 / 17

Chapter 7

Cheby Command-Line Tool

The cheby tool can generate various files from an input file. The input file must be specified with the -i flag:

```
$ cheby ACTION1 ACTION2... -i INPUT.cheby
```

An action flag is a flag optionally followed by a file name. If the file name is not present, the result is sent to the standard output.

```
$ cheby --gen-hdl=output.vhdl -i input.cheby
$ cheby --gen-hdl -i input.cheby
```

7.1 Generating HDL

Either VHDL or verilog can be generated by cheby. You can specify the language (either vhdl or verilog) with the --hdl flag, the default being vhdl.

```
$ cheby --hdl=vhdl --gen-hdl=OUTPUT.vhdl -i INPUT.cheby
```

By default, there is a comment header (at the start of the hdl file) with the options used to generate the file, the date of generation and the author. You can disable this header generation using --header=none option. You can remove the date and author using --header=commit.

7.2 Generating EDGE file

You can generate an EDGE block definition (in CSV) with the --gen-edge flag. Note that you need to provide the other part of the files.

```
$ cheby --gen-edge -i INPUT.cheby
```

7.3 Generating C header

The definition of a C structure representing the layout of the design is generated using the --gen-c flag.

```
$ cheby --gen-c -i INPUT.cheby
```

Through the submap feature of Cheby, a design can reference another design stored in a different file. In the header file generated, the structure for the referenced design is not redefined, but imported through an include directive, using the DESIGN.h name

Cheby User Guide 16 / 17

(without any directory). So it is expected that either all the headers are stored in the same directory or that the include pathes are specified to the C compiler (using -I for example).

The generated header files use the standard integer types defined in <stdint.h>, but without including <stdint.h>. This is done on purpose so that the file can still be used on systems that don't have stdint.h. So you need to include stdint.h before including the generated header files, or to include an equivalent header file.

With the option --c-style=arm, the header generated follows more closely the CMSIS style.

It is also possible to generate a C program that check the layout is the same as the layout seen by Cheby. This can be used as a consistency check.

```
$ cheby --gen-c-check-layout -i INPUT.cheby
```

7.4 Generating documentation

Documentation can be generated either in HTML or in markdown (tested with asciidoctor). The format is specified by the --doc=FORMAT flag and the format is either html or md.

```
$ cheby --doc=md --gen-doc=OUTPUT.md -i INPUT.cheby
```

7.5 Generating constants file

In order to write testbench, you can generate an include files that defines the address of the registers, the offset and a mask for each fields.

```
$ cheby --consts-style=STYLE --gen-consts -i INPUT.cheby
```

The STYLE can be either verilog, sv, h, python, vhdl, or vhdl-ohwr. For vhdl the addresses and the offsets are integers, and the mask is not generated (as it would often overflow the integer range).

7.6 Generating SILECS file

It is possible to generate SILECS (https://wikis.cern.ch/display/SIL/Design+document) XML file from a Cheby description. Not all features of Cheby are supported: only registers.

```
$ cheby --gen-silecs -i INPUT.cheby
```

7.7 Custom pass

If you need a very specific feature, you can implement your own pass, and invoke it using --gen-custom:

```
$ cheby --gen-custom[=OUTPUT] -i INPUT.cheby
```

The Cheby tool will read the gen_custom.py file in the current directory and call the generate_custom function.

Cheby User Guide 17 / 17

7.8 Generating text files

It is possible to general a compact text file describing the layout of a cheby file with the --print-memmap flag. This could be useful to have a quick look on alignment effects.

```
$ cheby --print-memmap -i INPUT.cheby
```

To display the fields, use $\operatorname{\mathsf{--print}}\operatorname{\mathsf{-simple}}$:

```
$ cheby --print-simple -i INPUT.cheby
```

When a part of the design is replicated (using the repeat attribute) you can view the effect of it with the --print-simple-expande flag.

```
$ cheby --print-simple-expanded -i INPUT.cheby
```

Finally to regenerated the initial file (properly indented but without the comments), you can use --print-pretty or --print-pret