Stream Model Independent Transaction User Guide

User Guide for Release 2021.06

Ву

Jim Lewis

SynthWorks VHDL Training

Jim@SynthWorks.com

http://www.SynthWorks.com

Table of Contents

1		Overview	3
2		Stream Transaction Interface (StreamRecType)	3
3		StreamOperationType	4
4		Usage of the Transaction Interface (StreamRecType)	5
5		Types of Transactions	5
6		Directive Transactions	5
7		Burst FIFOs and Burst Mode Controls	6
8		Set and Get Model Options	7
9		Transmitter Transactions	9
	9.1	Send	9
	9.2	SendAsync	9
	9.3	SendBurst	10
	9.4	SendBurstAsync	10
10		Receiver Transactions	11
	10.1	Get	11
	10.2	2 TryGet	11
	10.3	GetBurst	12
	10.4	TryGetBurst	12
	10.5	5 Check	13
	10.6	TryCheck	13
	10.7	7 CheckBurst	14
	10.8	3 TryCheckBurst	14
11		Verification Component Support Functions	15
12		Burst FIFOs Initiator	15
	12.1	BurstFifo is in the Interface	15
	12.2	2 Initializing Burst FIFOs	15
	12.3	Accessing Burst FIFOs from the Test Sequencer	16
	12.4	Filling the Burst FIFO from the Test Sequencer	16
	12.5	Reading and/or Checking the Read Burst in the Test Sequencer	17
	12.6	Packing and Unpacking the FIFO	18
	12.7	7 Examples	19
		12.7.1 Sending Bursts via the Transmitter	19
		12.7.2 Getting Bursts via the Receiver	19
		12.7.3 Checking Bursts in the Receiver	20
13		About the OSVVM Model Independent Transactions	20
14 About the Author - Jim Lewis		About the Author - Jim Lewis	20
15		References	21

1 Overview

The Stream Model Independent Transaction package (StreamTransactionPkg.vhd) defines a record for communication and transaction initiation procedures that are suitable for Stream Interfaces.

All verification components (VCs) that use this interface, support a common set of transactions (or API) that are defined in StreamTransactionPkg.vhd. Hence, a user who understand the transactions for one verification component will also understand the transactions of another verification component that also uses the same package. This makes the job of a verification engineer easier.

The main difference between verification components that support this package is the configuration of verification component interface specific features - such as error injection for a UART or configuration of TID, TDest, TUSer, and TLast for AxiStream.

Having a shared set of transactions improves test case reuse between different verification components – a case where reuse is rarely possible with other verification methodologies.

2 Stream Transaction Interface (StreamRecType)

The Stream Transaction Interface, StreamRecType shown in Figure 1, defines the transaction interface between the test sequencer and the verification component. As such, it is the primary channel for information exchange between the two.

```
type StreamRecType is record
 -- Handshaking controls
      Used by RequestTransaction in the Transaction Procedures
      Used by WaitForTransaction in the Verification Component
      RequestTransaction and WaitForTransaction are in osvvm.TbUtilPkg
 Rdy
                 : bit max ;
 Ack
                 : bit max ;
 -- Transaction Type
 Operation
                : StreamOperationType ;
 -- Data and Transaction Parameter to and from verification component
 DataToModel : std_logic_vector_max_c ;
 ParamToModel
                : std_logic_vector_max_c ;
 DataFromModel : std_logic_vector_max_c ;
 ParamFromModel : std_logic_vector_max_c ;
 -- BurstFifo
 BurstFifo
                 : ScoreboardIdType ;
 -- Verification Component Options Parameters - used by SetModelOptions
 IntToModel
               : integer_max ;
 BoolToModel
               : boolean max ;
 IntFromModel
                : integer_max ;
 BoolFromModel : boolean_max ;
 TimeToModel
                : time_max ;
 TimeFromModel
                 : time_max ;
 -- Verification Component Options Type
 Options
                 : integer_max ;
end record StreamRecType ;
```

Figure 1. StreamRecType

The record element types, bit_max, std_logic_vector_max_c, integer_max, time_max, and boolean_max, are defined in the OSVVM package ResolutionPkg. These types allow the record to support multiple drivers and use resolution functions based on function maximum (return largest value).

3 StreamOperationType

StreamOperationType is an enumerated type that indicates to the verification component type of transaction that is being dispatched. Being an enumerated type, it allows the determination of the operation in the simulator's waveform window. Table 2 shows the correlation between StreamOperationType values and the transaction name.

AddressBusOperationType Value	Transmitter Transaction Name	Receiver Transaction Name
WAIT_FOR_CLOCK	WaitForClock	WaitForClock
WAIT_FOR_TRANSACTION	WaitForTransaction	WaitForTransaction
GET_TRANSACTION_COUNT	GetTransactionCount	GetTransactionCount
GET_ALERTLOG_ID	GetAlertLogID	GetAlertLogID
SET_BURST_MODE	SetBurstMode	SetBurstMode
GET_BURST_MODE	GetBurstMode	GetBurstMode
SET_MODEL_OPTIONS	SetModelOptions	SetModelOptions
GET_MODEL_OPTIONS	GetModelOptions	GetModelOptions
SEND	Send	
SEND_ASYNC	SendAsync	
SEND_BURST	SendBurst	
SEND_BURST_ASYNC	SendBurstAsync	
GET		Get
TRY_GET		TryGet
GET_BURST		GetBurst
TRY_GET_BURST		TryGetBurst
CHECK		Check
TRY_CHECK		TryCheck
CHECK_BURST		CheckBurst
TRY_CHECK_BURST		TryCheckBurst

Figure 2. Correlation between StreamOperationType and the transaction name

4 Usage of the Transaction Interface (StreamRecType)

The data and parameter fields of the StreamRecType are unconstrained. Unconstrained objects may be used on component/entity interfaces. The record fields need to be sized by the record signal that is mapped as the actual in the test harness of the testbench. Figure 3 shows the declaration StreamTxRec (which connects the AxiStreamTransmitter to TestCtrl) and StreamRxRec (which connects the AxiStreamReceiver to TestCtrl).

```
constant AXI_PARAM_WIDTH : integer :=
    TID'length + TDest'length + TUser'length + 1;

signal StreamTxRec, StreamRxRec : StreamRecType(
    DataToModel (AXI_DATA_WIDTH-1 downto 0),
    ParamToModel (AXI_PARAM_WIDTH-1 downto 0),
    DataFromModel (AXI_DATA_WIDTH-1 downto 0),
    ParamFromModel(AXI_PARAM_WIDTH-1 downto 0)
);
```

Figure 3. StreamRecType

5 Types of Transactions

A transaction may be either a directive or an interface transaction.

Directive transactions interact with the verification component without generating any transactions or interface waveforms. Examples of these are WaitForClock and GetAlertLogID.

An interface transaction results in interface signaling to the DUT. An interface transaction may be either blocking (such as Send or Get) or non-blocking (such as SendAsync and TryGet).

A blocking transaction is an interface transaction that does not does not return (complete) until the interface operation requested by the transaction has completed.

An asynchronous transaction is nonblocking interface transaction that returns before the transaction has completed - typically immediately and before the transaction has started. An asynchronous transaction has "Async" as part of its name.

A Try transaction is nonblocking interface transaction that checks to see if transaction information is available, such as read data, and if it is returns it. A Try transaction has "Try" as part of its name.

6 Directive Transactions

Directive transactions interact with the verification component without generating any transactions or interface waveforms. These transactions are supported by all verification components.

```
______
procedure WaitForClock (
-- Wait for NumberOfClocks number of clocks
-- relative to the verification component clock
_____
 signal
       TransactionRec : inout StreamRecType ;
 constant WaitCycles : in natural := 1
 -----
procedure GetTransactionCount (
-- Get the number of transactions handled by the model.
______
       TransactionRec : inout StreamRecType ;
 variable TransactionCount : out integer
) ;
procedure GetAlertLogID (
-- Get the AlertLogID from the verification component.
_____
 signal
       TransactionRec : inout StreamRecType ;
 variable AlertLogID : out AlertLogIDType
) ;
 ------
procedure GetErrorCount (
-- Error reporting for testbenches that do not use OSVVM AlertLogPkg
-- Returns error count. If an error count /= 0, also print errors
______
 signal
       TransactionRec : inout StreamRecType ;
 variable ErrorCount : out natural
) ;
```

7 Burst FIFOs and Burst Mode Controls

The burst FIFOs hold bursts of data that is to be sent to or received from the interface. The burst FIFO can be configured in the modes defined for StreamFifoBurstModeType. Currently these modes defined as a subtype of integer, shown below. The intention is to facilitate model specific extensions without the need to define separate transactions.

```
subtype StreamFifoBurstModeType is integer ;

-- Word mode indicates the burst FIFO contains interface words.
-- The size of the word may either be interface specific (such as
-- a UART which supports up to 8 bits) or be interface instance specific
-- (such as AxiStream which supports interfaces sizes of 1, 2, 4, 8,
-- 16, ... bytes)
```

```
constant STREAM_BURST_WORD_MODE : StreamFifoBurstModeType := 0 ;
-- Word + Param mode indicates the burst FIFO contains interface
-- words plus a parameter.
                            The size of the parameter is also either
-- interface specific (such as the OSVVM UART, which uses 3 bits -
-- one bit for each of parity, stop, and break error injection) or
-- interface instance specific (such as AxiStream which uses the Param
-- field to hold TUser). AxiStream TUser may be different size for
-- different applications.
constant STREAM_BURST_WORD_PARAM_MODE : StreamFifoBurstModeType := 1 ;
-- Byte mode is experimental and may be removed in a future revision.
-- Byte mode indicates that the burst FIFO contains bytes.
-- The verification component assembles interface words from the bytes.
-- This allows transfers to be conceptualized in an interface independent
-- manner.
constant STREAM_BURST_BYTE_MODE : StreamFifoBurstModeType := 2 ;
```

SetBurstMode and GetBurstMode are directive transactions that configure the burst mode into one of the modes defined in for StreamFfifoBurstModeType.

```
procedure SetBurstMode (
    signal TransRec : InOut StreamRecType ;
    constant OptVal : In StreamFifoBurstModeType
) ;

procedure GetBurstMode (
    signal TransRec : InOut StreamRecType ;
    variable OptVal : Out StreamFifoBurstModeType
) ;
```

8 Set and Get Model Options

Model operations are directive transactions that are used to configure the verification component. They can either be used directly or with a model specific wrapper around them - see AXI VCs for an example.

```
procedure SetModelOptions (
    signal TransactionRec : InOut StreamRecType ;
    constant Option : In integer ;
    constant OptVal : In boolean
) ;

procedure SetModelOptions (
```

```
signal
     TransactionRec : InOut StreamRecType ;
 constant Option
           : In
                  integer ;
 constant OptVal : In
                  integer
) ;
------
procedure SetModelOptions (
_____
 signal
     TransactionRec : InOut StreamRecType ;
           : In integer ;
 constant Option
 constant OptVal : In std_logic_vector
) ;
 -----
procedure SetModelOptions (
_____
 signal TransactionRec : InOut StreamRecType ;
             : In
 constant Option
                  integer ;
 constant OptVal : In
                  time
) ;
  ______
procedure SetModelOptions (
_____
 signal TransactionRec : InOut StreamRecType ;
 constant Option : In integer
) ;
______
procedure GetModelOptions (
_____
     TransactionRec : InOut StreamRecType ;
 constant Option
           : In
                  integer ;
 variable OptVal : Out boolean
) ;
______
procedure GetModelOptions (
______
 signal TransactionRec : InOut StreamRecType ;
 constant Option
           : In
                  integer ;
 variable OptVal : Out
                  integer
) ;
_____
procedure GetModelOptions (
______
```

```
TransactionRec : InOut StreamRecType ;
 signal
 constant Option : In integer ;
 variable OptVal
            : Out std_logic_vector
______
procedure GetModelOptions (
______
 signal TransactionRec : InOut StreamRecType ;
 constant Option : In
                    integer ;
 variable OptVal : Out time
______
procedure GetModelOptions (
-----
 signal TransactionRec : InOut StreamRecType ;
 constant Option : In integer
) ;
```

9 Transmitter Transactions

9.1 Send

Blocking Send Transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for error injection.

```
-----
procedure Send (
 signal TransactionRec : inout StreamRecType ;
 constant Data : in std_logic_vector;
 constant Param
                 : in std_logic_vector;
 constant StatusMsgOn : in boolean := FALSE
) ;
______
procedure Send (
______
 signal TransactionRec : inout StreamRecType ;
 constant Data
                 : in std_logic_vector;
 constant StatusMsgOn : in boolean := FALSE
) ;
```

9.2 SendAsync

SendAsync is an asynchronous / non-blocking send transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for error injection.

```
procedure SendAsync (
```

```
signal TransactionRec : inout StreamRecType ;
constant Data : in std_logic_vector ;
constant Param : in std_logic_vector ;
constant StatusMsgOn : in boolean := FALSE
);

procedure SendAsync (

signal TransactionRec : inout StreamRecType ;
constant Data : in std_logic_vector ;
constant StatusMsgOn : in boolean := FALSE
);
```

9.3 SendBurst

SendBurst is a blocking send burst transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for error injection.

```
procedure SendBurst (
______
       TransactionRec : inout StreamRecType ;
 signal
 constant NumFifoWords : In integer ;
 constant Param
                 : in std_logic_vector;
 constant StatusMsgOn : in boolean := FALSE );
______
procedure SendBurst (
______
 signal
       TransactionRec : inout StreamRecType ;
 constant NumFifoWords : In integer ;
 constant StatusMsgOn : in
                       boolean := FALSE
) ;
```

9.4 SendBurstAsync

SendBurstAsync is an asynchronous / non-blocking send burst transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for error injection.

```
procedure SendBurstAsync (
    signal TransactionRec : inout StreamRecType ;
    constant NumFifoWords : In integer ;
    constant Param : in std_logic_vector ;
    constant StatusMsgOn : in boolean := FALSE
);
```

10 Receiver Transactions

10.1 Get

Get is a blocking get transaction. Param, when present, is an extra parameter used by the verification component.

10.2 TryGet

TryGet is a non-blocking try get transaction. If Data is available, get it and return available TRUE, otherwise Return Available FALSE. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for received error status.

```
procedure TryGet (
    signal TransactionRec : inout StreamRecType ;
    variable Data : out std_logic_vector ;
    variable Available : out boolean ;
    constant StatusMsgOn : in boolean := FALSE
);

procedure TryGet (
    signal TransactionRec : inout StreamRecType ;
```

```
variable Data : out std_logic_vector;
variable Param : out std_logic_vector;
variable Available : out boolean;
constant StatusMsgOn : in boolean := FALSE
);
```

10.3 GetBurst

GetBurst is a blocking get burst transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for checking error injection.

```
______
procedure GetBurst (
______
 signal
      TransactionRec : inout StreamRecType ;
 variable NumFifoWords : inout integer ;
 constant StatusMsgOn : in boolean := FALSE
______
procedure GetBurst (
_____
 signal
       TransactionRec : inout StreamRecType ;
 variable NumFifoWords : inout integer ;
 variable Param
                : out std_logic_vector ;
 constant StatusMsgOn : in boolean := FALSE
) ;
```

10.4 TryGetBurst

TryGetBurst is a non-blocking try get burst transaction. If Data is available, get it and return available TRUE, otherwise Return Available FALSE. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for received error status.

```
_____
procedure TryGetBurst (
_____
 signal
       TransactionRec : inout StreamRecType ;
 variable NumFifoWords : inout integer ;
 variable Available
                : out boolean ;
 constant StatusMsgOn : in boolean := FALSE
______
procedure TryGetBurst (
_____
 signal
       TransactionRec : inout StreamRecType ;
 variable NumFifoWords : inout integer ;
 variable Param
                     std_logic_vector ;
                : out
```

```
variable Available : out boolean;
constant StatusMsgOn : in boolean := FALSE
);
```

10.5 Check

Check is a blocking check transaction. Data is the expected value to be received. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for received error status.

```
______
procedure Check (
 signal
       TransactionRec : inout StreamRecType ;
            : in std_logic_vector;
 constant Data
 constant Param
                : in
                      std_logic_vector ;
 constant StatusMsgOn : in boolean := FALSE
) ;
______
procedure Check (
_____
       TransactionRec : inout StreamRecType ;
 signal
 constant Data
                : in std_logic_vector;
 constant StatusMsgOn : in boolean := FALSE
) ;
```

10.6 TryCheck

TryCheck is a non-blocking try check transaction If Data is available, check it and return available TRUE, otherwise Return Available FALSE. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for received error status.

```
______
procedure TryCheck (
_____
 signal
        TransactionRec : inout StreamRecType ;
 constant Data
                  : in
                        std_logic_vector ;
 constant Param
                  : in std logic vector ;
                  : out boolean ;
 variable Available
 constant StatusMsgOn
                  : in boolean := FALSE
) ;
procedure TryCheck (
______
 signal TransactionRec : inout StreamRecType ;
                  : in
 constant Data
                        std_logic_vector ;
 variable Available
                  : out boolean ;
 constant StatusMsgOn
                  : in boolean := FALSE
) ;
```

10.7 CheckBurst

CheckBurst is a blocking check burst transaction. Param, when present, is an extra parameter used by the verification component. The UART verification component uses Param for checking error injection.

```
_____
procedure CheckBurst (
______
       TransactionRec : inout StreamRecType ;
 signal
 constant NumFifoWords : In
                     integer ;
 constant Param
               : in std_logic_vector;
 constant StatusMsgOn : in boolean := FALSE
______
procedure CheckBurst (
______
      TransactionRec : inout StreamRecType ;
 constant NumFifoWords : In integer ;
 constant StatusMsgOn : in boolean := FALSE
) ;
```

10.8 TryCheckBurst

TryCheckBurst is a non-blocking try check burst transaction. Param, when present, is an extra parameter used by the verification component. If BURST Data is available, check it and return available TRUE, otherwise Return Available FALSE. The UART verification component uses Param for checking error injection.

```
______
procedure TryCheckBurst (
______
 signal
      TransactionRec : inout StreamRecType ;
 constant NumFifoWords : In integer ;
 constant Param
                 : in std logic vector ;
               : out boolean ;
 variable Available
 constant StatusMsgOn : in boolean := FALSE
) ;
______
procedure TryCheckBurst (
______
 signal
       TransactionRec : inout StreamRecType ;
 constant NumFifoWords : In
                      integer ;
 variable Available : out boolean;
 constant StatusMsgOn
                : in boolean := FALSE
) ;
```

11 Verification Component Support Functions

Verification component support functions help decode the operation value (StreamOperationType) to determine properties about the operation.

12 Burst FIFOs Initiator

12.1 BurstFifo is in the Interface

The BurstFifo is inside StreamRecType, see Figure 4. This makes the BurstFifo easily accessible to both the Verification component as well as the Test Sequencer (TestCtrl). The BurstFifo is implemented using a ScoreboardID from the scoreboard package. This allows a VC to either use it as a FIFO or as a scoreboard. The FIFO is std_logic_vector based and uses the OSVVM library ScoreboardGenericPkg instance defined in ScoreboardPkg_slv.vhd (OsvvmLibraries/osvvm).

```
type StreamRecType is record
    . . .
    -- BurstFifo
    BurstFifo : ScoreboardIdType ;
    . . .
end record StreamRecType ;
```

Figure 4. BurstFifo In StreamRecType

12.2 Initializing Burst FIFOs

The burst FIFOs need to be initialized. A good place to do this is in the transaction dispatcher of the verification components. Figure 5 shows the declaration of a BurstFifo.

```
TransactionDispatcher : process
    . . .
begin
    wait for 0 ns ;
    TransRec.BurstFifo <= NewID("RxBurstFifo", ModelID) ;
    wait for 0 ns ;</pre>
```

Figure 5. BurstFifo Initialization

12.3 Accessing Burst FIFOs

The Burst Fifos support basic FIFO operations. These are shown in Figure 6.

```
Push(TransRec.BurstFifo, Data) ;
Check(TransRec.BurstFifo, Data) ;
Data := Pop(TransRec.BurstFifo) ;
```

Figure 6. Making the BurstFifos visible in the test sequencer (TestCtrl)

12.4 Filling the Burst FIFO from the Test Sequencer

In the test sequencer, to send a burst to the transmitter or check a burst in the transmitter, the following procedures from FifoFillPkg slv.vhd (in osvvm common library) may be used.

```
_____
procedure PushBurst (
-- Push each value in the VectorOfWords parameter into the FIFO.
-- Only FifoWidth bits of each value will be pushed.
_____
 constant Fifo
                   : in ScoreboardIDType ;
 constant VectorOfWords : in integer_vector ;
 constant FifoWidth : in integer := 8
) ;
procedure PushBurstIncrement (
-- Push Count number of values into FIFO. The first value
-- pushed will be FirstWord and following values are one greater
-- than the previous one.
-- Only FifoWidth bits of each value will be pushed.
_____
               : in
 constant Fifo
                      ScoreboardIDType ;
 constant FirstWord : in integer ;
 constant Count : in integer ;
 constant FifoWidth : in     integer := 8
procedure PushBurstRandom (
-- Push Count number of values into FIFO. The first value
-- pushed will be FirstWord and following values are randomly generated
-- using the first value as the randomization seed.
-- Only FifoWidth bits of each value will be pushed.
______
 constant Fifo : in ScoreboardIDType ;
 constant FirstWord : in
                      integer ;
 constant Count : in integer ;
 constant FifoWidth : in     integer := 8
) ;
```

12.5 Reading and/or Checking the Read Burst in the Test Sequencer

The following PopBurst and CheckBurst are used in the test sequencer to verify received burst values.

```
______
procedure PopBurst (
-- Pop values from the FIFO into the VectorOfWords parameter.
-- Each value popped will be FifoWidth bits wide.
______
 constant Fifo
                  : in ScoreboardIDType ;
 variable VectorOfWords : out integer_vector ;
 constant FifoWidth : in integer := 8
______
procedure CheckBurst (
-- Pop values from the FIFO and check them against each value
-- in the VectorOfWords parameter.
-- Each value popped will be FifoWidth bits wide.
_____
 constant Fifo
                  : in ScoreboardIDType ;
 constant VectorOfWords : in integer_vector ;
 constant FifoWidth : in integer := 8
______
procedure CheckBurstIncrement (
-- Pop values from the FIFO and check them against values determined
-- by an incrementing pattern. The first check value will be FirstWord
-- and the following check values are one greater than the previous one.
-- Each value popped will be FifoWidth bits wide.
______
 constant Fifo : in ScoreboardIDType ;
 constant Count : in integer ;
 constant FifoWidth : in     integer := 8
_____
procedure CheckBurstRandom (
-- Pop values from the FIFO and check them against values determined
-- by a random pattern. The first check value will be FirstWord and the
-- following check values are randomly generated using the first
-- value as the randomization seed.
-- Each value popped will be FifoWidth bits wide.
______
 constant Fifo : in
                     ScoreboardIDType ;
 constant FirstWord : in integer ;
 constant Count : in
                     integer ;
```

```
constant FifoWidth : in integer := 8
);
```

12.6 Packing and Unpacking the FIFO

The burst FIFOs can be configured to be either byte width or match the verification component interface width. The following procedures (from FifoFillPkg_slv.vhd) are used to transform byte width data in the burst FIFO to/from the verification component interface width.

```
procedure PopWord (
-- Pop bytes from BurstFifo and form a word
-- Current implementation for now assumes it is assembling bytes.
-----
                      : in ScoreboardIDType;
: out boolean;
 constant Fifo
 variable Valid
variable Data
                        : out std_logic_vector ;
 variable BytesToSend : inout integer ;
constant ByteAddress : in natural := 0
) ;
______
procedure PushWord (
-- Push a word into the byte oriented BurstFifo
-- Current implementation for now assumes it is assembling bytes.
-----
 constant Fifo
                       : in ScoreboardIDType ;
                        : in std_logic_vector;
 variable Data
 constant DropUndriven : in boolean := FALSE ;
constant ByteAddress : in natural := 0
) ;
procedure CheckWord (
-- Check a word using the byte oriented BurstFifo
-- Current implementation for now assumes it is assembling bytes.
_____
 constant Fifo
                        : in ScoreboardIDType ;
                        : in std_logic_vector;
 variable Data
 constant DropUndriven : in boolean := FALSE;
constant ByteAddress : in natural := 0
) ;
```

12.7 Examples

The test, TbStream SendGetBurst1.vhd, interacts with an AxiStreamTransmitter and AxiStreamReceiver.

12.7.1 Sending Bursts via the Transmitter

The following are transactions initiated by the AxiStreamTransmitter verification component (see TbStream SendGetBurst1.vhd). .

```
constant DATA_WIDTH : integer := 32 ;
. . .
AxiTransmitterProc : process
begin
. . .
log("Transmit 32 Bytes -- word aligned") ;
PushBurstIncrement(TxRec.BurstFifo, 3, 32, DATA_WIDTH) ;
SendBurst(TxRec, 32) ;

WaitForClock(TxRec, 4) ;

log("Transmit 30 Bytes -- unaligned") ;
PushBurst(TxRec.BurstFifo, (1,3,5,7,9,11,13,15,17,19,21,23), WIDTH) ;
PushBurst(TxRec.BurstFifo, (31,33,35,37,39,41,43,45,47,49,1,3), WIDTH) ;
SendBurst(TxRec, 30) ;

WaitForClock(TxRec, 4) ;

log("Transmit 34 Bytes -- unaligned") ;
PushBurstRandom(TxRec.BurstFifo, 7, 34, DATA_WIDTH) ;
SendBurst(TxRec, 34) ;
```

12.7.2 Getting Bursts via the Receiver

The following are transactions initiated by the AxiStreamReceiver verification component (see TbStream_SendGetBurst1.vhd).

```
AxiReceiverProc : process
  variable NumBytes : integer ;
begin
  WaitForClock(RxRec, 2) ;

-- log("Transmit 32 Bytes -- word aligned") ;
  GetBurst (RxRec, NumBytes) ;
  AffirmIfEqual(NumBytes, 32, "Receiver: NumBytes Received") ;
  CheckBurstIncrement(RxRec.BurstFifo, 3, NumBytes, DATA_WIDTH) ;

-- log("Transmit 30 Bytes -- unaligned") ;
  GetBurst (RxRec, NumBytes) ;
  AffirmIfEqual(NumBytes, 30, "Receiver: NumBytes Received") ;
```

```
CheckBurst(RxRec.BurstFifo, (1,3,5,7,9,11,13,15,17,19,21,23), WIDTH);
CheckBurst(RxRec.BurstFifo, (31,33,35,37,39,41,43,45,47,49,1,3), WIDTH);
-- log("Transmit 34 Bytes -- unaligned");
GetBurst (RxRec, NumBytes);
AffirmIfEqual(NumBytes, 34, "Receiver: NumBytes Received");
CheckBurstRandom(RxRec.BurstFifo, 7, NumBytes, DATA_WIDTH);
```

12.7.3 Checking Bursts in the Receiver

The same bursts that were read in the receiver can also be checked in the receiver (see TbStream SendCheckBurst1.vhd).

```
AxiReceiverProc : process
 variable NumBytes : integer ;
begin
 WaitForClock(StreamReceiverTransRec, 2);
      log("Transmit 32 Bytes -- word aligned");
 PushBurstIncrement(RxRec.BurstFifo, 3, 32, FIFO_WIDTH) ;
 CheckBurst(RxRec, 32);
 WaitForClock(RxRec, 4);
      log("Transmit 30 Bytes -- unaligned");
 PushBurst(RxRec.BurstFifo, (1,3,5,7,9,11,13,15,17,19,21,23), WIDTH);
 PushBurst(RxRec.BurstFifo, (31,33,35,37,39,41,43,45,47,49,1,3), WIDTH);
 CheckBurst(RxRec, 30);
 WaitForClock(RxRec, 4);
      log("Transmit 34 Bytes -- unaligned");
 PushBurstRandom(RxRec.BurstFifo, 7, 34, FIFO WIDTH);
 CheckBurst(RxRec, 34);
```

13 About the OSVVM Model Independent Transactions

OSVVM Model Independent Transactions were developed and are maintained by Jim Lewis of SynthWorks VHDL Training. These evolved from methodology and packages developed for SynthWorks' VHDL Testbenches and verification class. They are part of the Open Source VHDL Verification Methodology (OSVVM) model library (osvvm_common), which brings leading edge verification techniques to the VHDL community.

Please support OSVVM by purchasing your VHDL training from SynthWorks.

14 About the Author - Jim Lewis

Jim Lewis, the founder of SynthWorks, has thirty plus years of design, teaching, and problem solving experience. In addition to working as a Principal Trainer for SynthWorks, Mr Lewis has done ASIC and FPGA design, custom model development, and consulting.

Mr. Lewis is chair of the IEEE 1076 VHDL Working Group (VASG) and is the primary developer of the Open Source VHDL Verification Methodology (OSVVM.org) packages. Neither of these activities generate revenue. Please support our volunteer efforts by buying your VHDL training from SynthWorks.

If you find bugs these packages or would like to request enhancements, you can reach me at jim@synthworks.com.

15 References

[1] Jim Lewis, VHDL Testbenches and Verification, student manual for SynthWorks' class.