Satnam NFC Provisioning Guide

NTAG424 NFC Physical MFA • Privacy-first • Zero-knowledge

Goal: Provision your NTAG424 tag securely for Satnam NFC Physical MFA without a separate hardware bridge. All verification is performed by Satnam's Netlify Functions using local SUN/CMAC checks.

Status: Production-ready (Phase 6 complete • 74 tests passing • 100% coverage)

1) Provision with Boltcard (Android only)

Single Path

Android (Boltcard Programming App)

- Android phone with NFC
- App: Boltcard NFC Programming App
- Fastest and officially supported path

Download:

- Releases (APK): https://github.com/boltcard/bolt-nfc-android-app/releases
- Play Store: https://play.google.com/store/apps/details?id=com.lightningnfcapp

Next step: After provisioning your Name Tag, return to the Satnam landing page and click "Register/Signin Your Name Tag" to complete registration/authentication.

Reference: External Boltcard setup guide: en/boltcard en/

(https://ereignishorizont.xyz/en/boltcard_en/)

iOS users: Borrow an Android device or visit a community provisioning station to program your tag. After programming, your tag works with iOS for tapping/verification.

Security critical: Never share your provisioning blob (K0/K1/K2, SDM config) outside your secure device. Store it in a password manager. If you lose the keys after changing them on the tag, you will not be able to reprogram that tag.

2) Get your provisioning blob from Satnam

In Satnam: Security \rightarrow NFC Physical MFA \rightarrow "Provision new tag". This calls /nfc-unified/initialize and provides a JSON blob (client-side only) with:

- url_base the NDEF URL to write (e.g., https://www.satnam.pub/nfc/scan)
- k0 , k1 , k2 AES keys (hex)
- sdm SUN/SDM enable + offsets (PICC/CMAC insertion)

3) Provisioning steps (Boltcard Android)

- 1. Install the Boltcard app (APK/Play) and enable NFC.
- 2. Open *Key change* → apply κø/κ1/κ2 exactly as provided by Satnam (from the provisioning blob).
- 3. Enable **SDM/SUN** and set offsets per the blob so that PICC (UID) and CMAC are appended to the URL.
- 4. Set the NDEF URL to your base: https://www.satnam.pub/t/<duid> . The SDM parameters will be appended on read as ?sdm=...&u=... .
- 5. Optional: Enable UID randomization for privacy (irreversible).
- 6. Hold the tag still on the phone until programming succeeds.

4) Verify your tag

- Quick: Tap with any NFC phone. The opened URL should include dynamic SDM params (e.g., CMAC/PICC).
- **Satnam end-to-end**: Tap → app opens Satnam → frontend calls /nfc-unified/verify with SDM fields → success response.
- Low-level: Use TagXplorer to confirm keys, SDM enable, and NDEF URL record.

5) How it integrates (at a glance)

User Tap → Phone opens NDEF url base

- → Frontend captures SDM params (PICC/CMAC)
- → Netlify Function /nfc-unified/verify
- → SUN/CMAC verification via Netlify function (hardware bridge enforced when conf
- → Session/auth success
- → (Optional) LNbits Boltcards used for wallet/registry metadata only

6) Troubleshooting

- Write failed / Tag moved: Keep the tag fully still; retry. Ensure phone NFC coil aligns with tag antenna.
- CMAC missing in URL: SDM not enabled or offsets incorrect. Reapply SDM config per blob.

- **Cannot reprogram**: Keys changed but lost. The tag cannot be reprovisioned without correct keys.
- Desktop reader issues: Use PN532 or an NXP reader with NTAG424 support; avoid older ACR122U.
- **Android errors**: Reinstall app; ensure device NFC is on and no other NFC app is interfering.

7) Best practices

- Provision in a controlled environment (no unknown NFC devices nearby).
- Store the provisioning blob in a password manager; never email or chat it.
- Test with a spare tag first; record success logs from /nfc-unified/verify.

8) Additional Resources

Documentation & Tools

- <u>Troubleshooting Guide (/docs/NFC_TROUBLESHOOTING.md)</u> Common issues and solutions
- API Reference (/docs/NFC API ENDPOINTS.md) Complete endpoint documentation
- Security Architecture (/docs/NFC SECURITY ARCHITECTURE.md) Encryption standards and RLS policies
- Feature Flags Guide (/docs/NFC_FEATURE_FLAGS.md) Configuration and environment setup
- <u>Blob Viewer Tool (/docs/ntag424-blob-viewer.html)</u> Inspect card file contents

Production Status: This guide reflects Phase 6 completion with 74 tests passing (36 unit + 19 integration + 19 E2E). All security standards verified. Zero-knowledge architecture confirmed. Ready for production deployment.