Emergency Checklists

Engine Malfunction During Takeoff (with sufficient runway ahead)

Thrust lever	IDLE
Brakes	APPLY
Flaps (if extended)	RETRACT
Engine master	OFF
Alternator, battery master	OFF
Fuel shutoff valve	CLOSED

Engine Malfunction Immediately After Takeoff

Airspeed	Flaps retracted	: 65 KIAS
	Flaps extended	I: 60 KIAS
Fuel shutoff va	lve	CLOSED
Engine master		OFF
FlapsAS REQUIRED (30°		
recommended)		
Alternator, bat	tery master	OFF

Engine Malfunction During Flight

Fuel shutoff valve OPEN (push full in)
Fuel selector BOTH
Electric fuel pump ON
Land ASAP.

Restart After Engine Failure

Note: If the propeller stops at an airspeed ≥ 65 KIAS, the reason for stoppage should be discovered before attempting a restart.

Airspeed 65-85 KIAS (max 100 KIAS) BELOW 13,000 FT Altitude Fuel shutoff valve OPEN (push full in) Fuel selector BOTH Electric fuel pump ON Thrust lever IDLE Engine master OFF THEN ON If propeller does not turn, then starter ON Thrust lever **FULL**

Check engine parameters, power

FADEC Malfunction in Flight: One FADEC Light is Flashing

FADEC test knob PRESS \geq 2 seconds If FADEC light extinguished (LOW warning):

Continue normal flight
If FADEC light illuminated steady (HIGH warning):

Monitor the other FADEC light Land ASAP

Select airspeed to avoid engine overspeed

FADEC Malfunction in Flight: Both FADEC Lights are Flashing

CED load displayCONSIDER UNRELIABLE

FADEC test knob PRESS ≥ 2 seconds If FADEC lights extinguished (LOW warning):

Continue normal flight
If FADEC lights illuminated steady
(HIGH warning):

Check the available engine power Expect engine failure

Select airspeed to avoid engine overspeed

Land ASAP

In case a fuel tank was flown empty:

Fuel selector

BOTH

Electric fuel pump

ON

Check the available engine power, thrust lever response

Land ASAP

Abnormal Engine Behavior

If the engine acts abnormal during flight and the system does not automatically switch to the B-FADEC, it is possible to switch to the B-FADEC manually.

Select an appropriate airspeed to avoid engine overspeed

Force-B switch ON Be prepared for an emergency landing

Land ASAP

Emergency Checklists

OFF

OEE

Engine Fire When Starting Engine on Ground Engine master OFF Fuel shutoff valve CLOSED Electric fuel pump OFF Battery master OFF Fire extinguisher USE

Engine Fire During Takeoff (on Ground)

Engine master	OFF
Fuel shutoff valve	CLOSED
Electric fuel pump	OFF
Battery master	OFF
Fire extinguisher	USE

Engine Fire in Flight

Engine master		OFF
Fuel shutoff valve	CLC	DSED
Electric fuel pump		OFF
Battery master		OFF
Cabin heat and air		OFF
Airspeed	65	KIAS
Emergency Landing With	Engine	RUN
Out procedure		

Electrical Fire In Flight Avionics master Cabin heat and air vents

Cabin neat and air, vents	OFF
Fire extinguisher	USE
All electrical switches except	OFF
alternator, battery master, and	
engine master	
If fire continues:	
Battery master, alternator	OFF
Cabin heat and air, vents	ON
Check circuit breakers, do not reset	
open breakers	
If fire extinguished:	
Avionics master	ON
Turn on electrical equipment requ	ired

to continue flight and land ASAP. Switch breakers ON one at a time, with delay after each.

Engine Shut Down In Flight AirspeedSELECT TO AVOID ENGINE

OVERSPEED (65 KIAS

RECOMMENDED)

Engine master OFF
Fuel shutoff valve CLOSED
Electric fuel pump OFF
To stop propeller (if needed):

Airspeed < 55 KIAS When propeller stopped 65 KIAS

Emergency Landing With Engine Out

Flaps up: 65 KIAS	
Flaps down: 60 KIAS	
CLOSED	
OFF	
FlapsAS REQUIRED (RECOMMEND	
master OFF	
UNLOCK	
SLIGHTLY NOSE UP	
FIRMLY	