Preflight Fluids Magnetos OFF Fuel quantity **CHECK VISUALLY** Fuel sumps DRAIN Left wing, right wing, fuel strainer. Inspect for contamination. Fuel filler caps **SECURE** Engine oil level **CHECK** Minimum 6 quarts Cabin **REMOVE** Pitot cover POH **VERIFY PRESENT** Master ON Flaps **EXTEND** Fuel gauges **CHECK QUANTITY** Lights **CHECK** Tach time RECORD **TEST** Pitot heat OFF Master Fire extinguisher **SECURE** Control lock **REMOVE** Empennage Rudder gust lock **REMOVE** Control surfaces CHECK Freedom of movement and security Right CHECK INFLATION Main wheel tire Aileron CHECK Freedom of movement and security Nose **CHECK** Propeller, spinner For nicks and security Landing light **CHECK CLEAR** Air filter **CHECK CLEAR** Nosewheel & strut **CHECK INFLATED** CHECK CLEAR Static source Left Main wheel tire CHECK INFLATION

Preflight (continued)		
Fuel tank vent	CHECK CLEAR	
Pitot tube	CHECK CLEAR	
Stall warning	TEST	
Aileron	CHECK	
Freedom of movement and security		
Final		
Final		
Flight Circle	DISPATCH	
	DISPATCH RECORD	
Flight Circle		
Flight Circle Tach, Hobbs times	RECORD	

Securing	
Control lock	INSTALL
Tie-downs, chocks	APPLY
Vents, windows	CLOSE
Pitot cover	APPLY
Tach, Hobbs times	RECORD
Flight Circle	CHECK IN
Doors	LOCK

Speeds		
		KIAS
Best glide (V _G)		65
Best angle of climb (V _x)	Sea level 10,000 ft	64 62
Best rate of climb (V _Y)	Sea level 10,000 ft	78 68
Landing approach	Flaps up Flaps 40	60-70 55-65
Normal takeoff climb		70-80
Short-field takeoff climb	Flaps up Flaps 10	59 55
Normal enroute climb	Sea level 10,000 ft	80-90 70-80
Design maneuvering speed (V _A)	2300 lbs 1950 lbs 1600 lbs	97 89 80

Aircraft on the Ground Cleared for takeoff Cleared for taxi STOP Taxi clear of the runway in use Exercise extreme caution Aircraft in Flight Cleared to land Return for landing (to be followed by steady green at the proper time) Give way to other aircraft and continue circling Airport unsafe, do not land Exercise extreme caution Exercise extreme caution

Operating Checklists

Start	
Before Start	
Preflight inspection	COMPLETE
Passenger briefing	COMPLETE
Brakes	TEST and SET
Seats, belts, harnesses	SECURE
Fuel valve	BOTH
Radios, electrical equipment	OFF
Circuit breakers	CHECK IN
Beacon switch	ON
Engine Start	
Mixture	RICH
Carburetor heat	COLD
Prime	AS REQUIRED
Throttle	OPEN 1/8 INCH
Master	ON
Propeller area	CLEAR
Ignition switch	START
Release whe	en engine starts
Oil pressure	CHECK
If no pressure in 30 sec	onds, shutdown
Mixture	GROUND LEAN
Before Taxi	
Avionics	ON
Headset	ON
Flaps	RETRACT
Weather	OBTAIN
Altimeter	SET
EFB Setup	AS DESIRED
Navigation, landing lights	ON

Run-up	
Instruments	CHECK and SET
VOR Check	IF NEEDED
Brakes	SET
Doors and windows	CLOSED, LOCKED
Flight controls	FREE and CORRECT
Fuel valve	вотн
Mixture	RICH (below 3000 feet)
Throttle	1700 RPM
Magnetos	CHECK
Max drop 12	5 RPM, max diff. 50 RPM
Engine gauges, amm	eter CHECK
Vacuum gauge	CHECK
Carburetor heat	TEST
Idle	TEST
Mixture	GROUND LEAN
Throttle friction	ADJUST

Before Takeoff	
Radios	SET
Instruments	SET
Takeoff briefing	COMPLETE
Beacon, navigation,	landing lights ON
Carburetor heat	AS REQUIRED
Flaps	0-10°
Trim	TAKEOFF
Fuel valve	BOTH
Fuel quantity	CHECK
Mixture	RICH (below 3000 feet)

70-90 KIAS
FULL
RICH (lean above 3000 feet)

Cruise	
Power	2200-2700 RPM
	No more than 75% power
Trim	ADJUST
Mixture	LEAN (for max RPM)

Descent	
Mixture	RICH
Power	AS DESIRED
Carburetor heat	AS REQUIRED
	To prevent carburetor icing

Before Landing	
Fuel valve	вотн
Mixture	RICH
Carburetor heat	ON
Apply full h	neat before closing throttle
Airspeed	60-70 KIAS (flaps UP)
Flaps	AS DESIRED
Airspeed	55-65 KIAS (flaps DOWN)

Balked Landing	
Throttle	FULL
Carburetor heat	COLD
Flaps	20°
Airspeed	55 KIAS
Flaps	RETRACT slowly

After Landing	
Flaps	UP
Caburetor heat	OFF
Mixture	GROUND LEAN

Shutdown	
Brakes	SET
Tach time	RECORD
Radios, electrical equipment	OFF
Mixture	CUT-OFF
Magnetos	OFF
Master	OFF

Version 1 PR 59

Engine Failures, Forced Landings

Engine Failure During Takeoff Run Throttle IDLE Brakes APPLY Flaps RETRACT Mixture CUT-OFF Magnetos OFF

Engine Failure Shortly After Takeoff Airspeed Flaps up: 65 KIAS Flaps down: 60 KIAS Mixture CUT-OFF Fuel valve OFF Magnetos OFF Flaps AS REQUIRED Master OFF

Engine Failure During Flight			
Airspeed	65 KIAS		
Carburetor heat	ON		
Fuel valve	ВОТН		
Mixture	RICH		
Magnetos	вотн		
	(START if prop stopped)		
Primer	IN and LOCKED		

Forced	Landing V	Vith Engine Failure
Airspee	d	Flaps up: 65 KIAS
		Flaps down: 60 KIAS
Mixture		CUT-OFF
Fuel val	lve	OFF
Magnet	os	OFF
Flaps		AS REQUIRED
		40° recommended
Master		OFF
Doors	UNLATCH B	BEFORE TOUCHDOWN
Touchdo	own	SLIGHTLY TAIL LOW
Brakes		APPLY HEAVILY

Precautionary L	anding.
Flaps	20°
Airspeed	60 KIAS
Selected field	FLY OVER
Note	terrain/obstructions.
Retra	ct flaps upon reaching
a safe	altitude and airspeed.
Radios, electrical	switches OFF
Flaps	40° (on final approach)
Airspeed	60 KIAS
Master	OFF
Doors UNLATCH	BEFORE TOUCHDOWN
Touchdown	SLIGHTLY TAIL LOW
Magnetos	OFF
Brakes	APPLY HEAVILY

Ditching			
Radio	MAYDAY on 121.5 MHz		
	Give location, intentions		
Heavy objects	SECURE or JETTISON		
Flaps	20°-40°		
Power 300 FT/	MIN DESCENT AT 55 KIAS		
If no power	available, approach		
flaps up 65	KIAS or flaps 10° 60 KIAS		
Strong wind, heavy seas:			
LAND INTO W			
Light wind, hea	vy swells:		
LAND PARALL	EL TO SWELLS		
Doors	UNLATCH		
Touchdown	LEVEL ATTITUDE		
at es	stablished rate of descent		
Face CUSHIOI	N at touchdown with coat		
Airplane	EVACUATE		
Life vests/raft	INFLATE		

Fires, Icing, Flat Tire, Electrical

Wing Fire

Cranking	CONTINUE	
If engine starts:		
Power	1700 RPM for a few minutes	
Engine	SHUTDOWN	
If engine fails to	start:	
Throttle	FULL OPEN	
Mixture	CUT-OFF	
Cranking	CONTINUE for 2-3 minutes	
Fire extinguish	er OBTAIN	
Master	OFF	
Magnetos	OFF	
Fuel valve	OFF	
Fire	EXTINGUISH	
Use fire	e extinguisher, seat cushion,	
wool bl	anket, or dirt. If practical, try	
to remove air filter if it is ablaze.		
Both cases: inspect and repair damage		
before conductin	g another flight.	

Engine Fire During Start On Ground

	Engine Fire in Flight		
	Mixture	CUT-OFF	
	Fuel valve	OFF	
Master			
	Cabin heat & air	OFF	
(except overhead vent			
Airspeed 100 KI			
	If fire is not extinguished, increase		
	glide speed to find an airspeed which		
will provide an incombustible mixtur			
	Forced Landing With	FXFCUTF	

Engine Failure checklist

Electrical Fire in Flight		
Master	OFF	
All other switches (except magnetos)	OFF	
Vents/cabin air/heat	CLOSE	
Fire extinguisher	USE	
If fire appears out and electrical power is		
necessary to continue flight:		
Master ON		
Circuit breakers CHE		
(do not reset faulty circuit)		
Radio/electrical switches	ON	
One at a time with delay a	fter	
each until short circuit is localized		
Vents/cabin air/heat	OPEN	

	Cabin Fire	
	Master	OFF
	Vents/cabin air/heat	CLOSED
		(to avoid drafts)
	Fire extinguisher	USE
WARNING: After discharging extinguish		
within a closed cabin, ventilate cabin		
	Land ASAP, inspect for dama	ige

(when fire completely extinguished)

nav lights	Οr
Pitot heat	OF
NOTE: Sideslip to keep flames away from	
fuel tanks and cabin. Land ASAP using fla	ps
only as required.	
Inadvertent Icing Encounter	
Pitot heat	0

	Inadvertent Icing Encounter			
	Pitot heat (
	Turn back or change altitude to obtain an			
	OAT less conducive to icing.			
Cabin heat FULL C				
Defroster OPE				
	Cabin air ADJUS			
	Maximize defroster h	neat and airflow		
	Throttle	OPEN		
	Carburetor/air filter icing	MONITOR		
	Apply carb heat as required, lean mixture			
	for maximum RPM if used	,		
	Land NEAREST AIRPOR			
	With very rapid ice build-up, selec			
	suitable off-airport	3		
	With ≥ 1/4 inch ice on the lea			
	prepare for significantly highe			
		AVE RETRACTED		
	Open left window and scrape ice from			
	windshield, if necessary for visibility Forward slip if necessary for visibility Approach speed 65-75 KIAS Depending on level of accumulation Landing Perform in level attitude			
	Landing Perform	iii ievei attitude		

Static Source blocks	ige	
Alternate static source	valve	PULL ON
Airspeed	Use cal	ibration table
	in POH	section 5

Landing with a Flat Main Tire		
Approach	NORMAL	
Touchdown	GOOD TIRE FIRST	
Hold airplane	off flat tire as long as possible	

Over-Voltage Light Illuminates		
Master	OFF (both sides)	
Master	ON	
If over-voltage light illuminates again:		
Flight	TEDMINIATE ASAD	

Ammeter Shows Discharge			
Alternator		OFF	
Nonessential electrical equipment		OFF	
Flight	TERMINATE as soon as	practical	