Atrial fibres

Standard Operating Procedure for Analysis with CemrgApp

1. Segmentation to labelled mesh

1.1 Images (Automatic) pipeline

- 1. Click on the menu: Window > Open Perspective > Cemrg Universal Atrial Coordinates
- 2. Click on Step3: Analysis Selector.
 - a) Select the project folder when prompted.
 - b) Make sure Images Automatic is selected and Consider LGE Scar projection ticked.
 - c) Select the MRA nii file (name starts with dcm-MRA)
 - i) Wait for automatic segmentation to occur.
 - ii) Wait for registration/transformation of segmentation to LGE space.
 - iii) You will then be prompted to select the parameters for creating the mesh form the automatic segmentation. Use the default.

1.2 Images (manual) pipeline

- 1. Click on the menu: Window > Open Perspective > Cemrg Universal Atrial Coordinates
- 2. Click on Step3: Analysis Selector.
 - a) Select the project folder when prompted.
 - b) Make sure Images Manual is selected. Tick Consider LGE Scar projection and Automatic Segmentation (CemrgNet).
 - c) Drag the MRA nii file (name starts with dcm-MRA) from the project folder into CemrgApp
- 3. Select the MRA file on the data manager and press Step4: Segmentation.
 - a) The automatic segmentation and registration step occurs here.
 - b) Once finished, click on the resulting segmentation (LA-reg) and click on the Preprocess Segmentation button.
 - i) The Segmentation Utilities view opens on the right
 - ii) Select Morphological Operations
 - iii) Doing an Opening/Closing: Select an appropriate radius (3-5) and click on Opening/Closing
 - iv) NOTE: Opening: separates joined PVs / Closing: will make some thin structures thicker
- 4. Select the segmentation in the Data Manager. Click Step5: Identify PVs
 - a) When prompted about the parameters, default work in most cases.
 - b) Select (and identify) all PVs and the LAA by hovering the mouse over the desired point and pressing the space bar on the keyboard.
 - c) Click on the Find Centrelines button.
 - d) Click on the Display Clippers button.
 - i) Move the clippers on each PV and LAA using the different tools.
 - ii) Make sure the clippers do not overlap and do not intersect with other structures of the atrium, for example, do not allow the clippers to intersect with the atrial body.
- 5. Drag the LGE-MRI to the Data Manager
- 6. Click Step6: Create Labelled Mesh

2. Mesh to fibres (steps common to automatic and manual)

Notice the button numbers are written for the automatic pipeline. They will be different when processing in manual.

2.1 Mesh preprocessing and PV clipping

- 1. Click Step4: Mesh Preprocessing.
 - a) Fix any mislabelling, selecting points with "X" and the Fix Mesh Labelling button
 - b) Identify PVs, MV, and LAA using the Spacebar. (Note: No need to Identify & Clip MV manually if used Automatic image pipeline in Step 1.).
 - c) Click Store Landmarks and Labels
 - d) Adjust the clippers' sizes using the slider at the bottom.
 - e) Move the sphere centre pressing "C" on the keyboard (tip: make the sphere small before moving)
 - f) Click Save clippers (at the bottom right)
 - g) Close panel
- 2. Click Step5: Clip PVs and/or MV. This step clips the mesh using the previously saved clippers and relabels the PVs and LAA to the default values.

2.2 UAC and Atrial fibres

- 1. Click Step 6: Select Landmarks
 - a) Select Rough (spacebar) landmarks. Then click the Save Rough Landmarks button.
 - b) Select the Refined ("X") landmarks. Then click the Save Refined Landmarks button.
- 2. Click StepW: Verify Labels. This step runs a connectivity filter on each of the labels.
 - a) If the labels are correct, the user is notified.
 - b) If there is a connectivity issue, click to fix automatically. If this fails, then go to Step4 and fix the labels manually.
- 3. Click StepX: Mesh Improvement. Use default values.
 - a) This creates clean-Labelled-reg-refined.vtk
 - b) Make sure to check the resulting file is not empty.
- 4. Click StepY: Convert format. Select clean-Labelled-reg-refined.vtk. Use default values.
- 5. Click Step7: Calculate UAC. Select carp pts file (clean-Labelled-reg-refined.pts) when prompted. Select Position: BiLayer, Fibre File 1, with Labelled PVs box ticked
 - a) Click UAC Stage 1 button
 - b) Click UAC Stage 2 button
- 6. Click Step8: UAC Fibre Mapping
 - a) For 'delete auxiliary and temporary files?' click Yes.

2.3 Scar projection

- 1. Click StepZ: Scar projection
 - a. A UI will come up with options for the analysis.
 - b. Make sure you select the Image Intensity Ratio button. All other default values are appropriate