

ARM® Cortex®-M 32-bit Microcontroller

NuMicro™ Family M058S Series BSP Revision History

The information described in this document is the exclusive intellectual property of Nuvoton Technology Corporation and shall not be reproduced without permission from Nuvoton.

Nuvoton is providing this document only for reference purposes of NuMicro microcontroller based system design. Nuvoton assumes no responsibility for errors or omissions.

All data and specifications are subject to change without notice.

For additional information or questions, please contact: Nuvoton Technology Corporation.

www.nuvoton.com



Revision 3.00.004 (Released 2019-11-07)

- 1. Added ISP Sample codes to bsp\SampleCode\ISP folder.
- 2. Supports GNU GCC.
- 3. Fixed PWM DisableCaptureInt bug of PWM Driver.
- 4. Fixed CLK driver CLK_SetHCLK() bug of CLK Driver.
- 5. Fixed CLK_EnablePLL() wrong PLL default setting value in CLK Driver

Revision 3.00.003 (Released 2017-10-20)

- Fixed clear Receive Line Status interrupt flag bug in UART_ClearIntFlag().
- 2. Fixed PLL clock source selection bug in CLK_SetCoreClock().
- 3. Fixed UART SelectLINMode() clear enable bit setting bug.
- 4. Add CLK_SysTickLongDelay() for longer delay time than CLK_SysTickDelay().
- 5. Modified to ignore debug message when enabling semihost without NuLink connected.
- 6. Add constant define "CLK_CLKSEL0_STCLK_S_HCLK" in CLKSEL0 constant definitions for CLK_EnableSysTick() function to select HCLK as sysTick clock source.
- 7. Add new function to control systick and select systick clock source, CLK_EnableSysTick() and CLK_DisableSysTick().
- 8. Add ADC_MeasureAVDD sample code.

Revision 3.00.002 (Released 2015-05-07)

- 1. Fixed UART, I2C, SYS definition error in header file.
- 2. Fixed reset entry pointer setting of IAR projects.
- 3. Add VECMAP relative API to FMC driver.
- 4. Add MCUIRQ control register to GCR INT T.
- 5. Add CAPIC control register to PWM T.
- 6. Add ISPSTA control register to FMC T.

Revision 3.00.001 (Released 2015-04-08)

First Release.



Important Notice

Nuvoton Products are neither intended nor warranted for usage in systems or equipment, any malfunction or failure of which may cause loss of human life, bodily injury or severe property damage. Such applications are deemed, "Insecure Usage".

Insecure usage includes, but is not limited to: equipment for surgical implementation, atomic energy control instruments, airplane or spaceship instruments, the control or operation of dynamic, brake or safety systems designed for vehicular use, traffic signal instruments, all types of safety devices, and other applications intended to support or sustain life.

All Insecure Usage shall be made at customer's risk, and in the event that third parties lay claims to Nuvoton as a result of customer's Insecure Usage, customer shall indemnify the damages and liabilities thus incurred by Nuvoton.

Please note that all data and specifications are subject to change without notice.

All the trademarks of products and companies mentioned in this datasheet belong to their respective owners