

- Home
- About
- Electrical Engineer Jobs
- Request Topic
- Resources



VHDL Type Conversion

Posted by Shannon Hilbert in Verilog / VHDL on 2-10-13


Any given VHDL FPGA design may have multiple VHDL types being used. The most common VHDL types used in synthesizable VHDL code are std_logic, std_logic_vector, signed, unsigned, and integer. Because VHDL is a strongly-typed language, most often differing types cannot be used in the same expression. In cases where you can directly combine two types into one expression, you are really leaving it up to the compiler or synthesis tool to determine how the expression should behave, which is a dangerous thing to do.

This article will discuss the following concepts:

- 1. Type casting and conversion functions.
- 2. The importance of using the appropriate type.
- 3. Common uses and examples.

VHDL Type Cast and Conversion Functions

The picture below illustrates how to convert between the most common VHDL types.



Type casting is used to move between the std_logic_vector type and the signed and unsigned types.

- 1 -- signal definitions
- 2 signal slv: std_logic_vector(7 downto 0);
- 3 signal s : signed(7 downto 0);
- 4 signal us : unsigned(7 downto 0);
- 5

6 --FROM std_logic_vector TO signed/unsigned

1 de 5 07/10/2015 14:58

```
7 sgn <= signed(slv);
8 usgn <= unsigned(slv);
9
10-- FROM signed/unsigned TO std_logic_vector
11svl <= std_logic_vector(sgn);
12svl <= std_logic_vector(usgn);
```

Functions are used to move between signed and unsigned types and the integer type.

```
1 --signal definitions
2 signal i: integer;
3 signal sgn: signed(7 downto 0);
4 signal usgn: unsigned(7 downto 0);
5
6 --FROM integer TO signed/unsigned
7 sgn <= to_signed(i,8);</li>
8 usgn <= to_unsigned(i,8);</li>
9
10--FROM signed/unsigned TO integer
11 <= to_integer(sgn);</li>
12i <= to_integer(usgn);</li>
```

An easy way to remember when to use function or type cast is to remember that both the std_logic_vector and signed/unsigned types both are defined with a specific bit width, while integers do not define a bit width.

A type cast between std_logic_vector and signed/unsigned can be used as long as the origin and destination signals have the same bit width. Integers do not have a set bit width, which is why the conversion function from integer to signed/unsigned includes a specification of the intended bit width.

As a side note on integers:

Notice that there is no direct conversion path between the std_logic_vector type and the integer type. Integer types do not have a set width, unlike signed, unsigned, and std_logic_vector types. To convert between integer and std_logic_vector types, you must first convert to signed or unsigned.

If you do not restrict the range when defining an integer, the compiler will assume a 32-bit width. Depending on your synthesis tool and its settings, the default bit width of 32 may or may not be optimized out to the appropriate bit width.

Using the Correct VHDL Type

Although it's possible to perform many math functions using the std_logic_vector type, doing that is unnecessarily difficult in digital signal processing (DSP) designs. Use the signed and unsigned types to keep track of your precision and sign type. After all, why use VHDL if you're not going to harness the power of the strong typing?

Don't leave it up to the compiler or synthesis tool to figure out what operation you want to perform or what an expression result should be!

Common Uses and Examples

Some common examples of situations needing to use type casting or conversion are in mathematical expressions. Another very common use is when you want to use a counter value as in index into an array. There are many more uses, but we'll just take a look at these two.

Take a look at what happens when we subtract two unsigned numbers:

```
1signal sum_u: unsigned(11 downto 0);

2signal sum_s: signed(11 downto 0);

3constant a: unsigned(3 downto 0) := X"A";

4

5sum_u <= counter_fr + (X"00" & a);

6sum_s <= signed(counter_fr) + signed(X"00" & a);
```

Depending on whether the result is defined as signed or unsigned, the results are drastically different. When counter_fr holds the value 1000 (binary), sum_u=18 and sum_s=2. That's because the binary value 1000 is 8 unsigned and -8 two's complement signed.

Another common use is converting a std_logic_vector or unsigned type to an integer so that it can be used as an array index. Arrays can only be indexed with integers.

```
1constant vec : std_logic_vector(15 downto 0);
2signal count : std_logic_vector(3 downto 0);
3signal element : std_logic_vector(0 downto 0);
4...
5element <= vec(to_integer(unsigned(count),4));
```

2 de 5 07/10/2015 14:58

Happy coding!

We want to hear from you! Do you have a comment, question, or suggestion? Feel free to drop us an email or post a comment.

Related content:

- VHDL Shift Register
 VHDL Counter
- 3. Verilog vs. VHDL



Submit a Comment

You must be logged in to post a comment.

Bitweenie on Twitter

- RT <u>@NikolaT_bw</u>: Part 3 of the <u>@bitweenie</u> <u>#Altium</u> <u>#pcbdesign</u> video tutorial is up: <u>http://t.co</u> /SpVnf2srH8 Learn the basics of #pcblayout in... about 2 years ago from TweetDeck ReplyRetweetFavorite
- @SHilbertBW posted part 2 of the #Xilinx system generator video series for doing #DSP #FPGA designs. http://t.co/GSQKLuMbJu about 2 years ago from TweetDeck in reply to SHilbertBW ReplyRetweetFavorite
- @shilbertbw just posted a good graphic to keep around the office, showing how to convert between #VHDL data types http://t.co/YRLQ7Nb5sC about 2 years ago from TweetDeck in reply to SHilbertBW ReplyRetweetFavorite

@@bitweenie

Topics

 $\underline{Altium\ bit\ BRAM\ byte\ cast\ clock\ distribution\ cons\ conversion\ }\underline{counter\ crosstalk\ dBm\ dBm/Hz\ dds\ direct\ digital}$ synthesizer dsp fft resolution fixed point floating point FPGA fpga programming function matlab model pcb construction pcb design pcb fabrication pcb layers PCB Materials pcb stackup power spectral density POWER SPECTRUM pros psd quantization Shift register simulation simulink system generator thermal noise two-dimensional type type conversion verilog VHDL xillinx

Recent Posts

Converting dBm to Watts

Recent Comments

• Oishi on Verilog vs. VHDL

3 de 5 07/10/2015 14:58

4 de 5 07/10/2015 14:58

© BitWeenie, LLC

Privacy Policy

Site Map

Designed by <u>Elegant Themes</u> | Powered by <u>WordPress</u>

5 de 5