程序的机器级表示

MIPS 指令系统简介

主讲人: 邓倩妮

上海交通大学





本节内容



■ MIPS 指令系统







MIPS的设计者、RISC的先驱

John Hennessy

- 1977年,进入斯坦福大学任职
- 1981年, 领导RISC微处理器的研究小组
- 1984年, 共同创立MIPS计算机系统公司
- 2000年, 任斯坦福大学校长
- 2018年,与Patterson 共同获得图灵奖



约翰.亨尼西



大卫·帕特森

David A. Patterson

- 1976~2016年, UC Berkeley计算机教授;
- 1990年,与Hennessy合著教材:Computer Architecture: A Quantitative Approach
- 2016年,加入谷歌TPU团队
- 2018年,与Hennessy 共同获得图灵奖



MIPS指令集发展过程

LUNE TO THE TOTAL THE TOTAL TO THE TOTAL TOT

- 1981年, MIPS I
- MIPS II
- MIPS III
- MIPS IV
- MIPS V
- 嵌入式指令体系MIPS16
- 1999年,MIPS32、MIPS64
- 龙芯2号: MIPS64



MIPS 的设计思想



- MIPS的全称
 - Microprocessor without Interlocked Piped Stages
- 主要关注点
 - 减少指令的类型
 - 降低指令复杂度
- 基本原则
 - A simpler CPU is a faster CPU.





MIPS指令系统的特征

- ■简单
 - 指令定长,都是32位。
 - 指令数量少、功能简单
 - 指令格式简单,只有三种:
 - 立即数型 (I) 、转移型 (J) 、寄存器型 (R)
 - 操作数寻址方式少:
 - 基址加16位偏移量的访存寻址
 - 立即数寻址
 - 寄存器寻址



MIPS指令系统的特征(续)




- 使用较多寄存器
 - 寄存器访问速度比存储器快
 - 32个通用寄存器
- 只有Load和Store指令可以访问存储器
 - 例如,不支持x86指令的这种操作:ADD AX,[3000H]
- ■需要优秀编译器支持
 - 无互锁流水段,依靠编译器进行指令序列的重新安排, 减少流水线中出现的冲突




MIPS寄存器



63	32 31	0
	r0	
	r1	
	r2	
	•	
	•	
	•	
	•	
	r29	
	r30	
	r31	







MIPS通用寄存器(32位宽)用途




编号	名称	用途	编号	名称	用途
0	\$zero	The Constant Value 0	24-25	\$t8-\$t9	Temporaries
1	\$at	Assembler Temporary	26-27	\$k0-\$k1	Reserved for OS Kernel
2-3	\$v0-\$v1	Values for Function Results and Expression Evaluation	28*	\$gp	Global Pointer
4-7	\$a0-a3	Arguments	29*	\$sp	Stack Pointer
8-15	\$t0-\$t7	Temporaries	30*	\$fp	Frame Pointer
16-23*	\$s0-\$s7	Saved Temporaries	31*	\$ra	Return Address

^{*} 在过程调用时需要保存, Preserved across a call



MIPS指令的三种格式







MIPS指令操作码定义



I28~I26	000	001	010	011	100	101	110	111
I31~I29								
000	R格式	Bltz/gez	j	jal	beq	bne	blez	bgtz
001	addi	addiu	slti	sltiu	andi	ori	xori	lui
010	TLB 指令	浮点指令						
011								
100	lb	lh	lwl	lw	lbu	lhu	lwr	
101	sb	sh	swl	SW			swr	
110	lwc0	lwc1						
111	swc0	swc1						



MIPS数据传递指令



指令举例	操作	说明
lw \$1,100(\$2)	\$1=M[\$2+100]	装入字
sw \$1,100(\$2)	M[\$2+100]=\$1	存储字
lui \$1,100	$$1=100 \times 2^{16}$	装入立即数到高位




MIPS 数据传递指令 Memory Access

两种数据传送指令:


- lw \$t0, 4(\$s3) #load word from memory sw \$t0, 8(\$s3) #store word to memory
- The data is loaded into (lw) or stored from (sw) a register in the register file – a 5 bit address
- 要访问的存储地址— a 32 bit address —基址加16位偏移量 formed by adding the contents of the base address register to the offset value
 - 16位偏移量 将访问范围限制在基地址偏移量为 ±2¹⁵ 或 32,768 bytes 的范围

Load/Store 指令格式 (I 型):



$$24_{10} + \$s3 =$$

... 0001 1000 + ... 1001 0100 ... 1010 1100 = 0x120040ac





指令: load 和 store 一个字节



sb \$t0, 6(\$s3) #store byte to memory

0x28 19 8	16 bit offset
-----------	---------------

□ 如何 load 和 store 一个字节?

load byte places the byte from memory in the rightmost 8 bits of the destination register

- what happens to the other bits in the register?

store byte takes the byte from the rightmost 8 bits of a register and writes it to a byte in memory

- what happens to the other bits in the memory word?



Example of Loading and Storing Bytes

• 给定指令序列、当前的存储器状态,大端方式存储:

add \$s3, \$zero, \$zero lb \$t0, 1(\$s3) sb \$t0, 6(\$s3)

Memory	
0x 0 0 0 0 0 0 0	24
0x 0 0 0 0 0 0 0 0	20
0x 0 0 0 0 0 0 0	16
0x1000010	12
0x 0 1 0 0 0 4 0 2	8
0x	4
0x 0 0 9 0 1 2 A 0	0
Data	Word Address (Decimal)

■ What value is left in \$t0? \$t0 = 0x00000090

■ What word is changed in Memory and to what?

$$mem(4) = 0xFFFF90FF$$

■ What if the machine was little Endian?

$$t0 = 0x00000012$$

$$mem(4) = 0xFF12FFFF$$



MIPS算术运算指令



指令举例	操作	说明
add \$1,\$2,\$3	\$1=\$2+\$3	寄存器加法
sub \$1,\$2,\$3	\$1=\$2-\$3	寄存器减法
addi \$1,\$2,100	\$1=\$2+100	立即数加法
addu \$1,\$2,\$3	\$1=\$2+\$3	无符号数加法
subu \$1,\$2,\$3	\$1=\$2-\$3	无符号数减法
addiu \$1,\$2,100	\$1=\$2+100	无符号立即数加法
mfco \$1,\$epc	\$1=\$epc	读取异常 PC
mult \$2,\$3	Hi,Lo=\$2×\$3	乘法
multu \$2,\$3	Hi,Lo=\$2×\$3	无符号数乘法
div \$2,\$3	Lo=\$2/\$3, Hi=\$2 mod \$3	除法
divu \$2,\$3	Lo=\$2/\$3, Hi=\$2 mod \$3	无符号数除法
mfhi \$1	\$1=Hi	从 Hi 中取数据
mflo \$1	\$1=10	从 lo 中取数据

MIPS 立即数(Immediate)指令 (I 型):

- □ 典型代码中常常会用到一些值不算大的常数
- 直接在指令中包含这些常数,速度比从存储器或寄存器中获得它们要快?

addi \$sp, \$sp, 4
$$#$sp = $sp + 4$$

slti \$t0, \$s2, 15 $#$t0 = 1 if $s2<15$

0x0A	18	8	0x0F
------	----	---	------

□ The constant is kept inside the instruction itself!

立即数的范围: $+2^{15}$ —1 to -2^{15}

what about upper 16 bits?

How About Larger Constants?

• 使用两条指令

lui \$t0, 10101010101010

16	0	8	10101010101010102
			_

ori \$t0, \$t0, 10101010101010

1010101010101010	0000000	0000000
000000000000000	10101010	010101010

1 0 1 0 1 0 1 0 1 0 1 0 1 0 1	$1 \cap 1 \cap 1$

why can't addi be used as the second instruction for this 32 bit constant?

MIPS Shift Operations

- Need operations to pack and unpack 8-bit characters into 32-bit words
- Shifts move all the bits in a word left or right

Instruction Format (R format)

0	16	10	8	0x00
---	----	----	---	------

Such shifts are called logical because they fill with zeros
 Notice that a 5-bit shamt field is enough to shift a 32-bit value 2⁵

 1 or 31 bit positions

MIPS Logical Operations

 There are a number of bit-wise logical operations in the MIPS ISA

```
and $t0, $t1, $t2  #$t0 = $t1 & $t2 or $t0, $t1, $t2 #$t0 = $t1 | $t2 nor $t0, $t1, $t2 #$t0 = not($t1 | $t2)
```

Instruction Format (R format)

10

andi	\$t0,	\$t1,	0xFF00	#\$t0 =	=	\$t1	&	ff00
ori	\$t0,	St.1.	0×FF00	#\$t0 =	_	\$t.1		ff00

0x24

Instruction Format (I format)

0x0D	9	8	0xFF00
0//0/	0		0/(1/00



MIPS逻辑运算指令



指令举例	操作	说明
and \$1,\$2,\$3	\$1=\$2&\$3	与操作
or \$1,\$2,\$3	\$1=\$2 \$3	或操作
andi \$1,\$2,100	\$1=\$2&100	立即数与操作
ori \$1,\$2,100	\$1=\$2 100	立即数或操作
sll \$1,\$2,10	\$1=\$2<<10	逻辑左移
srl \$1,\$2,10	\$1=\$2>>10	逻辑右移



MIPS R格式指令扩展操作码定义

I2~I0	000	001	010	011	100	101	110	111
I5~I3								
000	sll		srl	sra	sllv		srlv	srav
001	j \$r	jalr			syscall	break		
010	mfhi	mthi	mflo	mtlo				
011	mult	multu	div	divu				
100	add	addu	sub	subu	and	or	xor	nor
101			slt	sltu				
110								
111								

MIPS Control Flow Instructions

• MIPS conditional branch instructions:

```
bne $s0, $s1, Lbl #go to Lbl if $s0 \neq $s1 beq $s0, $s1, Lbl #go to Lbl if $s0 = $s1
```

```
• Ex: if (i==j) h = i + j;
bne $s0, $s1, Lb11
add $s3, $s0, $s1
Lb11: ...
```


■ Instruction Format (I format):

0x05 16 1/ 16 bit offset

How is the branch destination address specified?

Specifying Branch Destinations

from the low order 16 bits of the branch instruction




- Use a register (like in lw and sw) added to the 16-bit offset
 - which register? Instruction Address Register (the PC)
 - its use is automatically implied by instruction
 - PC gets updated (PC+4) during the fetch cycle so that it holds the address of the next instruction
 - limits the branch distance to -2^{15} to $+2^{15}$ –1 (word) instructions from the (instruction after the) branch instruction, but most branches are local anyway

In Support of Branch Instructions

- We have beq, bne, but what about other kinds of branches (e.g., branch-if-less-than)? For this, we need yet another instruction, slt
- Set on less than instruction:

• Instruction format (R format):



Alternate versions of slt

```
slti $t0, $s0, 25  # if $s0 < 25 then $t0=1 ...

sltu $t0, $s0, $s1  # if $s0 < $s1 then $t0=1 ...

sltiu $t0, $s0, 25  # if $s0 < 25 then $t0=1 ...
```

Aside: More Branch Instructions

 Can use slt, beq, bne, and the fixed value of 0 in register \$zero to create other conditions

```
less than
blt $$1, $$2, Label
slt $$at, $$1, $$2
bne $$at, $$zero, Label
#$$1 < $$2</li>
#$$at set to 1 if
bne $$at, $$zero, Label
#$$1 < $$2</li>
Label
greater than
great than or equal to
bge $$1, $$2, Label
great than or equal to
bge $$1, $$2, Label
```

 Such branches are included in the instruction set as pseudo instructions - recognized (and expanded) by the assembler

Its why the assembler needs a reserved register (\$at)



MIPS Instructions



Consider a comparison instruction: slt \$t0, \$t1, \$zero and \$t1 contains the 32-bit number 1111 01...01

What gets stored in \$t0?



MIPS Instructions



Consider a comparison instruction: slt \$t0, \$t1, \$zero

and \$t1 contains the 32-bit number 1111 01...01

What gets stored in \$t0?

The result depends on whether \$11 is a signed or unsigned number – the compiler/programmer must track this and accordingly use either slt or sltu

```
slt $t0, $t1, $zero stores 1 in $t0 sltu $t0, $t1, $zero stores 0 in $t0
```

Bounds Check Shortcut

• Treating signed numbers as if they were unsigned gives a low cost way of checking if $0 \le x < y$ (index out of bounds for arrays)

• The key is that negative integers in two's complement look like large numbers in unsigned notation. Thus, an unsigned comparison of x < y also checks if x is negative as well as if x is less than y.


Other Control Flow Instructions

■ Instruction Format (J Format):

0x02	26-bit address
0/10/2	20 bit address

MIPS also has an unconditional branch instruction or jump instruction:

from the low order 26 bits of the jump instruction





Aside: Branching Far Away

- What if the branch destination is further away than can be captured in 16 bits?
- The assembler comes to the rescue it inserts an unconditional jump to the branch target and inverts the condition

becomes

L2:



MIPS条件转移指令



指令举例	操作	说明
beq \$1,\$2,100	if $($1==$2)$ go to $PC+4+100$	相等时转移
bne \$1,\$2,100	if(\$1!=\$2) go to PC+4+100	不相等时转移
slt \$1,\$2,\$3	if(\$2<\$3) \$1=1;else \$1=0	小于时置位
slti \$1,\$2,100	if(\$2<100) \$1=1;else	小于立即数时置位
	\$1=0	
sltu \$1,\$2,\$3	if(\$2<\$3) \$1=1;else \$1=0	小于无符号数时置
		位
sltiu \$1,\$2,100	if(\$2<100) \$1=1;else	无符号数小于立即
	\$1=0	数时置位



MIPS无条件转移指令



指令举例	操作	说明
j 10000	go to 10000	转移到 10000
jr \$31	go to \$31	转移到\$31
jal 10000	\$31=PC+4; go to 10000	转移并链接

Compiling Another While Loop

 Compile the assembly code for the C while loop where i is in \$s3, k is in \$s5, and the base address of the array save is in \$s6

```
while (save[i] == k)
i += 1;
```



Compiling Another While Loop

 Compile the assembly code for the C while loop where i is in \$s3, k is in \$s5, and the base address of the array save is in \$s6

```
while (save[i] == k)
    i += 1;

Loop: sll $t1, $s3, 2
    add $t1, $t1, $s6
    lw $t0, 0($t1)
    bne $t0, $s5, Exit
    addi $s3, $s3, 1
    j Loop
Exit: . . .
```



思考题



■ MIPS指令系统有哪些优点? 哪些缺点?

谢谢!

