

TPS54202H (main +14V)

<https://www.ti.com/lit/ds/symlink/tps54202h.pdf?ts=1771882131912>

Setting the output voltage (E96):

$V_{OUT} = V_{ref} \times \left[\frac{R2}{R3} + 1 \right]$	R3 11 kR	R2 249 kR	V_{ref} 0,596 V	V_{OUT} 14,1 V
---	-------------	--------------	----------------------	---------------------

Setting under voltage-lockout:

$R4 = \left(\frac{V_{ENfalling} \times V_{START} - V_{STOP}}{V_{ENrising}} \right) / I_h$	$V_{ENfalling}$ 1,25 V	$V_{ENrising}$ 1,28 V	V_{START} 15 V	V_{STOP} 14 V	I_h 1 μ A	R4 648,4 kR	649kR E96
$R5 = \frac{R4 \times Rpd}{\left(\frac{V_{START}}{V_{ENrising}} - 1 \right) \times Rpd - R4}$	R4 648,4 kR	$V_{ENrising}$ 1,28 V	V_{START} 15 V	Rpd 1 MR		R5 64,4 kR	64,9kR E96

Setting the minimum value of the output inductor

$L_{MIN} = \frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{V_{IN(MAX)} \times K_{IND} \times I_{OUT} \times f_{sw}}$	V_{OUT} 14,1 V	$V_{IN(MAX)}$ 24 V	K_{IND} 0,3	I_{OUT} 0,85 A	f_{sw} 500 kHz	L_{MIN} 45,6 μ H	47 μ H E12
--	---------------------	-----------------------	------------------	---------------------	---------------------	---------------------------	----------------

Setting the RMS inductor current

$L_{RMS} = \sqrt{\frac{V_{OUT}}{f_{sw}} \times \left(\frac{1}{2} \times \left(\frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{V_{IN(MAX)} \times I_{OUT} \times f_{sw}} \right)^2 \right)}$	V_{OUT} 14,1 V	$V_{IN(MAX)}$ 24 V	L_O 47 μ H	$I_{OUT(MAX)}$ 1,2 A	f_{sw} 500 kHz	$L_{L(MAX)}$ 1,20 A
---	---------------------	-----------------------	---------------------	-------------------------	---------------------	------------------------

Setting the peak inductor current

$L_{PK} = \frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{1,8 \times V_{IN(MAX)} \times I_{OUT} \times f_{sw}}$	V_{OUT} 14,1 V	$V_{IN(MAX)}$ 24 V	L_O 47 μ H	$I_{OUT(MAX)}$ 1,2 A	f_{sw} 500 kHz	$I_{L(PK)}$ 1,35 A
---	---------------------	-----------------------	---------------------	-------------------------	---------------------	-----------------------

TPS54202H (+7V)

<https://www.ti.com/lit/ds/symlink/tps54202h.pdf?ts=1771882131912>

Setting the output voltage (E96):

$V_{OUT} = V_{ref} \times \left[\frac{R2}{R3} + 1 \right]$	R3 15 kR	R2 165 kR	V_{ref} 0,596 V	V_{OUT} 6,98 V
---	-------------	--------------	----------------------	---------------------

Setting under voltage-lockout:

$R4 = \left(\frac{V_{ENfalling} \times V_{START} - V_{STOP}}{V_{ENrising}} \right) / I_h$	$V_{ENfalling}$ 1,25 V	$V_{ENrising}$ 1,28 V	V_{START} 14 V	V_{STOP} 13 V	I_h 1 μ A	R4 671,9 kR	681kR E96
$R5 = \frac{R4 \times Rpd}{\left(\frac{V_{START}}{V_{ENrising}} - 1 \right) \times Rpd - R4}$	R4 681 kR	$V_{ENrising}$ 1,28 V	V_{START} 14 V	Rpd 1 MR		R5 73,6 kR	73,2kR E96

Setting the minimum value of the output inductor

$L_{MIN} = \frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{V_{IN(MAX)} \times K_{IND} \times I_{OUT} \times f_{sw}}$	V_{OUT} 6,98 V	$V_{IN(MAX)}$ 24 V	K_{IND} 0,3	I_{OUT} 0,15 A	f_{sw} 500 kHz	L_{MIN} 220 μ H	exact E12
--	---------------------	-----------------------	------------------	---------------------	---------------------	--------------------------	-----------

Setting the RMS inductor current

$L_{RMS} = \sqrt{\frac{V_{OUT}}{f_{sw}} \times \left(\frac{1}{2} \times \left(\frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{V_{IN(MAX)} \times I_{OUT} \times f_{sw}} \right)^2 \right)}$	V_{OUT} 6,98 V	$V_{IN(MAX)}$ 24 V	L_O 220 μ H	$I_{OUT(MAX)}$ 0,3 A	f_{sw} 500 kHz	$L_{L(MAX)}$ 0,30 A
---	---------------------	-----------------------	----------------------	-------------------------	---------------------	------------------------

Setting the peak inductor current

$L_{PK} = \frac{V_{OUT} \times (V_{IN(MAX)} - V_{OUT})}{1,8 \times V_{IN(MAX)} \times I_{OUT} \times f_{sw}}$	V_{OUT} 6,98 V	$V_{IN(MAX)}$ 24 V	L_O 220 μ H	$I_{OUT(MAX)}$ 0,3 A	f_{sw} 500 kHz	$I_{L(PK)}$ 0,33 A
---	---------------------	-----------------------	----------------------	-------------------------	---------------------	-----------------------

LT3471 ($\pm$ 18V)

<https://www.mouser.pl/datasheet/3/1014/1/3471fb.pdf>

Setting the output voltage (E96):

$V_{OUT} = V_{FBP} \left(1 + \frac{R1}{R2} \right)$	R1 255 kR	R2 15 kR	V_{FBP} 1 V	V_{OUT} 18 V
--	--------------	-------------	------------------	-------------------

Setting the output voltage (E96):

$V_{OUT} = V_{REF} \left(\frac{R1}{R2} \right)$	R1 274 kR	R2 15 kR	V_{REF} 1 V	V_{OUT} 18,3 V	/ negative
--	--------------	-------------	------------------	---------------------	------------