# Finite representation of real numbers Fixed-point arithmetic

Dr. Ing. Rodrigo Gonzalez

rodralez@frm.utn.edu.ar
rodrigo.gonzalez@ingenieria.uncuyo.edu.ar





# Summary

- Addition
  - Addition in 2's complement
  - Overflow
- A How to avoid overflow
  - Longer word-length accumulator
  - Saturation
- Multiplication
  - Multiplication in 2's complement
  - Four-bit signed integer multiplication
  - Four-bit Q0.3 multiplication
  - Underflow
- How to avoid underflow
  - Rounding schemes, Truncation
  - Rounding schemes, Round-off
  - Error in rounding schemes
- MAC operation
- 6 Shifts
  - Logical and Arithmetic shifts
  - Shifts implementation in DSP processors

### Addition in 2's complement


- Adding two N-bits numbers can produce a N+1 bits result.
- The result will have the same numbers of fractional bits.
- Only the integer part can grow.

```
11111 111
             (carry)
                                   (carry)
                           0111
 0000 1111
             (15)
                            0111
                                   (7)
 1111 1011
             (-5)
                          + 0011
                                   (3)
 0000 1010
             (10)
                            1010
                                   (-6)
                                          invalid!
```

The last two bits of the carry row show if overflow occurs.

#### Overflow


- An **overflow** occurs when a result is greater than  $(2^{N-1}-1)$ , or lesser than  $-2^{N-1}$ .
- An overflow produces a roll-over (wrap).



#### Addition

#### Overflow

- A roll-over usually has catastrophic consequences on a process.
- It only happens when two very large positive operands, or two very large negative operands, are added.
- It can never happen during the addition of a positive operand and a negative operand, whatever their magnitude.



#### How to avoid overflow

# Longer word-length accumulator

- Saving the result in a N+1 word avoids overflows.
- The general rule is the sum of s individual m-bit can require an accumulator of as many as  $m + log_2(s)$  bits.
- **Example:** 256 8-bits words requires an accumulator whose word length is  $8 + log_2(256) = 16$ .
- A 16-bits DSP processor usually have a 40-bit ALU accumulator.
- How many sums are supported by a 40-bits accumulator for 16-bits numbers?  $16 + log_2(s) = 40$ .


In C:

# C code

- int32\_t a[K] ;
- $2 int64_t c = 0 ;$
- for (i=0; i<K; i++)</pre>
- 0 { c = c + (int64\_t) a[i] };

# How to avoid overflow Saturation

- To avoid a rollover, overflow is detected and the result is saturated to the most positive or most negative value that can be represented.
- This procedure is called **saturation arithmetic**.
- DSP processors allows the results to be saturated automatically in hardware (In TI DSP C5505, SATD Bit at ST1\_55 register).




Be aware of non-linearity!

## Multiplication


## Multiplication in 2's complement

- The product of 2 N-bit numbers requires 2 · N bits bits to contain all possible values.
- The 2 Most Significant Bits (MSB) are always equal (extension sign bit).
- Therefore, 2N-1 bits are enough to store the result.
- A Q15 multiplication produces Q1.30 result (extension sign bit).
- To transform the result into Q31 notation, it must be left-shifted by one bit.
- DSP processors have a special mode that allows its ALU to automatically perform the left shift when Q15xQ15.




# Four-bit signed integer multiplication

Four-Bit Integer Multiplication			
	0100	4	
	x 1101	<b>x</b> -3	
	0000100		
0000000			
	000100		
	11100		
	11110100	-12	
Accumulator	11110100	-12	
Data Memory 11110100 -12			



# Multiplication Underflow

- After multiplication, 2N bits must be stored in a memory of N-bits word.
- An **underflow** occurs if the result is less than  $2^{-n}$ .
- **Example:** Q0.3 precision is  $2^{-3} = \frac{1}{8}$ .




- What value should the multiplication result take? -1/8 or -2/8?
- In other words, what bits should be discarded from the multiplication result?

# How to avoid underflow Rounding schemes, Truncation

Truncation, also known as round to minus infinity.

$$\bullet \ x = a \cdot b, y = Q(x).$$

# C code int32\_t truncation(int64\_t X) { int32\_t a; a = (int32\_t) (X » n); return a; } }






# How to avoid underflow Rounding schemes, Round-off

Round-off, also known as round to the nearest.

•  $x = a \cdot b$ ,  $y = Q(x + 2^{-(n+1)})$ , where  $2^{-(n+1)} = 2^{-n}/2$ , is half precision.

# C code int32\_t roundoff(int64\_t X) { int32\_t a; a = ( X + (1 « (n - 1) ) ); return truncation(a); } }






# How to avoid underflow Error in rounding schemes

Error in rounding schemes is modeled as a uniform probability distribution.

mean, 
$$\mu=\frac{a+b}{2}$$
 variance,  $\sigma^2=\frac{(b-a)^2}{12}$ 



- Truncation: e = Q(x) x,  $-2^{-n} \le e < 0$ ,  $\mu = -\frac{2^{-n}}{2} \mid \sigma^2 = \frac{2^{-n}}{12}$
- Round-off:  $e = Q\left(x + 2^{-(n+1)}\right) x$ ,  $-\frac{2^{-n}}{2} < e \le \frac{2^{-n}}{2}$ ,  $\boxed{\mu = 0}$   $\sigma^2 = \frac{2^{-n}}{12}$

DSP processors manage truncation and round-off automatically.

## MAC operation

- MAC stands for Multiply and ACcumulate.
- Since it represents the convolution operation, it is THE basic arithmetic operation in DSP. In C:

# C code


```
int32_t a[K];
int32_t b[K];
int64_t c = 0;
for (i=0; i<K; i++)
{ c = c + ((int64_t) a[i] * (int64_t) b[i] ) };</pre>
```

- A MAC operation summarizes the addition and multiplication problems, i.e., overflows and underflows.
- DSP processors have an accumulator with extra bits (guard bits) to avoid overflow during internal calculations (in TI DSP C5505, 40-bits accumulator).

b39-b32	b31-b16	b15-b0
G	Н	L
Guard bits	High-order bits	Low-order bits

## Logical and Arithmetic shifts

- Multiplication by 2: all bits are shifted left by one position.
- Division by 2: all bits are shifted right by one position (logical shift).
- What happens with 2-complement numbers?
- The sign bit must be preserved! (arithmetic shift).
- Arithmetic shift ≠ logical shift.



### Shifts implementation in DSP processors

### In DSP processors:

- ALU can perform logical shifts of 32-bit operands in one cycle, from 16 bits to the right, to 15 bits to the left.
- Sign extension is performed during shifts to the right, if the Sign Extension Mode control bit (in C5505, SXM) is set.
- Result is saturated during shifts to the left if an overflow is detected, and Overflow bit (in C5505, OVM) is set.

# **Bibliography**

- 1 Richard G. Lyons. *Understanding Digital Signal Processing, 3rd Ed.* Prentice Hill. 2010. Chapter 12.
- 2 Bruno Paillard. An Introduction To Digital Signal Processors, Chapter 5.