# Random Access Memory for a Multi-Processor System on Chip

## QueenField



Figure 1: QueenField

## 0. INTRODUCTION

- 0.0. DO-254
- 0.0.1. PLANNING PROCESS
- 0.0.1.1. Planning Process Objectives
- 0.0.1.2. Planning Process Activities
- 0.0.2. HARDWARE DESIGN PROCESS
- 0.0.2.1. Requirements Capture Process
- 0.0.2.2. Conceptual Design Process

| 0.0.2.3. Detailed Design Process                      |
|---|
| 0.0.2.4. Implementation Process                       |
| 0.0.2.5. Production Transition                        |
| 0.0.2.6. Acceptance Test                              |
| 0.0.2.7. Series Production                            |
| 0.0.3. VALIDATION AND VERIFICATION PROCESS            |
| 0.0.3.1. Validation Process                           |
| 0.0.3.2. Verification Process                         |
| 0.0.3.3. Validation and Verification Methods          |
| 0.0.4. CONFIGURATION MANAGEMENT PROCESS               |
| 0.0.4.1. Configuration Management Objectives          |
| 0.0.4.2. Configuration Management Activities          |
| 0.0.4.3. Data Control Categories                      |
| 0.0.5. PROCESS ASSURANCE                              |
| 0.0.5.1. Process Assurance Objectives                 |
| 0.0.5.2. Process Assurance Activities                 |
| 0.0.6. CERTIFICATION LIAISON PROCESS                  |
| 0.0.6.1. Means of Compliance and Planning             |
| 0.0.6.2. Compliance Substantiation                    |
| 0.0.7. HARDWARE DESIGN LIFECYCLE DATA                 |
| 0.0.7.1. Hardware Plans                               |
| 0.0.7.1.1. Plan for Hardware Aspects of Certification |
| 0.0.7.1.2. Hardware Design Plan                       |
| 0.0.7.1.3. Hardware Validation Plan                   |
| 0.0.7.1.4. Hardware Verification Plan                 |
| 0.0.7.1.5. Hardware Configuration Management Plan     |
| 0.0.7.1.6. Hardware Process Assurance Plan            |

| 0.0.7.2. Hardware Design Standards and Guidance   |
|---|
| 0.0.7.2.1. Requirements Standards   |
| 0.0.7.2.2. Hardware Design Standards  |
| 0.0.7.2.3. Validation and Verification Standards  |
| 0.0.7.2.4. Hardware Archive Standards   |
| 0.0.7.3. Hardware Design Data   |
| 0.0.7.3.1. Hardware Requirements  |
| 0.0.7.3.2. Hardware Design Representation Data 0.0.7.3.2.1. Conceptual Design Data 0.0.7.3.2.2. Detailed Design Data 0.0.7.3.2.2.1. Top-Level Drawing |
| 0.0.7.3.2.2.2. Assembly Drawings 0.0.7.3.2.2.3. Installation Control Drawings   |
| 0.0.7.3.2.2.4. Hardware/Software Interface Data   |
| 0.0.7.4. Validation and Verification Data   |
| 0.0.7.4.1. Traceability Data  |
| 0.0.7.4.2. Review and Analysis Procedures   |
| 0.0.7.4.3. Review and Analysis Results  |
| 0.0.7.4.4. Test Procedures  |
| 0.0.7.4.5. Test Results   |
| 0.0.8. ADDITIONAL CONSIDERATIONS  |
| 0.0.8.1. Use of Previously Developed Hardware   |
| 0.0.8.2. Commercial Components Usage  |
| 0.0.8.3. Product Service Experience   |
| 0.0.8.4. Tool Assessment and Qualification  |
| 0.1. BEST PRACTICES 0.1.1. HARDWARE   |

cd synthesis/yosys
source SYNTHESIZE-IT

#### **0.1.1.1. ASIC** type:

cd synthesis/qflow
source FLOW-IT

## **0.1.1.2. FPGA** type:

cd synthesis/symbiflow
source FLOW-IT

#### 0.1.2. SOFTWARE

0.1.2.1. MSP430

## 0.1.2.1.1. MSP430 Tests

#### 0.1.2.1.2. MSP430 Bare Metal

## **0.1.2.1.3.** MSP430 Operating System 0.1.2.1.3.1. GNU Linux

0.1.2.1.3.2. GNU Hurd

### **0.1.2.1.4. MSP430 Distribution** 0.1.2.1.4.1. GNU Debian

0.1.2.1.4.2. GNU Fedora

## 0.1.2.2. OpenRISC

## 0.1.2.2.1. OpenRISC Tests

## 0.1.2.2.2. OpenRISC Bare Metal

## **0.1.2.2.3.** OpenRISC Operating System 0.1.2.2.3.1. GNU Linux

0.1.2.2.3.2. GNU Hurd

## 0.1.2.2.4. OpenRISC Distribution 0.1.2.2.4.1. GNU Debian

0.1.2.2.4.2. GNU Fedora

## 0.1.2.3. RISC-V

## **0.1.2.3.1. RISC-V Tests** type:

export PATH=/opt/riscv-elf-gcc/bin:\${PATH}

rm -rf tests

rm -rf riscv-tests

mkdir tests

mkdir tests/dump

mkdir tests/hex

git clone --recursive https://github.com/riscv/riscv-tests
cd riscv-tests

```
autoconf
./configure --prefix=/opt/riscv-elf-gcc/bin
cd isa
source ../../elf2hex.sh
mv *.dump ../../tests/dump
mv *.hex ../../tests/hex
cd ..
make clean
elf2hex.sh:
riscv64-unknown-elf-objcopy -0 ihex rv32mi-p-breakpoint rv32mi-p-breakpoint.hex
riscv64-unknown-elf-objcopy -0 ihex rv32mi-p-csr rv32mi-p-csr.hex
riscv64-unknown-elf-objcopy -0 ihex rv64um-v-remw rv64um-v-remw.hex
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
spike rv32mi-p-breakpoint
spike rv32mi-p-csr
spike rv64um-v-remw
0.1.2.3.2. RISC-V Bare Metal type:
rm -rf hello_c.elf
rm -rf hello_c.hex
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
riscv64-unknown-elf-gcc -o hello_c.elf hello_c.c
riscv64-unknown-elf-objcopy -O ihex hello_c.elf hello_c.hex
C Language:
#include <stdio.h>
int main() {
  printf("Hello QueenField!\n");
  return 0;
}
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
spike pk hello_c.elf
type:
rm -rf hello_cpp.elf
```

```
rm -rf hello_cpp.hex
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
riscv64-unknown-elf-g++ -o hello_cpp.elf hello_cpp.cpp
riscv64-unknown-elf-objcopy -O ihex hello_cpp.elf hello_cpp.hex
C++ Language:
#include <iostream>
int main() {
  std::cout << "Hello QueenField!\n";</pre>
  return 0;
}
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
spike pk hello_cpp.elf
type:
rm -rf hello_go.elf
rm -rf hello_go.hex
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
export PATH=/opt/riscv-go/bin:${PATH}
GOOS=linux GOARCH=riscv64 go build -o hello_go.elf hello_go.go
riscv64-unknown-elf-objcopy -O ihex hello_go.elf hello_go.hex
Go Language:
package main
import "fmt"
func main() {
  fmt.Println("Hello QueenField!")
0.1.2.3.3. RISC-V Operating System 0.1.2.3.3.1. GNU Linux
Building BusyBox
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
git clone --recursive https://git.busybox.net/busybox
cd busybox
make CROSS_COMPILE=riscv64-unknown-linux-gnu- defconfig
make CROSS_COMPILE=riscv64-unknown-linux-gnu-
Building Linux
type:
```

```
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
git clone --recursive https://github.com/torvalds/linux
cd linux
make ARCH=riscv CROSS_COMPILE=riscv64-unknown-linux-gnu- defconfig
make ARCH=riscv CROSS_COMPILE=riscv64-unknown-linux-gnu-
Running Linux
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
qemu-system-riscv64 -nographic -machine virt \
-kernel Image -append "root=/dev/vda ro console=ttyS0" \
-drive file=busybox,format=raw,id=hd0 \
-device virtio-blk-device, drive=hd0
0.1.2.3.3.2. GNU Hurd
0.1.2.3.4. RISC-V Distribution 0.1.2.3.4.1. GNU Debian
0.1.2.3.4.2. GNU Fedora
0.2. OPEN SOURCE PHILOSOPHY
For Windows Users!
  1. Settings \rightarrow Apps \rightarrow Apps & features \rightarrow Related settings, Programs and Features \rightarrow Turn Windows
     features on or off \rightarrow Windows Subsystem for Linux
  2. Microsoft Store \rightarrow INSTALL UBUNTU
type:
sudo apt update
sudo apt upgrade
0.2.1. Open Source Hardware
0.2.1.1. MSP430 Processing Unit
0.2.1.2. OpenRISC Processing Unit
```

- 0.2.1.3. RISC-V Processing Unit
- 0.2.2. Open Source Software
- 0.2.2.1. MSP430 GNU Compiler Collection
- 0.2.2.2. OpenRISC GNU Compiler Collection
- 0.2.2.3. RISC-V GNU Compiler Collection

## 0.3. INSTRUCTION SET ARCHITECTURE

- 0.3.1. RISC-V ISA
- 0.3.1.1. ISA Bases

0.3.1.1.1. RISC-V 32

0.3.1.1.2. RISC-V 64

0.3.1.1.3. RISC-V 128

## 0.3.1.2. ISA Extensions

 $0.3.1.2.1. \ \ Base\ Integer\ Instruction\ Set\ \ RV32I: Base\ Integer\ Instruction\ Set\ (32\ bit)$ 

| LUI RD, IMM   | RV32I            | 31:25   | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|---|------------------|---------|--------|--------|-------|-------|---------|
| AUPIC RD, IMM         IIIIIII         IIIII         IIIII         IIII         IIII         RD4:0         0010111           JALR RD, IMM         IIIIIII         IIIIII         IIIII         IIIII         RD4:0         1001111           JALR RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         000         RD4:0         1101111           BEQ RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         001         IIIII         1100011           BLT RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         100         IIIIII         1100011           BGE RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         101         IIIIII         1100011           BGEU RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         110         IIIIII         1100011           BG RS1,RS2,IMM         IIIIIIII         RS24:0         RS14:0         111         IIIIIII         1100011           BG RS1,RS2,IMM         IIIIIII         IIIIII         RS14:0         000         RD4:0         0000011           LH RD, RS1         IIIIIII         IIIIII         RS14:0         001         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII  | LUI RD, IMM      | IIIIIII | IIIII  | IIIII  | III   | RD4:0 | 0110111 |
| JAL RD, IMM   |                  | IIIIIII | IIIII  | IIIII  | III   | RD4:0 |         |
| JALR RD,RS1,IMM   | •                |         | IIIII  |        | III   | RD4:0 |         |
| BEQ RS1,RS2,IMM   | ,                | IIIIIII | IIIII  | RS14:0 | 000   | RD4:0 |         |
| BNE RS1,RS2,IMM   | · · ·            | IIIIIII | RS24:0 | RS14:0 | 000   | IIIII | 1100011 |
| BLT RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         100         IIIII         1100011           BGE RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         101         IIIIII         1100011           BLTU RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         110         IIIIII         1100011           BGEU RS1,RS2,IMM         IIIIIIII         RS24:0         RS14:0         111         IIIIII         1100011           LB RD, RS1         IIIIIIII         IIIIII         RS14:0         000         RD4:0         00000011           LW RD, RS1         IIIIIIII         IIIIII         RS14:0         001         RD4:0         0000011           LBU RD, RS1         IIIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           LBU RD, RS1         IIIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           SB RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0000011           SW RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SLT RD,RS1,IMM         IIIIIII         RS24:0         RS14:0   |                  |         |        |        |       | IIIII |         |
| BLTU RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         110         IIIII         1100011           BGEU RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         111         IIIIII         1100011           LB RD, RS1         IIIIIIII         IIIIII         RS14:0         000         RD4:0         0000011           LW RD, RS1         IIIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LBU RD, RS1         IIIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LHU RD, RS1         IIIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           SB RS2,RS1         IIIIIIII         RS24:0         RS14:0         000         IIIII         000011           SH RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010   |                  | IIIIIII | RS24:0 | RS14:0 |       | IIIII | 1100011 |
| BGEU RS1,RS2,IMM         IIIIIII         RS24:0         RS14:0         111         IIIII         1100011           LB RD, RS1         IIIIIII         IIIIII         RS14:0         000         RD4:0         0000011           LH RD, RS1         IIIIIII         IIIIII         RS14:0         001         RD4:0         0000011           LW RD, RS1         IIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           LHU RD, RS2         IIIIIII         RS24:0         RS14:0         000         IIIII         0000011           SB RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         010         IIIII         0100011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010  | BGE RS1,RS2,IMM  | IIIIIII | RS24:0 | RS14:0 | 101   | IIIII | 1100011 |
| LB RD, RS1         IIIIIII         IIIIII         RS14:0         000         RD4:0         0000011           LH RD, RS1         IIIIIII         IIIIII         RS14:0         001         RD4:0         0000011           LW RD, RS1         IIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LBU RD, RS1         IIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           SB RS2,RS1         IIIIIII         RS24:0         RS14:0         000         IIIII         010011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         010         IIIII         0100011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         100         <  | BLTU RS1,RS2,IMM | IIIIIII | RS24:0 | RS14:0 | 110   | IIIII | 1100011 |
| LH RD, RS1         IIIIIII         IIIIII         RS14:0         001         RD4:0         0000011           LW RD, RS1         IIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LBU RD, RS1         IIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           LHU RD, RS1         IIIIIIII         RS14:0         000         IIIII         0000011           SB RS2,RS1         IIIIIIII         RS24:0         RS14:0         000         IIIII         0100011           SW RS2,RS1         IIIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIIII         RS24:0         RS14:0         010         IIIII         0100011           ADDI RD,RS1,IMM         IIIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0  | BGEU RS1,RS2,IMM | IIIIIII | RS24:0 | RS14:0 | 111   | IIIII | 1100011 |
| LW RD, RS1         IIIIIII         IIIIII         RS14:0         010         RD4:0         0000011           LBU RD, RS1         IIIIIII         IIIIII         RS14:0         100         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           SB RS2,RS1         IIIIIII         RS24:0         RS14:0         000         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           ADDI RD,RS1,IMM         IIIIIII         RS24:0         RS14:0         010         IIIII         0100011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLLI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         11 <td>LB RD, RS1</td> <td>IIIIIII</td> <td>IIIII</td> <td>RS14:0</td> <td>000</td> <td>RD4:0</td> <td>0000011</td>       | LB RD, RS1       | IIIIIII | IIIII  | RS14:0 | 000   | RD4:0 | 0000011 |
| LBU RD, RS1         IIIIIII         IIIII         RS14:0         100         RD4:0         0000011           LHU RD, RS1         IIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           SB RS2,RS1         IIIIIII         RS24:0         RS14:0         000         IIIII         0100011           SH RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         000         RD4:0         0010011           ADDI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           AND RD,RS1,RS1,IMM         0000000         IIII         RS14:0         011<   | LH RD, RS1       | IIIIIII | IIIII  | RS14:0 | 001   | RD4:0 | 0000011 |
| LHU RD, RS1         IIIIIII         IIIIII         RS14:0         101         RD4:0         0000011           SB RS2,RS1         IIIIIII         RS24:0         RS14:0         000         IIIII         0100011           SH RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         01         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         01         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         01         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0 <td>LW RD, RS1</td> <td>IIIIIII</td> <td>IIIII</td> <td>RS14:0</td> <td>010</td> <td>RD4:0</td> <td>0000011</td>        | LW RD, RS1       | IIIIIII | IIIII  | RS14:0 | 010   | RD4:0 | 0000011 |
| SB RS2,RS1         IIIIIII         RS24:0         RS14:0         000         IIIII         0100011           SH RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         000         RD4:0         0010011           ADDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           SLLI RD,RS1,IMM         IIIIIIII         IIIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,RS2         0000000         RS24:0         RS14:0 <t< td=""><td>LBU RD, RS1</td><td>IIIIIII</td><td>IIIII</td><td>RS14:0</td><td>100</td><td>RD4:0</td><td>0000011</td></t<> | LBU RD, RS1      | IIIIIII | IIIII  | RS14:0 | 100   | RD4:0 | 0000011 |
| SH RS2,RS1         IIIIIII         RS24:0         RS14:0         001         IIIII         0100011           SW RS2,RS1         IIIIIII         RS24:0         RS14:0         010         IIIII         0100011           ADDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         11         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         01         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,RS2         0000000         RS24:0         RS14:0 <t< td=""><td>LHU RD, RS1</td><td>IIIIIII</td><td>IIIII</td><td>RS14:0</td><td>101</td><td>RD4:0</td><td>0000011</td></t<> | LHU RD, RS1      | IIIIIII | IIIII  | RS14:0 | 101   | RD4:0 | 0000011 |
| SW RS2,RS1         IIIIIII         RS24:0         RS14:0         010         IIIII         0100011           ADDI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0   | SB RS2,RS1       | IIIIIII | RS24:0 | RS14:0 | 000   | IIIII | 0100011 |
| ADDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         000         RD4:0         0010011           SLTI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0   | SH RS2,RS1       | IIIIIII | RS24:0 | RS14:0 | 001   | IIIII | 0100011 |
| SLTI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         010         RD4:0         0010011           SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           SUB RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0   | SW RS2,RS1       | IIIIIII | RS24:0 | RS14:0 | 010   | IIIII | 0100011 |
| SLTIU RD,RS1,IMM         IIIIIII         IIIII         RS14:0         011         RD4:0         0010011           XORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         100         RD4:0         0010011           ORI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0010011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0   | ADDI RD,RS1,IMM  | IIIIIII | IIIII  | RS14:0 | 000   | RD4:0 | 0010011 |
| XORI RD,RS1,IMM         IIIIII         IIIII         RS14:0         100         RD4:0         0010011           ORI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0   | SLTI RD,RS1,IMM  | IIIIIII | IIIII  | RS14:0 | 010   | RD4:0 | 0010011 |
| ORI RD,RS1,IMM         IIIIIII         IIIIII         RS14:0         110         RD4:0         0010011           ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRAI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         01         RD4:0         0110011           SRA RD,RS1,RS2         0000000         RS24:0         RS14:0  | SLTIU RD,RS1,IMM | IIIIIII | IIIII  | RS14:0 | 011   | RD4:0 | 0010011 |
| ANDI RD,RS1,IMM         IIIIIII         IIIII         RS14:0         111         RD4:0         0010011           SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRLI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0  | XORI RD,RS1,IMM  | IIIIIII | IIIII  | RS14:0 | 100   | RD4:0 | 0010011 |
| SLLI RD,RS1,IMM         0000000         IIII         RS14:0         001         RD4:0         0010011           SRLI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0   | ORI RD,RS1,IMM   | IIIIIII | IIIII  | RS14:0 | 110   | RD4:0 | 0010011 |
| SRLI RD,RS1,IMM         0000000         IIII         RS14:0         101         RD4:0         0010011           SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLI RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0  | ANDI RD,RS1,IMM  | IIIIIII | IIIII  | RS14:0 | 111   | RD4:0 | 0010011 |
| SRAI RD,RS1,IMM         0100000         IIII         RS14:0         101         RD4:0         0010011           ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           AND RD,RS1,RS2         0000000         RS24:0         RS14:0   | SLLI RD,RS1,IMM  | 0000000 | IIII   | RS14:0 | 001   | RD4:0 | 0010011 |
| ADD RD,RS1,RS2         0000000         RS24:0         RS14:0         000         RD4:0         0110011           SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         110         RD4:0         0110011           AND RD,RS1,RS2         0000000         RS24:0         RS14:0   | SRLI RD,RS1,IMM  | 0000000 | IIII   | RS14:0 | 101   | RD4:0 | 0010011 |
| SUB RD,RS1,RS2         0100000         RS24:0         RS14:0         000         RD4:0         0110011           SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           AND RD,RS1,RS2         0000000         RS24:0         RS14:0         110         RD4:0         0110011           FENCE PRED,SUCC         0000PPP         PSSS         00000         000         00000         0001111   | SRAI RD,RS1,IMM  | 0100000 | IIII   | RS14:0 | 101   | RD4:0 | 0010011 |
| SLL RD,RS1,RS2         0000000         RS24:0         RS14:0         001         RD4:0         0110011           SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           AND RD,RS1,RS2         0000000         RS24:0         RS14:0         110         RD4:0         0110011           FENCE PRED,SUCC         0000PPP         PSSSS         00000         000         00000         0001111   | ADD RD,RS1,RS2   | 0000000 | RS24:0 | RS14:0 | 000   | RD4:0 | 0110011 |
| SLT RD,RS1,RS2         0000000         RS24:0         RS14:0         010         RD4:0         0110011           SLTU RD,RS1,RS2         0000000         RS24:0         RS14:0         011         RD4:0         0110011           XOR RD,RS1,RS2         0000000         RS24:0         RS14:0         100         RD4:0         0110011           SRL RD,RS1,RS2         0000000         RS24:0         RS14:0         101         RD4:0         0110011           SRA RD,RS1,RS2         0100000         RS24:0         RS14:0         101         RD4:0         0110011           OR RD,RS1,RS2         0000000         RS24:0         RS14:0         110         RD4:0         0110011           AND RD,RS1,RS2         0000000         RS24:0         RS14:0         110         RD4:0         0110011           FENCE PRED,SUCC         0000PPP         PSSS         00000         000         0000         0001111  | SUB RD,RS1,RS2   | 0100000 | RS24:0 | RS14:0 | 000   | RD4:0 | 0110011 |
| SLTU RD,RS1,RS2       0000000       RS24:0       RS14:0       011       RD4:0       0110011         XOR RD,RS1,RS2       0000000       RS24:0       RS14:0       100       RD4:0       0110011         SRL RD,RS1,RS2       0000000       RS24:0       RS14:0       101       RD4:0       0110011         SRA RD,RS1,RS2       0100000       RS24:0       RS14:0       101       RD4:0       0110011         OR RD,RS1,RS2       0000000       RS24:0       RS14:0       110       RD4:0       0110011         AND RD,RS1,RS2       0000000       RS24:0       RS14:0       111       RD4:0       0110011         FENCE PRED,SUCC       0000PPP       PSSS       00000       000       00000       0001111  | SLL RD,RS1,RS2   | 0000000 | RS24:0 | RS14:0 | 001   | RD4:0 | 0110011 |
| XOR RD,RS1,RS2       0000000       RS24:0       RS14:0       100       RD4:0       0110011         SRL RD,RS1,RS2       0000000       RS24:0       RS14:0       101       RD4:0       0110011         SRA RD,RS1,RS2       0100000       RS24:0       RS14:0       101       RD4:0       0110011         OR RD,RS1,RS2       0000000       RS24:0       RS14:0       110       RD4:0       0110011         AND RD,RS1,RS2       0000000       RS24:0       RS14:0       111       RD4:0       0110011         FENCE PRED,SUCC       0000PPP       PSSS       00000       000       00000       0001111  | SLT RD,RS1,RS2   | 0000000 | RS24:0 | RS14:0 | 010   | RD4:0 | 0110011 |
| SRL RD,RS1,RS2       0000000       RS24:0       RS14:0       101       RD4:0       0110011         SRA RD,RS1,RS2       0100000       RS24:0       RS14:0       101       RD4:0       0110011         OR RD,RS1,RS2       0000000       RS24:0       RS14:0       110       RD4:0       0110011         AND RD,RS1,RS2       0000000       RS24:0       RS14:0       111       RD4:0       0110011         FENCE PRED,SUCC       0000PPP       PSSS       00000       000       00000       0001111   | SLTU RD,RS1,RS2  | 0000000 | RS24:0 | RS14:0 | 011   | RD4:0 | 0110011 |
| SRA RD,RS1,RS2       0100000       RS24:0       RS14:0       101       RD4:0       0110011         OR RD,RS1,RS2       0000000       RS24:0       RS14:0       110       RD4:0       0110011         AND RD,RS1,RS2       0000000       RS24:0       RS14:0       111       RD4:0       0110011         FENCE PRED,SUCC       0000PPP       PSSS       00000       000       00000       0001111  | XOR RD,RS1,RS2   | 0000000 | RS24:0 | RS14:0 | 100   | RD4:0 | 0110011 |
| OR RD,RS1,RS2       0000000       RS24:0       RS14:0       110       RD4:0       0110011         AND RD,RS1,RS2       0000000       RS24:0       RS14:0       111       RD4:0       0110011         FENCE PRED,SUCC       0000PPP       PSSS       00000       000       00000       0001111   | SRL RD,RS1,RS2   | 0000000 | RS24:0 | RS14:0 | 101   | RD4:0 | 0110011 |
| AND RD,RS1,RS2 0000000 RS24:0 RS14:0 111 RD4:0 0110011 FENCE PRED,SUCC 0000PPP PSSSS 00000 000 00000 0001111  | SRA RD,RS1,RS2   | 0100000 | RS24:0 | RS14:0 | 101   | RD4:0 | 0110011 |
| FENCE PRED,SUCC 0000PPP PSSSS 00000 000 00000 0001111   | OR RD,RS1,RS2    | 0000000 | RS24:0 | RS14:0 | 110   | RD4:0 | 0110011 |
|   | AND RD,RS1,RS2   |         | RS24:0 | RS14:0 | 111   | RD4:0 | 0110011 |
| FENCE.I 0000P00 00000 00000 001 00000 0001111   | FENCE PRED,SUCC  | 0000PPP | PSSSS  | 00000  | 000   | 00000 | 0001111 |
|   | FENCE.I          | 0000P00 | 00000  | 00000  | 001   | 00000 | 0001111 |

RV64I : Base Integer Instruction Set (64 bit)

| RV64I            | 31:25   | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|------------------|---------|--------|--------|-------|-------|---------|
| LWU RD, RS1      | IIIIIII | IIIII  | RS14:0 | 110   | RD4:0 | 0000011 |
| LD RD, RS1       | IIIIIII | IIIII  | RS14:0 | 011   | RD4:0 | 0000011 |
| SD RD, RS1,RS2   | IIIIIII | RS24:0 | RS14:0 | 011   | IIIII | 0000011 |
| SLLI RD, RS1,IMM | 0000000 | IIIII  | RS14:0 | 001   | RD4:0 | 0010011 |
| SRLI RD, RS1,IMM | 0000000 | IIIII  | RS14:0 | 001   | RD4:0 | 0010011 |
| SRAI RD, RS1,IMM | 0100000 | IIIII  | RS14:0 | 001   | RD4:0 | 0010011 |
| ADDIW RD, RS1    | IIIIIII | IIIII  | RS14:0 | 000   | RD4:0 | 0011011 |
| SLLIW RD, RS1    | 0000000 | IIIII  | RS14:0 | 001   | RD4:0 | 0011011 |
| SRLIW RD, RS1    | 0000000 | IIIII  | RS14:0 | 101   | RD4:0 | 0011011 |
| SRAIW RD, RS1    | 0100000 | IIIII  | RS14:0 | 101   | RD4:0 | 0011011 |
| ADDW RD, RS1,RS2 | 0000000 | RS24:0 | RS14:0 | 000   | RD4:0 | 0111011 |
| SUBW RD, RS1,RS2 | 0100000 | RS24:0 | RS14:0 | 000   | RD4:0 | 0111011 |
| SLIW RD, RS1,RS2 | 0000000 | RS24:0 | RS14:0 | 001   | RD4:0 | 0111011 |
| SRLW RD, RS1,RS2 | 0000000 | RS24:0 | RS14:0 | 101   | RD4:0 | 0111011 |
| SRAW RD, RS1,RS2 | 0100000 | RS24:0 | RS14:0 | 101   | RD4:0 | 0111011 |

0.3.1.2.2. Standard Extension for Integer Multiply and Divide RV32M : Standard Extension for Integer Multiply and Divide (32 bit)

| RV32M             | 31:25   | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|-------------------|---------|--------|--------|-------|-------|---------|
| MUL RD,RS1,RS2    | 0000001 | RS24:0 | RS14:0 | 000   | RD4:0 | 0110011 |
| MULH RD,RS1,RS2   | 0000001 | RS24:0 | RS14:0 | 001   | RD4:0 | 0110011 |
| MULHSU RD,RS1,RS2 | 0000001 | RS24:0 | RS14:0 | 010   | RD4:0 | 0110011 |
| MULHU RD,RS1,RS2  | 0000001 | RS24:0 | RS14:0 | 011   | RD4:0 | 0110011 |
| DIV RD,RS1,RS2    | 0000001 | RS24:0 | RS14:0 | 100   | RD4:0 | 0110011 |
| DIVU RD,RS1,RS2   | 0000001 | RS24:0 | RS14:0 | 101   | RD4:0 | 0110011 |
| REM RD,RS1,RS2    | 0000001 | RS24:0 | RS14:0 | 110   | RD4:0 | 0110011 |
| REMU RD,RS1,RS2   | 0000001 | RS24:0 | RS14:0 | 111   | RD4:0 | 0110011 |

Standard Extension for Integer Multiply and Divide (64 bit)

| RV64M            | 31:25   | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|------------------|---------|--------|--------|-------|-------|---------|
| MULW RD,RS1,RS2  | 0000001 | RS24:0 | RS14:0 | 000   | RD4:0 | 0111011 |
| DIVW RD,RS1,RS2  | 0000001 | RS24:0 | RS14:0 | 100   | RD4:0 | 0111011 |
| DIVUW RD,RS1,RS2 | 0000001 | RS24:0 | RS14:0 | 101   | RD4:0 | 0111011 |
| REMW RD,RS1,RS2  | 0000001 | RS24:0 | RS14:0 | 110   | RD4:0 | 0111011 |
| REMUW RD,RS1,RS2 | 0000001 | RS24:0 | RS14:0 | 111   | RD4:0 | 0111011 |

0.3.1.2.3. Standard Extension for Atomic Instructions RV32A : Standard Extension for Atomic Instructions (32 bit)

| RV32A                     | 31:25      | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|---------------------------|------------|--------|--------|-------|-------|---------|
| LR.W AQRL,RD,RS1          | 00010AQRL  | 00000  | RS14:0 | 010   | RD4:0 | 0101111 |
| SC.W AQRL,RD,RS2,RS1      | 00011AQRL  | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOSWAP.W AQRL,RD,RS2,RS1 | 00001AQRL  | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOSADD.W AQRL,RD,RS2,RS1 | 00000AQRL  | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOSXOR.W AQRL,RD,RS2,RS1 | 00100 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOOR.W AQRL,RD,RS2,RS1   | 01000 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |

| RV32A                     | 31:25      | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|---------------------------|------------|--------|--------|-------|-------|---------|
| AMOAMD.W AQRL,RD,RS2,RS1  | 01100 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOMIN.W AQRL,RD,RS2,RS1  | 10000 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOMAX.W AQRL,RD,RS2,RS1  | 10100 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOMINU.W AQRL,RD,RS2,RS1 | 11000 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |
| AMOMAXU.W AQRL,RD,RS2,RS1 | 11100 AQRL | RS24:0 | RS14:0 | 010   | RD4:0 | 0101111 |

RV64A: Standard Extension for Atomic Instructions (64 bit)

| RV64A                     | 31:25      | 24:20  | 19:15  | 14:12 | 11:7  | 6:0     |
|---------------------------|------------|--------|--------|-------|-------|---------|
| LR.D AQRL,RD,RS1          | 00010 AQRL | 00000  | RS14:0 | 011   | RD4:0 | 0101111 |
| SC.D AQRL,RD,RS2,RS1      | 00011AQRL  | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOSWAP.D AQRL,RD,RS2,RS1 | 00001AQRL  | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOSADD.D AQRL,RD,RS2,RS1 | 00000AQRL  | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOSXOR.D AQRL,RD,RS2,RS1 | 00100 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOOR.D AQRL,RD,RS2,RS1   | 01000 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOAMD.D AQRL,RD,RS2,RS1  | 01100 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOMIN.D AQRL,RD,RS2,RS1  | 10000 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOMAX.D AQRL,RD,RS2,RS1  | 10100 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOMINU.D AQRL,RD,RS2,RS1 | 11000 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |
| AMOMAXU.D AQRL,RD,RS2,RS1 | 11100 AQRL | RS24:0 | RS14:0 | 011   | RD4:0 | 0101111 |

 $0.3.1.2.4.\ Standard\ Extension\ for\ Single-Precision\ Floating-Point\ \ RV32F: Standard\ Extension\ for\ Single-Precision\ Floating-Point\ (32\ bit)$ 

| 31:25      | 24:20   | 19:15  | 14:12   | 11:7    | 6:0     |
|------------|---|--|---|---------|---------|
| IIIIIII    | IIIII   | FRS1   | 010   | FRD     | 0000111 |
| IIIIIII    | FRS2  | FRS1   | 010   | IIIII   | 0100111 |
| $FRS3\_00$ | FRS2  | FRS1   | RM  | FRD     | 1000011 |
| $FRS3\_00$ | FRS2  | FRS1   | RM  | FRD     | 1000111 |
| $FRS3\_00$ | FRS2  | FRS1   | RM  | FRD     | 1001011 |
| $FRS3\_00$ | FRS2  | FRS1   | RM  | FRD     | 1001111 |
| 0000000    | FRS2  | FRS1   | RM  | FRD     | 1010011 |
| 0000100    | FRS2  | FRS1   | RM  | FRD     | 1010011 |
| 0001000    | FRS2  | FRS1   | RM  | FRD     | 1010011 |
| 0001100    | FRS2  | FRS1   | RM  | FRD     | 1010011 |
| 0010000    | FRS2  | FRS1   | 000   | FRD     | 1010011 |
| 0010000    | FRS2  | FRS1   | 001   | FRD     | 1010011 |
| 0010000    | FRS2  | FRS1   | 010   | FRD     | 1010011 |
| 0010100    | FRS2  | FRS1   | 000   | FRD     | 1010011 |
| 0010100    | FRS2  | FRS1   | 001   | FRD     | 1010011 |
| 0101100    | 00000   | FRS1   | RM  | FRD     | 1010011 |
| 1010000    | FRS2  | FRS1   | 000   | FRD     | 1010011 |
| 1010000    | FRS2  | FRS1   | 001   | FRD     | 1010011 |
| 1010000    | FRS2  | FRS1   | 010   | FRD     | 1010011 |
| 1100000    | 00000   | FRS1   | RM  | FRD     | 1010011 |
| 1100000    | 00010   | FRS1   | RM  | FRD     | 1010011 |
| 1101000    | 00000   | FRS1   | RM  | FRD     | 1010011 |
| 1101000    | 00010   | FRS1   | RM  | FRD     | 1010011 |
| 1110000    | 00000   | FRS1   | 000   | RD      | 1010011 |
|            | IIIIIII IIIIIIII IIIIIIII FRS3_00 FRS3_00 FRS3_00 FRS3_00 0000000 0001000 0001100 0010000 0010000 0010000 0010100 010100 010100 0101100 1010000 1010000 1100000 1100000 1100000 1100000 11010000 11010000 11010000 11010000 | IIIIIII         IIIIII           IIIIIII         FRS2           FRS3_00         FRS2           FRS3_00         FRS2           FRS3_00         FRS2           FRS3_00         FRS2           FRS3_00         FRS2           0000000         FRS2           000100         FRS2           0001000         FRS2           001000         FRS2           0010000         FRS2           0010100         FRS2           0010100         FRS2           0010100         FRS2           0101100         FRS2           0101100         FRS2           1010000         FRS2           1010000         FRS2           1100000         00000           1101000         00010           1101000         00000           1101000         00000           1101000         00000 | IIIIIII         IIIIII         FRS1           IIIIIII         FRS2         FRS1           FRS3_00         FRS2         FRS1           FRS3_00         FRS2         FRS1           FRS3_00         FRS2         FRS1           FRS3_00         FRS2         FRS1           0000000         FRS2         FRS1           0000100         FRS2         FRS1           0001000         FRS2         FRS1           001000         FRS2         FRS1           0010000         FRS2         FRS1           0010000         FRS2         FRS1           0010100         FRS2         FRS1           0010100         FRS2         FRS1           0010100         FRS2         FRS1           0010100         FRS2         FRS1           010100         FRS2         FRS1           1010000         FRS2         FRS1           1010000         FRS2         FRS1           100000         FRS2         FRS1           1100000         00000         FRS1           1100000         FRS1         FRS1           1100000         FRS2         FRS1 <td< td=""><td>  IIIIIII</td><td>  IIIIIII</td></td<> | IIIIIII | IIIIIII |

| RV32F            | 31:25   | 24:20 | 19:15 | 14:12 | 11:7 | 6:0     |
|------------------|---------|-------|-------|-------|------|---------|
| FCLASS.S RD,FRS1 | 1110000 | 00000 | FRS1  | 001   | RD   | 1010011 |
| FMV.S.X RD,FRS1  | 1111000 | 00000 | RS1   | 000   | FRD  | 1010011 |

 $RV64F: Standard\ Extension\ for\ Single-Precision\ Floating-Point\ (64\ bit)$ 

| RV64F                | 31:25   | 24:20 | 19:15 | 14:12 | 11:7 | 6:0     |
|----------------------|---------|-------|-------|-------|------|---------|
| FCVT.L.S RM,RD,FRS1  | 1100000 | 00010 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.LU.S RM,RD,FRS1 | 1100000 | 00011 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.S.L RM,RD,FRS1  | 1101000 | 00010 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.S.LU RM,RD,FRS1 | 1101000 | 00011 | FRS1  | RM    | FRD  | 1010011 |

0.3.1.2.5. Standard Extension for Double-Precision Floating-Point RV32D : Standard Extension for Double-Precision Floating-Point (32 bit)

| RV32F                          | 31:25      | 24:20 | 19:15 | 14:12 | 11:7  | 6:0     |
|--------------------------------|------------|-------|-------|-------|-------|---------|
| FLW FRD,RS1                    | IIIIIII    | IIIII | FRS1  | 011   | FRD   | 0000111 |
| FSW FRS2,RS1                   | IIIIIII    | FRS2  | FRS1  | 011   | IIIII | 0100111 |
| FMADD.D RM,FRD,FRS1,FRS2,FRS3  | $FRS3\_01$ | FRS2  | FRS1  | RM    | FRD   | 1000011 |
| FMSUB.D RM,FRD,FRS1,FRS2,FRS3  | $FRS3\_01$ | FRS2  | FRS1  | RM    | FRD   | 1000111 |
| FNMSUB.D RM,FRD,FRS1,FRS2,FRS3 | $FRS3\_01$ | FRS2  | FRS1  | RM    | FRD   | 1001011 |
| FNMADD.D RM,FRD,FRS1,FRS2,FRS3 | $FRS3\_01$ | FRS2  | FRS1  | RM    | FRD   | 1001111 |
| FADD.D RM,FRD,FRS1,FRS2,FRS3   | 0000001    | FRS2  | FRS1  | RM    | FRD   | 1010011 |
| FSUB.D RM,FRD,FRS1,FRS2,FRS3   | 0000101    | FRS2  | FRS1  | RM    | FRD   | 1010011 |
| FMUL.D RM,FRD,FRS1,FRS2,FRS3   | 0001001    | FRS2  | FRS1  | RM    | FRD   | 1010011 |
| FDIV.D RM,FRD,FRS1,FRS2,FRS3   | 0001101    | FRS2  | FRS1  | RM    | FRD   | 1010011 |
| FSGNJ.D FRD,FRS1,FRS2          | 0010001    | FRS2  | FRS1  | 000   | FRD   | 1010011 |
| FSGNJN.D FRD,FRS1,FRS2         | 0010001    | FRS2  | FRS1  | 001   | FRD   | 1010011 |
| FSGNJX.D FRD,FRS1,FRS2         | 0010001    | FRS2  | FRS1  | 010   | FRD   | 1010011 |
| FMIN.D FRD,FRS1,FRS2           | 0010101    | FRS2  | FRS1  | 000   | FRD   | 1010011 |
| FMAX.D FRD,FRS1,FRS2           | 0010101    | FRS2  | FRS1  | 001   | FRD   | 1010011 |
| FSQRT.D FRD,FRS1,FRS2          | 0101101    | 00000 | FRS1  | RM    | FRD   | 1010011 |
| FLE.D FRD,FRS1,FRS2            | 1010001    | FRS2  | FRS1  | 000   | FRD   | 1010011 |
| FLT.D FRD,FRS1,FRS2            | 1010001    | FRS2  | FRS1  | 001   | FRD   | 1010011 |
| FEQ.D FRD,FRS1,FRS2            | 1010001    | FRS2  | FRS1  | 010   | FRD   | 1010011 |
| FCVT.W.D RM,RD,FRS1            | 1100001    | 00000 | FRS1  | RM    | FRD   | 1010011 |
| FCVT.WU.D RM,RD,FRS1           | 1100001    | 00010 | FRS1  | RM    | FRD   | 1010011 |
| FCVT.D.W RM,RD,FRS1            | 1101001    | 00000 | FRS1  | RM    | FRD   | 1010011 |
| FCVT.D.WU RM,RD,FRS1           | 1101001    | 00010 | FRS1  | RM    | FRD   | 1010011 |
| FCLASS.D RD,FRS1               | 1110001    | 00000 | FRS1  | 001   | RD    | 1010011 |

RV64D : Standard Extension for Double-Precision Floating-Point (64 bit)

| RV64D                | 31:25   | 24:20 | 19:15 | 14:12 | 11:7 | 6:0     |
|----------------------|---------|-------|-------|-------|------|---------|
| FCVT.L.D RM,RD,FRS1  | 1100001 | 00010 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.LU.D RM,RD,FRS1 | 1100001 | 00011 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.D.L RM,RD,FRS1  | 1101001 | 00010 | FRS1  | RM    | FRD  | 1010011 |
| FCVT.D.LU RM,RD,FRS1 | 1101001 | 00011 | FRS1  | RM    | FRD  | 1010011 |
| FMV.X.D RD,FRS1      | 1110001 | 00000 | FRS1  | 000   | RD   | 1010011 |

| RV64D           | 31:25   | 24:20 | 19:15 | 14:12 | 11:7 | 6:0     |
|-----------------|---------|-------|-------|-------|------|---------|
| FMV.D.X RD,FRS1 | 1111001 | 00000 | RS1   | 000   | FRD  | 1010011 |

- **0.3.1.3. ISA** Modes
- 0.3.1.3.1. RISC-V User
- 0.3.1.3.2. RISC-V Supervisor
- 0.3.1.3.3. RISC-V Hypervisor
- 0.3.1.3.4. RISC-V Machine
- 0.3.2. OpenRISC ISA
- 0.3.2.1. ISA Bases
- $0.3.2.2.1. \ \mathrm{OpenRISC} \ 32$
- $0.3.2.2.2.\ OpenRISC\ 64$
- 0.3.2.2.3. OpenRISC 128
- 0.3.2.2. ISA Extensions
- 0.3.2.3. ISA Modes
- 0.3.2.3.1. OpenRISC User
- 0.3.2.3.2. OpenRISC Supervisor
- 0.3.2.3.3. OpenRISC Hypervisor
- 0.3.2.3.4. OpenRISC Machine
- 0.3.3. MSP430 ISA
- **0.3.3.1.** ISA Bases
- 0.3.3.2.1. MSP430 32
- 0.3.3.2.2. MSP430 64
- 0.3.3.2.3. MSP430 128
- 0.3.3.2. ISA Extensions
- **0.3.3.3. ISA** Modes
- 0.3.3.3.1. MSP430 User

- 0.3.3.3.2. MSP430 Supervisor
- 0.3.3.3.3. MSP430 Hypervisor
- 0.3.3.3.4. MSP430 Machine

## 1. METODOLOGY

- 1.1. Requirements
- 1.1.1. Structural UML diagrams
- 1.1.1.1. Class diagram
- 1.1.1.2. Component diagram
- 1.1.1.3. Composite diagram
- 1.1.1.4. Deployment diagram
- 1.1.1.5. Object diagram
- 1.1.1.6. Package diagram
- 1.1.1.7. Profile diagram
- 1.1.2. Behavioral UML diagrams
- 1.1.2.1. Activity diagram
- 1.1.2.2. Communication diagram
- 1.1.2.3. Interaction diagram
- 1.1.2.4. Sequence diagram
- 1.1.2.5. State diagram
- 1.1.2.6. Timing diagram
- 1.1.2.7. Use diagram

- 1.2. Source
- 1.2.1. MatLab Language
- 1.2.2. Rust Language
- 1.3. Model
- 1.3.1. VHDL
- 1.3.2. Verilog
- 1.4. Validation
- 1.4.1. VHDL
- 1.4.2. Verilog
- 1.5. Design
- 1.5.1. VHDL
- 1.5.2. Verilog
- 1.6. Verification
- 1.6.1. OSVVM-VHDL
- 1.6.1.1. OSVVM Checker
- 1.6.1.2. OSVVM Stimulus
- 1.6.1.3. OSVVM Testbench
- 1.6.2. UVM-Verilog
- 1.6.2.1. UVM Agent
- 1.6.2.2. UVM Driver
- 1.6.2.3. UVM Environment
- 1.6.2.4. UVM Monitor
- 1.6.2.5. UVM Scoreboard
- 1.6.2.6. UVM Sequence
- 1.6.2.7. UVM Sequencer
- 1.6.2.8. UVM Subscriber
- 1.6.2.9. UVM Test
- 1.6.2.10. UVM Testbench
- 1.6.2.11. UVM Transaction



Figure 2: UVM Diagram Overview

## 2. PROJECTS

A Random Access Memory (RAM) is a computer memory that can be read and changed in any order, typically used to store working data and machine code. A RAM device allows data items to be read or written in almost the same amount of time irrespective of the physical location of data inside the memory. RAM contains multiplexing and demultiplexing circuitry, to connect the data lines to the addressed storage for reading or writing the entry.

## 2.1. Random Access Memory for a Processing Unit

- 2.1.1. Functionality
- **2.1.1.1.** Structure
- 2.1.1.2. Behavior
- 2.1.2. Interface
- **2.1.2.1.** Constants
- 2.1.2.2. Signals
- 2.1.3. Registers
- 2.1.4. Interruptions
- 2.2. Random Access Memory for a System on Chip
- 2.2.1. Functionality
- **2.2.1.1.** Structure

| Core             | Module description                |
|------------------|-----------------------------------|
| mpsoc_axi4_spram | Multi-Port RAM for AMBA4 AXI-Lite |

| Core  | Module description   |
|---|--|
| <pre>mpsoc_ahb3_sprammpsoc_ram_1r1wmpsoc_ram_1r1w_generic</pre> | Multi-Port RAM for AMBA3 AHB-Lite<br>RAM Wrapper<br>RAM Generic Module |

| Core                               | Module description                                |
|------------------------------------|---|
| mpsoc_wb_sprammpsoc_wb_ram_generic | Multi-Port RAM for WishBone<br>RAM Generic Module |

- **2.2.1.2.** Behavior
- 2.2.2. Interface
- **2.2.2.1.** Constants
- **2.2.2.2.** Signals
- 2.2.3. Registers
- 2.2.4. Interruptions
- 2.3. Random Access Memory for a Multi-Processor System on Chip
- 2.3.1. Functionality
- **2.3.1.1.** Structure
- **2.3.1.2.** Behavior
- 2.3.2. Interface
- **2.3.2.1.** Constants
- **2.3.2.2.** Signals
- 2.3.3. Registers
- 2.3.4. Interruptions

## 3. ORGANIZATION

- 3.1. Mechanics
- 3.2. Information
- 3.2.1. Bit
- 3.2.2. Logic Gate
- **3.2.2.1.** YES/NOT Gate

- 3.2.2.2. AND/NAND Gate
- 3.2.2.3. OR/NOR Gate
- 3.2.2.4. XOR/XNOR Gate
- 3.2.3. Combinational Logic
- 3.2.3.1. Arithmetic Circuits
- 3.2.3.2. Logic Circuits
- 3.2.4. Finite State Machine
- 3.2.5. Pushdown Automaton
- 3.3. Neural Network
- 3.3.1. Feedforward Neural Network
- 3.3.2. Long Short Term Memory Neural Network
- 3.3.3. Transformer Neural Network
- 3.4. Turing Machine
- 3.4.1. Neural Turing Machine
- 3.4.1.1. Feedforward Neural Turing Machine
- 3.4.1.2. LSTM Neural Turing Machine
- 3.4.1.3. Transformer Neural Turing Machine
- 3.4.2. Differentiable Neural Computer
- 3.4.2.1. Feedforward Differentiable Neural Computer
- 3.4.2.2. LSTM Differentiable Neural Computer
- 3.4.2.3. Transformer Differentiable Neural Computer
- 3.5. Computer Architecture
- 3.5.1. von Neumann Architecture
- 3.5.1.1. Control Unit
- 3.5.1.2. ALU
- 3.5.1.3. Memory Unit
- 3.5.1.4. I/O Unit
- 3.5.2. Harvard Architecture
- 3.5.2.1. Control Unit

3.5.2.2. ALU

3.5.2.3. Memory Unit

3.5.2.4.I/O Unit

## 3.6. Advanced Computer Architecture

3.6.1. Processing Unit

3.6.1.1. SISD

3.6.1.2. SIMD

3.6.1.3. MISD

3.6.1.4. MIMD

3.6.2. System on Chip

3.6.2.1. Bus on Chip

3.6.2.2. Network on Chip

3.6.3. Multi-Processor System on Chip

### 4. HARDWARE WORKFLOW

#### 1. System Level (SystemC/SystemVerilog)

The System Level abstraction of a system only looks at its biggest building blocks like processing units or peripheral devices. At this level the circuit is usually described using traditional programming languages like SystemC or SystemVerilog. Sometimes special software libraries are used that are aimed at simulation circuits on the system level. The IEEE 1685-2009 standard defines the IP-XACT file format that can be used to represent designs on the system level and building blocks that can be used in such system level designs.

#### 2. Behavioral & Register Transfer Level (VHDL/Verilog)

At the Behavioural Level abstraction a language aimed at hardware description such as Verilog or VHDL is used to describe the circuit, but so-called behavioural modeling is used in at least part of the circuit description. In behavioural modeling there must be a language feature that allows for imperative programming to be used to describe data paths and registers. This is the always -block in Verilog and the process -block in VHDL.

A design in Register Transfer Level representation is usually stored using HDLs like Verilog and VHDL. But only a very limited subset of features is used, namely minimalistic always blocks (Verilog) or process blocks (VHDL) that model the register type used and unconditional assignments for the datapath logic. The use of HDLs on this level simplifies simulation as no additional tools are required to simulate a design in Register Transfer Level representation.

## 3. Logical Gate

At the Logical Gate Level the design is represented by a netlist that uses only cells from a small number of single-bit cells, such as basic logic gates (AND, OR, NOT, XOR, etc.) and registers (usually D-Type Flip-flops). A number of netlist formats exists that can be used on this level such as the Electronic Design Interchange Format (EDIF), but for ease of simulation often a HDL netlist is used. The latter is a HDL file (Verilog or VHDL) that only uses the most basic language constructs for instantiation and connecting of cells.

## 4. Physical Gate

On the Physical Gate Level only gates are used that are physically available on the target architecture. In some cases this may only be NAND, NOR and NOT gates as well as D-Type registers. In the case of an FPGA-based design the Physical Gate Level representation is a netlist of LUTs with optional output registers, as these are the basic building blocks of FPGA logic cells.

#### 5. Switch Level

A Switch Level representation of a circuit is a netlist utilizing single transistors as cells. Switch Level modeling is possible in Verilog and VHDL, but is seldom used in modern designs, as in modern digital ASIC or FPGA flows the physical gates are considered the atomic build blocks of the logic circuit.

- 1. Settings  $\rightarrow$  Apps  $\rightarrow$  Apps & features  $\rightarrow$  Related settings, Programs and Features  $\rightarrow$  Turn Windows features on or off  $\rightarrow$  Windows Subsystem for Linux
- 2. Microsoft Store  $\rightarrow$  INSTALL UBUNTU

```
Front-End and Back-End Library type:
```

```
sudo apt update
sudo apt install bison cmake flex freeglut3-dev libcairo2-dev libgs1-dev \
libncurses-dev libx11-dev m4 python-tk python3-tk swig tcl tcl-dev tk-dev tcsh
Synthesizer Library type:
sudo apt update
sudo apt upgrade
sudo apt upgrade
sudo apt -y install build-essential clang bison flex \
libreadline-dev gawk tcl-dev libffi-dev git make gnat \
graphviz xdot pkg-config python3 libboost-system-dev \
libboost-python-dev libboost-filesystem-dev zlib1g-dev
```

## 4.1. FRONT-END OPEN SOURCE TOOLS

### 4.1.1. Modeling System Level of Hardware

A System Description Language Editor is a computer tool that allows to generate software code. A System Description Language is a formal language, which comprises a Programming Language (input), producing a Hardware Description (output). Programming languages are used in computer programming to implement algorithms. The description of a programming language is split into the two components of syntax (form) and semantics (meaning).

#### System Description Language Editor

type:

git clone https://github.com/emacs-mirror/emacs

#### 4.1.2. Simulating System Level of Hardware

A System Description Language Simulator (translator) is a computer program that translates computer code written in a Programming Language (the source language) into a Hardware Description Language (the target language). The compiler is primarily used for programs that translate source code from a high-level programming language to a low-level language to create an executable program.

#### SystemVerilog System Description Language Simulator

```
git clone http://git.veripool.org/git/verilator

cd verilator
autoconf
./configure
make
sudo make install

cd sim/verilog/regression/wb/vtor
source SIMULATE-IT

cd sim/verilog/regression/ahb3/vtor
source SIMULATE-IT

cd sim/verilog/regression/axi4/vtor
source SIMULATE-IT
```

### 4.1.3. Verifying System Level of Hardware

A UVM standard improves interoperability and reduces the cost of repurchasing and rewriting IP for each new project or Electronic Design Automation tool. It also makes it easier to reuse verification components. The UVM Class Library provides generic utilities, such as component hierarchy, Transaction Library Model or configuration database, which enable the user to create virtually any structure wanted for the testbench.

## SystemVerilog System Description Language Verifier

type:

git clone https://github.com/QueenField/UVM

## 4.1.4. Describing Register Transfer Level of Hardware

A Hardware Description Language Editor is any editor that allows to generate hardware code. Hardware Description Language is a specialized computer language used to describe the structure and behavior of digital logic circuits. It allows for the synthesis of a HDL into a netlist, which can then be synthesized, placed and routed to produce the set of masks used to create an integrated circuit.

#### Hardware Description Language Editor

type:

git clone https://github.com/emacs-mirror/emacs

#### 4.1.5. Simulating Register Transfer Level of Hardware

A Hardware Description Language Simulator uses mathematical models to replicate the behavior of an actual hardware device. Simulation software allows for modeling of circuit operation and is an invaluable analysis tool. Simulating a circuit's behavior before actually building it can greatly improve design efficiency by making faulty designs known as such, and providing insight into the behavior of electronics circuit designs.

#### VHDL Hardware Description Language Simulator

```
type:
git clone https://github.com/ghdl/ghdl
cd ghdl
./configure --prefix=/usr/local
make
sudo make install
```

```
cd sim/vhdl/regression/wb/ghdl
source SIMULATE-IT
cd sim/vhdl/regression/ahb3/ghdl
source SIMULATE-IT
cd sim/vhdl/regression/axi4/ghdl
source SIMULATE-IT
Verilog Hardware Description Language Simulator
type:
git clone https://github.com/steveicarus/iverilog
cd iverilog
sh autoconf.sh
./configure
make
sudo make install
cd sim/verilog/regression/wb/iverilog
source SIMULATE-IT
cd sim/verilog/regression/ahb3/iverilog
source SIMULATE-IT
cd sim/verilog/regression/axi4/iverilog
```

#### 4.1.6. Synthesizing Register Transfer Level of Hardware

source SIMULATE-IT

A Hardware Description Language Synthesizer turns a RTL implementation into a Logical Gate Level implementation. Logical design is a step in the standard design cycle in which the functional design of an electronic circuit is converted into the representation which captures logic operations, arithmetic operations, control flow, etc. In EDA parts of the logical design is automated using synthesis tools based on the behavioral description of the circuit.

## Verilog Hardware Description Language Synthesizer

```
type:
git clone https://github.com/YosysHQ/yosys

cd yosys
make
sudo make install
cd synthesis/yosys
source SYNTHESIZE-IT

VHDL Hardware Description Language Synthesizer
type for Plugin:
git clone https://github.com/ghdl/ghdl-yosys-plugin

cd ghdl-yosys-plugin
make GHDL=/usr/local
sudo yosys-config --exec mkdir -p --datdir/plugins
sudo yosys-config --exec cp "ghdl.so" --datdir/plugins/ghdl.so
```

```
cd synthesis/yosys
source SYNTHESIZE-IT
```

#### 4.1.7. Optimizing Register Transfer Level of Hardware

A Hardware Description Language Optimizer finds an equivalent representation of the specified logic circuit under specified constraints (minimum area, pre-specified delay). This tool combines scalable logic optimization based on And-Inverter Graphs (AIGs), optimal-delay DAG-based technology mapping for look-up tables and standard cells, and innovative algorithms for sequential synthesis and verification.

## Verilog Hardware Description Language Optimizer

```
type:
git clone https://github.com/YosysHQ/yosys

cd yosys
make
sudo make install
cd synthesis/yosys
source SYNTHESIZE-IT
```

## 4.1.8. Verifying Register Transfer Level of Hardware

A Hardware Description Language Verifier proves or disproves the correctness of intended algorithms underlying a hardware system with respect to a certain formal specification or property, using formal methods of mathematics. Formal verification uses modern techniques (SAT/SMT solvers, BDDs, etc.) to prove correctness by essentially doing an exhaustive search through the entire possible input space (formal proof).

## Verilog Hardware Description Language Verifier

```
type:
```

git clone https://github.com/YosysHQ/SymbiYosys

## 4.2. BACK-END OPEN SOURCE TOOLS

#### Library

```
sudo apt upgrade

sudo apt install bison cmake flex freeglut3-dev libcairo2-dev libgsl-dev \
libncurses-dev libx11-dev m4 python-tk python3-tk swig tcl tcl-dev tk-dev tcsh

Back-End Workflow Qflow

type:
git clone https://github.com/RTimothyEdwards/qflow

cd qflow
   ./configure
make
sudo make install

mkdir qflow
cd qflow
```

#### 4.2.1. Planning Switch Level of Hardware

A Floor-Planner of an Integrated Circuit (IC) is a schematic representation of tentative placement of its major functional blocks. In modern electronic design process floor-plans are created during the floor-planning design stage, an early stage in the hierarchical approach to Integrated Circuit design. Depending on the design methodology being followed, the actual definition of a floor-plan may differ.

#### Floor-Planner

```
type:
git clone https://github.com/RTimothyEdwards/magic
cd magic
./configure
make
sudo make install
```

## 4.2.2. Placing Switch Level of Hardware

A Standard Cell Placer takes a given synthesized circuit netlist together with a technology library and produces a valid placement layout. The layout is optimized according to the aforementioned objectives and ready for cell resizing and buffering, a step essential for timing and signal integrity satisfaction. Physical design flow are iterated a number of times until design closure is achieved.

#### Standard Cell Placer

```
type:
git clone https://github.com/rubund/graywolf
cd graywolf
mkdir build
cd build
cmake ..
make
sudo make install
```

## 4.2.3. Timing Switch Level of Hardware

A Standard Cell Timing-Analizer is a simulation method of computing the expected timing of a digital circuit without requiring a simulation of the full circuit. High-performance integrated circuits have traditionally been characterized by the clock frequency at which they operate. Measuring the ability of a circuit to operate at the specified speed requires an ability to measure, during the design process, its delay at numerous steps.

#### Standard Cell Timing-Analizer

```
type:
git clone https://github.com/The-OpenROAD-Project/OpenSTA
cd OpenSTA
mkdir build
cd build
cmake ..
make
sudo make install
```

#### 4.2.4. Routing Switch Level of Hardware

A Standard Cell Router takes pre-existing polygons consisting of pins on cells, and pre-existing wiring called pre-routes. Each of these polygons are associated with a net. The primary task of the router is to create geometries such that all terminals assigned to the same net are connected, no terminals assigned to different nets are connected, and all design rules are obeyed.

#### Standard Cell Router

```
type:
git clone https://github.com/RTimothyEdwards/qrouter
cd qrouter
   ./configure
make
sudo make install
```

#### 4.2.5. Simulating Switch Level of Hardware

A Standard Cell Simulator treats transistors as ideal switches. Extracted capacitance and lumped resistance values are used to make the switch a little bit more realistic than the ideal, using the RC time constants to predict the relative timing of events. This simulator represents a circuit in terms of its exact transistor structure but describes the electrical behavior in a highly idealized way.

#### Standard Cell Simulator

```
type:
git clone https://github.com/RTimothyEdwards/irsim
cd irsim
./configure
make
sudo make install
```

## 4.2.6. Verifying Switch Level of Hardware LVS

A Standard Cell Verifier compares netlists, a process known as LVS (Layout vs. Schematic). This step ensures that the geometry that has been laid out matches the expected circuit. The greatest need for LVS is in large analog or mixed-signal circuits that cannot be simulated in reasonable time. LVS can be done faster than simulation, and provides feedback that makes it easier to find errors.

## Standard Cell Verifier

```
type:
git clone https://github.com/RTimothyEdwards/netgen
cd netgen
./configure
make
sudo make install
cd synthesis/qflow
source FLOW-IT
```

#### 4.2.7. Checking Switch Level of Hardware DRC

A Standard Cell Checker is a geometric constraint imposed on Printed Circuit Board (PCB) and Integrated Circuit (IC) designers to ensure their designs function properly, reliably, and can be produced with acceptable

yield. Design Rules for production are developed by hardware engineers based on the capability of their processes to realize design intent. Design Rule Checking (DRC) is used to ensure that designers do not violate design rules.

#### Standard Cell Checker

```
type:
git clone https://github.com/RTimothyEdwards/magic

cd magic
   ./configure
make
sudo make install
```

### 4.2.8. Printing Switch Level of Hardware GDS

A Standard Cell Editor allows to print a set of standard cells. The standard cell methodology is an abstraction, whereby a low-level VLSI layout is encapsulated into a logical representation. A standard cell is a group of transistor and interconnect structures that provides a boolean logic function (AND, OR, XOR, XNOR, inverters) or a storage function (flipflop or latch).

#### Standard Cell Editor

```
type:
git clone https://github.com/RTimothyEdwards/magic
cd magic
./configure
make
sudo make install
```

## 5. SOFTWARE WORKFLOW

## 5.1. BACK-END OPEN SOURCE TOOLS

```
sudo apt install autoconf automake autotools-dev curl python3 libmpc-dev \
libmpfr-dev libgmp-dev gawk build-essential bison flex texinfo gperf \
libtool patchutils bc zlib1g-dev libexpat-dev
```

- 5.1.1. MSP430
- 5.1.1.1. MSP430 GNU C/C++
- 5.1.1.2. MSP430 GNU Go
- 5.1.2. OpenRISC
- 5.1.2.1. OpenRISC GNU C/C++
- 5.1.2.2. OpenRISC GNU Go

```
5.1.3. RISC-V
5.1.3.1. RISC-V GNU C/C++ type:
git clone --recursive https://github.com/riscv/riscv-gnu-toolchain
cd riscv-gnu-toolchain
./configure --prefix=/opt/riscv-elf-gcc
sudo make clean
sudo make
./configure --prefix=/opt/riscv-elf-gcc
sudo make clean
sudo make linux
./configure --prefix=/opt/riscv-elf-gcc --enable-multilib
sudo make clean
sudo make linux
5.1.3.2. RISC-V GNU Go type:
git clone --recursive https://go.googlesource.com/go riscv-go
cd riscv-go/src
./all.bash
cd ../..
sudo mv riscv-go /opt
5.2. FRONT-END OPEN SOURCE TOOLS
5.2.1. MSP430
5.2.2. OpenRISC
5.2.3. RISC-V
type:
sudo apt install device-tree-compiler libglib2.0-dev libpixman-1-dev pkg-config
5.2.3.1. Hardware Engineers Compiler: Spike Building Proxy Kernel
type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
git clone --recursive https://github.com/riscv/riscv-pk
cd riscv-pk
mkdir build
cd build
../configure --prefix=/opt/riscv-elf-gcc --host=riscv64-unknown-elf
sudo make install
```

**Building Spike** 

```
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
git clone --recursive https://github.com/riscv/riscv-isa-sim

cd riscv-isa-sim
mkdir build
cd build
../configure --prefix=/opt/riscv-elf-gcc
make
sudo make install

5.2.3.2. Software Engineers Compiler: QEMU type:
export PATH=/opt/riscv-elf-gcc/bin:${PATH}
git clone --recursive https://github.com/qemu/qemu

cd qemu
./configure --prefix=/opt/riscv-elf-gcc \
--target-list=riscv64-softmmu,riscv32-softmmu,riscv64-linux-user,riscv32-linux-user
make
sudo make install
```