1. INTRODUCTION

A Processing Unit (PU) is an electronic system within a computer that carries out instructions of a program by performing the basic arithmetic, logic, controlling, and I/O operations specified by instructions. Instruction-level parallelism is a measure of how many instructions in a computer can be executed simultaneously. The PU is contained on a single Metal Oxide Semiconductor (MOS) Integrated Circuit (IC).

The RISC-V implementation has a 32/64/128 bit Microarchitecture, 6 stages data pipeline and an Instruction Set Architecture based on Reduced Instruction Set Computer. Compatible with AMBA and Wishbone Buses. For Researching and Developing.

Processing Unit	Module description
riscv_pu riscv_core	Processing Unit Core
\dots riscv $_$ imem $_$ ctrl	Instruction Memory Access Block
riscv_biu - imem riscv_dmem_ctrl	Bus Interface Unit (Instruction) Data Memory Access Block
$\dots riscv_biu$ - dmem	Bus Interface Unit (Data)

2. PROJECTS

2.1. CORE-RISCV

2.1.1. RISC Pipeline

In computer science, instruction pipelining is a technique for implementing instruction-level parallelism within a PU. Pipelining attempts to keep every part of the processor busy with some instruction by dividing incoming instructions into a series of sequential steps performed by different PUs with different parts of instructions processed in parallel. It allows faster PU throughput than would otherwise be possible at a given clock rate.

Typical	Modified	Module
FETCH	FETCH	riscv_if
	PRE-DECODE	riscv_id
DECODE	DECODE	$riscv_id$
EXECUTE	EXECUTE	$riscv_execution$
MEMORY	MEMORY	$riscv_memory$
WRITE-BACK	WRITE-BACK	$riscv_wb$

- IF Instruction Fetch Unit: Send out the PC and fetch the instruction from memory into the Instruction Register (IR); increment the PC to address the next sequential instruction. The IR is used to hold the next instruction that will be needed on subsequent clock cycles; likewise the register NPC is used to hold the next sequential PC.
- ID Instruction Decode Unit: Decode the instruction and access the register file to read the registers. This unit gets instruction from IF, and extracts opcode and operand from that instruction. It also retrieves register values if requested by the operation.
- EX Execution Unit: The ALU operates on the operands prepared in prior cycle, performing one functions depending on instruction type.
- MEM Memory Access Unit: Instructions active in this unit are loads, stores and branches.
- WB WriteBack Unit: Write the result into the register file, whether it comes from the memory system or from the ALU.

2.1.2. CORE-RISCV Organization

The CORE-RISCV is based on the Harvard architecture, which is a computer architecture with separate storage and signal pathways for instructions and data. A Harvard architecture machine has distinct code and data address spaces: instruction address zero is not the same as data address zero. Instruction address zero might identify a twenty-four-bit value, while data address zero might indicate an eight-bit byte that is not part of that twenty-four-bit value.

Core	Module description
riscv_core	Core
$\dots riscv_if$	Instruction Fetch
\dots riscv_id	Instruction Decoder
\dots riscv_execution	Execution Unit
riscv_alu	Arithmetic & Logical Unit
riscv_lsu	Load Store Unit
riscv_bu	Branch Unit
riscv_mul	Multiplier Unit
riscv_div	Division Unit
riscv_memory	Memory Unit
riscv_wb	Data Memory Access (Write Back)
riscv_state	State Unit
riscv_rf	Register File
$\dots riscv_bp$	Correlating Branch Prediction Unit
\dots riscv_ram_1r1w	RAM 1RW1
riscv_ram_1r1w_generic	RAM 1RW1 Generic

Core	Module description	
riscv_du	Debug Unit	

In a Harvard architecture, there is no need to make the two memories share characteristics. In particular, the word width, timing, implementation technology, and memory address structure can differ. In some systems, instructions for preprogrammed tasks can be stored in read-only memory while data memory generally requires read-write memory. In some systems, there is much more instruction memory than data memory so instruction addresses are wider than data addresses.

2.1.3. Parameters

Parameter	Type	Default	Description
JEDEC_BANK	Integer	0x0A	JEDEC Bank
JEDEC_MANUFACTURER_ID	Integer	0x6E	JEDEC Manufacturer ID
XLEN	Integer	64	Data Path Width
PLEN	Integer	64	Physical Memory Address Size
PMP_CNT	Integer	16	Physical Memory Protection Entries
PMA_CNT	Integer	16	Physical Menory Attribute Entries
HAS_USER	Integer	1	User Mode Enable
HAS_SUPER	Integer	1	Supervisor Mode Enable
HAS_HYPER	Integer	1	Hypervisor Mode Enable
HAS_RVM	Integer	1	"M" Extension Enable
HAS_RVA	Integer	1	"A" Extension Enable
HAS_RVC	Integer	1	"C" Extension Enable
HAS_BPU	Integer	1	Branch Prediction Unit Control Enable
IS_RV32E	Integer	0	Base Integer Instruction Set Enable
MULT_LATENCY	Integer	1	Hardware Multiplier Latency
ICACHE_SIZE	Integer	16	Instruction Cache size
ICACHE_BLOCK_SIZE	Integer	64	Instruction Cache block length
ICACHE_WAYS	Integer	2	Instruction Cache associativity
ICACHE_REPLACE_ALG	Integer	0	Instruction Cache replacement
DCACHE_SIZE	Integer	16	Data Cache size
DCACHE_BLOCK_SIZE	Integer	64	Data Cache block length
DCACHE_WAYS	Integer	2	Data Cache associativity
DCACHE_REPLACE_ALG	Integer	0	Data Cache replacement algorithm
HARTID	Integer	0	Hart Identifier
PC_INIT	Address	'h200	Program Counter Initialisation Vector
MNMIVEC_DEFAULT	Address	PC_INIT-'h004	Machine Mode Non-Maskable
MTVEC_DEFAULT	Address	PC_INIT-'h040	Machine Mode Interrupt Address
HTVEC_DEFAULT	Address	PC_INIT-'h080	Hypervisor Mode Interrupt Address
STVEC_DEFAULT	Address	PC_INIT-'hOCO	Supervisor Mode Interrupt Address

Parameter	Type	Default	Description
UTVEC_DEFAULT	Address	PC_INIT-'h100	User Mode Interrupt Address
BP_LOCAL_BITS	Integer	10	Number of local predictor bits
BP_GLOBAL_BITS	Integer	2	Number of global predictor bits
BREAKPOINTS	Integer	3	Number of hardware breakpoints
TECHNOLOGY	String	GENERIC	Target Silicon Technology

${\bf 2.1.4.\ Instruction\ INPUTS/OUTPUTS\ Bus}$

Port	Size	Direction	Description
ins_stb	1	Input	Strobe
ins_stb_ack	1	Output	Strobe acknowledge
ins_d_ack	1	Output	Data acknowledge
ins_adri	PLEN	Input	Start address
ins_adro	PLEN	Output	Response address
ins_size	3	Input	Syze
ins_type	3	Input	Type
ins_prot	3	Input	Protection
ins_lock	1	Input	Locked access
ins_d	XLEN	Input	Write data
ins_q	XLEN	Output	Read data
ins_ack	1	Output	Acknowledge
ins_err	1	Output	Error

2.1.5. Data INPUTS/OUTPUTS Bus

Port	Size	Direction	Description
dat_stb	1	Input	Strobe
dat_stb_ack	1	Output	Strobe acknowledge
dat_d_ack	1	Output	Data acknowledge
dat_adri	PLEN	Input	Start address
dat_adro	PLEN	Output	Response address
dat_size	3	Input	Syze
dat_type	3	Input	Type
dat_prot	3	Input	Protection
dat_lock	1	Input	Locked access
dat_d	XLEN	Input	Write data
dat_q	XLEN	Output	Read data
dat_ack	1	Output	Acknowledge
dat_err	1	Output	Error

2.2. INSTRUCTION CACHE

A PU cache is a hardware cache used by the PU to reduce the average cost (time or energy) to access instruction/data from the main memory. A cache is a smaller, faster memory, closer to a core, which stores copies of the data from frequently used main memory locations. Most CPUs have different independent caches, including instruction and data caches.

2.2.1. Instruction Organization

Instruction Memory	Module description
riscv_imem_ctrl	Instruction Memory Access Block
\dots riscv $_$ membuf	Memory Access Buffer
riscv_ram_queue	Fall-through Queue
\dots riscv_memmisaligned	Misalignment Check
riscv_mmu	Memory Management Unit
riscv_pmachk	Physical Memory Attributes Checker
\dots riscv_pmpchk	Physical Memory Protection Checker
\dots riscv_icache_core	Instruction Cache (Write Back)
\dots riscv $_{ram}1rw$	RAM 1RW
riscv_ram_1rw_generic	RAM 1RW Generic
riscv_dext	Data External Access Logic
riscv_ram_queue	Fall-through Queue
riscv_mux	Bus-Interface-Unit Mux
riscv_biu	Bus Interface Unit

2.2.2 Instruction INPUTS/OUTPUTS AMBA4 AXI-Lite Bus

2.2.2.1. Signals of the Read and Write Address channels

Write Port	Read Port	Size	Direction	Description
AWID	ARID	AXI_ID_WIDTH	Output	Address ID, to identify multiple streams
AWADDR	ARADDR	AXI_ADDR_WIDTH	Output	Address of the first beat of the burst
AWLEN	ARLEN	8	Output	Number of beats inside the burst
AWSIZE	ARSIZE	3	Output	Size of each beat
AWBURST	ARBURST	2	Output	Type of the burst
AWLOCK	ARLOCK	1	Output	Lock type, to provide atomic operations
AWCACHE	ARCACHE	4	Output	Memory type, progress through the system
AWPROT	ARPROT	3	Output	Protection type
AWQOS	ARQOS	4	Output	Quality of Service of the transaction
AWREGION	ARREGION	4	Output	Region identifier, physical to logical
AWUSER	ARUSER	AXI_USER_WIDTH	Output	User-defined data

Write Port	Read Port	Size	Direction	Description
AWVALID	ARVALID	1	Output	xVALID handshake signal
AWREADY	ARREADY	1	Input	xREADY handshake signal

2.2.2. Signals of the Read and Write Data channels

Write Port	Read Port	Size	Direction	Description
WID	RID	AXI_ID_WIDTH	Output	Data ID, to identify multiple streams
WDATA	RDATA	AXI_DATA_WIDTH	Output	Read/Write data
	RRESP	2	Output	Read response, current RDATA status
WSTRB		AXI_STRB_WIDTH	Output	Byte strobe, WDATA signal
WLAST	RLAST	1	Output	Last beat identifier
WUSER	RUSER	AXI_USER_WIDTH	Output	User-defined data
WVALID	RVALID	1	Output	xVALID handshake signal
WREADY	RREADY	1	Input	xREADY handshake signal

2.2.2.3. Signals of the Write Response channel

Write Port	Size	Direction	Description
BID BRESP	AXI_ID_WIDTH	Input Input	Write response ID, to identify multiple streams Write response, to specify the burst status
BUSER	AXI_USER_WIDTH	Input	User-defined data
BVALID	1	Input	xVALID handshake signal
BREADY	1	Output	xREADY handshake signal

${\bf 2.2.3.~Instruction~INPUTS/OUTPUTS~AMBA3~AHB-Lite~Bus}$

Port	Size	Direction	Description
HRESETn	1	Input	Asynchronous Active Low Reset
HCLK	1	Input	System Clock Input
IHSEL	1	Output	Instruction Bus Select
IHADDR	PLEN	Output	Instruction Address Bus
IHRDATA	XLEN	Input	Instruction Read Data Bus
IHWDATA	XLEN	Output	Instruction Write Data Bus
IHWRITE	1	Output	Instruction Write Select
IHSIZE	3	Output	Instruction Transfer Size
IHBURST	3	Output	Instruction Transfer Burst Size
IHPROT	4	Output	Instruction Transfer Protection Level

Port	Size	Direction	Description
IHTRANS	2	Output	Instruction Transfer Type
IHMASTLOCK	1	Output	Instruction Transfer Master Lock
IHREADY	1	Input	Instruction Slave Ready Indicator
IHRESP	1	Input	Instruction Transfer Response

2.2.4. Instruction INPUTS/OUTPUTS Wishbone Bus

Port	Size	Direction	Description
rst	1	Input	Synchronous Active High Reset
clk	1	Input	System Clock Input
iadr	AW	Input	Instruction Address Bus
idati	DW	Input	Instruction Input Bus
idato	DW	Output	Instruction Output Bus
isel	DW/8	Input	Byte Select Signals
iwe	1	Input	Write Enable Input
istb	1	Input	Strobe Signal/Core Select Input
icyc	1	Input	Valid Bus Cycle Input
iack	1	Output	Bus Cycle Acknowledge Output
ierr	1	Output	Bus Cycle Error Output
iint	1	Output	Interrupt Signal Output

2.3. DATA CACHE

2.3.1. Data Organization

Data Memory	Module description
riscv_dmem_ctrl	Data Memory Access Block
\dots riscv_membuf	Memory Access Buffer
riscv_ram_queue	Fall-through Queue
riscv_memmisaligned	Misalignment Check
riscv_mmu	Memory Management Unit
riscv_pmachk	Physical Memory Attributes Checker
riscv_pmpchk	Physical Memory Protection Checker
riscv_dcache_core	Data Cache (Write Back)
riscv_ram_1rw	RAM 1RW
riscv_ram_1rw_generic	RAM 1RW Generic
riscv dext	Data External Access Logic
riscv_mux	Bus-Interface-Unit Mux
riscv_biu	Bus Interface Unit

2.3.2. Data INPUTS/OUTPUTS AMBA4 AXI-Lite Bus

2.3.2.1. Signals of the Read and Write Address channels

Write Port	Read Port	Size	Direction	Description
AWID	ARID	AXI_ID_WIDTH	Output	Address ID, to identify multiple streams
AWADDR	ARADDR	AXI_ADDR_WIDTH	Output	Address of the first beat of the burst
AWLEN	ARLEN	8	Output	Number of beats inside the burst
AWSIZE	ARSIZE	3	Output	Size of each beat
AWBURST	ARBURST	2	Output	Type of the burst
AWLOCK	ARLOCK	1	Output	Lock type, to provide atomic operations
AWCACHE	ARCACHE	4	Output	Memory type, progress through the system
AWPROT	ARPROT	3	Output	Protection type
AWQOS	ARQOS	4	Output	Quality of Service of the transaction
AWREGION	ARREGION	4	Output	Region identifier, physical to logical
AWUSER	ARUSER	AXI_USER_WIDTH	Output	User-defined data
AWVALID	ARVALID	1	Output	xVALID handshake signal
AWREADY	ARREADY	1	Input	xREADY handshake signal

2.3.2.2. Signals of the Read and Write Data channels

Write Port	Read Port	Size	Direction	Description
WID	RID	AXI_ID_WIDTH	Output	Data ID, to identify multiple streams
WDATA	RDATA RRESP	AXI_DATA_WIDTH	Output Output	Read/Write data Read response, current RDATA status
WSTRB	KKESP	AXI_STRB_WIDTH	Output	Byte strobe, WDATA signal
WLAST	RLAST	1	Output	Last beat identifier
WUSER	RUSER	AXI_USER_WIDTH	Output	User-defined data
WVALID	RVALID	1	Output	xVALID handshake signal
WREADY	RREADY	1	Input	xREADY handshake signal

2.3.2.3. Signals of the Write Response channel

Write Port	Size	Direction	Description
BID	AXI_ID_WIDTH	Input	Write response ID, to identify multiple streams
BRESP	2	Input	Write response, to specify the burst status
BUSER	AXI_USER_WIDTH	Input	User-defined data
BVALID	1	Input	xVALID handshake signal
BREADY	1	Output	xREADY handshake signal

2.3.3. Data INPUTS/OUTPUTS AMBA3 AHB-Lite Bus

Port	Size	Direction	Description
HRESETn	1	Input	Asynchronous Active Low Reset
HCLK	1	Input	System Clock Input
DUCEI	1	Output	Data Bus Select
DHSEL	-	Output	
DHADDR	PLEN	Output	Data Address Bus
DHRDATA	XLEN	Input	Data Read Data Bus
DHWDATA	XLEN	Output	Data Write Data Bus
DHWRITE	1	Output	Data Write Select
DHSIZE	3	Output	Data Transfer Size
DHBURST	3	Output	Data Transfer Burst Size
DHPROT	4	Output	Data Transfer Protection Level
DHTRANS	2	Output	Data Transfer Type
DHMASTLOCK	1	Output	Data Transfer Master Lock
DHREADY	1	Input	Data Slave Ready Indicator
DHRESP	1	Input	Data Transfer Response

2.3.4. Data INPUTS/OUTPUTS Wishbone Bus

Port	Size	Direction	Description
rst	1	Input	Synchronous Active High Reset
clk	1	Input	System Clock Input
dadr	AW	Input	Data Address Bus
ddati	DW	Input	Data Input Bus
ddato	DW	Output	Data Output Bus
dsel	DW/8	Input	Byte Select Signals
dwe	1	Input	Write Enable Input
dstb	1	Input	Strobe Signal/Core Select Input
dcyc	1	Input	Valid Bus Cycle Input
dack	1	Output	Bus Cycle Acknowledge Output
derr	1	Output	Bus Cycle Error Output
dint	1	Output	Interrupt Signal Output

3. WORKFLOW

3.1. RISC-V ARCHITECTURE

3.1.1. Library

type:

sudo apt install autoconf automake autotools-dev curl python3 libmpc-dev \
libmpfr-dev libgmp-dev gawk build-essential bison flex texinfo gperf \
libtool patchutils bc zlib1g-dev libexpat-dev

3.1.2. Toolchain

mkdir tests

```
type:
git clone --recursive https://github.com/riscv/riscv-gnu-toolchain
cd riscv-gnu-toolchain
./configure --prefix=/opt/riscv
sudo make
./configure --prefix=/opt/riscv
sudo make linux
./configure --prefix=/opt/riscv --enable-multilib
sudo make linux
./configure --prefix=$RISCV
sudo make linux
sudo make report-linux
3.1.3. Software
type:
export PATH=$PATH:/opt/riscv/bin
cd software
rm -rf tests
rm -rf riscv-tests
```

```
mkdir tests/dump
mkdir tests/hex

git clone --recursive https://github.com/riscv/riscv-tests
cd riscv-tests

autoconf
./configure --prefix=/opt/riscv/bin
make

cd isa

source ../../elf2hex.sh

mv *.dump ../../tests/dump
mv *.hex ../../tests/hex

cd ..

make clean
```

3.2. FRONT-END OPEN SOURCE TOOLS

3.2.1. Verilator

SystemVerilog System Description Language Simulator

A System Description Language Simulator (translator) is a computer program that translates computer code written in a Programming Language (the source language) into a Hardware Design Language (the target language). The compiler is primarily used for programs that translate source code from a high-level programming language to a low-level language to create an executable program.

```
git clone http://git.veripool.org/git/verilator

cd verilator
autoconf
./configure
make
sudo make install
cd sim/verilog/regression/wb/vtor
source SIMULATE-IT
cd sim/verilog/regression/ahb3/vtor
```

3.2.2. Icarus Verilog

Verilog Hardware Description Language Simulator

A Hardware Description Language Simulator uses mathematical models to replicate the behavior of an actual hardware device. Simulation software allows for modeling of circuit operation and is an invaluable analysis tool. Simulating a circuit's behavior before actually building it can greatly improve design efficiency by making faulty designs known as such, and providing insight into the behavior of electronics circuit designs.

```
type:
```

```
git clone https://github.com/steveicarus/iverilog

cd iverilog
sh autoconf.sh
./configure
make
sudo make install

cd sim/verilog/regression/wb/iverilog
source SIMULATE-IT

cd sim/verilog/regression/ahb3/iverilog
source SIMULATE-IT
```

3.2.3. GHDL

VHDL Hardware Description Language Simulator

A Hardware Description Language Simulator uses mathematical models to replicate the behavior of an actual hardware device. Simulation software allows for modeling of circuit operation and is an invaluable analysis tool. Simulating a circuit's behavior before actually building it can greatly improve design efficiency by making faulty designs known as such, and providing insight into the behavior of electronics circuit designs.

```
type:
git clone https://github.com/ghdl/ghdl

cd ghdl
./configure --prefix=/usr/local
make
sudo make install
```

cd sim/vhdl/regression/wb/ghdl
source SIMULATE-IT
cd sim/vhdl/regression/ahb3/ghdl
source SIMULATE-IT

3.2.4. Yosys-ABC

Verilog Hardware Description Language Synthesizer

A Hardware Description Language Synthesizer turns a RTL implementation into a Logical Gate Level implementation. Logical design is a step in the standard design cycle in which the functional design of an electronic circuit is converted into the representation which captures logic operations, arithmetic operations, control flow, etc. In EDA parts of the logical design is automated using synthesis tools based on the behavioral description of the circuit.

Hardware Description Language Optimizer

A Hardware Description Language Optimizer finds an equivalent representation of the specified logic circuit under specified constraints (minimum area, prespecified delay). This tool combines scalable logic optimization based on And-Inverter Graphs (AIGs), optimal-delay DAG-based technology mapping for look-up tables and standard cells, and innovative algorithms for sequential synthesis and verification.

type:

git clone https://github.com/YosysHQ/yosys

cd yosys
make
sudo make install

cd synthesis/yosys
source SYNTHESIZE-IT

3.3. BACK-END OPEN SOURCE TOOLS

Library type:

sudo apt update
sudo apt upgrade

sudo apt install bison cmake flex freeglut3-dev libcairo2-dev libgs1-dev $\$ librcurses-dev libx11-dev m4 python-tk python3-tk swig tcl tcl-dev tk-dev tcsh

mkdir qflow cd qflow

3.3.1. Qflow

```
Back-End Workflow

type:

git clone https://github.com/RTimothyEdwards/qflow

cd qflow
./configure
make
sudo make install
```

3.3.2. Magic

Floor-Planner

A Floor-Planner of an Integrated Circuit (IC) is a schematic representation of tentative placement of its major functional blocks. In modern electronic design process floor-plans are created during the floor-planning design stage, an early stage in the hierarchical approach to Integrated Circuit design. Depending on the design methodology being followed, the actual definition of a floor-plan may differ.

Standard Cell Checker

A Standard Cell Checker is a geometric constraint imposed on Printed Circuit Board (PCB) and Integrated Circuit (IC) designers to ensure their designs function properly, reliably, and can be produced with acceptable yield. Design Rules for production are developed by hardware engineers based on the capability of their processes to realize design intent. Design Rule Checking (DRC) is used to ensure that designers do not violate design rules.

Standard Cell Editor

A Standard Cell Editor allows to print a set of standard cells. The standard cell methodology is an abstraction, whereby a low-level VLSI layout is encapsulated into a logical representation. A standard cell is a group of transistor and interconnect structures that provides a boolean logic function (AND, OR, XOR, XNOR, inverters) or a storage function (Flip-Flop or Latch).

```
git clone https://github.com/RTimothyEdwards/magic
```

```
cd magic
./configure
make
sudo make install
```

3.3.3. Graywolf

Standard Cell Placer

A Standard Cell Placer takes a given synthesized circuit netlist together with a technology library and produces a valid placement layout. The layout is optimized according to the aforementioned objectives and ready for cell resizing and buffering, a step essential for timing and signal integrity satisfaction. Physical design flow are iterated a number of times until design closure is achieved.

type:

```
git clone https://github.com/rubund/graywolf
```

cd graywolf
mkdir build
cd build
cmake ..
make
sudo make install

3.3.4. OpenSTA

Standard Cell Timing-Analizer

A Standard Cell Timing-Analizer is a simulation method of computing the expected timing of a digital circuit without requiring a simulation of the full circuit. High-performance integrated circuits have traditionally been characterized by the clock frequency at which they operate. Measuring the ability of a circuit to operate at the specified speed requires an ability to measure, during the design process, its delay at numerous steps.

type:

```
git clone https://github.com/The-OpenROAD-Project/OpenSTA
```

cd OpenSTA
mkdir build
cd build
cmake ..
make
sudo make install

3.3.5. Qrouter

Standard Cell Router

A Standard Cell Router takes pre-existing polygons consisting of pins on cells, and pre-existing wiring called pre-routes. Each of these polygons are associated with a net. The primary task of the router is to create geometries such that all terminals assigned to the same net are connected, no terminals assigned to different nets are connected, and all design rules are obeyed.

type:

git clone https://github.com/RTimothyEdwards/qrouter

cd qrouter
./configure
make
sudo make install

3.3.6. Irsim

Standard Cell Simulator

A Standard Cell Simulator treats transistors as ideal switches. Extracted capacitance and lumped resistance values are used to make the switch a little bit more realistic than the ideal, using the RC time constants to predict the relative timing of events. This simulator represents a circuit in terms of its exact transistor structure but describes the electrical behavior in a highly idealized way.

type:

git clone https://github.com/RTimothyEdwards/irsim

cd irsim
./configure
make
sudo make install

3.3.7. Netgen

Standard Cell Verifier

A Standard Cell Verifier compares netlists, a process known as LVS (Layout vs. Schematic). This step ensures that the geometry that has been laid out matches the expected circuit. The greatest need for LVS is in large analog or mixed-signal circuits that cannot be simulated in reasonable time. LVS can be done faster than simulation, and provides feedback that makes it easier to find errors.

```
git clone https://github.com/RTimothyEdwards/netgen

cd netgen
./configure
make
sudo make install
cd synthesis/qflow
source FLOW-IT
```

3.4. FOR WINDOWS USERS!

- 1. Settings \to Apps \to Apps & features \to Related settings, Programs and Features \to Turn Windows features on or off \to Windows Subsystem for Linux
- 2. Microsoft Store \rightarrow INSTALL UBUNTU

```
Library type:
```

```
sudo apt update
sudo apt upgrade
```

sudo apt install bison cmake flex freeglut3-dev libcairo2-dev libgs1-dev \ libncurses-dev libx11-dev m4 python-tk python3-tk swig tcl tcl-dev tk-dev tcsh

3.4.1. Front-End

```
type:
```

```
sudo apt install verilator
sudo apt install iverilog
sudo apt install ghdl

cd /mnt/c/../sim/verilog/regression/wb/iverilog
source SIMULATE-IT
sudo apt install yosys

cd /mnt/c/../synthesis/yosys
source SYNTHESIZE-IT
```

3.4.2. Back-End

```
mkdir qflow
cd qflow

git clone https://github.com/RTimothyEdwards/magic
git clone https://github.com/rubund/graywolf
git clone https://github.com/The-OpenROAD-Project/OpenSTA
git clone https://github.com/RTimothyEdwards/qrouter
git clone https://github.com/RTimothyEdwards/irsim
git clone https://github.com/RTimothyEdwards/netgen
git clone https://github.com/RTimothyEdwards/qflow

cd /mnt/c/../synthesis/qflow
source FLOW-IT
```

4. CONCLUSION