

ARM Instructions Worksheet #1

Function Call and Return

And their effect on registers PC, LR, and SP.

Prerequisite Reading: Chapter 3: Sections 3.1 and 3.2

Revised: March 26, 2020

Objectives: To become acquainted with the web-based simulator ("CPU1ator") and to use it to better understand how the are

- 1. Program Counter (PC) is used to fetch an instruction.
- 2. Branch and Link (BL) instruction is used to call a function,
- 3. Branch Indirect (BX) instruction is used to return from a function.
- 4. Link Register (LR) is used to hold the return address, and
- 5. PUSH and POP instructions use the Stack Pointer (SP) to preserve and restore register content.

To do offline: Answer the questions that follow the listing below. (Numbers at far left are memory addresses.)

```
.syntax
                               unified
                 .global
                               _start
 00000000
           _stack_end:
                 .skip 100
                                     // Reserve memory for stack
00000064
          tos:
00000064
          _start:
00000064
                 LDR
                       SP,=_tos
                                     // *** EXECUTION STARTS HERE ***
00000068
                 BL
                       f1
                                     // Simple function call
0000006C
                 BL
                       f2
                                     // Nested function call
00000070
                BL
                       f3
                                     // Optimized nested function
00000074
                В
                       done
                                     // End of demo
00000078
         f1:
                BX
                       LR
                                     // Simply returns
0000007c
         f2:
                PUSH
                       {LR}
                                     // Preserve LR
00000080
                BL
                       f1
                                     // Call f1 (changes LR)
00000084
                POP
                       {LR}
                                     // Restore LR
8800000
                BX
                       LR
                                     // Return (Copies LR into PC)
0000008C
         f3:
                PUSH
                       {LR}
                                     // Preserve LR
00000090
                BL
                       f1
                                     // Call f1 (Changes LR)
00000094
                POP
                       {PC}
                                     // Return
00000098 done: B
                       done
                                    // infinite loop
                 .end
```

What is left in SP after executing the LDR instruction at 00000064 ₁₆ ?	00000064
What is left in PC after executing the LDR instruction at 00000064 ₁₆ ?	0000008
What instruction is at the address that's now in the PC? (Include any referenced label)	RI fl
What address is left in register PC after executing the BL f1 instruction?	0000006C
What instruction is at the address that's now in the PC? (Include any referenced label)	BI 12
What address is left in register LR after executing the BL f1 instruction?	00000060
What instruction is at the address that's now in the LR? (Include any referenced label)	\$L +2
What value is in register PC after executing the BX LR instruction at 00000078 ₁₆ ?	0000076
What instruction is at the address that's now in the PC? (Include any referenced label)	ts: 621
 Click here to open a browser for the ARM instruction simulator with pre-loaded code Press Ctrl-E to open the "Editor" window and notice the LDR pseudo-instruction. Press Ctrl-D to replace the editor by the "Disassembly" window. Notice how the LDR by a <u>real</u> LDR instruction that loads SP from a word in memory whose content is the 	nserido-instruction has been replaced
The CPU registers are shown in the "Registers" window. Note that the PC value is 00000064 ram. At that address is the LDR instruction that initializes the stack pointer (SP), highlighted astruction to be executed. Press F2 once on the to execute that LDR instruction.	in yellow to indicate that it is the next
What is left in SP after executing the LDR instruction at 00000064 ₁₆ ?	00000064
What is left in PC after executing the LDR instruction at 00000064 ₁₆ ?	00000068
What instruction is at the address that's now in the PC? (Include any referenced label)	61 f1 .
he DC chariff and the DC chariff	
he PC should contain the address of the instruction, "BL f1". Press F2 once to execute the	instruction.
What address is left in register PC after executing the BL f1 instruction?	60000078
What instruction is at the address that's now in the PC? (Include any referenced label)	fl: Bx LR
What address is left in register LR after executing the BL f1 instruction?	0000060
What instruction is at the address that's now in the LR? (Include any referenced label)	bl f2
Step 3: Return from function f1	
The PC should contain the address of the instruction, "BX LR". Press F2 once to execute the i	nstruction.
What is in register PC after executing the BX LR instruction at 00000078 ₁₆ ? What instruction is at the address that's now in the PC? (Include any referenced label)	20000 fC
	u fz
Step 4: Continue exploring	
Continue pressing F2 to step through the program, noting changes to registers PC, LR and SP to function f1 that overwrites the return address of f2 in LR. In order for f2 to return properly f2 to copy the return address onto the stack and then restore it will.	
f2 to copy the return address onto the stack and then restore it with a POP {LR} before the relegiminates the BX LR by popping directly into the PC	furn. Function f3 does the same, but

eliminates the BX LR by popping directly into the PC.