

SAFE WORK METHOD STATEMENT

Persons responsible for supervising, inspecting work, work methods, plant & equipment and tools	Supervisor/Foreman:	Date:	
High Risk Construction Work:	Temporary Traffic Management in a Road Reserve, Underground Asset Location in a Rail Corridor	Project:	
SWMS prepared by Patrick Monaghan - Paneltec Group - Operations Manager and in consultation with management and workers – 2025. SWMS Review Date: August 2026 unless required earlier		Location:	
Signature: _____			
Approval to use this SWMS: "I certify that the attached SWMS has been reviewed by me, is endorsed for compliance with WorkSafe guidelines and is approved for use."			
John Guy Name	Director - Paneltec Pty Ltd Position	0408 449 023 	31/08/2025 – V12.0 Date

RISK MATRIX

Level	Description of Consequence or Impact	Consequence	Likelihood / Probability		
			L <i>Likely</i>	M <i>Moderate</i>	U <i>Unlikely</i>
H (1) <i>(High level of harm)</i>	Potential death, permanent disability or major structural failure/damage. Off-site environmental discharge/release not contained and significant long-term environmental harm.	H (1) <i>(High)</i>	1	1	2
M (2) <i>(Medium level of harm)</i>	Potential temporary disability or minor structural failure/damage. On-site environmental discharge/release contained, minor remediation required, short-term environmental harm.	M (2) <i>(Medium)</i>	1	2	3
L (3) <i>(Low level of harm)</i>	Incident that has the potential to cause persons to require first aid. On-site environmental discharge/release immediately contained, minor level clean up with no short-term environmental harm.	L (3) <i>(Low)</i>	2	3	3
Level	Likelihood / Probability				
Likely	Could happen frequently				
Moderate	Could happen occasionally				
Unlikely	May occur only in exceptional circumstances				

HIERARCHY OF RISK CONTROL

The hierarchy of controls must be applied in the order below for all identified hazards.

Level 1 Eliminate the hazard
Level 2 Substitute the hazard with something safer.
Level 3 Isolate the hazard from people. Reduce the risks through engineering controls.
Level 4 Reduce exposure to the hazard using administrative actions.
Level 5 Use personal protective equipment
The control measures that you put in place should be reviewed regularly to make sure they work as planned

ACTIVITY ANALYSIS

Steps in Activity	Potential Hazards	Risk Class	Risk Control Measure	Responsible Person/s	Residual Risk
1.0 General Safety Requirements 	Personal injury to operator and other workers.	1	- All persons and subcontractors working on site need a current TasWater Induction Card and a General Construction Industry White Card. - All persons and subcontractors entering and working within and around the rail corridor must have a current Track Safety Awareness Induction Card issued from TasRail - Compliance with these SWMS may be monitored via audit regimes throughout the duration of the project by Paneltec's Compliance Manager or TasWater Representative(s) - All Traffic Controllers on site must be accredited in: RIISS00059 - Traffic Controller Skill Set for High Volume Roads skill set (Traffic Controller) RIISS00061 – Traffic Management Implementer – High Volume Roads skill set (Traffic Management Implementer 2) In accordance with the Department of State Growth Guideline – Traffic Control for Work on Roads 2020 - Complete Site-Specific Risk Assessment (SSRA) prior to commencing works (Identify all Site-Specific Safety Requirements) - Conduct Tailgate Meeting during completion of SSRA discuss any pertinent site-specific hazards and lessons learnt (E.g., Asset Locations, Weather, No Go Areas etc.) - All asset locations are to be undertaken by a BYDA accredited locator. - All workers are to wear required PPE in accordance with TasWater & Paneltec's PIPE Policy: - Highly Visible Workwear – Long Pants & Shirt (Sleeves Down) - Safety Boots - Hard Hat – No caps underneath - Safety Glasses - AS/NZS1337 - Hearing Protection (Where Required) - Gloves and Glove Clip (Razor Shield) - Face Shield in addition to Safety Glasses when cutting, grinding, using compressed air or <u>high-pressure water jetting</u>	All Supervisor All Compliance Manager TasWater Traffic Controllers All BYDA Locator All	2

2.0 Setting Out or taking down Roadwork Signage for Traffic Control and setting out work area 	Persons being struck by oncoming traffic or construction plant	1	1. Traffic Controllers to verify that the correct signage, control devices Traffic Management Plan (TMP) and Traffic Guidance Scheme (TGS) are onsite and ready for implementation. 2. Verify all Traffic Controllers have PPE in accordance with 1.08 above. 3. Traffic Controller to adopt whichever control measure(s) is applicable to the site/situation as per TGS and or TMP: • Establish/Verify the clear escape route for all traffic controllers. • All control measures, traffic control devices and signage as per the TGS • Sequence of setup to be in accordance with TGS installation sequence. 4. If additional guidance to the TMP is required - refer to the Austroads Guide to Temporary Traffic Management on Temporary Traffic Management Category 2 environments. (AGTTM) and AS1742.3 5. If changes to the TGS are required due to operational conditions, changes may be made by a senior traffic controller providing they are documented. 6. Due diligence must be applied when setting up traffic control as personnel are working unprotected, except for the traffic vehicle with flashing arrow board and flashing lights on. 7. Refer to the TMP and TGS for all additional site-specific set up procedures. 8. Barricade the work area, to prevent inadvertent access by public. 9. Ensure all pedestrians and cyclists have safe passage around the work site. 10. Traffic control set out vehicles to display flashing amber lights & flashing arrow board. Reverse beepers and vehicle horn must all be functional. Safety signage and traffic control devices will conform with the <i>Austroads Guide to Temporary Traffic Management</i> and AS1742.3 to ensure safety and minimise inconvenience to traffic.	Traffic Controllers Supervisor Traffic Controllers Traffic Controllers Traffic Controllers Traffic Controllers	2
3.0 Traversing the TasRail Corridor 	Train collision between other vehicle and/or pedestrians.	1	1. A current TasRail permit for construction of services within rail corridor (permit) must be on-site prior to undertaking any works within or adjacent to, the rail corridor 2. At all stages throughout the project, the requirements of the permit shall be maintained. If the scope changes and alterations to the permit's conditions are sought, the permit must be reissued by TasRail 3. A Vehicle Movement Plan (VMP) will accompany the TGS/TMP for all pedestrian and traffic movements within and outside of the rail reserve. The VMP must always be complied with whilst on-site and its	Supervisor Supervisor All Traffic Controllers	

			requirements communicated with all persons at the tailgate meeting - All TasRail protocols must be followed on-site when movement of rolling stock is advised to be approaching by the TasRail Officer present on-site, no person or vehicle shall be in the prescribed vicinity of the rolling stock as prescribed by the TasRail Track Protection Officer (TTPO) - All works including HDD shall cease in the instance of rolling stock approaching site and all personnel shall move to the clearance zone designated by the TTPO - Any, breakdowns, near misses or accidents that occur on the rail corridor must be reported immediately to TasRail, Paneltec Management and TasWater	Supervisor All Supervisor	
3.0 Underground Asset Locating	Injuries or accidents occurring to employees/public and contact/damage with underground infrastructure	1	- All persons engaged in the locating works are to be trained and competent in <i>RIICCM202D Identify, locate and protect underground services</i>. - Locator to be an accredited Dial Before You Dig Certified Locator and Telstra Accredited Locator. Paneltec is a CLO with DBYD. - Locator to ensure all DBYD enquiry sequence numbers are in the work pack prior to location and that the DBYD enquiry is within 28 Days of enquiry date. - Locator to locate all known underground infrastructure and remain vigilant for any signs of unknown or unrecorded infrastructure. - Refer to Paneltec <i>SWP-30 Opening Manholes – Safe Handling</i> when opening manholes. - All location works to be completed under the TGS when working within the road reserve (Refer 2.0 Above)	Supervisor Asset Locator	2
4.0 Electrical Hazards 	Electrocution	1	<u>Ensure all underground electrical infrastructure has been located by consulting with the Paneltec Asset Locator</u> Conduct a visual inspection for overhead electrical infrastructure: If the distance between the vehicle/boom/cassette or operating implement and the LV (Bottom Powerlines, Wooden Pole WP) will be less than 1.0m or 3.0m (Top 22KV Powerlines, WP) reposition all equipment or introduce the control measures outlined in our SSRA/JSEA.	Supervisor BYDA Locator Supervisor Operator	2

			3. Ensure Paneltec's WHS 05: Emergency Procedures are available for reference in the event of an emergency.	Supervisor All	
12.0 Removal of Site Traffic Control Devices	Persons being struck by oncoming traffic or construction plant	1	On completion of the project all site signage is to be removed/decommissioned in the reverse order of its implementation.	Traffic Controllers	2

ENVIRONMENTAL RISK ASSESSMENT & CONTROL MEASURES THAT MAY BE REQUIRED ON SITE DEPENDING ON THE ACTIVITY					
Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Emergencies	Accident/ Incident Fire Spill	1	1. Personnel have been advised at tailgate meeting of designated emergency muster point and are prepared in the event of an incident occurring. 2. Emergency numbers are available in <i>WHS Monitor - WHS 05 Emergency Procedures</i>. 3. Fire Extinguishers/First Aid Kits/Spill Kits on site.	Supervisor All	2
Air Quality	Exhaust Fumes Dust	2	1. Control exhaust emissions e.g., Regular maintenance, replace old machinery, fit appropriate emission control measures.	Supervisor All	3
Community Relations	Inconvenience as a result of works/traffic management	2	1. TasWater to notify local residents in advance of works being undertaken. 2. All complaints to be reported to TasWater Customer Service Centre	Supervisor All	3
	Irate residents and complaints	2	1. All complaints to be reported to TasWater Customer Service Centre	Operators	3
Flora & Fauna	Some works may require removal of vegetation for truck access to TasWater Network.	2	1. Assess work area for significant vegetation: size of trees, faunal habitat defines work and exclusion areas using fencing and signage. 2. Approval to be sought from TasWater, prior to removal of any vegetation.	Supervisor All TasWater	3
	Transference of noxious weeds	3	1. Machinery is to be thoroughly washed down prior to leaving site where noxious weeds are present.	Operators	3

Work Activity Risk	Hazard	Risk Class	Risk Control Measure	Responsible Person/s	Risk Class after Controls in place
Noise Pollution	Sensitivity to noise - to public & fauna	1	1. Work undertaken during “normal” hours where possible. 2. Notification of works to effected residents. 3. Plant and equipment regularly serviced & fitted with efficient mufflers.	Supervisor All	2
Soil Management & Water Quality	Mud deposited onto roadways.	2	1. Wash down machinery in only nominated areas. 2. Drivers to check vehicle tires/bodies for buildup of mud.	Supervisor All	3
Fuels and Chemicals	Contamination of waterways due to spillages of oil, degreasers, diesel, etc.	1	1. Store fuel and chemicals in accordance with relevant standards/guidelines. 2. Spill kits or alternative spill containment materials available on site. 1. Use correct refueling equipment.	Supervisor All	2
Visual Impact Litter and Amenities Waste Management	Litter such as paper, plastic, and other refuse on-site. Artificial lighting, litter, mud, dirt and dust may also impact residents.	2	1. Use site induction to communicate the requirement for a tidy site. Also stress consideration for local residents. 2. If as a result of our works, dirt, mud, or litter affects a resident, then we will rectify this problem immediately. 3. Inspect the site frequently and insist on tidiness. Ensure public roads are free of dirt/mud from the work site. 4. Remove all rubbish from site each day.	Supervisor All	3

List of plant for this Activity

Vacuum Truck, HDD, Mechanical Excavator

Personal Protective Equipment

All site personnel must wear the required PPE specified in the controls above, such as:

Safety Highly Visible Vests/Workwear	Safety Boots	Sunscreen	Sun ring for Hard Hat (UV)	Sunglasses (Approved Safety)	Razor Shield Gloves & Clip	White reflective overalls (Nightworks)
Hard Hat at all Times	Safety Glasses	Hearing protection where required	Long Sleeves and Pants	Dust masks	Respiratory Helmets if and when required	Face Shield when using jetting hose

Workers may require Task Specific Training depending on activity each worker will be required to fulfill.

All workers shall hold a current Construction Induction Card			
- TasWater Induction - Activity Induction (SWMS & SWP's) - Site specific requirements (external)	- TasWater Induction - Activity Induction (SWMS & SWP's) - Site specific requirements (external)	- TasWater Induction - Activity Induction (SWMS & SWP's) - Site specific requirements (external)	- TasWater Induction - Activity Induction (SWMS & SWP's) - Site specific requirements (external)
First Aid certificate training	First Aid certificate training	First Aid certificate training	First Aid certificate training

A Daily Tailgate Meeting will be held each day prior to the start of works.

Legislation & Codes of Practice (refer to company Legislation register for applicable Australian Standards applicable to works)

Work Health & Safety Act 2012 and Work Health & Safety Regulations 2022

Codes of Practice

Confined Spaces - 2018	Hazardous Manual Tasks - 2018	Managing Noise & Preventing Hearing Loss at Work-2018	Managing Risks of Plant in the Workplace - 2018
Construction Work - 2018	How to Manage WH&S Risks - 2018	Managing Risk of Falls at Workplaces - 2018	Managing Electrical Risks in the Workplace -2018
Excavation Work - 2018	First Aid in the Workplace - 2018	Managing Work Environment & Facilities - 2018	WHS Consultation Co-operation & Co-ordination - 2018
Welding Processes - 2018	How to Safely Remove Asbestos - 2018	Managing Risk of Hazardous Chemicals - 2018	Safe Design of Structures - 2018
Guide for Managing Risks from High Pressure water Jetting 2012			

Plant & Equipment for this activity

- All plant is inspected prior to sending out to site – HDD & Vacuum Truck
- Daily maintenance & service checks.
- Daily pre-start checks are conducted on all plant and trucks by the operators and daily checklist filled out.
- Regular servicing at 250hr intervals or as per manufactures specifications. Service History available on request to the office.

WORK ACTIVITY BRIEFING

Implementation, Monitoring and Review of SWMS

The Supervisor on site has the responsibility to:

- Brief each team member on this SWMS before commencing work.
- Ensure control measures have been implemented prior to the start of works.
- Observe work being carried out.
- If controls documented in SWMS are not adequate, stop the work, review the SWMS, adjust as required and re-brief the team.
- Ensure team knows that work is to immediately stop if the SWMS is not being followed.
- Retain this SWMS on site for the duration of the high-risk construction work.
- All persons involved in these particular tasks on site must sign this document as read and understood.

SWMS attendance sheet — I have been given the opportunity to provide input into the development and review of this SWMS.

Name (please print clearly)	Signature	Company	Date

Daily pre-start meetings will be held to ensure all workers are informed of control measures and additional safety hazards & controls to be noted on toolbox form.