Computer Architecture (计算机体系结构)

Lecture 12 Instruction Representation III



2020-09-25

Lecturer Yuanqing Cheng

www.cadetlab.cn/~courses

Review

MIPS Machine Language Instruction:
 32 bits representing a single instruction

R	opcode	rs	rt	rd	shamt	funct	
I	opcode	rs	rt	immediate			
J	opcode		target address				

 Branches use PC-relative addressing, Jumps use absolute addressing.

Outline

- Disassembly
- Pseudoinstructions
- "True" Assembly Language (TAL) vs.
 "MIPS" Assembly Language (MAL)

Decoding Machine Language

 How do we convert 1s and 0s to assembly language and to C code?

Machine language \Rightarrow assembly \Rightarrow C?

- For each 32 bits:
 - 1. Look at opcode to distinguish between R-Format, J-Format, and I-Format.
 - 2. Use instruction format to determine which fields exist.
 - 3. Write out MIPS assembly code, converting each field to name, register number/name, or decimal/hex number.
 - 4. Logically convert this MIPS code into valid C code. Always possible? Unique?

Decoding Example (1/7)

 Here are six machine language instructions in hexadecimal:

```
00001025_{hex} \\ 0005402A_{hex} \\ 11000003_{hex} \\ 00441020_{hex} \\ 20A5FFFF_{hex} \\ 08100001_{hex}
```

- Let the first instruction be at address $4,194,304_{\text{ten}}$ (0x00400000_{hex}).
- Next step: convert hex to binary

Decoding Example (2/7)

The six machine language instructions in binary:

Next step: identify opcode and format

R	0	rs	rt	rd	shamt	funct
I	1, 4-62	rs	rt	immediate		
J	2 or 3	target address				

Decoding Example (3/7)

 Select the opcode (first 6 bits) to determine the format:

Format:

- Look at opcode:
 0 means R-Format,
 2 or 3 mean J-Format,
 otherwise I-Format.
- Next step: separation of fields

Decoding Example (4/7)

Fields separated based on format/opcode:

Format:

R	0	0	0	2	0	37
R	0	0	5	8	0	42
T	4	8	0	+3		
R	0	2	4	2	0	32
T	8	5	5	-1		
J	2	1,048,577				

 Next step: translate ("disassemble") to MIPS assembly instructions

Decoding Example (5/7)

MIPS Assembly (Part 1):

Address: Assembly instructions:

```
0x00400000
                          $2,$0,$0
                  or
                          $8,$0,$5
0 \times 00400004
                  slt
0 \times 00400008
                          $8,$0,3
                  beq
                          $2,$2,$4
                  add
0x0040000c
                  addi
                          $5,$5,-1
0 \times 00400010
                          0x100001
0 \times 00400014
```

 Better solution: translate to more meaningful MIPS instructions (fix the branch/jump and add labels, registers)

Decoding Example (6/7)

MIPS Assembly (Part 2):

```
or $v0,$0,$0

Loop: slt $t0,$0,$a1

beq $t0,$0,Exit

add $v0,$v0,$a0

addi $a1,$a1,-1

j Loop

Exit:
```

 Next step: translate to C code (must be creative!)

Decoding Example (7/7)

Before Hex:

```
00001025_{hex}
0005402A_{hex}
11000003_{hex}
00441020_{hex}
20A5FFFF_{hex}
08100001_{hex}
```

```
    After C code (Mapping below)
```

```
$v0: product
$a0: multiplicand
$a1: multiplier
```

```
product = 0;
while (multiplier > 0) {
    product += multiplicand;
    multiplier -= 1;
}
```

```
or $v0,$0,$0

Loop: slt $t0,$0,$a1

beq $t0,$0,Exit

add $v0,$v0,$a0

addi $a1,$a1,-1

j Loop
```

Demonstrated Big Idea: Instructions are just numbers, code is treated like data

Exit:

Review from before: lui

- •So how does lui help us?
 - Example:

```
addi $t0,$t0, 0xABABCDCD
```

becomes:

```
lui $at, 0xABAB
ori $at, $at, 0xCDCD
add $t0,$t0,$at
```

- Now each I-format instruction has only a 16bit immediate.
- Wouldn't it be nice if the assembler would this for us automatically?
 - If number too big, then just automatically replace addi with lui, ori, add

True Assembly Language (1/3)

- Pseudoinstruction: A MIPS instruction that doesn't turn directly into a machine language instruction, but into other MIPS instructions
- What happens with pseudo-instructions?
 - They're broken up by the assembler into several "real" MIPS instructions.
- Some examples follow

Example Pseudoinstructions

Register Move

```
move reg2, reg1
Expands to:
add reg2, $zero, reg1
```

Load Immediate

```
li reg, value
If value fits in 16 bits:
addi reg, $zero, value
else:
lui reg, upper 16 bits of value
ori reg, reg, lower 16 bits
```

Example Pseudoinstructions

 Load Address: How do we get the address of an instruction or global variable into a register?

```
la reg,label
Again if value fits in 16 bits:
addi reg,$zero,label_value
else:
lui reg,upper 16 bits of value
ori reg,reg,lower 16 bits
```

True Assembly Language (2/3)

Problem:

- When breaking up a pseudo-instruction, the assembler may need to use an extra register
- If it uses any regular register, it'll overwrite whatever the program has put into it.

• Solution:

- Reserve a register (\$1, called \$at for "assembler temporary") that assembler will use to break up pseudo-instructions.
- Since the assembler may use this at any time, it's not safe to code with it.

Example Pseudoinstructions

Rotate Right Instruction

```
ror reg, value

Expands to:

srl $at, reg, value

sll reg, reg, 32-value

or reg, reg, $at
```

"No OPeration" instruction

```
nop
Expands to instruction = \mathbf{0}_{ten},
$11 $0, $0, 0
```

Example Pseudoinstructions

Wrong operation for operand

```
addu reg, reg, value # should be addiu
```

```
If value fits in 16 bits, addu is changed to:
addiu reg, reg, value
else:
lui $at, upper 16 bits of value
ori $at, $at, lower 16 bits
addu reg, reg, $at
```

 How do we avoid confusion about whether we are talking about MIPS assembler with or without pseudoinstructions?

True Assembly Language (3/3)

- MAL (MIPS Assembly Language): the set of instructions that a programmer may use to code in MIPS; this includes pseudoinstructions
- TAL (True Assembly Language): set of instructions that can actually get translated into a single machine language instruction (32-bit binary string)
- A program must be converted from MAL into TAL before translation into 1s & 0s.

Questions on Pseudoinstructions

Question:

How does MIPS assembler / SPIM recognize pseudo-instructions?

Answer:

- It looks for officially defined pseudoinstructions, such as mrand m ove
- It looks for special cases where the operand is incorrect for the operation and tries to handle it gracefully

Rewrite TAL as MAL

• TAL:

```
or $v0,$0,$0

Loop: slt $t0,$0,$a1

beq $t0,$0,Exit

add $v0,$v0,$a0

addi $a1,$a1,-1

j Loop

Exit:
```

- This time convert to MAL
- It's OK for this exercise to make up MAL instructions

Rewrite TAL as MAL (Answer)

```
• TAL:

Loop:

slt $t0,$0,$a1

beq $t0,$0,Exit

add $v0,$v0,$a0

addi $a1,$a1,-1

j Loop

Exit:
```

• MAL:

```
li $v0,0
Loop: ble $a1,$zero,Exit
add $v0,$v0,$a0
sub $a1,$a1,1
j Loop
Exit:
```

Peer Instruction

- Which of the instructions below are MAL and which are TAL?
 - 1. addi \$t0, \$t1, 40000
 - 2. beq \$s0, 10, Exit

12
a) MM
b) MT
c) TM
d) TT


Peer Instruction Answer

 Which of the instructions below are MAL and which are TAL?

- 1. addi \$t0, \$t1, 40000 40,000 > +32,767 =>lui,ori
- 2. beq \$s0, 10, Exit

Beq: both must be registers

Exit: if $> 2^{15}$, then MAL



In Conclusion

- Disassembly is simple and starts by decoding opcode field.
 - Be creative, efficient when authoring C
- Assembler expands real instruction set (TAL) with pseudoinstructions (MAL)
 - Only TAL can be converted to raw binary
 - Assembler's job to do conversion
 - Assembler uses reserved register \$at
 - MAL makes it much easier to write MIPS