CAN Expansion Module V1

Document Number		PR035_CANExpansionMod	R035_CANExpansionModuleV1_12JAN2023		
Title		CAN Expansion Module V1			
Team Member / Engineer		Raheel Farouk			
Creation Date		12 JAN 2023			
Prepared By	Date	Checked By	Change History		
Raheel Farouk	12JAN2023	-	Initial Version		
Raheel Farouk	16JAN2023	-	Added Endianness and Cleaned up formatting		
Raheel Farouk	06MAR2023	-	Removed slip angle sensor and added Aux2		
Patrick Murphy	09MAR2023	-	Added Descriptions of data and Setup information		
Patrick Murphy	21APR2023	-	Added Changes Relating to Library change, data frame update and connections.		
Patrick Murphy	24MAY2023	-			

Purpose of Module

The purpose of the CAN Expansion Module is to convert desired analog sensor inputs into digital data on the CAN bus.

Setup Guide

Setting up the Expansion Module requires a CAN ID for the expansion module and the sensors to be plugged into their corresponding spots on the module. The MoTeC firmware will decide between what input will be used for each function, for example brake temperature will select the brake temperature input but you will be able to choose between front and rear, left and right.

Board Configuration

The initial version of the board was using the Canduino V3.1 which has the CS as Pin 10, the V3.0 is Pin 8, the custom PCB is 10. The Board Programming library for the Canduino's and the Custom PCB.

Custom PCB - V1

A custom PCB designed around the ATMEGA328P (16 MHz) with an MCP25625 (8 MHz) SPI to CAN controller at a 5v logic level. Includes 4 ADC (10 bit) pins with independent power and ground wires to reduce common wiring failure points for each sensor. The PCB has a selection bridge for enabling a 120 ohm CAN termination resistor if needed. Featuring a serial programming header for debugging and an ICSP interface for programming.

https://github.com/Panther-Racing/Expansion-Module-V1

Canduino V3.1 (Deprecated)

The Canduino V3.1 was an atmega328P with an attached MCP2515 and MCP2551 to allow communication onto a CAN network.

The Canduino possessed 8 ADCs, a 3v and 5v output, SPI interface and 10 Digital outputs. There is the option of having a CAN termination resistor through a solder bridge aswell as a chip select through a solder jumper.

More information on this can be found in the following locations.

This board has entered deprecated status from the manufacturer.

https://www.tindie.com/products/massivegroup/canduino-v31-atmega328p-with-can-bus/

https://github.com/MassiveButDynamic/canduino-v3.1

Can Library Configuration

The library used to communicate with the MCP2515 as recommended by the Canduino is the Arduino-mcp2515 library. Previously the MCP_CAN library by coryjfowler was used however issues were encountered relating to significant transmit errors on the bus so this is no longer used.

Analog Sensor Wiring

Sensor Name	PIN	Colors
Brake Temperature	ADC 0	White - Yellow
DPOS	ADC 1	White – Brown
AUX 1	ADC 2	White - Green
AUX 2	ADC 3	White – Black

Module Specifications

Messaging Structure

SPI Message structure

<u></u>			
Endianness	Big Endian		
Message Length	8		
Byte	Contents*		
Byte0	Brake Temp (9-2)		
Byte1	Brake Temp (1-0)	DPOS (9-4)	
Byte2	DPOS (3-0)	Aux 1 (9-6)	
Byte3	Aux 1 (5-0)	Aux 2 (9-8)	
Byte4	Aux 2 (7-0)		

Byte5	Firmware Version
Byte6	Transmit Error Counter (TEC)
Byte7	Counter

^{*}Note: The numbers in brackets are the bit numbers of the data stored in the byte. For example if Brake temp is a 10bit value, then the most significant first 8 bits of brake temp, Bits 9 to 2 will be stored in byte 1, then the remaining 2 bits will be stored in byte 1.

Can Message Structure of Data

Base CAN ID: 0:	0x760; +1; +2; +3					
F	FL - 0x760		FR – 0x761			
R	RL - 0x762		RR -	RR – 0x763		
Data Name*		Length (Bits)		Position in Message		
				Start	End	
Brake Temp	1	10		0	9	
DPOS	1	10		10	19	
Aux 1	1	10		20	29	
Aux 2		10		30	39	
Firmware Version		8		40	47	
Transmit Error Counter (TEC)		8		48	55	
Counter		4		56	59	

^{*}Note: that the Data will effectively be sent as unsigned integers with values in the range of 0 to 2^(length of bits). Any conversion of this information currently needs to be performed on the receiving end of the data.

Additional Notes

Auxiliary sensor attached to things like steering position.

Description of Firmware Version

The firmware version corresponds to the current version of the Module. This is represented in format the format of vXX.X. In the software this is programmed as a uint8_t type. To achieve the decimal position the firmware version must be 100 times the current version. For example if the current version of the module is v0.1 then the firmware version shall be 100*0.1 or 100.

Description of Compound

Compound is unimplemented. To be used if the length of data the module transmits exceeds 8 bytes of information to allow more data extraction from the same CAN ID.

Description of Counter

Counter is a 4bit value used to determine if loss of transmission occurs. If observing transmission from the board this value shall go from 0 to 15 and rollover, if any value is missed while this is occurring then a loss of transmission has occurred and should be investigated.

ADC

For the ATMEGA328P there are 6 ADC pins which are multiplexed to a single ADC. The ADC can use the internal voltage, a reference voltage, or 3.3V using the registers.

Transmit Error Counter (TEC)

The TEC is read from the mcp2515 / 25625 registers using SPI. This describes the number of times that the controller has been broadcasting to the CAN bus but has detected that a value it sent was not properly sent.