

Experiment 009 Humidity

I Made This!

OVERVIEW

In this experiment you will control how read from the humidity sensor on the 321Maker Shield.

OUTCOMES

By the end of this experiment you will be able to:

- Install an Arduino library.
- Read both temperature and Humidity from a DHT11 sensor.

REQUIREMENTS

- Arduino-Compatible board
- 321Maker Things Shield
- USB Cable
- Arduino Software

PREREQUISITES

Getting Started Tutorial: http://321maker.com/start

the bottom of your screen, then something went wrong.

Source Code: https://git.io/vP2vhDHT11 Library: https://git.io/vP2Ya

VIDEO TUTORIAL

http://youtube.com/indevelopment

BACKGROUND

The DHT11 is a smart sensor that has its own internal microcontroller. The sensor takes about 2 seconds to sample the environment. The sensor uses a digital serial connection to transmit the sensor readings.

LEVEL 1 PROCEDURE

being displayed.

EVEL	1 PROCEDURE				
	Connect your Arduino to your computer using the USB port. Open the	Ardı	uino softwa	re.	
	Download and install the DHT11 library. Click on this link: https://git.io/vP2Ya				
	From the github page click the green Clone or Download button on	the r	ight hand s	ide,	
	choose Download ZIP. This should download the library zip file.	File Edit S	Verify/Compile	Ctrl+R	
	From within the Arduino software choose. Sketch, include	E015-L	Upload Upload Using Programmer	Ctrl+U Ctrl+Shift+U	
	Library, Add .ZIP Library	//1	Export compiled Binary Show Sketch Folder	Ctrl+Alt+S	
	Browse to your downloads folder and select the	#ir	Include Library	Ctrl+K	△ Manage Libraries
	DHT-sensor-library-master.zip file	#in	Add File STUUE \LUCI	J . 11 /	Add .ZIP Library
	Download the Humidity program code from here:	#ind	clude < Li	quidC	Arduino libraries Bridge
	https://git.io/vP2vh				EEPROM
	Copy and paste the program code into the Arduino software editor.	⊚ Sele	ect a zip file or a folder contain	ning the library yo	ou'd like to add
	Make sure you have the correct Arduino Board port setup.		Look in: Universely DHT-sensor-library-master.zip		
	Click the upload button in the upper left corner to compile and	Recen	t Items	orary-master.zip	
	upload the code to the Arduino device. If you see an Orange error in		File name: C:\	Users\321maker\Do	ownloads Open

Congratulations, if you open up the serial monitor you should see the data from the sensor





Experiment 009 Humidity

I Made This!

LEVEL 2 PROGRAM MODIFICATION

	Add the following lines inside the loop function.
	Serial.print("Dewpoint:");
	Serial.println(dewPoint(celsius,humidity));
	Add the following lines to the very end of the program. (Outside of loop)
	<pre>double dewPoint(double celsius, double humidity) { double a = 17.271; double b = 237.7; double temp = (a * celsius) / (b + celsius) + log(humidity*0.01); double dP = (b * temp) / (a - temp); return dP; }</pre>
LEVEL 3	ADVANCED APPLICATION
	Have the Red LED (D12) turn on when the temperature is 25C or and the Blue LED (D13) when the temperature is below 25C.

LEVEL 4 PROJECT CHALLENEGE

LED on the RGB (D11) when it's above 50%.

Create a humidity alarm such that when the humidity is above a threshold set by the rotation sensor (A0). Then the buzzer will chirp.

Have the Green LED on the RGB (D9) turn on when the humidity is below 50% and Blue