
# Lab 8: Requirement Description

- Timer explanation video:
  - https://youtu.be/yZ0k2NbJ3QI
- Basic (40%):
  - Description: Connect 4 LEDs at RD0 ~ RD3. The LED should follow the state diagram below to blink. You must use TIMER2 to create the proper delay interval. You are not allowed to use DELAY macro.



- Standard of Grading:
  - 1. Set LEDs at RD0 ~ RD3
  - 2. Explain how timer 2 can trigger the interrupt every sec.
  - 3. Don't use DELAY macro which come from previous labs
  - 4. Code in C or assembly
- o Hint:

### 13.1 Timer2 Operation

In normal operation, TMR2 is incremented from 00h on each clock (Fosc/4). A 4-bit counter/prescaler on the clock input gives direct input, divide-by-4 and divide-by-16 prescale options; these are selected by the prescaler control bits, T2CKPS<1:0> (T2CON<1:0>). The value of TMR2 is compared to that of the Period register, PR2, on each clock cycle. When the two values match, the comparator generates a match signal as the timer output. This signal also resets the value of TMR2 to 00h on the next cycle and drives the output counter/postscaler (see Section 13.2 "Timer2 Interrupt").

#### 13.2 Timer2 Interrupt

Timer2 also can generate an optional device interrupt. The Timer2 output signal (TMR2 to PR2 match) provides the input for the 4-bit output counter/postscaler. This counter generates the TMR2 match interrupt flag which is latched in TMR2IF (PIR1<1>). The interrupt is enabled by setting the TMR2 Match Interrupt Enable bit, TMR2IE (PIE1<1>).

A range of 16 postscale options (from 1:1 through 1:16 inclusive) can be selected with the postscaler control bits, T2OUTPS<3:0> (T2CON<6:3>).

#### REGISTER 13-1: T2CON: TIMER2 CONTROL REGISTER

U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
_	T2OUTPS3	T2OUTPS2	T2OUTPS1	T2OUTPS0	TMR2ON	T2CKPS1	T2CKPS0	
bit 7		,					bit 0	

Legend:

R = Readable bit

W = Writable bit

U = Unimplemented bit, read as '0'

-n = Value at POR

'1' = Bit is set

'0' = Bit is cleared

x = Bit is unknown

bit 7

Unimplemented: Read as '0'

bit 6-3

T2OUTPS<3:0>: Timer2 Output Postscale Select bits

0000 = 1:1 Postscale 0001 = 1:2 Postscale

•

•

1111 = 1:16 Postscale

bit 2

TMR2ON: Timer2 On bit

1 = Timer2 is on

0 = Timer2 is off

bit 1-0

T2CKPS<1:0>: Timer2 Clock Prescale Select bits

00 = Prescaler is 1

01 = Prescaler is 4


1x = Prescaler is 16

#### TABLE 13-1: REGISTERS ASSOCIATED WITH TIMER2 AS A TIMER/COUNTER

Name	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	Reset Values on page	
INTCON	GIE/GIEH	PEIE/GIEL	TMR0IE	INT0IE	RBIE	TMR0IF	INT0IF	RBIF	49	
PIR1	PSPIF <sup>(1)</sup>	ADIF	RCIF	TXIF	SSPIF	CCP1IF	TMR2IF	TMR1IF	52	
PIE1	PSPIE <sup>(1)</sup>	ADIE	RCIE	TXIE	SSPIE	CCP1IE	TMR2IE	TMR1IE	52	
IPR1	PSPIP <sup>(1)</sup>	ADIP	RCIP	TXIP	SSPIP	CCP1IP	TMR2IP	TMR1IP	52	
TMR2	Timer2 Register									
T2CON	_	T2OUTPS3	T2OUTPS2	T2OUTPS1	T2OUTPS0	TMR2ON	T2CKPS1	T2CKPS0	50	
PR2	Timer2 Period Register									

## Advanced (60%):

 Description: Following the Basic with its limitation, while running over a round, change the time interval into 0.5 sec. Then 0.25. Then back to original interval 1sec.(You may refer to the diagram below)



- Standard of Grading:
  - 0.Properly wiring.
  - 1.Set LEDs at RD0 ~ RD3
  - 2.Explain how timer2 can trigger the interrupt every interval.
  - 3.Don't use DELAY macro in this program.
  - 4.Code in C or assembly
  - 5. Change the time interval while running over each round.