Module Declaration

Nesting of modules possible

Basic Structure

For whatever digital circuit, you have to create two files: main file and validation file

Main file

```
/* Simple AND gate: and2.v */
module andgate2 (y,a,b);
    input a,b;
    output y;
    assign y = a&b; /* assign -> keyword that assigns value to op var */
endmodule
```

Validation file

```
/* testbench for AND gate: and2_tb.v */
module and_test;
       reg a, b; // register a and b
       wire y;  // named container for values that are "stateless" (no memory)
       andgate2 and_test(y,a,b);
       // calling the function defined earlier and assigning it to and_test
        initial // initialises a block
               // begins block statements
       begin
               #0 a=0; b=0;
               #100 a=0; b=1;
               #100 a=1; b=0;
               #100 a=1; b=1;
               #100 a=1; b=1;
              // ends block
        end
```

NOTE - Dumpfiles:

VCD is an ASCII format of dumping defined originally by Verilog IEEE standard (1364–1995). It contains information about value changes in variables across time. There are system functions supported to control dump scope and duration.

It was originally intended to be used with waveform viewers for debug. Given that it is part of the IEEE Verilog standard, all waveform viewers across vendors support it. However since it is ASCII, the dump file sizes can be really large and generally it is not commonly used these days. The other usage of VCD dump is for estimating power consumption (RTL/gate power analysis) based on signals toggling across various time boundaries.

Execution

```
>> iverilog -o output_file_name and2.v and2_tb.v
>> vvp output_file_name
>> gtkwave and2_test.vcd
```

- -0 = output
- Line 1 creates a compiled simulation file with the name output_file_name. Line 2 runs that simulation using the vvp command.
- Line 3 opens GTKWave where you can view the input and output waveforms.