LDR and STR Addressing Modes

Mode	Pseudo-code Operation *	Example		
Offset modes – the base address register is not modified				
[Rn]	EA = Rn	LDR R0, [R1]		
[Rn, #offset]	EA = Rn + offset	LDR R0, [R1, #4]		
[Rn, Rm]	EA = Rn + Rm	LDR R0, [R1, R2]		
[Rn, Rm, LSL #shift]	$EA = Rn + (Rm \ll shift)$	LDR R0, [R1, R2, LSL #2]		
[Rn, Rm, LSR #shift]	$EA = Rn + (Rm \gg shift)$	LDR R0, [R1, R2, LSR #2]		
Pre-indexed modes – the base address register is modified before accessing memory				
[Rn, #offset]!	Rn = Rn + offset	LDR R0, [R1, #4]!		
	EA = Rn			
[Rn, Rm]!	Rn = Rn + Rm	LDR R0, [R1, R2]!		
	EA = Rn			
[Rn, Rm, LSL #shift]!	$Rn = Rn + (Rm \ll shift)$	LDR R0, [R1, R2, LSL #2]!		
	EA = Rn			
[Rn, Rm, LSR #shift]!	Rn = Rn + (Rm >> shift)	LDR R0, [R1, R2, LSR #2]!		
	EA = Rn			
Post-indexed modes – the base address register is modified after accessing memory				
[Rn], #offset	EA = Rn	LDR R0, [R1], #4		
	Rn = Rn + offset			
[Rn], Rm	EA = Rn	LDR R0, [R1], R2		
	Rn = Rn + Rm			
[Rn], Rm, LSL #shift	EA = Rn	LDR R0, [R1], R2, LSL #2		
	$Rn = Rn + (Rm \ll shift)$			
[Rn], Rm, LSR #shift	EA = Rn	LDR R0, [R1], R2, LSR #2		
	$Rn = Rn + (Rm \gg shift)$			

^{*} EA is the *Effective Address*, which is the memory address to which the load or store operation is applied.

Note: only a subset of the above addressing modes can be used to load or store halfwords, signed-halfwords or signed-bytes. See ARM Architecture Reference Manual section A5.3.

STM and LDM - STore and LoaD Multiple

Instruction	Example		
Base register Rn is not modified (no !)			
STM <i>mode</i> Rn, {list}	STMIA R12, {R0-R3}	Store the contents of R0-R3 in memory at the address contained in R12	
LDM <i>mode</i> Rn, {list}	LDMIA R12, {R5,R7,R10}	Load R5, R7 and R10 with the contents of memory at the address contained in R12	
Base register Rn is modified (Rn!)			
STMmode Rn!, {list}	STMFD SP!, {R4-R12,R14}	Push R4-R12 and R14 on to the system stack, updating the system stack pointer	
LDM <i>mode</i> Rn!, {list}	LDMFD SP!, {R4-R12,R14}	Pop 10 words off the top of the system stack into R4-R12 and R14, updating the system stack pointer	

mode

STM – STore Multiple			
Instruction	Stack-Oriented Synonym		
STMDB (decrement before)	STMFD (full descending)		
STMIB (increment before)	STMFA (full ascending)		
STMDA (decrement after)	STMED (empty decending)		
STMIA (increment after)	STMEA (empty ascending)		

LDM – LoaD Multiple			
Instruction	Stack-Oriented Synonym		
LDMIA (increment after)	LDMFD (full descending)		
LDMDA (decrement after)	LDMFA (full ascending)		
LDMIB (increment before)	LDMED (empty decending)		
LDMDB (decrement before)	LDMEA (empty ascending)		