LAr Filter Regeneration Procedure

Yun-Tse Tsai

May 10, 2022

General steps:

- 1. Preheat the LAr filter to $175 180^{\circ}$ C with Ar gas at 160 slpm (~ 6.7 scfm on the flowmeter). It takes about 3 hours.
- 2. Use 1-2% H₂ balanced with Ar to regenerate the LAr filter. Keep the temperature between 175 and 225°C. With the flowrate of 80 slpm (3.3 scfm on the flowmeter), we expect to use 5 gas bottles, each takes a bit less than an hour.
- 3. Cool down the system with ultra high purity Ar gas.

Time to stop regeneration:

- Humidity plateaus. Better plateaus at 0%.
- 5 hours of 2% H₂ gas at 80 slpm (3.3 scfm on the flowmeter).
- Temperature in the LAr filter does not rise anymore.

Notes:

- V3, V5, V6, V9, V18 isolate the LAr filter. During the regeneration, V3, V5, and V6 should be always closed.
- Control V9 and V18 carefully to avoid compromising the LAr filter; V9 is the gas inlet and V18 is the exhausting valve.
- The torque for V9 is 50 inch-pound, 7/8" socket.
- The torque for V18 is 21.7 foot-pound, 3/4" socket. Need different torque wrenches for V9 and V18 typically.
- The gas flow has to be greater than 2 scfm (marked on the flowmeter) to prevent the heater from getting too hot.
- We should keep the gas flow (Ar or $2\%H_2+Ar$) between 2 and 6.7 scfm (marked on the flowmeter), but preferably at 6.7 scfm.
- Maintain the catalyst temperature between about 175°C and 225°C.
- Do NOT exceed 225°C, even though 250°C may be tolerated.
- If we keep the gas flow at 400 scfm, a gas bottle should be finished in about an hour.
- If seeing smoke or smelling something unusual, shut down the variac power supply (heater) and investigate.




Figure 1: P&ID

| Checklist | What to Do and Detailed Description |
|---|---------------------------------------|
| Preparation | |
| 3 bottle of ultra high purity Ar gas (TBC) | |
| 5 bottles of Ar+2%H ₂ gas (TBC) | |
| Tubes connecting the heater and the LAr filter wrapped with aluminum foils for thermal insulation | |
| V4 connected to the scroll pump | Prepare to evacuate the vacuum vessel |
| V4 open, scroll pump on | Evacuate the vacuum vessel |
| V3, V5, V6, V7, V8, V9, V10, V11, V12, v18 closed | |
| Exhausting gas line connected and humidity meter hooked | |
| Preheating with Ar gas | |
| V3, V5, V6, V7, V8, V9, V10, V11, V12, V18 closed | |
| PG6 at 0 psi | |
| Variac power supply off. Voltage set at 0 | |
| Heater plugged in to the variac power supply | |
| Ar gas bottle connected to Reg1 and $V7/V8$ line | |
| GMV1 opened, Reg1 increased, V7 opened, air purged | Purge the air in the connection tube |
| V7 closed | Finish purging |
| V8, V9 opened | |
| PG3 at $5-10$ psig, $V18$ opened | |
| Gas flow ~ 6.7 scfm, stable | |
| Variac power supply on, increase the voltage | Turn on the heater |
| Humidity plateaued at 0% for > 10 minutes | Molecular sieves regenerated |
| Preheated for > 2 hours | |
| $TC0, 1, 2, 3 \text{ at } 175 - 180^{\circ}C$ | |
| Variac power supply off. Voltage set at 0 | Turn off the heater |
| V8, V9, V18 closed | |
| GMV1 and Reg1 closed | |
| Paganarating conner giovag | |

Regenerating copper sieves

 $\mathrm{Ar}{+}2\%\mathrm{H}_2$ gas bottle connected to Reg1 and V7/V8 line

GMV1 opened, Reg1 increased, V7 opened, air Purge the air in the connection tube purged V7 closed Finish purging V8, V9 opened PG3 at 5-10 psig, V18 opened Gas flow between 50 and 160 slpm (Ar), or between 2.2 and 6.7 scfm (marked as Air). Preferably at 3.5 scfm Air Turn on the heater Variac power supply on, increase the voltage Should the temperature exceed 225°C anywhere in the bed, switch to H₂-free gas until the hot zone cools back down to 200 – 210°C, then resume feeding the H_2 gas mixture The temperature of the all catalyst bed is stable or subsiding Humidity plateaued at 0% for > 10 minutes Copper sieves regenerated Turn off the heater Variac power supply off. Voltage set at 0 V8, V9, V18 closed GMV1 and Reg1 closed Completion; cooling down Variac power supply off. Voltage set at 55 V Ultra high purity Ar gas bottle connected to Reg1 and V7/V8 line GMV1 opened, Reg1 increased, V7 opened, air Purge the air in the connection tube purged V7 closed Finish purging V8, V9 opened PG3 at 5-10 psig, V18 opened Gas flow ~ 6.7 scfm, stable Variac power supply on, decrease the voltage Turn on the heater Variac power supply off. Voltage set at 0 Turn off the heater V8, V9, V18 closed GMV1 and Reg1 closed