
Introduction


BoardView is a software to draw solderless prototyping board layout. These layouts can be saved as editable *.bvp files or as bitmap files. The bitmap file can be used to communicate the design to others.




BoardView is so simple and obvious to use this manual is very brief.

Menus description

File menu



• **Protoboard...** Let you select the prototyping board size. Shortcut key: **<CTRL+B>** dialog box




- New Begin a new project.
- Open... Open a previously saved BoardView *.bvp file for further editing. Shortcut key: <CTRL+O>






 Save... Save your Boardview design as a *.bvp file that can be re-open for further editing. Shortcut key: <CTRL+S> Toolbar icon:





- Save as... Save your design under a new name.
- Save to bitmap... Save your design as a bitmap file. That file can't be edited in BoardView.
- Print... Print prototyping board design. Printing is done in landscape orientation. Shortcut key: <CTRL+P>
- Quit Leave the application. Shortcut key: <CTRL+Q>

Edit menu



• Undo Delete the last added component,tag or jumper.

Shortcut key: <CTRL+U>

Toolbar icon:



Component library Let you modify the components library. Component can be added to a category. New categories can be created. Existing component or category can be deleted.



Jumpers menu



This menu contain only one item **color...** which open the wire color dialog. Shorcut key: **CTRL+J>**.

Toolbar icon:



dialog box:

Jumper color X

predefined colors

Black
Brown
Red
Orange
Yellow
Green
Blue
Purple
Gray
Fushia

This dialog let you select the color of wire installed on the board. There is 10 defined colors.

Add menu



• component.. Open the electronic components selector dialog. Components are grouped in categories. Components are represented as bitmap files. You can add component to database, this is explained below.

Shortcut key: CTRL+E


Toolbar icon:



dialog box: Components X Component Category DIL 14 DIL 16 DIL 18 electro mechanical opto other DIL 20 passive semi-conductors DIL 24 transistor DIL 28 DIL 40 DIL 8 Freeze Tag tag tag Font... rot +90 OK rot 180 Cancel rot -90

 tag... Open the add tag dialog box. This let you add text to identify component. Shortcut key: CTRL+T. toolbar icon:







Help menu



- manual Open the user's manual in default web browser. Shorcut key: F1
- preferences... Open the help prefrences dialog. User can choose betwen english manual or french manual and 2 formats, html format or pdf format. These choices are peresistants and recorded in boardview.ini file. dialog box:




o about... display the about dialog box.



toolbar

The toolbar present the most used menu items as icons. Placing the mouse over an icon will display the corresponding tip in a balloon. Each element of toolbar as a shorcut key associated with its corresponding menu item.



statusbar



The statusbar at bottom of main window is divided in 2 panels. Left panel display the number of elements placed on the board.


elements types

- Components are electronic components making the circuit.
- Jumpers are wires that connect components togethers to form the circuit.
- Tags are short text used to identify components or give other information.

The right panel of status bar display information about current operation. If there is no operation active then it display current jumper color and mouse position relative to left-top corner of prototyping board. Hence the coordinates can be negatives.

Placing elements on the board


- To Add a jumper first click on the starting point of wire. The cursor change for a cross. Click a second time when the mouse cursor is over the position of the other end of wire. While moving the mouse a line follow the mouse cursor. Clicking with the right mouse button cancel the operation.
- To add a component click the component icon on the toolbar to open the component dialog to select the component. When the dialog is closed the component follow the mouse until the mouse left button is clicked. The component is then set at this position.




A tag can be overlaid on the bitmap of the selected component. Fill the **tag** field with the desired text, select the font then with the mouse drag the tag over the component. The **freeze** button must be clicked before the **OK** button to fix this tag to the component. Once frozen it is no more modifyable. The tag added this way follow the component. It part of its bitmap representation, hence if this component is cloned the clone carry the same tag. The tag must fit inside the surface of component bitmap otherwise it will be truncated when frozen.

The component bitmap may also be rotated by +90°,180° or -90°.

• To add a tag click the tag icon on the toolbar to open the tag dialog. When the dialog is closed the tag follow the mouse cursor until the left mouse button is clicked. The tag is then set to that position.



Popup menu




When clicking on a jumper, component or tag a popup menu appear. Only the items concerning the chosen element are activated in the menu.

- **Delete** Apply to all 3 types of elements. Delete the selected element from the board.
- Jumper color... Applay to jumpers only. Open the jumper color selection dialog. The color of the selected jumper is changed to this new color and next added jumpers will be this color until the color is changed again.
- tag font... Apply to tag only. This item let you modify a tag font properties.
- Move Apply only to components and tags. Let you move the selected element around. The element follow mouse cursor until Left click fix it at that position.
- Clone Apply only to components and tags. Clone the selected element then move the clone at chosen position. Left click at the desired position.

Elements are drawn on the board in the order they are created. If you move a more recently added element over another one it mask the older one.

Library dialog



Controls on the left side of dialog are for categories and those on the right side are for components. The selected category can be delete by clicking **remove cat** button. All components of that category will be lost.

Adding a category is as simple as typing its name in the **new category** field and clicking **add cat** button. The new category will appear at the end of the list and be selected.

To delete a component from a category click remove comp button. The selected component will be deleted from library.

To add a component to a category, first select the category, then type the component name in **new component** field. Components are displayed as bitmaps, so you must specify the bitmap file for that component before clicking **add comp** button. The new component will be added at end of list and selected. All bitmaps must be saved in the bitmaps subdirectory of the application executable. The ... button at right of **bitmap file** field is to open the file browser dialog.

The components library file is a Windows *.ini file named components.ini in the same directory as the executable. If its structure is well understood it can be modified in a text editor.

component bitmap

Components are standard Windows bitmaps. They can be drawn in any application that can save in that format. All bitmaps used by the component library must be saved in the **bitmaps** subdirectory of the application executable.


Resistor component

The resistors components with black bands are specially designed for the bands to be filled with value color code. This band black is defined in the source code as constant clBLACK2=0x020202 so the application can see it a fillable region. When one of banded resistor is selected, i.e. resistor 1%, resistor 5% or resistor 10% clicking with the left button on one clBLACK2 band color selection dialog is shown with the predefined colors for standard resistors. The standard color code for resistor are

- BLACK = 0
- BROWN = 1
- RED = 2
- ORANGE = 3
- YELLOW = 4
- GREEN = 5
- BLUE = 6
- PURPLE = 7
- GRAY = 8
- WHIRE = 9
- SILVER = 10% precision resistor
- GOLD = 5% precision resistor

5% and 10% resistors have 3 black bands and 1% have 4 black bands. The precision band is already colored.

In the example below a 5% resistor have been selected then rotated by +90° and colored to 12Kohm value.



Saving a project

When saving a project a subdirectory with same name as project is created. This directory contain the **project.bvp** file as well as all components bitmaps used by the project. The components bitmaps are named **component-n.bmp** where **n** correspond to the section [**noden**] in the project file. Project files are Windows *.ini files. Hence they can read an modified in a text editor.