
The Intel Microprocessors

8086/8088, 80186/80188, 80286, 80386, 80486 Pentium, Pentium Pro Processor, Pentium II, Pentium 4, and Core2 with 64-bit Extensions

Architecture, Programming, and Interfacing



EIGHTH EDITION

Barry B. Brey



Chapter 6: Program Control Instructions

Introduction

- This chapter explains the program control instructions, including the jumps, calls, returns, interrupts, and machine control instructions.
- This chapter also presents the relational assembly language statements (.IF, .ELSE, .ELSEIF, .ENDIF, .WHILE, .END W, .REPEAT, and .UNTIL) that are available in version 6.xx and above of MASM or TASM, with version 5.xx set for MASM compatibility.



Chapter Objectives

Upon completion of this chapter, you will be able to:

- Use both conditional and unconditional jump instructions to control the flow of a program.
- Use the relational assembly language statements .IF, .REPEAT, .WHILE, and so forth in programs.
- Use the call and return instructions to include procedures in the program structure.



Chapter Objectives

(cont.)

Upon completion of this chapter, you will be able to:

- Explain the operation of the interrupts and interrupt control instructions.
- Use machine control instructions to modify the flag bits.
- Use ENTER and LEAVE to enter and leave programming structures.

6-1 THE JUMP GROUP

- The main program control instruction, jump (JMP), allows programmer to skip program sections and branch to any part of memory for the next instruction.
- A conditional jump instruction allows decisions based upon numerical tests.
 - results are held in the flag bits, then tested by conditional jump instructions
- LOOP and conditional LOOP are also forms of the jump instruction.



Unconditional Jump (JMP)


- Three types:
 - short jump
 - near jump
 - far jump
- **Short jump** is a 2-byte instruction that allows jumps or branches to memory locations within +127 and -128 bytes.
 - from the address following the jump
- 3-byte **near jump** allows a branch or jump within ±32K bytes (or anywhere in the current segment) from the instruction in the current code segment.



- Segments are cyclic in nature
 - Which means the one location above offset address
 FFFFH is offset address 0000H.
 - Suppose instruction pointer address offset address FFFFH and if there is jump instruction for jumping 2 bytes ahead in memory, then the flow continues at offset address 0001H.
- 5-byte far jump allows a jump to any memory location within the real memory system.
- The short and near jumps are often called intrasegment jumps.
- Far jumps are called intersegment jumps.



Figure 6-1 The three main forms of the JMP instruction. Note that Disp is either an 8- or 16-bit signed displacement or distance.





- In 80386-core2 processors:
 - The Near jump is within ±2G bytes if the machine is operated in the protected mode (code segment size will be 4G bytes)
 - If operated in real mode, the near jump is within ±32K bytes
 - If the Pentium 4 operated in the 64-bit mode, a jump can be to any address in its 1T bytes memory space.




Short Jump

- Called relative jumps because they can be moved, with related software, to any location in the current code segment without a change.
 - jump address is not stored with the opcode
 - a distance, or displacement, follows the opcode
- The short jump displacement is a distance represented by a 1-byte signed number whose value ranges between +127 and –128.
- Short jump instruction appears in Figure 6–2.



Figure 6-2 A short jump to four memory locations beyond the address of the next instruction.



 when the microprocessor executes a short jump, the displacement is signextended and added to the instruction pointer (IP/EIP) to generate the jump address within the current code segment

CS = 1000H IP = 0002H New IP = IP + 4 New IP = 0006H The instruction branches to this new address for the next instruction in the program

Example 6–1 shows how short jump instructions pass control from one part of the program to another.

EXAMPLE 6-1

0000 33 DB XOR BX,BX 0002 B8 0001 START: MOV AX,1 0005 03 C3 ADD AX,BX

0007 EB 17 JMP SHORT NEXT

<skipped memory locations>

0020 8B D8 NEXT: MOV BX,AX 0022 EB DE JMP START



- When a jump references an address, a label normally identifies the address.
- The JMP NEXT instruction is an example.
 - it jumps to label NEXT for the next instruction
 - very rare to use an actual hexadecimal address with any jump instruction
- The label NEXT must be followed by a colon (NEXT:) to allow an instruction to reference it
 - if a colon does not follow, you cannot jump to it
- The only time a colon is used is when the label is used with a jump or call instruction.




Near Jump

- A near jump passes control to an instruction in the current code segment located within ±32K bytes from the near jump instruction.
 - distance is ±2G in 80386 and above when operated in protected mode
- Near jump is a 3-byte instruction with opcode followed by a signed 16-bit displacement.
 - 80386 Pentium 4 displacement is 32 bits and the near jump is 5 bytes long

- The signed displacement adds to the instruction pointer (IP) to generate the jump address.
 - because signed displacement is ±32K, a near jump can jump to any memory location within the current real mode code segment
- The protected mode code segment in the 80386 and above can be 4G bytes long.
 - 32-bit displacement allows a near jump to any location within ±2G bytes
- Figure 6–3 illustrates the operation of the real mode near jump instruction.



Figure 6-3 A near jump that adds the displacement (0002H) to the contents of IP.



*IP = 0003H



Example 6–2 shows the same basic program that appeared in Example 6–1, except that the jump distance is greater.

EXAMPLE 6-2

0000 33DB XOR BX,BX 0002 B8 0001 START: MOV AX,1 0005 03 C3 ADD AX,BX 0007 E9 0200 R JMP NEXT

<skipped memory locations>

0200 8B D8 NEXT: MOV BX,AX 0202 E9 0002 R JMP START




- The near jump is also relocatable because it is also a relative jump.
- This feature, along with the relocatable data segments, Intel microprocessors ideal for use in a general-purpose computer system.
- Software can be written and loaded anywhere in the memory and function without modification because of the relative jumps and relocatable data segments.

Far Jump

- Obtains a new segment and offset address to accomplish the jump:
 - bytes 2 and 3 of this 5-byte instruction contain the new offset address
 - bytes 4 and 5 contain the new segment address
 - in protected mode, the segment address accesses a descriptor with the base address of the far jump segment
 - offset address, either 16 or 32 bits, contains the offset address within the new code segment



Figure 6-4 A far jump instruction replaces the contents of both CS and IP with 4 bytes following the opcode.





Example 6–3 lists a short program that uses a far jump instruction.

EXAMPLE 6-3

EXTRN UP:FAR

0000 33 DB XOR BX,BX 0002 B8 0001 START: ADD AX,1 0005 E9 0200 R JMP NEXT

; <skipped memory locations>

0200 8B D8 NEXT: MOV BX, AX

0202 EA 0002 — R JMP FAR PTR START

0207 EA 0000 - R JMP UP



- The far jump instruction sometimes appears with the FAR PTR directive.
 - another way to obtain a far jump is to define a label as a far label
 - a label is far only if it is external to the current code segment or procedure
- The JMP UP instruction references a far label.
 - label UP is defined as a far label by the EXTRN UP:FAR directive
- External labels appear in programs that contain more than one program file.



- Another way of defining a label as global is to use a double colon (LABEL::)
 - required inside procedure blocks defined as near if the label is accessed from outside the procedure block
- When the program files are joined, the linker inserts the address for the UP label into the JMP UP instruction.
- Also inserts segment address in JMP START instruction.
 - The segment address in JMP FAR PTR START is listed as - - - - R for relocatable;



Jumps with Register Operands

- Jump can also use a 16- or 32-bit register as an operand.
 - automatically sets up as an indirect jump
 - address of the jump is in the register specified by the jump instruction
- Unlike displacement associated with the near jump, register contents are transferred directly into the instruction pointer.
- An indirect jump does not add to the instruction pointer.



- JMP AX, for example, copies the contents of the AX register into the IP.
 - allows a jump to any location within the current code segment
- In 80386 and above, JMP EAX also jumps to any location within the current code segment;
 - in protected mode the code segment can be 4G bytes long, so a 32-bit offset address is needed



Example 6–4 shows how the JMP AX instruction accesses a jump table in the code segment.

EXAMPLE 6-4

```
; Instructions that read 1, 2, or 3 from the keyboard.
                  The number is displayed as 1, 2, or 3 using a jump table
                  .MODEL SMALL
                                                  ;select SMALL model
0000
                  . DATA
                                                  ;start data segment
                  TABLE: DW ONE
0000 0030 R
                                                  ;jump table
0002 0034 R
                          DW TWO
0004 0038 R
                          DW THREE
0000
                  . CODE
                                                  ;start code segment
                  .STARTUP
                                                  ;start program
0017 B4 01
                  TOP:
                          MOV AH,1
                                                  ;read key into AL
                          INT 21H
0019 CD 21
001B 2C 31
                          SUB AL,31
                                                  ;convert to BCD
001D 72 F9
                          JB TOP
                                                  ; if key < 1
001F 32 02
                          CMP AL, 2
0021 77 F4
                          JA TOP
                                                  ;if key > 3
0023 B4 00
                                                  ;double key code
                          MOV AH, 0
0025 03 C0
                          ADD AX, AX
0027 BE 0000 R
                          MOV SI,OFFSET TABLE
                                                  ; address TABLE
002A 03 F0
                          ADD SI,AX
                                                  ;form lookup address
002C 8B 04
                          MOV AX,[SI]
                                                  ;get ONE, TWO or THREE
002E FF E0
                          JMP AX
                                                  ; jump to ONE, TWO or THREE
0030 B2 31
                  ONE:
                          MOV DL,'1'
                                                  ; get ASCII 1
0032 EB 06
                          JMP BOT
0034 B2 32
                          MOV DL, '2'
                                                  get ASCII 2
                  TWO:
0036 EB 02
                          JMP BOT
0038 B2 33
                  THREE: MOV DL, '3'
                                                  ;get ASCII 3
003A B4 02
                  BOT:
                          MOV AH,2
                                                  ; display number
003C CD 21
                          INT 21H
                  .EXIT
                  END
```



Indirect Jumps Using an Index

- Jump instruction may also use the [] form of addressing to directly access the jump table.
- The jump table can contain offset addresses for near indirect jumps, or segment and offset addresses for far indirect jumps.
 - also known as a double-indirect jump if the register jump is called an indirect jump
- The assembler assumes that the jump is near unless the FAR PTR directive indicates a far jump instruction.



- Mechanism used to access the jump table is identical with a normal memory reference.
 - JMP TABLE [SI] instruction points to a jump address stored at the code segment offset location addressed by SI
- Both the register and indirect indexed jump instructions usually address a 16-bit offset.
 - both types of jumps are near jumps
- If JMP FAR PTR [SI] or JMP TABLE [SI], with TABLE data defined with the DD directive:
 - microprocessor assumes the jump table contains doubleword, 32-bit addresses (IP and CS)



Conditional Jumps and Conditional Sets

- Always short jumps in 8086 80286.
 - limits range to within +127 and –128 bytes from the location following the conditional jump
- In 80386 and above, conditional jumps are either short or near jumps (±32K).
 - in 64-bit mode of the Pentium 4, the near jump distance is ±2G for the conditional jumps
- Allows a conditional jump to any location within the current code segment.



TABLE 6–1 Conditional jump instructions.

Assembly Language	Tested Condition	Operation
JA	Z = 0 and C = 0	Jump if above
JAE	C = 0	Jump if above or equal
JB	C = 1	Jump if below
JBE	Z = 1 or C = 1	Jump if below or equal
JC	C = 1	Jump if carry
JE or JZ	Z = 1	Jump if equal or jump if zero
JG	Z = 0 and $S = 0$	Jump if greater than
JGE	S = 0	Jump if greater than or equal
JL	S != O	Jump if less than
JLE	Z = 1 or S != O	Jump if less than or equal
JNC	C = 0	Jump if no carry
JNE or JNZ	Z = 0	Jump if not equal or jump if not zero
JNO	O = 0	Jump if no overflow
JNS	S = 0	Jump if no sign (positive)
JNP or JPO	P = 0	Jump if no parity or jump if parity odd
JO	O = 1	Jump if overflow
JP or JPE	P = 1	Jump if parity or jump if parity even
JS	S = 1	Jump if sign (negative)
JCXZ	CX = 0	Jump if CX is zero
JECXZ	ECX = 0	Jump if ECX equals zero
JRCXZ	RCX = 0	Jump if RCX equals zero (64-bit mode)




- Conditional jump instructions test the following flag bits:
 - sign (S), zero (Z), carry (C)
 - parity (P), overflow (0)
- If the condition under test is true, a branch to the label associated with the jump instruction occurs.
 - if false, next sequential step in program executes
 - for example, a JC will jump if the carry bit is set
- Most conditional jump instructions are straightforward as they often test one flag bit.
 - although some test more than one




- Because both signed and unsigned numbers are used in programming.
- Because the order of these numbers is different, there are two sets of conditional jump instructions for magnitude comparisons.
- 16- and 32-bit numbers follow the same order as 8bit numbers, except that they are larger.
- Figure 6–5 shows the order of both signed and unsigned 8-bit numbers.



Figure 6-5 Signed and unsigned numbers follow different orders.





- When signed numbers are compared, use the JG, JL, JGE, JLE, JE, and JNE instructions.
 - terms greater than and less than refer to signed numbers
- When unsigned numbers are compared, use the JA, JB, JAE, JBE, JE, and JNE instructions.
 - terms *above* and *below* refer to unsigned numbers
- Remaining conditional jumps test individual flag bits, such as overflow and parity.



- Remaining conditional jumps test individual flag bits, such as overflow and parity.
 - notice that JE has an alternative opcode JZ
- All instructions have alternates, but many aren't used in programming because they don't usually fit the condition under test.



The Conditional Set Instructions

- 80386 Core2 processors also contain conditional set instructions.
 - conditions tested by conditional jumps put to work with the conditional set instructions
 - conditional set instructions set a byte to either
 01H or clear a byte to 00H, depending on the outcome of the condition under test
- Useful where a condition must be tested at a point much later in the program.



TABLE 6-2 Conditional set instructions.

Assembly Language	Tested Condition	Operation
SETA	Z = 0 and C = 0	Set if above
SETAE	C = 0	Set if above or equal
SETB	C = 1	Set if below
SETBE	Z = 1 or C = 1	Set if below or equal
SETC	C = 1	Set if carry
SETE or SETZ	Z = 1	Set if equal or set if zero
SETG	Z = 0 and $S = 0$	Set if greater than
SETGE	S = 0	Set if greater than or equal
SETL	S != O	Set if less than
SETLE	Z = 1 or S != O	Set if less than or equal
SETNC	C = 0	Set if no carry
SETNE or SETNZ	Z = 0	Set if not equal or set if not zero
SETNO	O = 0	Set if no overflow
SETNS	S = 0	Set if no sign (positive)
SETNP or SETPO	P = 0	Set if no parity or set if parity odd
SETO	O = 1	Set if overflow
SETP or SETPE	P = 1	Set if parity or set if parity even
SETS	S = 1	Set if sign (negative)



LOOP

- A combination of a decrement CX and the JNZ conditional jump.
- In 8086 80286 LOOP decrements CX.
 - if CX != 0, it jumps to the address indicated by the label
 - If CX becomes 0, the next sequential instruction executes
- In 80386 and above, LOOP decrements either CX or ECX, depending upon instruction mode.



- In 16-bit instruction mode, LOOP uses CX; in the 32-bit mode, LOOP uses ECX.
 - default is changed by the LOOPW (using CX) and LOOPD (using ECX) instructions 80386 - Core2
- In 64-bit mode, the loop counter is in RCX.
 - and is 64 bits wide
- There is no direct move from segment register to segment register instruction.



Conditional LOOPs

- LOOP instruction also has conditional forms:
 - LOOPE and LOOPNE
- LOOPE (loop while equal) instruction jumps if CX != 0 while an equal condition exists.
 - will exit loop if the condition is not equal or the CX register decrements to 0
- LOOPNE (loop while not equal) jumps if CX != 0 while a not-equal condition exists.
 - will exit loop if the condition is equal or the CX register decrements to 0



- In 80386 Core2 processors, conditional LOOP can use CX or ECX as the counter.
 - LOOPEW/LOOPED or LOOPNEW/LOOPNED override the instruction mode if needed
- Under 64-bit operation, the loop counter uses
 RCX and is 64 bits in width
- Alternates exist for LOOPE and LOOPNE.
 - LOOPE same as LOOPZ
 - LOOPNE instruction is the same as LOOPNZ
- In most programs, only the LOOPE and LOOPNE apply.



6–2 CONTROLLING THE FLOW OF THE PROGRAM

- It is much easier to use assembly language statements .IF, .ELSE, .ELSEIF, and .ENDIF to control the flow of the program than to use the correct conditional jump statement.
- Other statements developed include
 - REPEAT—.UNTIL and .WHILE—.ENDW
- But these statements are only available to MASM version 6.xx



.IF, .ELSE, .ELSEIF, and .ENDIF

Example 6–8(a) shows how these statements are used to control the flow of a program by testing AL for the ASCII letters A through F. If the contents of AL are A through F, 7 is subtracted from AL.

EXAMPLE 6-8(a)

```
.IF AL >= 'A' && AL <= 'F'

SUB AL,7

.ENDIF

SUB AL,30H
```



.IF, .ELSE, .ELSEIF, and .ENDIF

Example 6–8(b) shows the same task using the inline assembler in Visual C++ and conditional jumps in assembly language.

EXAMPLE 6-8(b)

```
char temp;
asm{
                al, temp
        mov
                al.41h
        cmp
        ib.
                Later
                al,46h
        cmp
        ia
                Later
        sub
                al,7
Later:
        sub
                al,30h
                temp,al
        mov
```



.IF, .ELSE, .ELSEIF, and .ENDIF

.IF condition expression .ENDIF .IF condition
 expression
.ELSEIF condition
 expression
.ENDIF

Example: .IF AL >= 'A' && AL <= 'F' SUB AL,7 .ENDIF SUB AL,30H



TABLE 6–3 Relational operators used with the .IF statement in assembly language.

Operator	Function		
==	Equal or the same as		
!=	Not equal		
>	Greater than		
>=	Greater than or equal		
<	Less than		
<=	Less than or equal		
&	Bit test		
!	Logical inversion		
&&	Logical AND		
II	Logical OR		
I	Or		



WHILE Loops

- Used with a condition to begin the loop.
 - the .ENDW statement ends the loop
- The .BREAK and .CONTINUE statements are available for use with the while loop.
 - BREAK is often followed by .IF to select the break condition as in .BREAK .IF AL == 0DH
 - CONTINUE can be used to allow a DO—.WHILE loop to continue if a certain condition is met
- The .BREAK and .CONTINUE commands function the same manner in C++.



WHILE Loops

```
.WHILE AL != 0DH ;loop while not enter jmp @C0001
```

MOV AH,1 ; read key

INT 21H

STOSB ; store key code

.ENDW



REPEAT-UNTIL Loops

- A series of instructions is repeated until some condition occurs.
- The .REPEAT statement defines the start of the loop.
 - end is defined with the .UNTIL statement, which contains a condition
- An .UNTILCXZ instruction uses the LOOP instruction to check CX for a repeat loop.
 - .UNTILCXZ uses the CX register as a counter to repeat a loop a fixed number of times



REPEAT-UNTIL Loops

.REPEAT ;repeat until enter

MOV AH,1 ;read key

INT 21H

STOSB ;store key code

.UNTIL AL == 0DH



6-3 PROCEDURES

- A procedure is a group of instructions that usually performs one task.
 - subroutine, method, or **function** is an important part of any system's architecture
- A procedure is a reusable section of the software stored in memory once, used as often as necessary.
 - saves memory space and makes it easier to develop software



- Disadvantage of procedure is time it takes the computer to link to, and return from it.
 - CALL links to the procedure; the RET (return) instruction returns from the procedure
- CALL pushes the address of the instruction following the CALL (return address) on the stack.
 - the stack stores the return address when a procedure is called during a program
- RET instruction removes an address from the stack so the program returns to the instruction following the CALL.



- A procedure begins with the PROC directive and ends with the ENDP directive.
 - each directive appears with the procedure name
 - Makes it easy to locate the procedure in a program
- PROC is followed by the type of procedure:
 - NEAR or FAR
- In MASM version 6.x, the NEAR or FAR type can be followed by the USES statement.
 - USES allows any number of registers to be automatically pushed to the stack and popped from the stack within the procedure



EXAMPLE 6-14

0000 0000 03 C3 0002 03 C1 0004 03 C2 0006 C3	SUMS	PROC ADD ADD ADD RET ENDP	NEAR AX,BX AX,CX AX,DX
0007 0007 03 C3 0009 03 C1 000B 03 C2 000D CB	SUMS1	ADD ADD ADD RET	FAR AX,BX AX,CX AX,DX
000E 0011 03 C3 0013 03 C1 0015 03 C2	SUMS3	PROC ADD ADD ADD RET ENDP	NEAR USE BX CX DX AX,BX AX,CX AX,DX



- Procedures that are to be used by all software (global) should be written as far procedures.
- Procedures that are used by a given task (local) are normally defined as near procedures.
- Most procedures are near procedures.



CALL

- Transfers the flow of the program to the procedure.
- CALL instruction differs from the jump instruction because a CALL saves a return address on the stack.
- The return address returns control to the instruction that immediately follows the CALL in a program when a RET instruction executes.

Near CALL


- 3 bytes long.
 - the first byte contains the opcode; the second and third bytes contain the displacement or distance
 - identical to the the form of the near jump instruction.
- When the near CALL executes, it first pushes the offset address of the next instruction onto the stack.
 - offset address of the next instruction appears in the instruction pointer (IP or EIP)
- It then adds displacement from bytes 2 & 3 to the IP to transfer control to the procedure.



- Why save the IP or EIP on the stack?
 - the instruction pointer always points to the next instruction in the program
- For the CALL instruction, the contents of IP/EIP are pushed onto the stack.
 - program control passes to the instruction following the CALL after a procedure ends
- Figure 6–6 shows the return address (IP) stored on the stack and the call to the procedure.



Figure 6-6 The effect of a near CALL on the stack and the instruction pointer.



Far CALL


- 5-byte instruction contains an opcode followed by the next value for the IP and CS registers.
 - bytes 2 and 3 contain new contents of the IP
 - bytes 4 and 5 contain the new contents for CS
- Far CALL places the contents of both IP and CS on the stack before jumping to the address indicated by bytes 2 through 5.
- This allows far CALL to call a procedure located anywhere in the memory and return from that procedure.



- Figure 6–7 shows how far CALL calls a far procedure.
 - contents of IP and CS are pushed onto the stack
- The program branches to the procedure.
 - A variant of far call exists as CALLF, but should be avoided in favor of defining the type of call instruction with the PROC statement
- In 64-bit mode a far call is to any memory location and information placed onto the stack is an 8-byte number.
 - the far return instruction retrieves an 8-byte return address from the stack and places it into RIP



Figure 6-7 The effect of a far CALL instruction.



CALLs with Register Operands

- An example CALL BX, which pushes the contents of IP onto the stack.
 - then jumps to the offset address, located in register
 BX, in the current code segment
- Always uses a 16-bit offset address, stored in any 16-bit register except segment registers.



CALLs with Indirect Memory Addresses


- Particularly useful when different subroutines need to be chosen in a program.
 - selection process is often keyed with a number that addresses a CALL address in a lookup table
- Essentially the same as the indirect jump that used a lookup table for a jump address.



RET

- Removes a 16-bit number (near return) from the stack placing it in IP, or removes a 32-bit number (far return) and places it in IP & CS.
 - near and far return instructions in procedure's
 PROC directive
 - automatically selects the proper return instruction
- Figure 6–8 shows how the CALL instruction links to a procedure and how RET returns in the 8086–Core2 operating in the real mode.

Figure 6-8 The effect of a near return instruction on the stack and instruction pointer.





- Another form of return adds a number to the contents of the stack pointer (SP) after the return address is removed from the stack.
- A return that uses an immediate operand is ideal for use in a system that uses the C/C++ or PASCAL calling conventions.
 - these conventions push parameters on the stack before calling a procedure
- If the parameters are discarded upon return, the return instruction contains the number of bytes pushed to the stack as parameters.



- Parameters are addressed on the stack by using the BP register, which by default addresses the stack segment.
- Parameter stacking is common in procedures written for C++ or PASCAL by using the C++ or PASCAL calling conventions.
- Variants of the return instruction:
 - RETN and RETF
- Variants should also be avoided in favor of using the PROC statement to define the type of call and return.



6-4 INTRO TO INTERRUPTS

- An interrupt is a hardware-generated CALL
 - externally derived from a hardware signal
- Or a software-generated CALL
 - internally derived from the execution of an instruction or by some other internal event
 - at times an internal interrupt is called an *exception*
- Either type interrupts the program by calling an interrupt service procedure (ISP) or interrupt handler.



Interrupt Vectors

- A 4-byte number stored in the first 1024 bytes of memory (00000H–003FFH) in real mode.
 - in protected mode, the vector table is replaced by an interrupt descriptor table that uses 8-byte descriptors to describe each of the interrupts
- 256 different interrupt vectors.
 - each vector contains the address of an interrupt service procedure



- Each vector contains a value for IP and CS that forms the address of the interrupt service procedure.
 - the first 2 bytes contain IP; the last 2 bytes CS
- Intel reserves the first 32 interrupt vectors for the present and future products.
 - interrupt vectors (32-255) are available to users
- Some reserved vectors are for errors that occur during the execution of software
 - such as the divide error interrupt



- Some vectors are reserved for the coprocessor.
 - others occur for normal events in the system
- In a personal computer, reserved vectors are used for system functions
- Vectors 1–6, 7, 9, 16, and 17 function in the real mode and protected mode.
 - the remaining vectors function only in the protected mode



TABLE 6–4 Interrupt vectors defined by Intel.

Number	Address	Microprocessor	Function			
0	0H–3H	All	Divide error			
1	4H-7H	All	Single-step			
2	8-BH	All	NMI pin			
3	CH-FH	All	Breakpoint			
4	10H-13H	All	Interrupt on overflow			
5	14H-17H	80186-Core2	Bound instruction			
6	18H-1BH	80186-Core2	Invalid opcode			
7	1CH-1FH	80186-Core2	Coprocessor emulation			
8	20H-23H	80386-Core2	Double fault			
9	24H-27H	80386	Coprocessor segment overrun			
Α	28H-2BH	80386-Core2	Invalid task state segment			
В	2CH-2FH	80386-Core2	Segment not present			
С	30H-33H	80386-Core2	Stack fault			
D	34H-37H	80386-Core2	General protection fault (GPF)			
E	38H-3BH	80386-Core2	Page fault			
F	3CH-3FH	_	Reserved			
10	40H-43H	80286-Core2	Floating-point error			
11	44H-47H	80486SX	Alignment check interrupt			
12	48H-4BH	Pentium-Core2	Machine check exception			
13-1F	4CH-7FH	_	Reserved			
20-FF	80H-3FFH	_	User interrupts			



Interrupt Instructions

- Three different interrupt instructions available:
 - INT, INTO, and INT 3
- In real mode, each fetches a vector from the vector table, and then calls the procedure stored at the location addressed by the vector.
- In protected mode, each fetches an interrupt descriptor from the interrupt descriptor table.
- Similar to a far CALL instruction because it places the return address (IP/EIP and CS) on the stack.



INTs

- 256 different software interrupt instructions (INTs) available to the programmer.
 - each INT instruction has a numeric operand whose range is 0 to 255 (00H–FFH)
- For example, INT 100 uses interrupt vector 100, which appears at memory address 190H–193H.
 - address of the interrupt vector is determined by multiplying the interrupt type number by 4



- Address of the interrupt vector is determined by multiplying the interrupt type number by 4.
 - -INT 10H instruction calls the interrupt service procedure whose address is stored beginning at memory location 40H (10H \times 4) in the mode
- In protected mode, the interrupt descriptor is located by multiplying the type number by 8
 - because each descriptor is 8 bytes long
- Each INT instruction is 2 bytes long.
 - the first byte contains the opcode
 - the second byte contains the vector type number



- When a software interrupt executes, it:
 - pushes the flags onto the stack
 - clears the T and I flag bits
 - pushes CS onto the stack
 - fetches the new value for CS from the interrupt vector
 - pushes IP/EIP onto the stack
 - fetches the new value for IP/EIP from the vector
 - jumps to the new location addressed by CS and IP/EIP



- INT performs as a far CALL
 - not only pushes CS & IP onto the stack, also pushes the flags onto the stack
- The INT instruction performs the operation of a PUSHF, followed by a far CALL instruction.
- Software interrupts are most commonly used to call system procedures because the address of the function need not be known.
- The interrupts often control printers, video displays, and disk drives.



- INT replaces a far CALL that would otherwise be used to call a system function.
 - INT instruction is 2 bytes long, whereas the far CALL is 5 bytes long
- Each time that the INT instruction replaces a far CALL, it saves 3 bytes of memory.
- This can amount to a sizable saving if INT often appears in a program, as it does for system calls.



IRET/IRETD

- Used only with software or hardware interrupt service procedures.
- IRET instruction will
 - pop stack data back into the IP
 - pop stack data back into CS
 - pop stack data back into the flag register
- Accomplishes the same tasks as the POPF followed by a far RET instruction.



- When IRET executes, it restores the contents of I and T from the stack.
 - preserves the state of these flag bits
- If interrupts were enabled before an interrupt service procedure, they are automatically reenabled by the IRET instruction.
 - because it restores the flag register
- IRET is used in real mode and IRETD in the protected mode.



INT 3

- A special software interrupt designed to function as a breakpoint.
 - a 1-byte instruction, while others are 2-byte
- Common to insert an INT 3 in software to interrupt or break the flow of the software.
 - function is called a breakpoint
 - breakpoints help to debug faulty software
- A breakpoint occurs for any software interrupt, but because INT 3 is 1 byte long, it is easier to use for this function.



INTO

- Interrupt on overflow (INTO) is a conditional software interrupt that tests overflow flag (O).
 - If O = 0, INTO performs no operation
 - if O = 1 and an INTO executes, an interrupt occurs via vector type number 4
- The INTO instruction appears in software that adds or subtracts signed binary numbers.
 - with these operations, it is possible to have an overflow
- JO or INTO instructions detect the overflow.



An Interrupt Service Procedure

- Interrupts are usually reserved for system events.
- Suppose a procedure is required to add the contents of DI, SI, BP, and BX and save the sum in AX.
 - as a common task, it may be worthwhile to develop the task as a software interrupt
- It is also important to save all registers are changed by the procedure using USES.



Example 6–18 shows the software interrupt.

EXAMPLE 6-18

0000			-	INTS	F	PROC	FAF	USES	AX
0000	03	C3			P	ADD	AX,	BX	
0002	03	05			I	ADD	AX,	BP	
0004	03	C7			P	NDD	AX,	DI	
0006	03	С6			P	NDD	AX,	SI	
8000	${\tt CF}$				I	RET			
0009			-	INTS	E	NDP			



Interrupt Control

- Two instructions control the INTR pin.
- The **set interrupt flag** instruction (STI) places 1 in the I flag bit.
 - which enables the INTR pin
- The clear interrupt flag instruction (CLI) places a 0 into the I flag bit.
 - which disables the INTR pin
- The STI instruction enables INTR and the CLI instruction disables INTR.



- In software interrupt service procedure, hardware interrupts are enabled as one of the first steps.
 - accomplished by the STI instruction
- Interrupts are enabled early because just about all of the I/O devices in the personal computer are interrupt-processed.
 - if interrupts are disabled too long, severe system problems result




Interrupts in the Personal Computer

- Interrupts found in the personal computer only contained Intel-specified interrupts 0–4.
- Access to protected mode interrupt structure in use by Windows is accomplished through kernel functions Microsoft provides.
 - and cannot be directly addressed
- Protected mode interrupts use an interrupt descriptor table.



Figure 6-9 Interrupts in a typical personal computer.





64-Bit Mode Interrupts

- The 64-bit system uses the IRETQ instruction to return from an interrupt service procedure.
 - IRETQ retrieves an 8-byte return from the stack
- IRETQ also retrieves the 32-bit EFLAG register from the stack and places it into the RFLAG register.
- It appears that Intel has no plans for using the leftmost 32 bits of the RFLAG register.
 - otherwise, 64-bit mode interrupts are the same as 32-bit mode interrupts



6-5 MACHINE CONTROL AND MISCELLANEOUS INSTRUCTIONS

 These instructions provide control of the carry bit, sample the BUSY/TEST pin, and perform various other functions.



Controlling the Carry Flag Bit

- The carry flag (C) propagates the carry or borrow in multiple-word/doubleword addition and subtraction.
 - can indicate errors in assembly language procedures
- Three instructions control the contents of the carry flag:
 - STC (set carry), CLC (clear carry), and CMC (complement carry)



WAIT

- Monitors the hardware BUSY pin on 80286 and 80386, and the TEST pin on 8086/8088.
- If the WAIT instruction executes while the *BUSY* pin = 1, nothing happens and the next instruction executes.
 - pin inputs a busy condition when at a logic 0 level
 - if BUSY pin = 0 the microprocessor waits for the pin to return to a logic 1



HLT

- Stops the execution of software.
- There are three ways to exit a halt:
 - by interrupt; a hardware reset, or DMA operation
- Often synchronizes external hardware interrupts with the software system.
- DOS and Windows both use interrupts extensively.
 - so HLT will not halt the computer when operated under these operating systems



NOP

- In early years, before software development tools were available, a NOP, which performs absolutely no operation, was often used to pad software with space for future machine language instructions.
- When the microprocessor encounters a NOP, it takes a short time to execute.

- If you are developing machine language programs, which are extremely rare, it is recommended that you place 10 or so NOPS in your program at 50-byte intervals.
 - in case you need to add instructions at some future point
- A NOP may also find application in time delays to waste time.
- A NOP used for timing is not very accurate because of the cache and pipelines in modern microprocessors.



LOCK Prefix

- Appends an instruction and causes the pin to become a logic 0.
- LOCK pin often disables external bus masters or other system components
 - causes pin to activate for duration of instruction
- If more than one sequential instruction is locked, LOCK pin remains logic 0 for duration of the sequence of instructions.
- The LOCK:MOV AL,[SI] instruction is an example of a locked instruction.



ESC

- Passes instructions to the floating-point coprocessor from the microprocessor.
- When an ESC executes, the microprocessor provides the memory address, if required, but otherwise performs a NOP.
- Six bits of the ESC instruction provide the opcode to the coprocessor and begin executing a coprocessor instruction.
- ESC is considered obsolete as an opcode.



BOUND

- A comparison instruction that may cause an interrupt (vector type number 5).
- Compares the contents of any 16-bit or 32-bit register against the contents of two words or doublewords of memory
 - an upper and a lower boundary
- If register value compared with memory is not within the boundary, a type 5 interrupt ensues.
- If it is within the boundary, the next instruction in the program executes.



ENTER and LEAVE


- Used with stack frames, mechanisms used to pass parameters to a procedure through the stack memory.
- Stack frame also holds local memory variables for the procedure.
- Stack frames provide dynamic areas of memory for procedures in multiuser environments.



- ENTER creates a stack frame by pushing BP onto the stack and then loading BP with the uppermost address of the stack frame.
 - allows stack frame variables to be accessed through the BP register
- ENTER contains two operands:
 - first operand specifies the number of bytes to reserve for variables on the stack frame
 - the second specifies the level of the procedure
- The ENTER and LEAVE instructions were used to call C++ functions in Windows 3.1.



Figure 6-10 The stack frame created by the ENTER 8,0 instruction. Notice that BP is stored beginning at the top of the stack frame. This is followed by an 8-byte area called a stack frame.





- There are three types of unconditional jump instructions: short, near, and far.
- The short jump allows a branch to within +127 and -128 bytes. The near jump (using a displacement of ±32K) allows a jump to any location in the current code segment (intrasegment). The far jump allows a jump to any location in the memory system (intersegment).

- Whenever a label appears with a JMP instruction or conditional jump, the label, located in the label field, must be followed by a colon (LABEL:). For example, the JMP DOGGY instruction jumps to memory location DOGGY:.
- The displacement that follows a short or near jump is the distance from the next instruction to the jump location.

- Indirect jumps are available in two forms:

 (1) jump to the location stored in a register and (2) jump to the location stored in a memory word (near indi-rect) or doubleword (far indirect).
- Conditional jumps are all short jumps that test one or more of the flag bits: C, Z, O, P, or S. If the condition is true, a jump occurs; if the condition is false, the next sequential instruction executes.

- The 80386 and above allow a 16-bit signed displacement for the conditional jump instructions.
- In 64-bit mode, the displacement is 32 bits allowing a range of ±2G.
- A special conditional jump instruction (LOOP) decrements CX and jumps to the label when CX is not 0.

- The 80386 through the Core2 contain conditional set instructions that either set a byte to 01H or clear it to 00H.
- If the condition under test is true, the operand byte is set to 01H; if the condition under test is false, the operand byte is cleared to 00H.

- The .IF and .ENDIF statements are useful in assembly language for making decisions.
- The instructions cause the assembler to generate conditional jump statements that modify the flow of the program.
- The .WHILE and .ENDW statements allow an assembly language program to use the WHILE construction, and the .REPEAT and .UNTIL statements allow use of the REPEAT-UNTIL construct.



- Procedures are groups of instructions that perform one task and are used from any point in a program.
- The CALL instruction links to a procedure and the RET instruction returns from a procedure. In assembly language, the PROC directive defines the name and type of procedure.
- The ENDP directive declares the end of the procedure.



- The CALL construction is a combination of a PUSH and a JMP instruction.
- When CALL executes, it pushes the return address on the stack and then jumps to the procedure.
- A near CALL places the contents of IP on the stack, and a far CALL places both IP and CS on the stack.

- The RET instruction returns from a procedure by removing the return address from the stack and placing it into IP (near return), or IP and CS (far return).
- Interrupts are either software instructions similar to CALL or hardware signals used to call procedures. This process interrupts the current program and calls a procedure.
- After the procedure, a special IRET instruction returns control to the software.



- Real mode interrupt vectors are 4 bytes long and contain the address (IP and CS) of the interrupt service procedure.
- The microprocessor contains 256 interrupt vectors in the first 1K bytes of memory.
 The first 32 are defined by Intel; the remaining 224 are user interrupts.
- In protected mode, the interrupt vector is 8 bytes long and the vector table may be relocated to any section of the memory.



- Whenever an interrupt is accepted by the microprocessor, the flags IP and CS are pushed onto the stack.
- Besides pushing the flags, the T and I flag bits are cleared to disable both the trace function and the INTR pin.
- The final event that occurs for the interrupt is that the interrupt vector is fetched from the vector table and a jump to the interrupt service procedure occurs.

- Software interrupt instructions (INT) often replace system calls. Soft-ware interrupts save 3 bytes of memory each time they replace CALL instructions.
- A special return instruction (IRET) must be used to return from an in-terrupt service procedure. The IRET instruction not only removes IP and CS from the stack, it also removes the flags from the stack.

- Interrupt on an overflow (INTO) is a conditional interrupt that calls an interrupt service procedure if overflow flag (O) = 1.
- The interrupt enable flag (I) controls the INTR pin connection.
- If the STI instruction executes, it sets I to enable the INTR pin. If the CLI instruction executes, it clears I to disable the INTR pin.

- The carry flag bit (C) is clear, set, and complemented by the CLC, STC, and CMC instructions.
- The BOUND instruction compares the contents of any 16-bit register against the contents of two words of memory: an upper and a lower boundary.
- If the value in the register compared with memory is not within the upper and lower boundary, a type 5 interrupt ensues.

- The ENTER and LEAVE instructions are used with stack frames. A stack frame is a mechanism used to pass parameters to a procedure through the stack memory.
- The stack frame also holds local memory variables for the procedure.
- The ENTER instruction creates the stack frame, and the LEAVE instruction removes the stack frame from the stack. The BP register addresses stack frame data.

